

SERVICE MANUAL

MODEL
L14, L16 & L18 SERIES
ENGINES

SECTION ET

ENGINE TUNE-UP

ET

ENGINE TUNE-UP	ET- 2
SERVICE DATA AND SPECIFICATIONS	ET- 7
TROUBLE DIAGNOSES AND CORRECTIONS	ET- 9



NISSAN MOTOR CO., LTD.
TOKYO, JAPAN

ENGINE TUNE-UP

CONTENTS

GENERAL DESCRIPTION	ET-2	ADDITIONAL PROCEDURE	ET-5
BASIC PROCEDURE	ET-2	Compression pressure-test each cylinder	ET-5
Connect tune-up equipment	ET-2	High tension wires, distributor cap	
Battery inspection	ET-2	and rotor cleaning and inspection	ET-6
Spark plugs-remove and recondition	ET-3	Distributor lubricate	ET-6
Distributor points cleaning and adjustment	ET-3	Intake manifold and carburetor	
Ignition timing setting	ET-3	attaching nuts tightening	ET-6
Fan belt inspection	ET-4	Oil filter inspection	ET-6
Engine oil inspection	ET-4	Air cleaner inspection	ET-6
Carburetor overhaul and adjustment	ET-4	Fuel strainer inspection	ET-6
Adjustment	ET-4	Cooling system inspection	ET-6

GENERAL DESCRIPTION

A minor tune-up consists of testing battery, cleaning, regapping or replacing, if required, spark plugs and distributor points; adjusting distributor dwell angle, ignition timing, carburetor idle mixture, and hot idle speed.

The complete or major tune-up procedure consists of these basic items plus other ignition, compression, electrical and carburetor checks, and a final road test to ensure continued trouble-free operation.

BASIC PROCEDURE

Connect tune-up equipment

Follow manufacturer recommendations for the use of testing equipment. Figure ET-1 shows a basic schematic for instrumentation which will apply to many types of test equipment and may be used as a rough guide if equipment manufacturer's instructions are not available.

Connections shown in Figure ET-1 are made as follows:

1. Voltmeter
 - (1) Positive lead to resistor side of coil.
 - (2) Negative lead to ground.
2. Timing light
 - (1) Positive lead to positive battery terminal.

- (2) Negative lead to ground.
- (3) Trigger lead to number 1 spark plug.

3. Tachometer

- (1) Positive lead to distributor side of coil.
- (2) Negative lead to ground.

Note: Attach pick-up to either number one or four spark plug.

4. Dwell meter

- (1) Positive lead to distributor side of coil.
- (2) Negative lead to ground.




Fig. ET-1 Simple schematic of tune-up instrumentation

Battery inspection

Standard type

Check the electrolyte level in each battery cell once a month.

1. Unscrew each filler cap and inspect fluid level. If the fluid is low, add distilled water to bring the level up approximately 5 mm (0.2 in) above the plates. Do not overfill.
2. Measure the specific gravity of battery electrolyte.



Fig. ET-2 Checking the specific gravity of battery electrolyte

Self-filling battery

In case of self-filling battery.

1. Remove filler cap and inspect the float position. If the float is lower than the normal condition, add distilled water into case attached on battery upper face. The fluid will be equally self-filled for each cell.

After replenishing, install filler cap. Do not overfill over the projections.




Fig. ET-3 Checking electrolyte level

ENGINE TUNE-UP

2. Measure the specific gravity of battery electrolyte as shown in Figure ET-2.

	Permissible value	Fully charged value (at 20°C, 68°F)
F ind climates	Over 1.22	1.28
Tropical climates	Over 1.18	1.23
Other climates	Over 1.20	1.26

Clean the top of battery and terminals with a solution of baking soda and water. Rinse off and dry with compressed air. The top of battery must be clean to prevent current leakage between terminals and from positive terminal to hold-down clamp.

In addition to current leakage, prolonged accumulation of acid and dirt on the top of battery may cause corrosion of straps. After tightening terminals, coat them with petrolatum (vaseline) to protect them from corrosion.

Spark plugs-remove and recondition

See that correct spark plugs are used. Spark plug insulators should be thoroughly cleaned to prevent possible flash-over.

Thoroughly clean lower insulator and cavity by blast type cleaner. File both electrodes flat (rounded surfaces increase voltage required to fire plugs) and set gap to 0.8 to 0.9 mm (0.031 to 0.035 in). Tighten plugs to 1.5 to 2.0 kg-m (11.0 to 15.0 ft-lb) torque.

Distributor points cleaning and adjustment




Fig. ET-4 Checking distributor point gap

Remove distributor cap and inspect points for excessive burning or pitting. Replace points if necessary. Use a point file to clean contact area and remove scale from points. Adjust distributor point gap to 0.45 to 0.55 mm (0.0177 to 0.0217 in). Filing is for cleaning purposes only. Do not attempt to remove all roughness. Apply a trace of bearing lubricant to the breaker cam. Adjust distributor dwell angle to 49 to 55 degrees on all engines.

Ignition timing setting

With distributor vacuum line disconnected and vehicle operating at normal idle speed or below, set ignition timing.

The timing can be observed by the stationary markings at front cover and a groove on crankshaft pulley with a device called a stroboscopic light (also referred to as a timing light).

Note that the front cover markings is graduated 5° per scale division in terms of the crank angle. The top dead center is located to the extreme right as viewed from the inspector's side.




Fig. ET-5 Checking ignition timing

Adjust the timing to the specifications, turning distributor body loosened securing bolts.





Fig. ET-6 Adjusting ignition timing

Ignition timing

	L14	L16 and L18	L16 and L18
	Single Carb.	Single Carb.	Twin Carb.
Manual transmission	8°/600 rpm	10°/600 rpm	14°/650 rpm
Automatic transmission	—	10°/650 rpm	14°/700 rpm

ENGINE TUNE-UP

Fan belt inspection



ET007

Fig. ET-7 Fan belt tension

1. Check for a cracked or damaged V-belt. Replace if defective.
2. Adjust belt tension, if necessary.
Belt tension is correct if belt can be depressed 8 to 12 mm (0.315 to 0.472 in) midway between fan pulley and alternator pulley by a force 10 kg (22.0 lb).

the specified level, replenish oil of the same grade up to the H level.



ET008

Fig. ET-8 Checking engine oil level

Engine oil inspection

Oil capacity of engine (including oil filter)

	L14, L16 and L18
Maximum (H level)	4.3 ℓ (4 ½ U.S. qts., 3 ¾ Imper. qts.)
Minimum (L level)	3.3 ℓ (3 ½ U.S. qts., 2 ⅞ Imper. qts.)

1. Check if engine oil has been deteriorated by invading cooling water or gasoline. Drain and refill oil, if necessary.

Notes:

- a. A milky oil indicates the presence

of cooling water.

Discover the cause for necessary measure.

- a. An oil with extremely low viscosity suggests dilution with gasoline.
2. Check oil level, and if it is below

Carburetor overhaul and adjustment

Overhaul

The detailed information for carburetor overhauling is outlined in section EF (ENGINE FUEL SYSTEM).

Overhaul carburetor assembly by referring to section EF.

Adjustment

Adjust carburetor idle speed and mixture to the following specifications.

For details, refer to section EF (ENGINE FUEL SYSTEM).

Engine idling

	L14	L16 and L18	L16 and L18
	Single Carb.	Single Carb	Twin Carb.
Manual transmission rpm	600	600	650
Automatic transmission rpm	—	650	700
Engine manifold at idle speed mmHg/rpm	450/600	450/600	400/650

ENGINE TUNE-UP

Valve clearance adjustment

This adjustment is impossible when the engine is in operation. Follow the procedure described below:




Fig. ET-9 Adjusting valve clearance

Valve clearance

Valve clearance mm (in)	Cold	Intake	0.20 (0.0079)
		Exhaust	0.25 (0.0098)
	Warm	Intake	0.25 (0.0098)
		Exhaust	0.30 (0.0118)

ADDITIONAL PROCEDURE

For diagnosis purposes, it is sometimes necessary to proceed further than the basic tune-up procedure. The following steps plus a road test are included in a complete or major tune-up and test procedure.

1. Loosen pivot locking nut and turn pivot screw until the specified clearance is obtained with engine cold.

Using service tool, tighten pivot locking nut securely after adjustment, and recheck the clearance.

2. Warm up engine, and stop it. Then, measure the warm engine valve clearance in the same manner as above. If it deviates from the given warm-engine valve setting value, make necessary adjustment.



Fig. ET-10 Testing compression pressure

Test compression with engine warm, all spark plugs removed and throttle and choke opened. No cylinder compression should be less than 80% of highest cylinder's. Excessive variation between cylinders, accompanied by low speed missing of the cylinder or cylinders which are low, usually indicates a valve not properly seating or a broken piston ring. Low pressures, even though uniform, may indicate worn rings. This may be accompanied by excessive oil consumption.

Test conclusion

If one or more cylinders read low, inject about one tablespoon of engine oil on top of the pistons in low reading cylinders through spark plug port. Repeat compression check on these cylinders.

1. If compression improves considerably, piston rings are defective.
2. If compression does not improve, valves are sticking or seating properly.
3. If two adjacent cylinders indicate low compression and injecting oil on pistons does not increase compression, the cause may be a cylinder head gasket leak between the cylinders. Engine oil and coolant in cylinder could result from this problem.

Compression pressure-test each cylinder

Note: If this test is to be performed, it should be done when plugs are removed for service during basic tune-up procedure.

Unless checking for worn rings or for the cause of low speed miss, compression check should not be necessary.

Compression pressure kg/cm² (lb/sq in) at rpm

	L14, L16 and L18	L16 and L18
	Single Carb.	Twin Carb.
Standard	12.0 (171)/350	12.5 (178)/350
Minimum	9.0 (128)/350	9.0 (128)/350

ENGINE TUNE-UP

High tension wires, distributor cap and rotor cleaning and inspection

Note: This operation is to be performed while checking distributor points during the basic tune-up procedure. Inspect distributor cap for cracks and flash over.

External surfaces of all parts of secondary system must be cleaned to reduce possibility of voltage loss. All wires should be removed from distributor cap and coil so that terminals can be inspected and cleaned. Burned or corroded terminals indicate that wires were not fully seated, which causes arcing between end of wire and terminal. When replacing wires in terminal, be sure they are fully seated before pushing rubber nipple down over tower. Check distributor rotor for damage, and distributor cap for cracks.

Distributor lubricate

Slightly apply multi-purpose grease on cam lobes when servicing.

Intake manifold and carburetor attaching nuts tightening

Bolts and nuts retaining intake manifold to engines should be tightened to proper torque. Nuts attaching carburetor should be tightened securely. Leaks at these areas can cause rough idle, surging, deceleration popping or deceleration whistle.

Oil filter inspection

1. Check for oil leaks at packing flange. If any leakage is discovered, tighten it a little, or replace oil filter assembly. Do not overtighten.

2. Replace filter at the first oil change.
3. Then replace filter every 10,000 km (6,000 miles) running.

Air cleaner inspection

Viscous type element makes cleaning unnecessary until the engine used for two years, or for 40,000 km (24,000 miles) running; more often under dusty driving conditions.

Fuel strainer inspection

Check for a contaminated element, and water deposit.




Fig. ET-11 Fuel strainer

All engines use a cartridge type strainer, so if the malfunction is detected, replace as an assembly.

Cooling system inspection

Inspection of radiator cap

Apply reference pressure [0.9 kg/cm² (12.8 lb/sq in)] to the radiator

cap by means of a cap tester to see if it is satisfactory. Replace cap assembly if necessary.



Fig. ET-12 Testing radiator cap

Cooling system pressure test

With radiator cap removed, apply reference pressure [1.6 kg/cm² (22.8 sq in)] to the cooling system by means of a tester to check for leaks at system components. Water capacity 6.0 L (6 3/8 U.S. qts., 5 1/4 Imper. qts.) less heater.



Fig. ET-13 Testing cooling system pressure

ENGINE TUNE-UP

SERVICE DATA AND SPECIFICATIONS

Battery specific gravity

	Permissible value	Fully charged value (at 20°C, 68°F)
Frigid climates	Over 1.22	1.28
Tropical climates	Over 1.18	1.23
Other climates	Over 1.20	1.26

Spark plug gap	mm (in)	0.8 to 0.9 (0.031 to 0.035)
Spark plug tightening torque	kg-m (ft-lb)	1.5 to 2.0 (11.0 to 15.0)
Distributor point gap	mm (in)	0.45 to 0.55 (0.0177 to 0.0217)

Ignition timing

	L14	L16 and L18	L16 and L18
	Single carb.	Single carb.	Twin carb.
Manual transmission	8°/600 rpm	10°/600 rpm	14°/650 rpm
Automatic transmission	—	10°/650 rpm	14°/700 rpm

Fan belt tension	mm (in)/kg (lb)	8 to 12 (0.315 to 0.472)/10 (22)
-------------------------	-----------------------	----------------------------------

Engine oil capacity (including oil filter)

	L14, L16 and L18
Maximum (H level)	4.3 ℓ (4 ½ U.S. qts., 3 ¾ Imper. qts.)
Minimum (L level)	3.3 ℓ (3 ½ U.S. qts., 2 ⅞ Imper. qts.)

ENGINE TUNE-UP

Engine idling speed

	L14	L16 and L18	L16 and L18
	Single carb.	Single carb.	Twin carb.
Manual transmission rpm	600	600	650
Automatic transmission rpm	—	650	700
Engine manifold vacuum at idling speed mmHg (inHg)/rpm	450 (17.7)/600	450 (17.7)/600	400 (15.7)/650

Valve clearance

Cold:

Intake	mm (in)	0.20 (0.0079)
Exhaust	mm (in)	0.25 (0.0098)

Warm :

Intake	mm (in)	0.25 (0.0098)
Exhaust	mm (in)	0.30 (0.0118)

Compression pressure kg/cm² (lb-in²) at rpm

	L14, L16 and L18	L16 and L18
	Single carb.	Twin carb.
Standard	12.0 (171)/350	12.5 (178)/350
Minimum	9.0 (128)/350	9.0 (128)/350

ENGINE TUNE-UP

TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
CANNOT CRANK ENGINE OR SLOW CRANKING	Improper grade oil.	Replace with proper grade oil.
	Discharged battery.	Charge battery.
	Defective battery.	Replace.
	Loose fan belt.	Adjust.
	Trouble in charge system.	Inspect.
	Wiring connection trouble in starting circuit.	Correct.
	Defective starter switch.	Repair or replace.
	Defective starter motor.	Repair or replace.

(Trouble-shooting procedure on starting circuit)

Switch on the starting motor with light "ON."

When light goes off or dims considerably.

- a. Check battery.
- b. Check connection and cable.
- c. Check starter motor.

When light stays bright.

- a. Check wiring connection between battery and starter motor.
- b. Check starter switch.
- c. Check starter motor.

ENGINE WILL CRANK NORMALLY BUT WILL NOT START

In this case, the following trouble causes may exist, but in many cases ignition system or fuel system is in trouble.

Ignition system in trouble

Fuel system in trouble

Valve mechanism does not work properly

Low compression

(Trouble-shooting procedure)

Check spark plug firstly by following procedure.

Disconnect high tension cable from one spark plug and hold it about 10 mm (0.3937 in) from the engine metal part and crank the engine.

Good spark occurs.

- a. Check spark plug.
- b. Check ignition timing.
- c. Check fuel system.
- d. Check cylinder compression.

No spark occurs.

Very high current.

Check the current flow in primary circuit.

Inspect primary circuit for short.
Check breaker point operation.

ENGINE TUNE-UP

Condition	Probable cause	Corrective action
	Low or no current.	Check for loose terminal or disconnection in primary circuit. Check for burned points.
Ignition system in trouble	Burned distributor point. Improper point gap. Defective condenser. Leak at rotor cap and rotor. Defective spark plug. Improper ignition timing. Defective ignition coil. Disconnection of high tension cable. Loose connection or disconnection in primary circuit.	Repair or replace. Adjust. Replace. Clean or replace. Clean, adjust plug gap or replace. Adjust. Replace. Replace. Repair or replace.
Fuel system in trouble	Lack of fuel. Dirty fuel strainer. Dirty or clogged fuel pipe. Fuel pump will not work properly. Carburetor choke will not work properly. Improper adjustment of float level. Improper idling. Dirty or clogged carburetor. Clogged breather pipe of fuel tank.	Supply. Replace. Clean. Repair or replace. Check and adjust. Correct. Adjust. Disassemble and clean. Repair and clean.
Low compression	Incorrect spark plug tightening or defective gasket. Improper grade engine oil or low viscosity. Incorrect valve clearance. Compression leak from valve seat. Sticky valve stem. Weak or defective valve springs. Compression leak at cylinder head gasket. Sticking or defective piston ring. Worn piston ring or cylinder.	Tighten to normal torque or replace gasket. Replace with proper grade oil. Adjust . Remove cylinder head and lap valves. Correct or replace valve and valve guide. Replace valve springs. Replace gasket. Replace piston rings. Overhaul engine.
	(Trouble shooting procedure) Pour the engine oil from plug hole, and then measure cylinder compression. Compression increases. Compression does not change.	Trouble in cylinder or piston ring. Compression leaks from valve, cylinder head or head gasket.

ENGINE TUNE-UP

Condition	Probable cause	Corrective action
IMPROPER ENGINE IDLING Fuel system in trouble Low compression Others	Clogged or damaged carburetor jets. Incorrect idle adjustment. Clogged air cleaner. Defective manifold gaskets or carburetor insulator. Improper float level adjustment. Incorrect valve clearance. Extremely low revolution. Poor acceleration above 1,000 rpm (Twin carb.)	Clean or replace. Adjust. Replace element. Replace gasket or insulator. Adjust. Previously mentioned. Adjust. Adjust. Loosen idling adjusting nuts about a half turn.
ENGINE POWER NOT UP TO NORMAL Low compression Ignition system in trouble Fuel system in trouble Air intake system in trouble Overheating	Incorrect ignition timing. Defective spark plugs. Defective distributor points. Malfunction of choke system. Clogged fuel pipe or floating valve. Dirty or clogged fuel strainer. Fuel pump will not work properly. Clogged carburetor jets. Clogged air cleaner. Air inhaling from manifold gasket or carburetor gasket. Insufficient coolant. Loose fan belt. Worn or defective fan belt. Defective thermostat. Defective water pump. Clogged or leaky radiator. Defective radiator filler cap. Air in cooling system. Improper engine oil grade.	Previously mentioned. Adjust. Clean, adjust or replace plugs. Dress, or replace points. Also check condenser. Adjust. Clean. Replace. Repair or replace. Disassemble and clean. Replace element. Replace gasket. Replenish. Adjust fan belt. Replace. Replace. Replace. Flush, repair or replace. Replace. Retighten each part of cooling system. Replace with proper grade oil.

ENGINE TUNE-UP

Condition	Probable cause	Corrective action
<p>Overcooling</p> <p>Others</p>	<p>Incorrect ignition timing.</p> <p>Defective carburetor (lean mixture).</p> <p>Defective thermostat.</p> <p>Improper octane fuel.</p> <p>Improper tire pressure.</p> <p>Dragging brake.</p> <p>Clutch slipping.</p>	<p>Adjust.</p> <p>Overhaul carburetor.</p> <p>Replace.</p> <p>Replace with specified octane fuel.</p> <p>Inflate to specified pressure.</p> <p>Adjust.</p> <p>Adjust.</p>
<p>NOISY ENGINE</p> <p>Car knocking</p> <p>Mechanical knocking</p> <p>Crankshaft bearing knocking.</p> <p>Connecting rod bearing knocking.</p> <p>Piston and cylinder noise.</p> <p>Piston pin noise.</p> <p>Water pump noise.</p> <p>Others.</p>	<p>Overloaded engine.</p> <p>Carbon knocking.</p> <p>Timing knocking.</p> <p>Fuel knocking.</p> <p>Preignition (misusing of spark plug).</p> <p>This strong dull noise increases when engine is accelerated. To locate the place, cause a misfire on each cylinder. If the noise stops by the misfire, this cylinder generates the noise.</p> <p>This is a little higher-pitched noise than the crankshaft knocking, and also increases when engine is accelerated. Cause a misfire on each cylinder and if the noise diminishes almost completely, this crankshaft bearing generates the noise.</p> <p>When you hear an overlapping metallic noise which increases its magnitude with the revolution of engine and which decreases as engine is warmed up, this noise is caused by piston and cylinder. To locate the place, cause a misfire on each cylinder.</p> <p>This noise is heard at each highest and lowest dead end of piston. To locate the place, cause a misfire on each cylinder.</p> <p>This noise may be caused by worn or damaged bearings, or by the uneven surface of sliding parts.</p> <p>An improper adjustment of valve clearance.</p> <p>Noise of timing chain.</p>	<p>Use right gear in driving.</p> <p>Disassemble cylinder head and remove carbon.</p> <p>Adjust ignition timing.</p> <p>Use specified octane fuel.</p> <p>Use specified spark plug.</p> <p>This is caused by worn or damaged bearings, or unevenly worn crankshaft. Renew bearings and adjust or change crankshaft. Check lubrication system.</p> <p>Same as the case of crankshaft bearings.</p> <p>This may cause an abnormal wearing of cylinder and lower compression which in turn will cause a lower out-put power and excessive consumption of oil.</p> <p>Overhaul engine.</p> <p>This may cause a wear on piston pin, or piston pin hole.</p> <p>Renew piston and piston pin assembly.</p> <p>Replace water pump with a new one.</p> <p>Adjust.</p> <p>Adjust the tension of chain.</p>

ENGINE TUNE-UP

Condition	Probable cause	Corrective action
Others.	<p>An excessive end-play on crankshaft.</p> <p>Note: This noise will be heard when clutch is disengaged.</p> <p>Wear on clutch pilot bushing.</p> <p>Note: This noise will be heard when clutch is disengaged.</p>	<p>Disassemble engine and renew main bearing.</p> <p>Renew bush and adjust drive shaft.</p>
<p>ABNORMAL COMBUSTION (back fire, after fire run-on etc.)</p> <p>Improper ignition timing</p> <p>Fuel system in trouble</p> <p>Defective cylinder head, etc.</p>	<p>Improper ignition timing.</p> <p>Improper heat range of spark plugs.</p> <p>Damaged carburetor or manifold gasket. (back fire, after fire)</p> <p>Defective carburetor jet.</p> <p>Improper function of the float.</p> <p>Uneven idling. (Run on)</p> <p>Improperly adjusted valve clearance.</p> <p>Excess carbon in combustion chamber.</p> <p>Damaged valve spring (back fire, after fire).</p>	<p>Adjust ignition timing.</p> <p>Use specified spark plugs.</p> <p>Replace them with new parts.</p> <p>Disassemble carburetor and check it.</p> <p>Adjust the level, and check needle valve.</p> <p>Adjust.</p> <p>Adjust.</p> <p>Remove head and get rid of carbon.</p> <p>Replace it with a new one.</p>
<p>EXCESSIVE OIL CONSUMPTION</p> <p>Oil leakage</p> <p>Excessive oil consumption</p>	<p>Loose oil drain plug.</p> <p>Loose or damaged oil pan gasket.</p> <p>Loose or damaged chain cover gasket.</p> <p>Defective oil seal in front and rear of crankshaft.</p> <p>Loose or damaged locker cover gasket.</p> <p>Improper tightening of oil filter.</p> <p>Loose or damaged oil pressure switch.</p> <p>Cylinder and piston wear.</p> <p>Improper location of piston ring gap or reversely assembled piston ring.</p> <p>Damage piston rings.</p> <p>Worn piston ring groove and ring.</p> <p>Fatigue of valve oil seal lip.</p> <p>Worn valve stem.</p>	<p>Tighten it.</p> <p>Renew gasket or tighten it.</p> <p>Renew gasket or tighten it.</p> <p>Renew oil seal.</p> <p>Renew gasket or tighten it (but not too much).</p> <p>Renew gasket and tighten it with the proper torque.</p> <p>Renew oil pressure switch or tighten it.</p> <p>Overhaul cylinder and renew piston.</p> <p>Remount piston rings.</p> <p>Renew rings.</p> <p>Repair or renew piston and cylinder.</p> <p>Renew piston and piston ring.</p> <p>Replace seal lip with a new one.</p> <p>Renew valve or guide.</p>

ENGINE TUNE-UP

Condition	Probable cause	Corrective action
Others	Inadequate quality of engine oil. Engine overheat.	Use the designated oil. Previously mentioned.
POOR FUEL ECONOMY See the explanation of the power decrease Others	Exceeding idling revolution. Defective acceleration recovery. Fuel leakage. Poor fuel economy (Twin carb.)	Adjust it to the designated rpm. Adjust it. Repair or tighten the connection of fuel pipes. Tighten idling adjusting nuts a quarter to a half turn.
TROUBLE IN OTHER FUNCTIONS Decreased oil pressure	Inadequate oil quality. Overheat. Defective function of oil pump regulator valve. Functional deterioration of oil pump. Blocked oil filter. Increased clearance in various sliding parts. Blocked oil strainer. Troubles in oil gauge pressure switch.	Use the designated oil. Previously mentioned. Disassemble oil pump and repair or renew it. Repair or replace it with a new one. Renew it. Disassemble and replace the worn parts with new ones. Clean it. Replace it with a new one.
Excessive wear on the sliding parts	Oil pressure decreases. Defective quality or contamination of oil. Defective air cleaner. Overheat or overcool. Improper fuel mixture.	Previously mentioned. Exchange the oil with proper one and change element. Change element. Previously mentioned. Check the fuel system.
Scuffing of sliding parts	Decrease of oil pressure. Insufficient clearances. Overheat. Improper fuel mixture.	Previously mentioned. Readjust to the designated clearances. Previously mentioned. Check the fuel system.