

RESTRAINT SYSTEM

SECTION RS

CONTENTS

PRECAUTION2	TROUBLE DIAGNOSES - Supplemental Restraint System (SRS) - 2WD models17
Supplemental Restraint System (SRS) "AIR BAG" (4WD models)2	How to Perform Trouble Diagnoses for Quick and Accurate Repair.....17
Supplemental Restraint System (SRS) "AIR BAG" (2WD models)2	Wiring Diagram - SRS -18
SEAT BELTS3	Self-diagnosis19
Front Seat Belt.....4	COLLISION DIAGNOSIS - 2WD models21
Rear Seat Belt5	TROUBLE DIAGNOSES - Supplemental Restraint System (SRS) - 4WD models22
SUPPLEMENTAL RESTRAINT SYSTEM (SRS)6	Trouble Diagnoses Introduction.....22
Precautions for SRS "AIR BAG" Service.....6	How to Perform Trouble Diagnoses for Quick and Accurate Repair24
Special Service Tools6	Wiring Diagram - SRS -26
Description7	SRS Operation Check28
SRS Component Parts Location8	Trouble Diagnoses with CONSULT29
Maintenance Items9	Trouble Diagnoses without CONSULT37
Removal and Installation - Diagnosis Sensor Unit (4WD models).....10	Trouble Diagnoses: Air Bag Warning Lamp Does Not Turn OFF.....40
Removal and Installation - Air Bag Module and Spiral Cable (4WD models).....11	Trouble Diagnoses: Air Bag Warning Lamp Does Not Turn ON41
Removal and Installation - Air Bag Module and Spiral Cable (2WD models).....11	Trouble Diagnoses: SRS Does Not Enter Diagnosis Mode Using Door Switch.....41
Removal - Air Bag Module and Spiral Cable12	COLLISION DIAGNOSIS - 4WD models42
Installation - Air Bag Module and Spiral Cable13	
Disposal of Air Bag Module14	

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

PRECAUTION

Supplemental Restraint System (SRS) “AIR BAG” (4WD models)

The Supplemental Restraint System “AIR BAG”, used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of air bag module (located in the center of the steering wheel), diagnosis sensor unit, warning lamp, wiring harness and spiral cable.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

Supplemental Restraint System (SRS) “AIR BAG” (2WD models)

The Supplemental Restraint System “AIR BAG”, used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of air bag module (located in the center of the steering wheel), diagnosis sensor unit, warning lamp, wiring harness and spiral cable.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual.

SEAT BELTS

CAUTION:

- Do not disassemble buckle or seat belt assembly.
- Replace anchor bolts if they are deformed or worn out.
- Never oil tongue and buckle.
- If any component of seat belt assembly is questionable, do not repair. Replace the whole seat belt assembly.
- If webbing is cut, frayed, or damaged, replace seat belt assembly.
- When replacing seat belt assembly, use a genuine seat belt assembly.
- After any collision, inspect all seat belt assemblies, including retractors and other attached hardware.

GI

MA

EM

LC

EC

FE

CL

MT

TF

PD

FA

RA

BR

ST

RS

BT

HA





EL

IDX

SEAT BELTS

Front Seat Belt

- ① Remove front seat. Refer to "SEAT" in BT section for details.
- ② Remove anchor bolt cover.
- ③ Remove floor anchor bolt.
- ④ Remove center pillar garnish. Refer to "INTERIOR TRIM" in BT section for details.
- ⑤ Remove shoulder anchor bolt.
- ⑥ Remove second sash guide.
- ⑦ Remove bolts securing seat belt retractor, then remove seat belt and seat belt retractor.






 : N·m (kg-m, ft-lb)

SRS320

SEAT BELTS

Rear Seat Belt

- ① Tilt the seatback forward.
- ② Remove each anchor bolt.



 : N·m (kg-m, ft-lb)

SRS321





GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

Precautions for SRS "AIR BAG" Service

- Do not use a circuit tester to check SRS circuits unless instructed to in this Service Manual.
- Before servicing the SRS, turn ignition switch "OFF", disconnect both battery cables and wait for at least 3 minutes.
For approximately 3 minutes after the cables are removed, it is still possible for the air bag to deploy. Therefore, do not work on any SRS connectors or wires until at least 3 minutes have passed.
- For 2WD models, do not separate diagnosis sensor unit from steering wheel.
- For 4WD models, diagnosis sensor unit must always be installed with their arrow marks "↖" pointing towards the front of the vehicle for proper operation. Also check diagnosis sensor unit for cracks, deformities or rust before installation and replace as required.
- The spiral cable must be aligned with the neutral position since its rotations are limited. Do not attempt to turn steering wheel or column after removal of steering gear.
- Handle air bag module carefully. Always place it with the pad side facing upward.
- Conduct self-diagnosis to check entire SRS for proper function after replacing any components.

Special Service Tools

Tool number Tool name	Description
KV991072S0 Air bag deployment kit	Disposing of air bag module 
KV99106400 Deployment tool	NT357
KV991065S0 Deployment tool adapters	For seat belt pre-tensioner For passenger air bag module Black White 
KV99105300 Air bag module bracket	Anchoring air bag module 
HT61961000 and HT62152000 combined *1 Special torx bit	Use for special bolts [TAMPER RESISTANT TORX (Size T50)] a: 3.5 (0.138) dia. b: 8.5 - 8.6 (0.335 - 0.339) dia. c: approx. 10 (0.39) sq. 
	NT361



Unit: mm (in)

*1: Special tool or commercial equivalent

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

Description



The air bag deploys if the diagnosis sensor unit activates while the ignition switch is in the "ON" or "START" position.



GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

SRS Component Parts Location





Maintenance Items

CAUTION:

Do not use a circuit tester to check SRS circuit.

1. Check "AIR BAG" warning lamp operation.
After turning ignition key to "ON" position, "AIR BAG" warning lamp illuminates. The "AIR BAG" warning lamp will turn off after about 7 seconds if no malfunction is detected.

If any of the following air bag warning lamp conditions occur, immediately check the air bag system. Refer to RS-28 (4WD models), RS-19 (2WD models) for details.

- The warning lamp does not illuminate when the ignition switch is turned "ON".
- The warning lamp does not turn off about 7 seconds after the ignition switch is turned "ON".
- The warning lamp blinks about 7 seconds after the ignition switch is turned "ON".

2. Visually check SRS components.

(1) Diagnosis sensor unit

- Check diagnosis sensor unit and bracket for dents, cracks or deformities.
- Check connectors for damage, and terminals for deformities.

(2) Air bag module and steering wheel

- Remove air bag module from steering wheel. Check harness cover and connectors for damage, terminals for deformities, and harness for binding.

- Install driver side air bag module to steering wheel to check fit and alignment with the wheel.

- Check steering wheel for excessive free play.

(3) Spiral cable

- Check spiral cable for dents, cracks, or deformities.

- Check connectors and protective tape for damage.

- Check steering wheel for noise, binding or heavy operation.

(4) Main harness and air bag harness

- Check connectors for poor connections, damage, and terminals for deformities.

- Check harnesses for binding, chafing or cut.

CAUTION:

Replace previously used special bolts and ground bolt with new ones.

GI

MA

EM

LC

EC

FE

CL

MT

TF

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

Removal and Installation — Diagnosis Sensor Unit (4WD models)

CAUTION:

- Before servicing SRS, turn the ignition switch off, disconnect both battery cables and wait for at least 3 minutes.
- The special bolts are coated with bonding agent while the other bolt is for ground. Do not use old bolts after removal; replace with new ones.
- Check diagnosis sensor unit for proper installation.
- Check diagnosis sensor unit to ensure they are free of deformities, dents, cracks or rust. If they show any visible signs of damage, replace them with new ones.
- Check diagnosis sensor unit brackets to ensure they are free of deformities or rust.
- Replace diagnosis sensor unit if it has been dropped or sustained an impact.
- After replacement of diagnosis sensor unit, perform self-diagnosis for SRS. Refer to “Self-diagnosis” for details (RS-28).



REMOVAL OF DIAGNOSIS SENSOR UNIT


1. Disconnect air bag module connector.
2. Remove console box. Refer to “INSTRUMENT PANEL” in BT section. (4WD Double Cab models)
3. Remove console bracket.
4. Disconnect diagnosis sensor unit connector.
5. Remove bolt and also remove special bolts using the TAMPER RESISTANT TORX (Size T50), from diagnosis sensor unit. Then remove the diagnosis sensor unit.

NOTE:


- To install, reverse the removal procedure sequence.

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

Removal and Installation — Air Bag Module and Spiral Cable (4WD models)







Removal and Installation — Air Bag Module and Spiral Cable (2WD models)



GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)



Removal — Air Bag Module and Spiral Cable

CAUTION:

- Before servicing SRS, turn the ignition switch off, disconnect both battery cables and wait for at least 3 minutes.
 - Always work from the side of air bag module.
1. Remove lower lid from steering wheel, and disconnect air bag module connector.
 2. Remove side lids. Using the TAMPER RESISTANT TORX (Size T50), remove left and right special bolts. Air bag module can then be removed.

CAUTION:

- Always place air bag module with pad side facing upward.
- Do not attempt to disassemble air bag module.
- The special bolts are coated with bonding agent. Do not use old bolts after removal; replace with new ones.

- Replace air bag module if it has been dropped or sustained an impact.
- Do not expose the air bag module to temperatures exceeding 90°C (194°F).
- Do not allow oil, grease or water to come in contact with the air bag module.

3. Set steering wheel in the neutral position.
4. Disconnect horn connector (Dual Air Bag System)/spiral cable steering connector (Single Air Bag System) and remove nuts.
5. Using steering wheel puller, remove steering wheel. Be careful not to over-tighten puller bolt on steering wheel.

CAUTION:

- Do not tap or bump the steering wheel.
6. Remove steering column cover.
 7. Disconnect connectors and remove the four screws. The spiral cable can then be removed.

CAUTION:

- Do not attempt to disassemble spiral cable.

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

Removal — Air Bag Module and Spiral Cable (Cont'd)

- Do not apply lubricant to the spiral cable.
- For 2WD models, do not separate diagnosis sensor unit from steering wheel.

GI

MA

EM

LC

Installation — Air Bag Module and Spiral Cable

1. Set the front wheels in the straight-ahead position.
2. Connect spiral cable connector and tighten spiral cable with screws. Install steering column cover.

CAUTION:

- The spiral cable may snap due to steering operation if the cable is installed in an improper position.
 - Also, with the steering linkage disconnected, the cable may snap by turning the steering wheel beyond the limited number of turns. The spiral cable can be turned left about 2.5 turns from the right end position.
3. Make sure that the spiral cable is in the neutral position. The neutral position is detected by turning left about 2.5 revolutions from the right end position. Align the two marks (▲).

EC

FE

CL



MT

TF

PD

FA

RA



4WD MODELS

4. Install steering wheel setting spiral cable pin guide, and pull spiral cable through.
5. Connect horn connector and engage spiral cable with pawls in steering wheel.
6. Tighten nut.


: 29 - 39 N·m (3.0 - 4.0 kg·m, 22 - 29 ft·lb)

BR

ST

RS

BT



2WD MODELS

4. Install steering wheel setting spiral cable pin guide, and pull spiral cable through.
5. Connect spiral cable steering connector to diagnosis sensor unit in steering wheel.
6. Tighten nut.

: 29 - 39 N·m (3.0 - 4.0 kg·m, 22 - 29 ft·lb)


HA

EL

IDX

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)


Installation — Air Bag Module and Spiral Cable (Cont'd)



7. Position air bag module and tighten with new special bolts.
8. Connect air bag module connector.
9. Install all lids.
10. Conduct self-diagnosis to ensure entire SRS operates properly. (Use CONSULT or warning lamp check.)
Before performing self-diagnosis, connect both battery cables.
11. Turn steering wheel to the left end and then to the right end fully to make sure that spiral cable is set in the neutral position.
If air bag warning lamp blinks or stays ON (at the user mode), it shows the spiral cable may be snapped due to its improper position. Perform self-diagnosis again (use CONSULT or warning lamp). If a malfunction is detected, replace the spiral cable with a new one.

Disposal of Air Bag Module

- Before disposing of air bag modules or vehicles equipped with such a system, deploy the system. If such a system has already been deployed due to an accident, dispose of as indicated in "DISPOSING OF AIR BAG MODULE" (RS-16).
- When deploying the air bag module, always use the Special Service Tool; Deployment tool KV99106400.
- When deploying the air bag module stand at least 5 m (16 ft) away from the deployment component.
- When deploying the air bag module, a fairly loud noise is made, followed by smoke being released. The smoke is not poisonous, however, be careful not to inhale smoke since it irritates throat and can cause choking.
- Always activate one air bag module at a time.
- Due to heat, leave air bag module unattended for more than 30 minutes after deployment.
- Be sure to wear gloves when handling a deployed air bag module.
- Never apply water to a deployed air bag module.
- Wash your hands clean after finishing work.
- Place the vehicle outdoors with an open space of at least 6 m (20 ft) on all sides when deploying the air bag module while mounted in vehicle.
- Use a voltmeter to make sure the vehicle battery is fully charged.
- Do not dispose of the air bag module un-deployed.



CHECKING DEPLOYMENT TOOL Connecting to battery

CAUTION:

The battery must show voltage of 9.6V or more.

Remove the battery from the vehicle and place it on dry wood blocks approximately 5 m (16 ft) away from the vehicle.

- Wait 10 to 12 minutes after the vehicle battery is disconnected before proceeding.
- Connect red clip of deployment tool to battery positive terminal and black clip to negative terminal.


Make sure the polarity is correct. The right side lamp in the tool, marked "deployment tool power", should glow with a green light. If the right side lamp glows red, reverse the connections to the battery.

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

Disposal of Air Bag Module (Cont'd)

Deployment tool check


Press the deployment tool switch to the "ON" position. The left side lamp in the tool, marked "air bag connector voltage" should illuminate. If it does not illuminate, replace the tool.



Air bag deployment tool lamp illumination chart (Battery connected)

Switch operation	Left side lamp, green* "AIR BAG CONNECTOR VOLTAGE"	Right side lamp, green* "DEPLOYMENT TOOL POWER"
OFF	OFF	ON
ON	ON	ON

*: If this lamp glows red, the tool is connected to the battery incorrectly. Reverse the connections and make sure the lamp glows green.



DEPLOYMENT PROCEDURES FOR AIR BAG MODULE (OUTSIDE OF VEHICLE)

Unless the vehicle is being scrapped, deploying the air bag in the vehicle is not recommended. This may cause damage to the vehicle interior.

Anchor air bag module in a vise secured to a firm foundation during deployment.



Deployment of driver's air bag module (outside of vehicle)

1. Using wire, secure air bag module to air bag module bracket (SST: KV99105300).

CAUTION:


Use wire of at least 1 mm (0.04 in) diameter.

2. Firmly secure air bag module bracket (SST: KV99105300) with air bag module attached, in a vise.



3. Connect deployment tool (SST: KV99106400) to air bag module connector.

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)




Disposal of Air Bag Module (Cont'd)

4. Connect red clip of deployment tool to battery positive terminal and black clip to negative terminal.
5. The lamp on the right side of the tool, marked "deployment tool power", should glow green, not red.
6. Press the button on the deployment tool. The left side lamp on the tool, marked "air bag connector voltage", will illuminate and the air bag module will deploy.

CAUTION:

When deploying the air bag module, stand at least 5 m (16 ft) away from the air bag module.



DEPLOYMENT OF AIR BAG MODULE WHILE MOUNTED IN VEHICLE

When disposing of a vehicle, deploy air bag module while it is mounted in vehicle.



CAUTION:

When deploying air bag module, ensure vehicle is empty.

1. Disconnect both battery cables and wait 3 minutes.
2. Disconnect air bag module connector.
3. Connect deployment tool (SST: KV99106400) to air bag module.
4. Connect red clip of deployment tool to battery positive terminal and black clip to negative terminal.
5. The lamp on the right side of the tool, marked "deployment tool power", should glow green, not red.
6. Press the button on the deployment tool. The left side lamp on the tool, marked "air bag connector voltage", will illuminate and the air bag module will deploy.

CAUTION:

- Place the vehicle outdoors with an open space of at least 6 m (20 ft) on all sides when deploying the air bag module while mounted in the vehicle.



DISPOSING OF AIR BAG MODULE

Deployed air bag module is very hot. Before disposing of air bag module, wait at least 30 minutes. Seal it in a plastic bag before disposal.

CAUTION:

- Never apply water to a deployed air bag module.
- Be sure to wear gloves when handling a deployed air bag module.
- No poisonous gas is produced upon air bag module deployment. However, be careful not to inhale gas since it irritates throat and can cause choking.
- Do not attempt to disassemble air bag module.
- Air bag module cannot be re-used.
- Wash your hands clean after finishing work.

**How to Perform Trouble Diagnoses for Quick
and Accurate Repair**

A good understanding of the malfunction conditions can make troubleshooting faster and more accurate. In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

INFORMATION FROM CUSTOMER

- WHAT Vehicle model
- WHEN Date, Frequencies
- WHERE Road conditions
- HOW Operating conditions, Symptoms

PRELIMINARY CHECK

Check that the following parts are in good order.

- Battery [Refer to MA section (“GENERAL MAINTENANCE”).]
- Fuse [Refer to EL section (“Fuse”, “POWER SUPPLY ROUTING”).]
- System component-to-harness connections

DIAGNOSIS FUNCTION


The SRS self-diagnosis results can be read by using “AIR BAG” warning lamp.

Note: CONSULT cannot be used for trouble diagnoses.

CAUTION:

- Do not use a circuit tester to check SRS harness connectors unless instructed to in this Service Manual.
- Do not attempt to repair, splice or modify the SRS wiring harness. If the harness is damaged, replace it with a new one.
- Keep ground portion clean.


WORK FLOW





GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Wiring Diagram — SRS —


RS-SRS-01



Refer to EL-POWER.



* : This connector is not shown in "HARNESS LAYOUT", EL section.



Self-diagnosis

DIAGNOSTIC PROCEDURE (⊗ without CONSULT)


Checking SRS operation by using “AIR BAG” warning lamp — User mode

1. After turning ignition switch from “OFF” to “ON”, “AIR BAG” warning lamp operates.

2. Compare “AIR BAG” warning lamp operation to the chart below.

Note: CONSULT cannot be used for trouble diagnoses.

“AIR BAG” warning lamp operation — User mode



GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Self-diagnosis (Cont'd)

REPAIR PROCEDURES

CAUTION:

Before servicing air bag, turn the ignition switch off and disconnect both battery cables and wait at least 3 minutes.

Warning lamp operation	Explanation	Repair order
Warning lamp blinks.*	Open or short in the air bag module circuit.	<ol style="list-style-type: none"> 1. Visually check the wiring harness and connectors. 2. Replace air bag module. 3. Replace steering wheel assembly (including diagnosis sensor unit).
	Malfunctioning diagnosis sensor unit	
Warning lamp does not illuminate at all.	Meter fuse is blown.	<ol style="list-style-type: none"> 1. Check meter fuse. 2. Visually check the wiring harnesses and connectors. 3. Check warning lamp LED. 4. Replace spiral cable. 5. Replace steering wheel assembly (including diagnosis sensor unit). 6. Replace combination meter.
	Open in the warning lamp power supply circuit	
	Short circuit between the warning lamp and diagnoses sensor unit.	
	Malfunctioning LED	
	Malfunctioning combination meter	
	Malfunctioning diagnosis sensor unit	
Warning lamp is continuously ON.	SRS air bag fuse is blown.	<ol style="list-style-type: none"> 1. Check air bag fuse. 2. Visually check the wiring harnesses and connectors for combination meter, diagnosis sensor unit and spiral cable. 3. Replace spiral cable. 4. Replace steering wheel assembly (including diagnosis sensor unit).
	Open in circuit between the warning lamp and diagnoses sensor unit.	
	Malfunctioning diagnosis sensor unit	

*: After air bag is deployed, the warning lamp might blink due to an open circuit in the air bag module. Follow the procedures in numerical order when repairing malfunctioning parts. Confirm whether malfunction is eliminated using the air bag warning lamp each time repair is finished. If malfunction is still observed, proceed to the next step. When malfunction is eliminated, further repair work is not required.

COLLISION DIAGNOSIS — 2WD models

To repair the SRS “AIR BAG”, perform the following steps:

When SRS is activated in a collision:

- ① Remove the air bag module. GI
- ② Remove the steering wheel assembly. MA
- ③ Check the spiral cable using the table shown below:
 - If the spiral cable shows any visible damage such as dents, cracks, or deformation, replace it with a new one. EM
- ④ Install new steering wheel assembly. LC
- ⑤ Install new air bag module. EC
- ⑥ Conduct self-diagnosis using “AIR BAG” warning lamp to ensure that entire SRS operates properly. Refer to RS-19 for details. FE

When SRS is not activated in a collision:

- ① Check the SRS components using the table shown below:
 - If the SRS components show any visible damage such as dents, cracks, or deformation, replace them with new ones. CL
- ② Conduct self-diagnosis using “AIR BAG” warning lamp to ensure that entire SRS operates properly. Refer to RS-19 for details. MT

SRS inspection

Part	SRS is activated	SRS is NOT activated
Air bag module	REPLACE Install with new bolts.	1. Remove air bag module. Check harness cover and connectors for damage, terminals for deformities, and harness for binding. TF 2. Install air bag module into the steering wheel to check fit and alignment with the wheel. PD 3. No damage found, reinstall with new bolts. FA 4. If damaged—REPLACE. Air bag must be deployed before discarding. RA
Steering wheel assembly (including diagnosis sensor unit)	REPLACE	1. Visually check steering wheel for deformities. BR 2. Check harness and connectors for damage, and terminals for deformities. ST 3. Check diagnosis sensor unit for dents, cracks or deformities. RS Do not remove diagnosis sensor unit from steering wheel. 4. Install air bag module to check fit or alignment with steering wheel. 5. If no damage is found, reinstall the steering wheel assembly. 6. If damaged—REPLACE.
Spiral cable		1. Check spiral cable for dents, cracks or deformities. BT 2. Check connectors and protective tape for damage. HA 3. Check steering wheel for noise, binding or heavy operation. EL 4. If no damage is found, reinstall it. IDX 5. If damaged—REPLACE.
Harness and Connectors		1. Check connectors for poor connection, damage, and terminals for deformities. 2. Check harness for binding, chafing, cuts, or deformities. 3. If no damage is found, reinstall the harness and connectors. 4. Damaged—REPLACE damaged section of harness. Do not attempt to repair, splice or modify any SRS harness.

Trouble Diagnoses Introduction

CAUTION:

- Do not use a circuit tester to check SRS harness connectors unless instructed to in this Service Manual. SRS wiring harnesses can be identified with yellow harness protector or yellow insulation tape before the harness connectors.
- Do not attempt to repair, splice or modify the SRS wiring harness. If the harness is damaged, replace it with a new one.
- Keep ground portion clean.

DIAGNOSIS FUNCTION

The SRS self-diagnosis results can be read by using “AIR BAG” warning lamp and/or CONSULT. The reading of these results is accomplished using one of two modes — “User mode” and “Diagnosis mode”.

The User mode is exclusively prepared for the customer (driver). This mode warns the driver of a system malfunction through the operation of the “AIR BAG” warning lamp.


The Diagnosis mode allows the technician to locate and inspect the malfunctioning part.

The mode applications for the “AIR BAG” warning lamp and CONSULT are as follows:

	User mode	Diagnosis mode	Display type
“AIR BAG” warning lamp	X	X	ON-OFF operation
CONSULT	—	X	Monitoring

DIAGNOSIS MODE FOR CONSULT

- “SELF-DIAG [CURRENT]”
A current Self-diagnosis result (also indicated by the warning lamp flashes in the Diagnosis mode) is displayed on the CONSULT screen in real time. This refers to a malfunctioning part requiring repairs.
- “SELF-DIAG [PAST]”
Diagnosis results previously stored in the memory (also indicated by the warning lamp flashes in the Diagnosis mode) are displayed on the CONSULT screen. The stored results are not erased until memory erasing is executed.
- “TROUBLE DIAG RECORD”
With TROUBLE DIAG RECORD, diagnosis results previously erased by a reset operation can be displayed on the CONSULT screen.



- ECU DISCRIMINATED NO.
The diagnosis sensor unit for each vehicle model is assigned with its own, individual classification number. This number will be displayed on the CONSULT screen, as shown at left. When replacing the diagnosis sensor unit, refer to the part number for the compatibility. After installation, replacement with a correct unit can be checked by confirming this classification number on the CONSULT screen.

For NISSAN D22 4WD models, the diagnosis sensor unit classification number assigned is 74.


Trouble Diagnoses Introduction (Cont'd)

HOW TO CHANGE SELF-DIAGNOSIS MODE

With CONSULT



From User mode to Diagnosis mode

After selecting AIR BAG on the “SELECT SYSTEM” screen, User mode automatically changes to Diagnosis mode.



From Diagnosis mode to User mode

To return to User mode from Diagnosis mode, touch “BACK” key of CONSULT until “SELECT SYSTEM” appears. Diagnosis mode automatically changes to User mode.



Without CONSULT

From User mode to Diagnosis mode

Diagnosis mode activates only when a malfunction is detected, by pressing the driver's door switch at least 5 times within 7 seconds after turning the ignition “ON”. SRS will not enter Diagnosis mode if no malfunction is detected.

From Diagnosis mode to User mode

When a malfunction is detected to return to User mode from Diagnosis mode, switch the ignition “OFF”, then back “ON” and press the driver's door switch at least 5 times within 7 seconds. After a malfunction is repaired, switch the ignition “OFF” for at least one second, then back “ON”. Diagnosis mode returns to User mode.


GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses Introduction (Cont'd)

HOW TO ERASE SELF-DIAGNOSIS RESULTS

With CONSULT

- “SELF-DIAG [CURRENT]”
A current Self-diagnosis result is displayed on the CONSULT screen in real time. After the malfunction is repaired completely, no malfunction is detected on “SELF-DIAG [CURRENT]”.



- “SELF-DIAG [PAST]”
Return to the “SELF-DIAG [CURRENT]” CONSULT screen by pushing “BACK” key of CONSULT and select “SELF-DIAG [CURRENT]” in “SELECT DIAG MODE”. Touch “ERASE” in “SELF-DIAG [CURRENT]” mode.

NOTE:

If the memory of the malfunction in “SELF-DIAG [PAST]” is not erased, the User mode shows the system malfunction by the operation of the warning lamp even if the malfunction is repaired completely.

- “TROUBLE DIAG RECORD”
The memory of TROUBLE DIAG RECORD cannot be erased.

Without CONSULT

After a malfunction is repaired, switch the ignition “OFF” for at least one second, then back “ON”. Diagnosis mode returns to the User mode. At that time, the problem code is cleared.

How to Perform Trouble Diagnoses for Quick and Accurate Repair

A good understanding of the malfunction conditions can make troubleshooting faster and more accurate. In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

INFORMATION FROM CUSTOMER

- WHAT Vehicle model
- WHEN Date, Frequencies
- WHERE Road conditions
- HOW Operating conditions, Symptoms

PRELIMINARY CHECK


Check that the following parts are in good order.

- Battery [Refer to EL section (“BATTERY”).]
- Fuse [Refer to EL section (“Fuse”, “POWER SUPPLY ROUTING”).]
- System component-to-harness connections

TROUBLE DIAGNOSES — Supplemental Restraint System (SRS) — 4WD models

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)




WORK FLOW



GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Wiring Diagram — SRS —

RS-SRS-02




Wiring Diagram — SRS — (Cont'd)

RS-SRS-03



* : This connector is not shown in "HARNES LAYOUT", EL section.

GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



SRS Operation Check

DIAGNOSTIC PROCEDURE 1


Checking SRS operation by using “AIR BAG” warning lamp — User mode

1. After turning ignition switch from “OFF” to “ON”, “AIR BAG” warning lamp operates.
2. Compare “AIR BAG” warning lamp operation to the chart below.

“AIR BAG” warning lamp operation — User mode —	SRS condition	Reference item
<p align="right">MRS095A</p>	No malfunction is detected. No further action is necessary.	—
<p align="right">MRS096A</p>	The system has problem and needs to be repaired as indicated.	Go to DIAGNOSTIC PROCEDURE 2 or 6 (RS-29 or 37).
<p align="right">MRS097A</p>	Air bag is deployed. Air bag fuse, diagnosis sensor unit or harness is malfunctioning and needs to be repaired.	Go to COLLISION DIAGNOSIS (RS-42). Go to DIAGNOSTIC PROCEDURE 9 (RS-40).
<p align="right">MRS098A</p>	One of the following has occurred and needs to be repaired. <ul style="list-style-type: none"> ● Meter fuse is blown. ● “AIR BAG” warning lamp circuit has short. ● Diagnosis sensor unit is malfunctioning. 	Go to DIAGNOSTIC PROCEDURE 10 (RS-41).

NOTE:

If “AIR BAG” warning lamp operates differently from the operations shown above, refer to “AIR BAG” warning lamp operation — Diagnosis mode —, DIAGNOSTIC PROCEDURE 6 (step 4), RS-37.




Trouble Diagnoses with CONSULT


DIAGNOSTIC PROCEDURE 2

Inspecting SRS malfunctioning parts by using CONSULT — Diagnosis mode


1. Turn ignition switch "OFF".
2. Connect "CONSULT" to Data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "AIRBAG".




6. Touch "SELF-DIAG [CURRENT]".



7. Diagnostic codes are displayed on "SELF-DIAG [CURRENT]".

GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses with CONSULT (Cont'd)



If no self-diagnostic failure is detected on “SELF-DIAG [CURRENT]” even though malfunction is detected in DIAGNOSTIC PROCEDURE 1, check the battery voltage. If the battery voltage is less than 9V, charge the battery. Then go to DIAGNOSTIC PROCEDURE 3, page RS-31. If the battery voltage is OK, go to DIAGNOSTIC PROCEDURE 4, page RS-33, to diagnose the following situations:

- Diagnosis results (previously stored in the memory) might not be erased after repair.
 - The SRS system malfunctions intermittently.
8. Touch “PRINT”.
 9. Compare diagnostic codes to the CONSULT DIAGNOSTIC CODE CHART, page RS-30.
 10. Touch “BACK” key of CONSULT until SELECT SYSTEM appears in order to return to User mode from Diagnosis mode, then turn off CONSULT.
 11. Turn ignition switch “OFF”, then disconnect CONSULT and both battery cables.
 12. Repair the system as outlined by the “Repair order” in CONSULT DIAGNOSTIC CODE CHART, that corresponds to the problem code. For replacement procedure of component parts, refer to RS-10.
 13. After repairing the system, go to DIAGNOSTIC PROCEDURE 3 for final checking, page RS-31.

CONSULT DIAGNOSTIC CODE CHART (“SELF-DIAG [CURRENT]”)

Diagnostic item	Explanation/Possible causes	Repair order Recheck SRS at each replacement.
NO SELF DIAGNOSTIC FAILURE INDICATED.	When malfunction is indicated by the “AIR BAG” warning lamp in User mode. <ul style="list-style-type: none"> ● Self-diagnostic failure “SELF-DIAG [PAST]” (previously stored in the memory) might not be erased after repair. ● Intermittent problem has been detected in the past. 	● Go to DIAGNOSTIC PROCEDURE 4 (RS-33).
	● No malfunction is detected.	● Go to DIAGNOSTIC PROCEDURE 3 (RS-31).
AIRBAG MODULE [OPEN]	● Driver’s air bag module circuit is open. (including the spiral cable)	1. Visually check the wiring harness connection.
AIRBAG MODULE [VB-SHORT]	● Driver’s air bag module circuit is shorted to some power supply circuit. (including the spiral cable)	2. Replace the harness if it has visible damage.
AIRBAG MODULE [GND-SHORT]	● Driver’s air bag module circuit is shorted to ground. (including the spiral cable)	3. Replace driver’s air bag module. (Before disposal of it, it must be deployed.)
AIRBAG MODULE [SHORT]	● Driver’s air bag module circuits are shorted to each other.	4. Replace the spiral cable.
CONTROL UNIT	● Diagnosis sensor unit is out of order.	5. Replace the diagnosis sensor unit.
		1. Visually check the wiring harness connections.
		2. Replace the diagnosis sensor unit.






* Follow the procedures in numerical order when repairing malfunctioning parts. Confirm whether malfunction is eliminated using the air bag warning lamp or CONSULT each time repair is finished. If malfunction is still observed, proceed to the next step. When malfunction is eliminated, further repair work is not required.

Trouble Diagnoses with CONSULT (Cont'd)

DIAGNOSTIC PROCEDURE 3

Final checking after repairing SRS by using CONSULT — Diagnosis mode

1. After repairing SRS, connect both battery cables.
2. Connect CONSULT to Data link connector.
3. Turn ignition switch from "OFF" to "ON".



4. Touch "START".




5. Touch "AIRBAG".

6. Touch "SELF-DIAG [CURRENT]".

7. If no malfunction is detected on "SELF-DIAG [CURRENT]", repair of SRS is completed.
If any problem code is displayed on "SELF-DIAG [CURRENT]", the malfunctioning part is not repaired completely or another malfunctioning part is detected. Go to DIAGNOSTIC PROCEDURE 2, page RS-29, and repair malfunctioning part completely.

GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses with CONSULT (Cont'd)



8. Touch "ERASE".

NOTE:

Touch "ERASE" to clear the memory of the malfunction (SELF-DIAG [PAST]).

If the memory of the malfunction is "SELF-DIAG [PAST]" is not erased, the User mode shows the system malfunction by the operation of the warning lamp even if the malfunction is repaired completely.

9. Touch "BACK" key of CONSULT to select "SELF-DIAG [PAST]" in the "SELECT DIAG MODE" screen. Touch "SELF-DIAG [PAST]".

10. Check that no self-diagnostic failure is detected on "SELF-DIAG [PAST]".

11. Touch "BACK" key of CONSULT until SELECT SYSTEM appears in order to return to User mode from Diagnosis mode, turn off CONSULT, then disconnect CONSULT.


12. Turn ignition switch "OFF".

13. Go to DIAGNOSTIC PROCEDURE 1, page RS-28 to check SRS operation by using "AIR BAG" warning lamp with User mode.

Trouble Diagnoses with CONSULT (Cont'd)

DIAGNOSTIC PROCEDURE 4 (Continued from DIAGNOSTIC PROCEDURE 2)

Inspecting SRS malfunctioning record




GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses with CONSULT (Cont'd)


DIAGNOSTIC PROCEDURE 5

Inspecting SRS intermittent problem by using CONSULT — Diagnosis mode


1. Turn ignition switch "OFF".
2. Connect "CONSULT" to Data link connector.




3. Turn ignition switch "ON".
4. Touch "START".




5. Touch "AIRBAG".



6. Touch "SELF-DIAG [PAST]".






7. If diagnostic codes are displayed on "SELF-DIAG [PAST]", go to step 10.



Trouble Diagnoses with CONSULT (Cont'd)

If no self-diagnostic failure is detected on "SELF-DIAG [PAST]", touch "BACK" and go back to "SELECT DIAG MODE".



8. Touch "TROUBLE DIAG RECORD".

NOTE:

With TROUBLE DIAG RECORD, diagnosis results previously erased by a reset operation can be displayed.

9. Diagnostic code is displayed on "TROUBLE DIAG RECORD".

10. Touch "PRINT".

11. Compare diagnostic codes to the INTERMITTENT PROBLEM DIAGNOSTIC CODE CHART, page RS-36.

12. Touch "BACK" key of CONSULT until SELECT SYSTEM appears, then turn off CONSULT.

13. Turn ignition switch "OFF", then disconnect CONSULT and both battery cables.

14. Repair the system as outlined by the "Repair order" in INTERMITTENT PROBLEM DIAGNOSTIC CODE CHART, that corresponds to the problem code. For replacement procedure of component parts, refer to RS-10.

15. Go to DIAGNOSTIC PROCEDURE 3, page RS-31, for final checking.

GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


TROUBLE DIAGNOSES — Supplemental Restraint System (SRS) — 4WD models

Trouble Diagnoses with CONSULT (Cont'd)

INTERMITTENT PROBLEM DIAGNOSTIC CODE CHART (“SELF-DIAG [PAST]” or “TROUBLE DIAG RECORD”)

Diagnostic item	Explanation	Repair order
NO SELF DIAGNOSTIC FAILURE INDICATED.	<ul style="list-style-type: none"> ● No malfunction is detected. 	<ul style="list-style-type: none"> ● Go to DIAGNOSTIC PROCEDURE 3 (RS-31) after charging battery.
AIRBAG MODULE [OPEN]	<ul style="list-style-type: none"> ● Driver's air bag module circuit is open. (including the spiral cable) 	<ul style="list-style-type: none"> ● Visually check the wiring harness connection. ● Replace the harness if it has visible damage. ● Replace driver's air bag module. (Before disposal of it, it must be deployed.) ● Replace the spiral cable. ● Replace the diagnosis sensor unit.
AIRBAG MODULE [VB-SHORT]	<ul style="list-style-type: none"> ● Driver's air bag module circuit is shorted to some power supply circuit. (including the spiral cable) 	
AIRBAG MODULE [GND-SHORT]	<ul style="list-style-type: none"> ● Driver's air bag module circuit is shorted to ground. (including the spiral cable) 	
AIRBAG MODULE [SHORT]	<ul style="list-style-type: none"> ● Driver's air bag module circuits are shorted to each other. 	
CONTROL UNIT	<ul style="list-style-type: none"> ● Diagnosis sensor unit is out of order. 	<ul style="list-style-type: none"> ● Visually check the wiring harness connection. ● Replace the diagnosis sensor unit.

* Intermittent problem areas cannot be easily located. For this reason, perform the procedures outlined under the repair order, then make the final system check.



Trouble Diagnoses without CONSULT

DIAGNOSTIC PROCEDURE 6

Inspecting SRS malfunctioning parts by using “AIR BAG” warning lamp — Diagnosis mode

NOTE:

SRS will not enter Diagnosis mode if no malfunction is detected in User mode.

1. Open driver’s door.
2. Turn ignition switch from “OFF” to “ON”.
3. Press driver’s door switch at least 5 times within 7 seconds after turning ignition switch “ON”.
SRS is now in Diagnosis mode.
4. “AIR BAG” warning lamp operates in Diagnosis mode as follows:

NOTE:

If SRS does not enter Diagnosis mode even though malfunction is detected in User mode, go to DIAGNOSTIC PROCEDURE 11, page RS-41.

No.	“AIR BAG” warning lamp flash pattern — Diagnosis mode —	SRS condition
1	<p style="text-align: right;">Ⓐ through Ⓑ are repeated.</p> <p style="text-align: center;">SRS333</p>	<ul style="list-style-type: none"> • Diagnosis results (previously stored in the memory) might not be erased after repair. • Intermittent problem has been detected in the past. <p>Go to DIAGNOSTIC PROCEDURE 8 (RS-40).</p>
2	<p style="text-align: right;">Ⓐ through Ⓓ are repeated.</p> <p style="text-align: center;">SRS341</p> <p style="text-align: right;">Ⓓ — Indicates malfunctioning part. The number of flash varies with malfunctioning part (0.5 sec. ON and 0.5 sec. OFF is counted as one flash.)</p>	<p>The system has a problem and needs to be repaired.</p>

5. Malfunctioning part is indicated by the number of flashes (part Ⓓ or Ⓕ). Compare the number of flashes to AIR BAG WARNING LAMP FLASH CODE CHART, page RS-38, and locate malfunctioning part.
6. Turn ignition switch “OFF”, and disconnect both battery cables.
7. Repair the system as outlined by the “Repair order” in AIR BAG WARNING LAMP FLASH CODE CHART that corresponds to the flash code. For replacement procedure of component parts, refer to RS-10.
8. After repairing the system, go to DIAGNOSTIC PROCEDURE 7, page RS-38.

GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses without CONSULT (Cont'd)



5. If "AIR BAG" warning lamp operates as shown in No. 1 in chart above, turn ignition switch "OFF" to reset from Diagnosis mode to User mode and to erase the memory of the malfunction. Then go to step 6.

If "AIR BAG" warning lamp operates as shown in No. 2 or No. 3 in chart above, the malfunctioning part is not repaired completely, or another malfunctioning part is detected. Go to DIAGNOSTIC PROCEDURE 6, page RS-37, and repair malfunctioning part completely.

6. Turn ignition switch "ON". "AIR BAG" warning lamp operates in User mode. Compare "AIR BAG" warning lamp operation to the chart below.




NOTE:

If switching Diagnosis mode to User mode is required while malfunction is being detected, turn ignition switch from "OFF" to "ON". Then press driver's door switch at least 5 times within 7 seconds after turning ignition switch "ON". SRS is now in User mode.

"AIR BAG" warning lamp operation — User mode —	SRS condition	Reference item
 <p>MRS095A</p>	No malfunction is detected. No further action is necessary.	—
 <p>MRS096A</p>	The system has problem and needs to be repaired as indicated.	Go to DIAGNOSTIC PROCEDURE 2 or 6 (RS-29 or 37).
 <p>MRS097A</p>	Air bag is deployed. Air bag fuse, diagnosis sensor unit or harness is malfunctioning and needs to be repaired.	Go to COLLISION DIAGNOSIS (RS-42). Go to DIAGNOSTIC PROCEDURE 9 (RS-40).
 <p>MRS098A</p>	One of the following has occurred and needs to be repaired. <ul style="list-style-type: none"> ● Meter fuse is blown. ● "AIR BAG" warning lamp circuit has open or short. ● Diagnosis sensor unit is malfunctioning. 	Go to DIAGNOSTIC PROCEDURE 10 (RS-41).


**Trouble Diagnoses without CONSULT (Cont'd)
DIAGNOSTIC PROCEDURE 8 (Continued from
DIAGNOSTIC PROCEDURE 6)**


Inspecting SRS malfunctioning record



Trouble Diagnoses: Air Bag Warning Lamp Does Not Turn OFF

DIAGNOSTIC PROCEDURE 9







SRS317

Trouble Diagnoses: Air Bag Warning Lamp Does Not Turn ON



DIAGNOSTIC PROCEDURE 10




SRS263

Trouble Diagnoses: SRS Does Not Enter Diagnosis Mode Using Door Switch

DIAGNOSTIC PROCEDURE 11



SRS264-B



SRS265-B

Condition	Continuity
Door switch is depressed (Door is closed).	NO
Door switch is released (Door is open).	YES

GI
MA
EM
LC
EC
FE
CL
MT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

FOR FRONTAL COLLISION

To repair the SRS for a frontal collision, perform the following steps.

When SRS is activated in a collision:

- ① Replace the diagnosis sensor unit.
- ② Remove the air bag module.
- ③ Check the SRS components using the table shown below:
 - Replace any SRS components showing visible signs of damage (dents, cracks, deformation).
- ④ Install new air bag module.
- ⑤ Conduct self-diagnosis using CONSULT, and “AIR BAG” warning lamp. Refer to “Self-diagnosis” for details (RS-28). Ensure entire SRS operates properly.

When SRS is not activated in a collision:

- ① Check the SRS components using the table shown below:
 - Replace any SRS components showing visible signs of damage (dents, cracks, deformation).
- ② Conduct self-diagnosis using CONSULT, and “AIR BAG” warning lamp. Refer to “Self-diagnosis” for details (RS-28). Ensure entire SRS operates properly.

SRS inspection

Part	SRS is activated	SRS is NOT activated
Air bag module	REPLACE Install air bag module with new bolts.	<ol style="list-style-type: none"> 1. Remove air bag module. Check harness cover and connectors for damage, terminals for deformities, and harness for binding. 2. Install driver air bag module into the steering wheel to check fit and alignment with the wheel. 3. No damage found, reinstall with new bolts. 4. If damaged—REPLACE. Air bag must be deployed before discarding.
Diagnosis sensor unit	REPLACE Install diagnosis sensor unit with new bolts.	<ol style="list-style-type: none"> 1. Check case and bracket for dents, cracks or deformities. 2. Check connectors for damage, and terminals for deformities. 3. If no damage is found, reinstall with new bolts. 4. If damaged—REPLACE. Install diagnosis sensor unit with new bolts.
Steering wheel		<ol style="list-style-type: none"> 1. Visually check steering wheel for deformities. 2. Check harness (built into steering wheel) and connectors for damage, and terminals for deformities. 3. Install air bag module to check fit or alignment with steering wheel. 4. Check steering wheel for excessive free play. 5. If no damage is found, reinstall. 6. If damaged—REPLACE.
Spiral cable		<ol style="list-style-type: none"> 1. Visually check spiral cable and combination switch for damage. 2. Check connectors, lead wires and protective tape for damage. 3. Check steering wheel for noise, binding or heavy operation. 4. If no damage is found, reinstall it. 5. If damaged—REPLACE.
Harness and Connectors		<ol style="list-style-type: none"> 1. Check connectors for poor connection, damage, and terminals for deformities. 2. Check harness for binding, chafing, cuts, or deformities. 3. If no damage is found, reinstall harness and connectors. 4. Damaged—REPLACE damaged section of harness. Do not attempt to repair, splice or modify any SRS harness.