


SECTION **EM****ENGINE MECHANICAL****EM****CONTENTS**

<b>ENGINE COMPONENTS</b> .....	EM- 2	CRANKSHAFT .....	EM-10
<b>ENGINE DISASSEMBLY</b> .....	EM- 3	BEARING .....	EM-11
PRELIMINARY CLEANING AND		MISCELLANEOUS COMPONENTS .....	EM-11
INSPECTION .....	EM- 3	<b>ENGINE ASSEMBLY</b> .....	EM-13
DISASSEMBLY .....	EM- 3	PRECAUTIONS .....	EM-13
PISTON AND CONNECTING ROD .....	EM- 5	CYLINDER HEAD .....	EM-13
CYLINDER HEAD AND VALVE .....	EM- 5	PISTON AND CONNECTING ROD .....	EM-14
<b>INSPECTION AND REPAIR</b> .....	EM- 6	ENGINE ASSEMBLY .....	EM-14
PREPARATION FOR INSPECTION .....	EM- 6	<b>SERVICE DATA AND</b>	
CYLINDER HEAD AND VALVE .....	EM- 6	<b>SPECIFICATIONS</b> .....	EM-18
CAMSHAFT AND CAMSHAFT BEARING ..	EM- 7	INSPECTION AND ADJUSTMENT .....	EM-18
CYLINDER BLOCK .....	EM- 8	TIGHTENING TORQUE .....	EM-22
PISTON, PISTON PIN AND		<b>TROUBLE DIAGNOSES AND</b>	
PISTON RING .....	EM- 9	<b>CORRECTIONS</b> .....	EM-23
CONNECTING ROD .....	EM-10	<b>SPECIAL SERVICE TOOLS</b> .....	EM-25


# ENGINE COMPONENTS

- |   |                |    |                 |
|---|----------------|----|-----------------|
| 1 | Rocker cover   | 8  | Crankshaft      |
| 2 | Camshaft       | 9  | Oil pan         |
| 3 | Timing gear    | 10 | Flywheel        |
| 4 | Front cover    | 11 | Thermostat      |
| 5 | Oil pump       | 12 | Cylinder block  |
| 6 | Piston         | 13 | Cylinder head   |
| 7 | Connecting rod | 14 | Valve mechanism |



EM704

Engine Components



- |   |                  |
|---|------------------|
| 1 | Manifold gasket  |
| 2 | Exhaust manifold |
| 3 | Intake manifold  |

EM759

Manifold


# ENGINE DISASSEMBLY

## PRELIMINARY CLEANING AND INSPECTION


Before disassembling engine, observe the following items:

1. Prior to disassembling, check outer parts for sign of leak past their gasketed surfaces.
2. Check fuel hoses for deterioration, cracks or otherwise leakage of fuel past their jointed or connected surfaces.
3. Wipe dust and mud off engine.
4. Inspect outer parts for visual faults and broken or missing parts such as bolts and nuts.
5. Check piping and electrical circuits for deterioration, breakage, fittings, discontinuity or insulation.

Engine Attachment ST05340001  
Engine Stand Assembly ST0501S000



Engine on Engine Stand




EM745

Intake Manifold Assembly

- Exhaust manifold
- Thermostat housing
- Crank pulley using Puller Crank Pulley ST16540000.

6. Thoroughly drain engine oil and coolant by removing drain plugs.
7. Remove the following outer parts and electrical parts.
  - Distributor cap and high tension cable.
  - Distributor
  - Hose and pipe connected to engine
  - Fuel line
  - Intake manifold



EM706

Removing Crank Pulley

## DISASSEMBLY

To remove engine from car, refer to Section ER.


1. Remove starting motor and transmission from engine.
2. Remove clutch assembly, using Clutch Aligning Bar KV30100100 to support weight of clutch disc.
3. Remove auxiliary cooling fan assembly (if so equipped).
4. Remove alternator and alternator bracket.
5. Place engine assembly on the engine stand.
  - (1) Remove engine mounting bracket R.H.
  - (2) Remove oil filter using Oil Filter Wrench ST19320000.
  - (3) Install engine attachment to cylinder block using bolt holes securing alternator bracket and engine mounting.
  - (4) Remove oil pressure switch.
  - (5) Set engine on the stand.

**Note:** Remove intake manifold as an assembly of fuel pipe, injector, air regulator, etc. as follows:

- a. Disconnect hose connecting rocker cover to throttle chamber at rocker cover.
- b. Disconnect water pipe connecting heater housing to water inlet at water inlet.  
Remove bolt which secures water pipe and fuel pipe to cylinder head.
- c. Remove tube connecting heater housing to thermostat housing.
- d. Remove bolt which secures intake manifold to cylinder head and remove intake manifold as an assembly.
- e. Remove P.C.V. valve hose, sub heat shield plate and E.G.R. tube (if so equipped).

- Water pump
- Oil pump and oil pump drive spindle.
- Rocker cover
- Oil level gauge
- Spark plugs, etc.

8. Remove cylinder head assembly.
  - (1) Remove camshaft sprocket and slowly lower timing chain.




EM707

Removing Camshaft Sprocket



(2) Loosen cylinder head bolts in the sequence using Cylinder Head Bolt Wrench ST10120000.



EM708


*Cylinder Head Bolt Loosening Sequence*

(3) Remove bolts securing cylinder head to front cover.

Note: When removing cylinder head from engine installed on car, follow the instructions below.

- Turn crankshaft until No. 1 piston is at T.D.C. on its compression stroke.
- To facilitate assembling operation, scribe a mark on timing chain and camshaft sprocket with paint before removal.
- Support timing chain by utilizing Chain Stopper KV10105800 (ST17420001) between timing chains.


KV10105800  
(ST17420001)



SEM132

*Supporting Timing Chain*

- Remove oil pan and oil strainer.
- Remove front cover.
- Remove chain tensioner and chain guide.
- Remove timing chain.
- Remove oil thrower, oil pump drive gear and crankshaft sprocket from crankshaft.




- Chain tensioner
- Slack side chain guide
- Tension side chain guide
- Oil thrower
- Oil pump drive gear
- Crankshaft sprocket

EM709

*Removing Chain Tensioner and Timing Chain*


Note: If it is hard to extract crankshaft sprocket, use a suitable puller.



EM286

*Removing Crankshaft Sprocket*

14. Remove piston and connecting rod assembly.




EM287

*Removing Piston and Connecting Rod Assembly*

Note: Numbers are stamped on connecting rod and cap corresponding to each cylinder. Care should be taken to avoid wrong combination including bearing.

- Remove crankshaft.
- Remove flywheel and end plate.

**WARNING:**  
When removing flywheel, be careful not to drop it.




EM710

*Removing Flywheel*

- Remove main bearing cap.

Note:

- When loosening main bearing cap bolt, loosen from outside in sequence.
- Use Crankshaft Main Bearing Cap Puller KV101041S0 to remove center and rear main bearing caps. Keep them in order.




EM608

*Removing Rear Main Bearing Cap*

- Remove rear oil seal.
- Remove crankshaft.




16. Remove baffle plate and steel net.



Removing Baffle Plate and Net


## PISTON AND CONNECTING ROD

1. Remove piston rings with a ring remover.



Removing Piston Rings


2. Press piston pin out. Using press and Piston Pin Press Stand ST13030001.



Removing Piston Pin

Note: Keep the disassembled parts in order.

## CYLINDER HEAD AND VALVE




- 1 Camshaft
- 2 Valve rocker spring
- 3 Valve rocker
- 4 Valve rocker guide
- 5 Valve spring collet
- 6 Valve spring retainer
- 7 Valve outer spring
- 8 Valve inner spring
- 9 Valve oil seal
- 10 Valve outer spring seat
- 11 Valve inner spring seat
- 12 Valve
- 13 Valve rocker pivot
- 14 Rocker pivot rock nut
- 15 Rocker spring retainer
- 16 Rocker pivot bushing

EM712

Valve Mechanism

1. Remove valve rocker spring.
2. Loosen valve rocker pivot lock nut and remove rocker arm by pressing down valve spring.




Removing Rocker Arm

Note: At this time, take care not to damage camshaft bearings and cam lobes.

4. Remove valve rocker pivot, rocker pivot lock nut and rocker spring retainer.

Note: Do not remove rocker pivot bushing.


5. Remove valves using Valve Lifter ST12070000.



Removing Valve

Note: Be sure to leave camshaft bearing intact. Because the bearing center is liable to be out of alignment.

3. Remove camshaft.



Removing Camshaft

## INSPECTION AND REPAIR

### PREPARATION FOR INSPECTION

1. Before cleaning, check for sign of water and oil leaks.
2. Clean oil and carbon deposits from all parts. They should be clean from gasket or sealant.
3. Clean all oil holes with solvent and dry with compressed air. Make sure that they are not restricted.

### CYLINDER HEAD AND VALVE

#### CHECKING CYLINDER HEAD MATING FACE


##### CAUTION:

Never remove camshaft bearings unless you have a suitable machine for boring camshaft bearing in line. If you once remove camshaft bearings, bearing centers will be out of alignment and reconditioning is very difficult without center borings.

1. Make a visual check for cracks and flaws.
2. Measure the surface of cylinder head (on cylinder block side) for warpage.

If beyond the specified limit, correct with a surface grinder.

Warpage of surface:  
Less than  
0.1 mm (0.004 in)



EM713  
Measuring Cylinder Head Surface

Note: Surface grinding limit


The grinding limit of cylinder head is determined by the cylinder block grinding in an engine.

Depth of cylinder head grinding is "A"

Depth of cylinder block grinding is "B"

The limit is as follows:

$$A + B = 0.2 \text{ mm (0.008 in)}$$



EM296  
Measuring Spring Squareness

#### VALVE


1. Check each of the intake and exhaust valve for worn, damaged or deformed valve caps or stems. Correct or replace the valve that is faulty.

For standard size of valve, refer to Service Data and Specifications.

2. Valve face or valve stem end surface should be refaced by using a valve grinder.

Note: When valve head has been worn down to 0.5 mm (0.020 in) in thickness, replace the valve.

Grinding allowance for valve stem end surface is 0.5 mm (0.020 in) or less.



EM111  
Regrinding Valve Face

#### VALVE SPRING

1. Check valve spring for squareness using a steel square and surface plate. If spring is out of square "S" more than specified limit, replace with new ones.

Out of square ("S")

Outer:

Less than

2.2 mm (0.087 in)


Inner:

Less than

1.2 mm (0.047 in)

2. Measure the free length and the tension of each spring. If the measured value exceeds the specified limit, replace spring.

Refer to Service Data and Specifications.



EM113  
Measuring Spring Tension

#### ROCKER ARM AND VALVE ROCKER PIVOT

Check pivot head and cam contact and pivot contact surfaces of rocker arm for damage or wear. If faults are found, replace them. A faulty pivot necessitates its replacement together with the corresponding rocker arm.

#### VALVE GUIDE


Measure the clearance between valve guide and valve stem. If the clearance exceeds the specified limit, replace the worn parts or both valve and valve guide. In this case, it is essential to determine if such a clearance has been caused by a worn or bent valve stem or by a worn valve guide.



## Determining clearance

Precise measurement of clearance between valve stem and valve guide needs the aid of a micrometer and a telescope hole gauge. By using these gauges, measure the diameter of valve stem in three places; top, center and bottom.

Refer to Service Data and Specifications.



EM030

Measuring Valve Stem Diameter

Insert telescope hole gauge in valve guide bore, measuring at center.


Subtract the highest reading of valve stem diameter from valve guide bore to obtain the stem to guide clearance.

As an expedient, a valve is pushed in valve guide and moved to the right and left. If its tip deflects beyond the specified limit there, it will be known that the clearance between stem and guide exceeds the maximum limit.

**Max. allowable deflection:**  
0.2 mm (0.008 in)

**Max. tolerance:**  
Stem to guide clearance  
0.1 mm (0.004 in)

**Note:** Valve should be moved in parallel with rocker arm. (Generally, a large amount of wear occurs in this direction.)



EM115


Measuring deflection between Valve Stem and Valve Guide

## Replacement of valve guide

1. To remove old guides, use Drift ST11033000 and a press (under a 2-ton pressure) or a hammer.

Drive them out from combustion chamber side toward rocker cover. Heated cylinder head will facilitate the operation.

2. Ream cylinder head valve guide hole using Reamer ST11081000 [12.2 mm (0.480 in) dia.] at room temperature.



ST11081000

Reaming Valve Guide

3. Press new valve guide into head carefully so that it will fit smoothly after heating cylinder head to 150 to 200°C (302 to 392°F).

Valve guide of 0.2 mm (0.008 in) oversize diameter is available for service. Refer to Service Data and Specifications.

4. Ream the bore with valve guide pressed in, using Valve Guide Reamer ST11032000 [8.0 mm (0.315 in) dia.].

**Reaming bore:**  
8.000 - 8.018 mm  
(0.3150 - 0.3157 in)

5. Correct valve seat surface with new valve guide as the axis.


## VALVE SEAT INSERTS

Check valve seat inserts for any evidence of pitting at valve contact surface, and reseal or replace if worn out excessively.

Correct valve seat surface with Valve Seat Cutter ST11650001 and grind with a grinding compound.

Valve seat insert of 0.5 mm (0.020 in) oversize is available for service.

Refer to Service Data and Specifications.



ST11650001

EM299

Correcting Valve Seat

## Replacement valve seat insert

1. Old insert can be removed by boring out until it collapses. The machine depth stop should be set so that boring cannot continue beyond the bottom face of the insert recess in cylinder head.

2. Select a suitable valve seat insert and check its outside diameter.

3. Machine cylinder head recess to the concentric circles to valve guide center so that insert will have the correct fit.

4. Ream the cylinder head recess at room temperature.

5. Heat cylinder head to a temperature of 150 to 200°C (302 to 392°F).

6. Fit insert ensuring that it beds on the bottom face of its recess, and caulk more than 4 points.

7. Valve seats newly fitted should be cut or ground using Valve Seat Cutter ST11650001 at the specified dimensions as shown in Service Data and Specifications.

8. Apply small amount of fine grinding compound to valve contacting face and put valve into guide. Lap valve against its seat until proper valve seating is obtained. Remove valve and then clean valve and valve seat.


## CAMSHAFT AND CAMSHAFT BEARING

### CAMSHAFT BEARING CLEARANCE

Measure the inside diameter of camshaft bearing with an inside dial gauge and the outside diameter of camshaft

journal with a micrometer. If any malfunction is found, replace camshaft or cylinder head assembly.

**Max. tolerance of camshaft bearing clearance:**  
0.1 mm (0.004 in)



EM119

*Measuring Camshaft Bearing*

## CAMSHAFT ALIGNMENT


1. Check camshaft, camshaft journal and cam surface for bend, wear or damage. If problems are beyond the limits, replace the parts.

2. Camshaft can be checked for bend by placing it on V-blocks and using a dial gauge with its indicating finger resting on center journal.

**Camshaft bend**

(Total indicator reading):

Less than 0.10 mm (0.0039 in)



EM302


*Measuring Camshaft Bend*

3. Measure camshaft end play. If beyond the specified limit, replace locating plate.

**Camshaft end play:**

0.08 - 0.38 mm

(0.0031 - 0.0150 in)



EM310

*Measuring Camshaft End Play*

4. Measure camshaft cam height. If beyond the specified limit, replace camshaft.

Refer to Service Data and Specifications.

## VALVE TIMING

If any valve is found out of specifications (refer to Service Data and Specifications), one possibility is that cam lobe is worn or damaged, calling for replacement of camshaft.


## CYLINDER BLOCK

1. Visually check cylinder block for cracks or flaws.

2. Measure the top of cylinder block (cylinder head mating face) for warp. If warp exceeds the specified limit, correct with a grinder.

**Warpage of cylinder block surface:**

Less than 0.10 mm (0.0039 in)



EM751

*Measuring Cylinder Block Surface*

**Note: Surface grinding limit;**

The grinding limit of cylinder block is determined by the cylinder head grinding in an engine.

Depth of cylinder head grinding is "A"

Depth of cylinder block grinding is "B"


The limit is as follows:

$A + B = 0.2 \text{ mm (0.008 in)}$

3. Using a bore gauge, measure cylinder bore for out-of-round or taper. If, out-of-round or taper is excessive, rebore the cylinder walls by means of a boring machine. Measurement should be taken along bores for taper and around bores for out-of-round.

Refer to Service Data and Specifications.


**Out-of-round** X-Y  
**Taper** A-B



Unit: mm (in)

EM125

*Cylinder Bore Measuring Positions*



EM304

*Measuring Cylinder Bore Diameter*

4. When wear, taper or out-of-round is minor and within the limit, remove the step at the topmost portion of cylinder using a ridge reamer or other similar tool.

## CYLINDER BORING


1. When any cylinder needs boring, all other cylinders must also be bored at the same time.

2. Determine piston oversize according to amount of wear of cylinder.

Refer to Service Data and Specifications.

3. The size to which cylinders must be honed is determined by adding piston-to-cylinder clearance to the piston skirt diameter "A".






Measuring Piston Skirt Diameter

Note: Measure dimension "a" at position shown below.

Dimension "a"  
(distance from center of pin):  
Approximately  
20 mm (0.79 in)



Measuring Position of Piston Skirt Diameter

Rebored size calculation

$$D = A + B - C = A + [0.005 \text{ to } 0.025 \text{ mm (0.0002 to 0.0010 in)}]$$

where,

- D : Honed diameter
- A : Skirt diameter as measured
- B : Piston-to-wall clearance
- C : Machining allowance  
0.02 mm (0.0008 in)

**CAUTION:**

- a. To prevent strain due to cutting heat, bore the cylinders in the order of 1-5-3-6-2-4.
- b. Before boring any cylinder, install main bearing caps in place and tighten to the specification so that the crankshaft bearing bores will not become distorted from the boring operation.

4. Do not cut too much out of cylinder bore at a time. Cut only 0.05 mm (0.0020 in) or so in diameter at a time.

5. Measurement of a just machined cylinder bore requires utmost care since it is expanded by cutting heat.

6. As a final step, cylinders should be honed to size.

7. Measure the finished cylinder bore for out-of-round or tapered part.

Refer to Service Data and Specifications.


8. Measure piston-to-cylinder clearance.

This clearance can be checked easily by using a feeler gauge and a spring balance hooked on feeler gauge, measuring the amount of force required to pull gauge out from between piston and cylinder.

Feeler gauge used:  
0.04 mm (0.0016 in)  
Extracting force:  
2.0 - 14.7 N  
(0.2 - 1.5 kg,  
0.4 - 3.3 lb)

Note:

- a. When measuring clearance, slowly pull feeler gauge straight upward.
- b. It is recommended that piston and cylinder be heated to 20°C (68°F).



Measuring Piston Fit in Cylinder

Note: If cylinder bore has worn beyond the wear limit, use-cylinder liner.

Undersize cylinder liners are available for service.

Interference fit of cylinder liner in cylinder block should be 0.08 to 0.09 mm (0.0031 to 0.0035 in).


## PISTON, PISTON PIN AND PISTON RINGS

1. Measure the side clearance of rings in ring grooves as each ring is installed.

If side clearance exceeds the specified limit, replace piston together with piston ring.

Max. tolerance of side clearance:

0.1 mm (0.004 in)



EM129

Measuring Piston Ring Side Clearance


2. Measure ring gap with a feeler gauge, placing ring squarely in cylinder.

Ring should be placed to diameter at upper or lower limit of ring travel.

If ring gap exceeds the specified limit, replace ring.

Max. tolerance of ring gap:

1.0 mm (0.039 in)



EM130

Measuring Ring Gap

Note:


- a. When piston ring only is to be replaced, without cylinder bore being corrected, measure the gap at the bottom of cylinder where the wear is minor.

b. Oversize piston rings are available for service. [0.5 mm (0.020 in), 1.0 mm (0.039 in) oversize].

3. Measure piston pin hole in relation to the outer diameter of pin. If wear exceeds the limit, replace such piston pin together with piston on which it is installed.

**Piston pin to piston clearance:**  
0.006 - 0.013 mm  
(0.0002 - 0.0005 in)


**Note:** Determine the fitting of piston pin into piston pin hole to such an extent that it can be pressed smoothly by finger at room temperature. This piston pin must be a tight press fit into connecting rod.



## CONNECTING ROD

1. Check connecting rod for bend or torsion using a connecting rod aligner. If bend or torsion exceeds the limit, correct or replace.

**Bend and torsion**  
[per 100 mm (3.94 in) length]:  
Less than  
0.05 mm (0.0020 in)




Measuring Rod Alignment

2. When replacing connecting rod, select rod so that weight difference between new and old ones is within 7 gr (0.25 oz).

3. Install connecting rods with bearings on to corresponding crank pins and measure the thrust clearance. If the measured value exceeds the limit, replace such connecting rod.

**Max. tolerance of big end play:**  
0.6 mm (0.024 in)




## CRANKSHAFT

1. Repair or replace as required. If faults are minor, correct with fine crocus cloth.

2. Check with a micrometer journals and crank pins for taper and out-of-round. Measurement should be taken along journals for taper and around journals for out-of-round.

If out-of-round or taper exceeds the specified limit, replace or repair.

**Out-of-round (X-Y):**  
Less than 0.03 mm (0.0012 in)  
**Taper (A-B):**  
Less than 0.03 mm (0.0012 in)




Measurement Point

3. After regrounding crankshaft, finish it to the necessary size indicated in the chart under Service Data and Specifications by using an adequate undersize bearing according to the extent of required repair.

4. Crankshaft can be checked for bend by placing it on V-blocks and using a dial gauge with its indicating finger resting on center journal.


If bend exceeds the specified limit, replace or repair.



Measuring Crankshaft Bend

**Bend (Total indicator reading):**  
Less than 0.10 mm (0.0039 in)

5. Measure crankshaft end play. If beyond the specified limit, replace main bearing.




Measuring Crankshaft End Play

**Max. tolerance of end play:**  
0.3 mm (0.012 in)

6. To replace crankshaft rear pilot bushing, proceed as follows:

(1) Pull out bushing using Pilot Bushing Puller ST16610001.






EM718

*Pulling Out Pilot Bushing*

- (2) Before installing a new bushing, thoroughly clean bushing hole.
- (3) Insert pilot bushing until distance between flange end and pilot bushing is the specified distance "A".

Distance "A":  
Approximately  
4.0 mm (0.157 in)

Do not oil bushing.



EM719

*Installing Pilot Bushing*

Note: When installing pilot bushing, be careful not to damage edge of pilot bushing and not to insert excessively.

## BEARING


### MEASUREMENT OF MAIN BEARING CLEARANCE

1. Thoroughly clean all bearings and check for scratches, melt, score or wear.

Replace bearings, if any fault is detected.

2. Crankshaft journals and bearings should be clean and free from dust and dirt before oil clearance is measured.
3. Set main bearing on cap block.
4. Cut a plastigage to the width of bearing and place it in parallel with crank journal, getting clear of the oil hole. Install cap on the assembly and tighten them together to the specified torque.

⊕ : Main bearing cap  
44 - 54 N·m  
(4.5 - 5.5 kg·m,  
33 - 40 ft·lb)




EM141

*Fig. EM-49 Plastigage*

Note: Do not turn crankshaft while the plastigage is being inserted.

5. Remove cap, and compare width of the plastigage at its widest part with the scale printed in the plastigage envelope.



EM142

*Measuring Bearing Clearance*

6. If clearance exceeds the specified value, replace bearing with an under-size bearing and grind crankshaft journal adequately.

Max. tolerance of main bearing clearance:  
0.12 mm (0.0047 in)

### MEASUREMENT OF CONNECTING ROD BEARING

1. Measure connecting rod bearing clearance in the same manner as above.

⊕ : Connecting rod bearing cap  
44 - 54 N·m  
(4.5 - 5.5 kg·m,  
33 - 40 ft·lb)

2. If clearance exceeds the specified value, replace bearing with an under-size bearing and grind the crankshaft journal adequately.

Max. tolerance of connecting rod bearing clearance:  
0.12 mm (0.0047 in)


## MISCELLANEOUS COMPONENTS

### CAMSHAFT SPROCKET

Install camshaft sprocket in position and check for runout.

If runout exceeds the specified limit, replace camshaft sprocket.

Runout:  
(Total indicator reading)  
Less than 0.1 mm (0.004 in)



EM309

*Measuring Camshaft Sprocket Runout*


### CHAIN

1. Check chain for damage, excessive wear or stretch at roller links. Replace if faulty.
2. To properly adjust chain tension (or valve timing), camshaft sprocket has a cam locating plate and three location holes (Nos. 1, 2 and 3).


Camshaft sprocket is preset at No. 1 hole at the factory. If chain becomes loose, adjust it by setting camshaft sprocket at No. 2 or No. 3 hole.

To check and adjust stretch of chain, proceed as follows:

- ① to ③: Timing mark  
1 to 3: Location hole




Before adjustment



After adjustment

Adjusting Camshaft Sprocket Location

(1) Turn engine until No. 1 piston is at T.D.C. on its compression stroke. Determine whether camshaft sprocket location notch comes off the left end of the oblong groove on camshaft locating plate.



Camshaft Location Plate

(2) If the location notch is off the left end of the oblong groove, chain stretch is beyond limits and No. 2 location hole of camshaft sprocket is set on camshaft pin. This No. 2 notch should then be on the oblong groove. When No. 2 hole is used, No. 2 timing mark must also be used. The amount of the modification is a 4° rotation of crankshaft.

(3) If the valve timing cannot be corrected by using No. 2 hole, use No. 3 hole in the same procedure as above. The amount of modification by using No. 3 hole is an 8° rotation of crankshaft.

(4) When modification becomes impossible even by transferring camshaft location hole, replace chain assembly.

## CHAIN TENSIONER AND CHAIN GUIDE

Check for wear and breakage. Replace if necessary.


## FLYWHEEL

1. Check the clutch disc contact surface with flywheel for damage or wear. Repair or replace if necessary.
2. Measure runout of the clutch disc contact surface with a dial gauge. If it exceeds the specified limit, replace it.

## Runout:

(Total indicator reading)

Less than 0.15 mm (0.0059 in)



Measuring Flywheel Deviation


3. Check tooth surfaces of ring gear for flaws or wear. Replace if necessary.

Note: Replace ring gear at about 180 to 220°C (356 to 428°F).

## FRONT AND REAR OIL SEAL

First check front and rear oil seals for worn or folded over sealing lip or oil leakage. If necessary, replace with a new seal. When installing a new seal, pay attention to its mounting direction.

Note: It is good practice to renew oil seal whenever engine is overhauled.



Front

Rear

EM150

Oil Seal of Crankshaft



# ENGINE ASSEMBLY

## PRECAUTIONS


1. Use thoroughly cleaned parts. Particularly, make sure that oil holes are clear of foreign matter.
2. When installing sliding parts such as bearings, be sure to apply engine oil to them.
3. Use new packings and oil seals.
4. Do not reuse lock washers that have been removed.
5. Keep tools and work benches clean.
6. Keep the necessary parts and tools ready near at hand.
7. Be sure to follow specified tightening torque and order.
8. Applying sealant

Use sealant to eliminate water and oil leaks. Parts requiring sealant are:

- (1) Front cover gasket: Front side of cylinder block and cover gasket.
- (2) Front cover: Top of front cover.
- (3) Main bearing cap and cylinder block: Each side of rear main bearing cap and each corner of cylinder block.
- (4) Cylinder block: Step portions at four mating surfaces (cylinder block to front chain cover and cylinder block to rear main bearing cap).


Note: Do not apply sealant too much.

Apply sealant at these points.




EM153

Applying Sealant (Front cover and gasket)



Applying Sealant (Main bearing cap and cylinder block)



EM315

Applying Sealant (Cylinder block)


## CYLINDER HEAD

1. To install valve, proceed as follows:

- (1) Set valve spring inner and outer seat and valve oil seal.

Then insert valve into valve guide smoothly without scratching lip of oil seal.

- (2) Install valve spring inner and outer, valve spring retainer, valve spring collet and valve rocker guide by using Valve Lifter ST12070000.




Installing Valve

Note:

- a. Check whether the valve face is free from foreign matter.
- b. Outer valve spring is of an uneven pitch type. Install valve spring with its narrow pitch side (painted) at cylinder head side.

Painted color: Red



EM316

Installing Valve Spring

2. Valve rocker pivot assembly

Screw valve rocker pivots joined with lock nuts into pivot bushing.

Install valve rocker spring retainer.

Note: Fully screw in valve rocker pivot.

3. Camshaft assembly

Note:

- a. Set locating plate and install camshaft in cylinder head carefully.

① : Camshaft locating plate


5.9 - 9.8 N·m

(0.6 - 1.0 kg·m,

4.3 - 7.2 ft·lb)

- b. Do not damage the bearing inside.


- c. The oblong groove of locating plate must be directed toward the front side of engine.



EM317

Installing Camshaft Locating Plate

4. Install rocker arms by pressing down valve springs with a screwdriver, etc.




5. Install valve rocker springs.
6. After assembling cylinder head, turn camshaft until No. 1 piston is at T.D.C. on its compression stroke.

## PISTON AND CONNECTING ROD


1. Assemble pistons, piston pins and connecting rods on the designated cylinder.

### Note:

- a. Piston is pressed into connecting rod, and fitting force is from 4.9 to 14.7 KN (0.5 to 1.5 t, 0.6 to 1.7 US ton, 0.5 to 1.5 Imp ton) and the aid of Piston Pin Press Stand ST13030001 is necessary. When pressing piston pin in connecting rod, apply engine oil to pin and small end of connecting rod.




- b. Arrange so that oil jet of connecting rod big end is directed toward the right side of cylinder block.
- c. Be sure to install piston in cylinders with notch mark of piston head toward the front of engine.



2. Install piston ring.

### Note:

- a. Install so that marks stamped on top and 2nd rings face upward.
- b. Top ring is chromium-plated on liner contacting face.
- c. Second ring has larger taper surface than top ring.
- d. In the combined oil ring, upper rail is the same as lower one.



## ENGINE ASSEMBLY

1. Install baffle plate including steel net.
2. Set main bearings at the proper portion of cylinder block.




Fig. EM-66 Main Bearing

### Note:

- a. Only center bearing (No. 4) is a flanged type.
- b. All inter-bearings are the same type.
- c. Front bearing (No. 1) is also the same type as rear bearing (No. 7).

### CAUTION:

Use care when installing main bearings. Side with oil groove should be at cylinder block side and side without oil groove should be at main cap side.

3. Apply engine oil to main bearing surfaces on both sides of cylinder block and cap.


Install crankshaft.

4. Install main bearing cap and tighten bolts to specified torque.

T : Main bearing cap  
44 - 54 N·m  
(4.5 - 5.5 kg·m,  
33 - 40 ft·lb)

### Note:


- a. Apply sealant to each side of rear main bearing cap and each corner of cylinder block.
- b. Arrange the parts so that the arrow mark on bearing cap faces toward the front of engine.
- c. Prior to tightening bearing cap bolts, place bearing cap in proper position by shifting crankshaft in the axial direction.
- d. Tighten bearing cap bolts gradually in separating two to three stages and outwardly from center bearing in sequence.
- e. After securing bearing cap bolts, ascertain that crankshaft turn smoothly.



Torque Sequence of Cap Bolts

5. Install side oil seals into rear main bearing cap. Prior to installing, apply sealant to these seals.






EM724

Driving Side Oil Seal

Note: Install oil seal with its core at bearing cap side.

6. Make sure that there exists proper end play at crankshaft.


Max. tolerance of end play:  
0.3 mm (0.012 in)



EM717

Checking Crankshaft End Play

7. Install rear oil seal using Crankshaft Rear Oil Seal Drift KV10105500 (ST15310000)



KV10105500  
(ST15310000)


SEM133

Installing Rear Oil Seal

Note: When installing oil seal, give coating of engine oil to mating shaft to prevent scratches and folded lip. Also apply coating of oil to periphery of oil seal.

8. Install rear end plate.
9. Install flywheel securely, and tighten bolts to specified torque.


Ⓣ : Flywheel fixing bolts  
127 - 147 N·m  
(13.0 - 15.0 kg·m,  
94 - 108 ft·lb)



EM327

Installing Flywheel

10. Insert pistons in corresponding cylinder using Piston Ring Compressor EM03470000.




EM03470000

EM328

Installing Piston-Rod Assembly

Note:

- a. Apply engine oil to sliding parts.
- b. Arrange so that the front mark on piston head faces to the front of engine.
- c. Install piston ring as shown below.




EM725

Piston Ring Direction

11. Install connecting rod caps.

Ⓣ : Connecting rod cap nut  
44 - 54 N·m  
(4.5 - 5.5 kg·m,  
33 - 40 ft·lb)



EM329

Installing Connecting Rod Cap

Note: Arrange connecting rods and connecting rod caps so that the cylinder numbers face in the same direction.

12. Make sure that there exists proper end play at connecting rod big end. Refer to connecting rod for inspection and repair.

13. Install crankshaft sprocket and oil pump drive gear and fit oil thrower.

Note:

- a. Make sure that the mating marks of crankshaft sprocket faces to the front.
- b. Install oil pump drive gear so that large chamfered inner side faces rearward.

14. Install cylinder head assembly through gasket by accommodating knock pin of cylinder block.

Note:


- a. Thoroughly clean cylinder block and head surface.  
Do not apply sealant to any other part of cylinder block and head surface.
- b. Turn crankshaft until No. 1 piston is at T.D.C. on its compression stroke.
- c. When installing cylinder head, make sure that all valves are apart from head of pistons.
- d. Do not rotate crankshaft and camshaft separately, because valves will hit head of pistons.
- e. Temporarily tighten two center bolts.

Ⓣ : Cylinder head bolt (Temporary tightening torque)

20 N·m (2 kg·m, 14 ft·lb)

15. Set chain by aligning mating mark on camshaft sprocket with that of crankshaft sprocket and install camshaft sprocket to camshaft.

- Ⓙ : Camshaft sprocket  
118 - 157 N·m  
(12 - 16 kg-m,  
87 - 116 ft-lb)



- 1 Chain guide (Slack side)
- 2 Chain tensioner
- 3 Crank sprocket
- 4 Cam sprocket
- 5 Chain guide (Tension side)

EM726

## Installing Timing Chain


### Note:

- a. Set timing chain by making its mating marks align with those of crankshaft sprocket and camshaft sprocket the right hand side.
- b. No. 1 hole is factory adjusted. When chain stretches excessively, adjust camshaft sprocket at No. 2 or No. 3 hole.  
For adjustment, refer to Inspection and Repair of Chain.

16. Install chain guide and chain tensioner.

- Ⓙ : 5.9 - 9.8 N·m  
(0.6 - 1.0 kg-m,  
4.3 - 7.2 ft-lb)

Note: Adjust the protrusion of chain tensioner spindle to 0 mm (0 in) with slack side chain guide.



EM170

## Installing Chain Tensioner

17. Press new oil seal in front cover.

Note: Front cover oil seal should be replaced when front cover is disassembled.

18. Install front cover with gasket in place.

### Note:

- a. Apply sealant to front side of cylinder block and front cover gasket.
- b. Apply sealant only to the top of front cover.
- c. Install front cover with head gasket in place.
- d. Check the height difference between cylinder block upper face and front cover upper face. Its difference must be less than 0.15 mm (0.0059 in).
- e. Note that different lengths of bolts are used.

- Ⓙ : Front cover bolts

Size M8

10 - 16 N·m  
(1.0 - 1.6 kg-m,  
7 - 12 ft-lb)

Size M6


3.9 - 9.8 N·m  
(0.4 - 1.0 kg-m,  
2.9 - 7.2 ft-lb)

19. Install crankshaft pulley and water pump.

- Ⓙ : Crankshaft pulley nut

118 - 157 N·m  
(12 - 16 kg-m,  
87 - 116 ft-lb)

20. Finally tighten head bolts to the specified torque in several steps, by using Cylinder Head Bolt Wrench ST10120000.



EM727

## Tightening Sequence

- Ⓙ : Cylinder head bolt  
69 - 83 N·m  
(7.0 - 8.5 kg-m,  
51 - 61 ft-lb)


### Note:

- a. Be sure to tighten bolt securing cylinder head to front cover.
- b. After engine has been operated for several minutes; if necessary, re-tighten.

21. Install oil pump and distributor driving spindle in front cover.

- Ⓙ : Oil pump bolts

11 - 15 N·m  
(1.1 - 1.5 kg-m,  
8 - 11 ft-lb)




EL011

## Installing Oil Pump

### Note:

- a. Assemble oil pump and drive spindle, aligning driving spindle face with oil pump hole.




EL009

## Setting Distributor Driving Spindle

- b. Install oil pump together with drive spindle so that the projection on its top is located at the 11:25 a.m. position. At this point, the smaller bow-shape will be facing toward the front.





Setting Distributor Drive Spindle

c. Be sure to install gasket.

22. Install oil strainer and oil pan with gasket in place.

Ⓣ : Oil strainer bolts  
10 - 16 N·m  
(1.0 - 1.6 kg-m,  
7 - 12 ft-lb)

Oil pan bolts  
5.9 - 9.8 N·m  
(0.6 - 1.0 kg-m,  
4.3 - 7.2 ft-lb)

Note:

- Apply sealant to the step portions at four mating surfaces.
- Oil pan should be tightened in criss-cross pattern.

23. Adjust valve clearance to the specified dimensions Using Pivot Adjuster ST10640001.

Ⓣ : 49 - 59 N·m  
(5.0 - 6.0 kg-m,  
36 - 43 ft-lb)


Valve clearance:

Cold - Intake  
0.17 mm (0.007 in)\*  
Cold - Exhaust  
0.24 mm (0.009 in)\*  
Hot - Intake  
0.25 mm (0.010 in)  
Hot - Exhaust  
0.30 mm (0.012 in)

\*: Ambient temperature at 20°C (68°F)

Note:

- First set clearance to the cold specifications.



EM338


Adjusting Valve Clearance

- After engine has been assembled, run it for at least several minutes, finally adjust the clearance to the hot specifications.

24. Install the following outer parts and electrical parts.

Note: For tightening torque specifications, refer to Service Data and Specifications.

- Rocker cover
- Exhaust manifold and intake manifold with gasket.




- Long bolt 40 mm (1.57 in)
- Short bolt 32 mm (1.26 in)

Location of Intake Manifold Securing Bolts

- Fuel line
- Water inlet and thermostat housing.
- Water piping.
- Engine slinger
- Idler pulley and power steering oil pump mounting bracket. (if so equipped)
- Idler pulley and air conditioning compressor mounting bracket. (if so equipped)
- Distributor
- High tension cable
- Engine mounting bracket L.H.
- Auxiliary cooling fan assembly (if so equipped)

- Clutch assembly, using Clutch Aligning Bar KV30100100



Installing Clutch Assembly

25. Using an overhead hoist and lifting cable, hoist engine away from engine stand and remove engine attachment.

26. Install alternator bracket adjusting bar, alternator, cooling fan and belt.


Be sure that belt deflection is held within specified range when moderate force is applied midway between pulleys.

Belt deflection:

8 - 12 mm  
(0.31 - 0.47 in)

Pushing force:

98 N (10 kg, 22 lb)



Fan Belt Tension

27. Install engine mounting bracket R.H., oil filter, oil pressure sending unit and oil level gauge. When installing oil filter, fasten it to cylinder block by hand.

Note: Do not overtighten filter, otherwise oil leakage may occur.

28. Fill engine oil up to specified level.

# SERVICE DATA AND SPECIFICATIONS

## INSPECTION AND ADJUSTMENT

### CYLINDER HEAD AND VALVE


#### Cylinder head

Unit: mm (in)

	Standard	Limit
Head surface flatness	Less than 0.05 (0.0020)	0.1 (0.004)

#### Valve

Unit: mm (in)



EM109

Valve head diameter "H"	Intake	44.0 (1.732)
	Exhaust	35.0 (1.378)
Valve length "L"	Intake	114.9 - 115.2 (4.52 - 4.54)
	Exhaust	115.7 - 116.0 (4.56 - 4.57)
Valve stem diameter "D"	Intake	7.965 - 7.980 (0.3136 - 0.3142)
	Exhaust	7.945 - 7.960 (0.3128 - 0.3134)
Valve seat angle "α"	Intake Exhaust	45°30'

#### Valve spring

Free height mm (in)	Outer-	49.98 (1.9677)
	Inner-	44.85 (1.7657)
Pressure height mm/N (mm/kg, in/lb)	Outer-	29.5/480.5 (29.5/49.0, 1.161/108.0)
	Inner-	24.5/250.1 (24.5/25.5, 0.965/56.2)
Assembled height mm/N (mm/kg, in/lb)	Outer-	40.0/208.9 (40.0/21.3, 1.575/47.0)
	Inner-	35.0/120.6 (35.0/12.3, 1.378/27.1)
Out of square ("S") mm (in)	Outer-	2.2 (0.087)
	Inner-	1.2 (0.047)

#### Valve guide

Unit: mm (in)

EXHAUST

8.3 - 8.5 (0.327 - 0.335) dia.

3 (0.12)

INTAKE

10.7 - 11.0  
(0.421 - 0.433)

59.0 (2.323)

EM730

10.4 -  
10.6  
(0.409 -  
0.417)10.4 -  
10.6  
(0.409 -  
0.417)

INTAKE

EXHAUST

EM116


	Standard	Service
Valve guide Outer diameter "D"	12.023 - 12.034 (0.4733 - 0.4738)	12.223 - 12.234 (0.4812 - 0.4817)
Valve guide Inner diameter "d" [Finished size]	8.000 - 8.018 (0.3150 - 0.3157)	
Cylinder head valve guide hole diameter "a"	11.985 - 11.996 (0.4718 - 0.4723)	12.185 - 12.196 (0.4797 - 0.4802)
Interference fit of valve guide	0.027 - 0.049 (0.0011 - 0.0019)	
	Standard	Max. tolerance
Stem to guide clearance	Intake	0.020 - 0.053 (0.0008 - 0.0021)
	Exhaust	0.040 - 0.073 (0.0016 - 0.0029)
		0.1 (0.004)




# Valve seat

## Service valve insert dimensions

Unit: mm (in)



D <sub>1</sub>	45.597 - 45.613 (1.7952 - 1.7958)
D <sub>2</sub>	39 (1.54)
H	6.7 - 6.8 (0.264 - 0.268)
L	1.0 - 2.0 (0.039 - 0.079)
R	9 (0.35)



D <sub>1</sub>	STD	37.080 - 37.096 (1.4598 - 1.4605)
	0.5 (0.020) oversize	37.580 - 37.596 (1.4795 - 1.4802)
D <sub>2</sub>		30 (1.18)
D <sub>3</sub>		32.6 (1.283)
H		7.4 - 7.5 (0.291 - 0.295)
φ		30°


## Cylinder head recess diameter

Unit: mm (in)


Intake		
0.5 (0.020) oversize		45.500 - 45.516 (1.7913 - 1.7920)
Exhaust	STD	37.000 - 37.016 (1.4567 - 1.4573)
	0.5 (0.020) oversize	37.500 - 37.516 (1.4764 - 1.4770)

## Finished size of service valve insert cutter

Unit: mm (in)



D <sub>1</sub>	45.5 (1.791)
D <sub>2</sub>	43.8 (1.724)
D <sub>3</sub>	41.6 (1.638)



D	34.6 (1.362)
C	1.9 (0.075)

## Interference fit


Unit: mm (in)

Intake	0.081 - 0.113 (0.0032 - 0.0044)
Exhaust	0.064 - 0.096 (0.0025 - 0.0038)

# CAMSHAFT AND CAMSHAFT BEARING

Unit: mm (in)


	Standard	Max. tolerance
Camshaft journal to bearing clearance	0.038 - 0.067 (0.0015 - 0.0026)	0.1 (0.004)
Inner diameter of camshaft bearing	48.000 - 48.016 (1.8898 - 1.8904)	—
Outer diameter of camshaft journal	47.949 - 47.962 (1.8878 - 1.8883)	—
Camshaft bend (Total indicator reading)	Less than 0.02 (0.0008)	0.05 (0.0020)
Camshaft end play	0.08 - 0.38 (0.0031 - 0.0150)	



EM671

Cam height "A"	Intake	40.30 - 40.35 (1.5866 - 1.5886)
	Exhaust	
Wear limit of cam height		0.15 (0.0059)

## Valve timing




EM120

Unit: degree

a	b	c	d	e	f
248	248	16	52	14	54

# CYLINDER BLOCK

Unit: mm (in)



EM125


		Standard	Wear limit
Surface flatness		Less than 0.05 (0.0020)	0.10 (0.0039)
Cylinder bore	Inner diameter	86.000 - 86.050 (3.3858 - 3.3878)	0.2 (0.008)
	Out-of-round (X-Y)	Less than 0.02 (0.0008)	—
	Taper (A-B)	Less than 0.02 (0.0008)	—
Difference in inner diameter between cylinders		Less than 0.05 (0.0020)	0.2 (0.008)
Piston to cylinder clearance		0.025 - 0.045 (0.0010 - 0.0018)	—
		Outer diameter	Remarks
Cylinder liner for service	4.0 (0.157) Undersize	90.00 - 90.05 (3.5433 - 3.5453)	Interference fit cylinder liner to cylinder block 0.075 - 0.085 (0.0030 - 0.0033)
	4.5 (0.177) Undersize	90.50 - 90.55 (3.5630 - 3.5650)	
	5.0 (0.197) Undersize	91.00 - 91.05 (3.5827 - 3.5846)	



## PISTON, PISTON RING AND PISTON PIN

### Piston

Unit: mm (in)



EM714

Piston skirt diameter "A"	STD	85.985 - 86.035 (3.3852 - 3.3872)
	0.5 (0.0197) oversize	86.465 - 86.515 (3.4041 - 3.4061)
	1.0 (0.0394) oversize	86.965 - 87.015 (3.4238 - 3.4258)
"a" dimension		About 20 (0.79)

### Piston ring

Unit: mm (in)

		Standard	Limit
Side clearance	Top	0.040 - 0.073 (0.0016 - 0.0029)	0.1 (0.004)
	2nd	0.030 - 0.063 (0.0012 - 0.0025)	
	Oil	Combined	
Ring gap	Top	0.25 - 0.40 (0.0098 - 0.0157)	1.0 (0.039)
	2nd	0.30 - 0.50 (0.0118 - 0.0197)	
	Oil (rail ring)	0.3 - 0.9 (0.012 - 0.035)	

### Piston pin

Unit: mm (in)

Piston pin outer diameter	20.993 - 20.998 (0.8265 - 0.8267)
Piston pin hole diameter	21.001 - 21.008 (0.8268 - 0.8271)
Piston pin to piston clearance	0.006 - 0.013 (0.0002 - 0.0005)
Interference fit of piston pin to connecting rod	0.015 - 0.033 (0.0006 - 0.0013)


## CONNECTING ROD

Unit: mm (in)

	Standard	Limit
Connecting rod bend or torsion [per 100 mm (3.94 in) length]	Less than 0.025 (0.0010)	0.05 (0.0020)
Big end play	0.2 - 0.3 (0.008 - 0.012)	0.6 (0.024)

## CRANKSHAFT


Unit: mm (in)



EM737

Journal diameter "A"	54.942 - 54.955 (2.1631 - 2.1636)
Pin diameter "B"	49.961 - 49.974 (1.9670 - 1.9675)
"S"	39.5 (1.555)
Pilot bushing inserting distance	4.0 (0.157)

Out-of-round  
Taper



EM715

	Standard	Limit
Taper of journal and pin "A-B"	Less than 0.01 (0.0004)	0.03 (0.0012)
Out-of-round of journal and pin "X-Y"	Less than 0.01 (0.0004)	0.03 (0.0012)
Crankshaft bend	Less than 0.05 (0.0020)	0.10 (0.0039)
Crankshaft free end play	0.05 - 0.18 (0.0020 - 0.0071)	0.30 (0.0118)

## BEARING

### Bearing clearance

Unit: mm (in)

	Standard	Limit
Main bearing clearance	0.020 - 0.066 (0.0008 - 0.0026)	0.12 (0.0047)
Connecting rod bearing clearance	0.024 - 0.066 (0.0009 - 0.0026)	0.12 (0.0047)

### Main bearing undersize

Unit: mm (in)

	Crank journal diameter
STD	54.942 - 54.955 (2.1631 - 2.1636)
0.25 (0.0098) Undersize	54.692 - 54.705 (2.1532 - 2.1537)
0.50 (0.0197) Undersize	54.442 - 54.455 (2.1434 - 2.1439)
0.75 (0.0295) Undersize	54.192 - 54.205 (2.1335 - 2.1341)
1.00 (0.0394) Undersize	53.942 - 53.955 (2.1237 - 2.1242)

### Connecting rod bearing undersize

Unit: mm (in)

	Crank journal diameter
STD	49.961 - 49.974 (1.9670 - 1.9675)
0.06 (0.0024) Undersize	49.901 - 49.914 (1.9646 - 1.9651)
0.12 (0.0047) Undersize	49.841 - 49.854 (1.9622 - 1.9628)
0.25 (0.0098) Undersize	49.711 - 49.724 (1.9571 - 1.9576)
0.50 (0.0197) Undersize	49.461 - 49.474 (1.9473 - 1.9478)
0.75 (0.0295) Undersize	49.211 - 49.224 (1.9374 - 1.9379)
1.00 (0.0394) Undersize	48.961 - 48.974 (1.9276 - 1.9281)

## MISCELLANEOUS COMPONENTS

Unit: mm (in)

Camshaft sprocket	
Runout (Total indicator reading)	Less than 0.1 (0.004)
Flywheel	
Runout (Total indicator reading)	Less than 0.15 (0.0059)

## TIGHTENING TORQUE

Unit	N·m	kg·m	ft·lb
Main bearing cap bolt	44 - 54	4.5 - 5.5	33 - 40
Connecting rod big end nut	44 - 54	4.5 - 5.5	33 - 40

Unit	N·m	kg·m	ft·lb
Flywheel bolt (M/T)	127 - 147	13.0 - 15.0	94 - 108
Drive plate bolt (A/T)	127 - 147	13.0 - 15.0	94 - 108
Front cover bolt	M8	10 - 16	7 - 12
	M6	3.9 - 9.8	0.4 - 1.0
Cylinder head	69 - 83	7.0 - 8.5	51 - 61
Cylinder head to front cover bolt	7.8 - 13.7	0.8 - 1.4	5.8 - 10.1
Camshaft locating plate bolt	5.9 - 9.8	0.6 - 1.0	4.3 - 7.2
Pivot bushing bolt	78 - 118	8.0 - 12.0	58 - 87
Pivot lock nut	49 - 59	5.0 - 6.0	36 - 43
Camshaft sprocket bolt	127 - 147	13.0 - 15.0	94 - 108
Chain guide bolt	5.9 - 9.8	0.6 - 1.0	4.3 - 7.2
Chain tensioner bolt	5.9 - 9.8	0.6 - 1.0	4.3 - 7.2
Oil pump bolt	11 - 15	1.1 - 1.5	8 - 11
Water pump bolt	M6	3.9 - 9.8	0.4 - 1.0
	M8	10 - 16	7 - 12
Water pump pulley stud	5.9 - 9.8	0.6 - 1.0	4.3 - 7.2
Water inlet bolt	10 - 16	1.0 - 1.6	7 - 12
Crank pulley bolt	137 - 157	14.0 - 16.0	101 - 116
Oil strainer bolt	10 - 16	1.0 - 1.6	7 - 12
Oil pan bolt	5.9 - 9.8	0.6 - 1.0	4.3 - 7.2
Oil pan drain plug	20 - 29	2.0 - 3.0	14 - 22
Clutch cover bolt	20 - 29	2.0 - 3.0	14 - 22
Rocker cover bolt	10 - 16	1.0 - 1.6	7 - 12
Spark plug	15 - 20	1.5 - 2.0	11 - 14
Manifold Bolt and Nut	M8 Bolt	15 - 25	1.5 - 2.5
	M10 Bolt	34 - 44	3.5 - 4.5
	M8 Nut	12 - 16	1.2 - 1.6
Water outlet bolt	10 - 16	1.0 - 1.6	7 - 12
Thermostat housing	12 - 20	1.2 - 2.0	9 - 14
Distributor support bolt	3.9 - 7.8	0.4 - 0.8	2.9 - 5.8
Oil pressure sending unit	10 - 16	1.0 - 1.6	7 - 12
Alternator bracket	39 - 59	4.0 - 6.0	29 - 43
Alternator to adjusting bar bolt	20 - 29	2.0 - 3.0	14 - 22
Engine mounting bracket	29 - 39	3.0 - 4.0	22 - 29



## TROUBLE DIAGNOSES AND CORRECTIONS










Condition	Probable cause	Corrective action
<b>I. Noisy engine</b> Piston and connecting rod knocking.	Seized piston pin. Seized piston in cylinder.  Broken piston ring. Improper connecting rod alignment. Seized on loose connecting rod bearing.	Replace piston with pin. Recondition cylinder and replace piston with pin.  Replace ring and/or recondition cylinder. Realign rod or replace rod. Replace.
Knocking of crankshaft and bearing.	Sized or loose main bearing. Bent crankshaft. Uneven wear of journal. Excessive crankshaft end play.	Replace. Repair or replace. Correct. Replace center bearing.
Timing chain noise.	Improper chain tension. Worn and/or damaged chain. Worn sprocket. Worn and/or broken chain guide and/or tension adjusting mechanism.	Adjust. Replace. Replace. Replace.
Camshaft and valve mechanism knocking.	Improper valve clearance. Worn rocker pivot. Worn rocker face. Loose valve stem in guide. Weakened valve spring. Seized valve.	Adjust. Replace. Replace. Replace guide. Replace. Replace.
Camshaft knocking.	Excessive camshaft clearance. Excessive axial play. Worn cam gear.	Replace. Replace thrust plate. Replace.
Water pump knocking.	Improper shaft end play. Broken impeller.	Replace water pump assembly. Replace water pump assembly.
<b>II. Other mechanical troubles</b> Stuck valve.	Improper valve clearance. Insufficient clearance between valve stem and guide. Weakened or broken valve spring. Seized or damage of valve stem. Poor quality fuel.	Adjust. Clean stem or ream guide.  Replace. Replace or clean. Use good fuel.

# Engine Mechanical

Condition	Probable cause	Corrective action
Seized valve seat.	Improper valve clearance. Weakened valve spring. Thin valve head edge. Narrow valve seat. Overheating. Over speeding. Stuck valve guide.	Adjust. Replace. Replace valve. Reface. Repair or replace. Drive at proper speed. Repair.
Excessively worn cylinder and piston.	Shortage of engine oil. Dirty engine oil. Poor quality of oil. Overheating Wrong assembly of piston with connecting rod. Improper piston ring clearance. Broken piston ring. Dirty air cleaner. Mixture too rich. Engine over run.	Add or replace oil. Clean crankcase, replace oil and oil filter element. Use proper oil. Repair or replace. Repair or replace. Adjust. Replace. Clean. Adjust. Drive at proper speeds.
Faulty connecting rod.	Shortage of engine oil. Low oil pressure. Poor quality engine oil. Rough surface of crankshaft. Clogged oil passage. Bearing worn or eccentric. Bearing improperly assembled. Loose bearing. Incorrect connecting rod alignment.	Add oil. Correct. Use proper oil. Grind and replace bearing. Clean. Replace. Correct. Replace. Repair or replace.
Faulty crankshaft bearing.	Shortage of engine oil. Low oil pressure. Poor quality engine oil. Crankshaft journal worn or out-of-round. Clogged oil passage in crankshaft. Bearing worn or eccentric. Bearing improperly assembled. Eccentric crankshaft or bearing.	Add or replace. Correct. Use specified oil. Repair. Clean. Replace. Correct. Replace.



## SPECIAL SERVICE TOOLS

Tool number & tool name	Kent-Moore No.	Tool number & tool name	Kent-Moore No.
	Reference page		Reference page
ST19320000 Oil filter wrench 	J25664 Page EM-3	ST10120000 Cylinder head bolt wrench 	J25613 Page EM-4 Page EM-16
ST05340001 Engine attachment 	J26032 Page EM-3	KV101041S0 Crankshaft main bearing cap puller ① KV10104110 Crankshaft main bearing puller ② ST16512001 Adapter ③ ST16701001 Adapter 	J25647 Page EM-4
ST0501S000 Engine stand assembly ① ST05011000 Engine stand ② ST05012000 Base 	J26023 ① J26023-2 ② J26023-1 Page EM-3		
ST16540000 Puller crank pulley 	Page EM-3	ST13030001 Piston pin press stand 	J25634 Page EM-5 Page EM-14
KV10105800 (ST17420001) Chain stopper 	J25660-1 Page EM-4	ST12070000 Valve lifter 	J25631 Page EM-5 Page EM-13

# Engine Mechanical

Tool number & tool name	Kent-Moore No.	Tool number & tool name	Kent-Moore No.
	Reference page		Reference page
<b>KV101039S0</b> Valve guide reamer set <b>① ST11081000</b> Reamer [12.2 mm (0.480 in) dia.] <b>② ST11032000</b> Reamer [8.0 mm (0.31 in) dia.] <b>③ ST11033000</b> Drift	J25618	<b>KV10105500</b> Crankshaft rear oil seal drift <b>(ST15310000)</b>	J25640-1
	① J25618-3 ② J24618-2 ③ J25618-1		Page EM-15
	Page EM-7	<b>EM03470000</b> Piston ring compressor	—
			Page EM-15
<b>ST11650001</b> Valve seat cutter set	—	<b>ST10640001</b> Pivot adjuster	J25615-1
	Page EM-7		Page EM-17
<b>ST16610001</b> Pilot bushing puller	J23907	<b>KV30100100</b> Clutch aligning bar	—
	Page EM-11		Page EM-3 Page EM-17