

ENGINE COMPONENTS (Outer parts)

ENGINE MECHANICAL

SECTION EM



CONTENTS

ENGINE COMPONENTS (Outer parts) . . .	EM- 2	CYLINDER BLOCK, CRANKSHAFT AND PISTON	EM- 9
CYLINDER HEAD	EM- 4	Piston and connecting rod	EM-10
Cylinder head disassembly	EM- 4	Crankshaft	EM-11
Valve guide	EM- 5	Jack shaft and jack shaft bushing	EM-12
Valve seat inserts	EM- 6	Cylinder block	EM-12
Camshaft and camshaft bearing	EM- 6	Front cover	EM-13
Valve	EM- 6	Flywheel	EM-13
Valve spring	EM- 6	Oil seal	EM-13
Valve lifter	EM- 6	Distributor	EM-13
Cylinder head assembly	EM- 6		
CAMSHAFT AND JACK SHAFT DRIVE	EM- 8	SERVICE DATA AND SPECIFICATIONS	EM-14
Valve timing	EM- 8	General specifications	EM-14
Chain tensioner	EM- 8	Inspection and adjustment	EM-14
		Tightening torque	EM-18
		SPECIAL SERVICE TOOLS	EM-19

