


# DATSUN PICK-UP SERVICE MANUAL

# 1977



# DATSUN PICK-UP

## SERVICE MANUAL

MODEL  
620 SERIES



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

### QUICK REFERENCE INDEX

GENERAL INFORMATION .. ..	GI
ENGINE TUNE-UP .. .	ET
ENGINE MECHANICAL .. .	EM
ENGINE LUBRICATION SYSTEM .. .	EL
COOLING SYSTEM .. .	CO
ENGINE FUEL .. .	EF
EMISSION CONTROL SYSTEM .. .	EC
ENGINE ELECTRICAL SYSTEM .. .	EE
ENGINE REMOVAL & INSTALLATION .. .	ER
CLUTCH .. .	CL
MANUAL TRANSMISSION .. .	MT
AUTOMATIC TRANSMISSION .. .	AT
PROPELLER SHAFT & DIFFERENTIAL CARRIER .. .	PD
FRONT AXLE & FRONT SUSPENSION .. .	FA
REAR AXLE & REAR SUSPENSION .. .	RA
BRAKE SYSTEM .. .	BR
WHEEL AND TIRE .. .	WT
STEERING SYSTEM .. .	ST
ENGINE CONTROL, FUEL & EXHAUST SYSTEMS .. .	FE
BODY & FRAME .. .	BF
BODY ELECTRICAL SYSTEM .. .	BE
AIR CONDITIONING .. .	AC
SERVICE EQUIPMENT .. .	SE



# FOREWORD

This service manual has been prepared for the purpose of assisting service personnel of authorized NISSAN/DATSUN dealers in providing effective service and maintenance of the 1977 Datsun Pick-up.

Since proper maintenance and service are absolutely essential in satisfying the Datsun owners, this manual should be kept in a handy place for ready reference and should be carefully studied.

This manual includes procedures for maintenance adjustments, minor service operations, removal and installation, and for disassembly and assembly of components.

Some of these service operations require the use of Special Tools especially designed for effective performance of service operations.

The special tools are presented in the "SE" section.

As you read through the maintenance procedures in this service manual, you will occasionally come across paragraphs headed NOTE or CAUTION. A NOTE is supplemental information that is important to a particular procedure. CAUTION warns of steps that must be followed to prevent personal injury and/or damage to some part of your DATSUN.

The Quick Reference Index on the first page enables the user to quickly locate the desired section. At the beginning of each individual section is a table of contents, which gives the page number on which each major subject begins. An index is placed at the beginning of each major subject within the section.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication approval. If your DATSUN model differs from the specifications contained in this manual, consult your NISSAN/DATSUN dealer for information.

Rights for alteration at any time of specifications and methods are reserved.

Liability for any personal injury or property damage occasioned by the use of this service manual in effecting maintenance or repair of your Datsun is in no way assumed by Nissan Motor Co., Ltd.

Accordingly, anyone using a service procedure or tool which is not specifically recommended by Nissan must first completely satisfy himself that neither his safety nor the vehicle's safety will be jeopardized by the service method selected.

**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

## SECTION GI


GI

## GENERAL INFORMATION

GENERAL INFORMATION ..... GI- 3

## General Information

---



*Fig. GI-1 Standard wheelbase model*



*Fig. GI-2 Deluxe Cab*

# GENERAL INFORMATION

## CONTENTS

MODEL VARIATION .....	GI-3	APPROXIMATE REFILL CAPACITIES .....	GI-8
IDENTIFICATION NUMBERS .....	GI-5	RECOMMENDED FUEL .....	GI-8
LIFTING POINTS AND TOWING .....	GI-6	RECOMMENDED LUBRICANTS .....	GI-8
LIFTING POINTS .....	GI-6	RECOMMENDED SAE VISCOSITY	
SUPPORTABLE POINTS .....	GI-7	NUMBER .....	GI-8
TOWING .....	GI-7	LUBRICANT SPECIFICATIONS .....	GI-9
TIE DOWN .....	GI-7		


## MODEL VARIATION

Destination		Class	Model		Engine	Transmission	Differential carrier model and gear ratio	Pay load kg (lb)
U.S.A.	California and high altitude locations outside California	Standard wheelbase	California models	HL620TUV	L20B	F4W71B	H190 4.375	500 (1.100)
				HL620FTUV		FS5W71B		
				HL620KTUV		3N71B		
		Long wheelbase		HLG620TUV		F4W71B		
				HLG620FTUV		FS5W71B		
				HLG620KTUV		3N71B		
		Deluxe Cab		KHL620TUV		F4W71B		
				KHL620FTUV		FS5W71B		
				KHL620KTUV		3N71B		
	All low altitude locations outside California	Standard wheelbase	Non California models	HL620TU		F4W71B		
				HL620FTU		FS5W71B		
				HL620KTU		3N71B		
		Long wheelbase		HLG620TU		F4W71B		
				HLG620FTU		FS5W71B		
				HLG620KTU		3N71B		
		Deluxe Cab		KHL620TU		F4W71B		
				KHL620FTU		FS5W71B		
				KHL620KTU		3N71B		

## General Information

Destination	Class	Model		Engine	Transmission	Differential carrier model and gear ratio	Pay load kg (lb)
Canada	Standard wheelbase	Non-California models	HL620TUN	L20B	F4W71B	H190 4.375	500 (1.100)
			HL620KTUN		3N71B		
	HLG620TUN		F4W71B				
	HLG620KTUN		3N71B				
	Deluxe Cab		KHL620TUN		F4W71B		
			KHL620FTUN		FS5W71B		
			KHL620KTUN		3N71B		

### Model identification



Note: ☐ means no identification.


## IDENTIFICATION NUMBERS

The unit and vehicle numbers are stamped and registered at the factory.

The engine and vehicle identification numbers are used on legal documents. These numbers are used for factory communications such as Technical Reports, Warranty Claims, Service Journals and other information.

### Vehicle Identification plate

The vehicle identification plate is located at the hood ledge in the engine compartment.




SP029

Fig. GI-3 Vehicle identification plate location

### Vehicle serial number

The vehicle serial number is stamped on the upper face of the right side member. The number is identified by the following figures as a serial number.

HL620-XXXXXX  
 \_\_\_\_\_ Serial number  
 \_\_\_\_\_ Vehicle model




GI268

Fig. GI-4 Vehicle serial number location

### Engine serial number

The engine serial number is stamped on the right-hand side of the cylinder block.

L20B-XXXXXX  
 \_\_\_\_\_ Serial number  
 \_\_\_\_\_ Engine model




SP027

Fig. GI-5 Engine serial number location

### Color code number

The color code number label is stuck on the radiator support.




GI326

Fig. GI-6 Color code number label location

### M.V.S.S. certification label

The M.V.S.S. certification label is located at the driver side lock pillar.




SP031

Fig. GI-7 M.V.S.S. certification label location

### Vehicle emission control information label

The vehicle emission control information label is stuck on the inside of the hood panel.



SP076


Fig. GI-8 Vehicle emission control information label location

### Manual transmission number

The transmission serial number is stamped on the front upper face of transmission case.

(Number system)

XX XXXXX  
 \_\_\_\_\_ Serial number (monthly)  
 \_\_\_\_\_ Month of manufacture (1, 2, ... 9, X, Y, Z)  
 \_\_\_\_\_ Line code of manufacture





TM235

Fig. GI-9 Manual transmission number location

## Automatic transmission number

The transmission serial number is attached to the right-hand side of transmission case.

(Numbering system)



AT344

Fig. GI-10 Automatic transmission number location

## LIFTING POINTS AND TOWING

### LIFTING POINTS

#### Screw jack


Before using the jack, proceed as follows:

Apply parking brake firmly and block rear wheels if the front of the vehicle is to be raised.

#### Notes:

- Never get under the vehicle while it is supported only by the jack. Always use safety stands to support frame or rear axle case when you have to get beneath the vehicle.
- In no event should the jack be applied to any points except the following specified portions.


When jacking up the front side, place a screw jack under side frame [about 520 mm (20.5 in) at rear of front axle center].



WT012

Fig. GI-11 Front lifting point

When jacking up the rear side, place a screw jack under rear axle case close to the side of rear spring.




WH077

Fig. GI-12 Rear lifting point

#### Notes:

- When the yellow mark appears on the screw jack, it indicates the maximum permissible height. Do not jack up further.
- When the jack is at lower limit, do not add large force downward.



WH080


Fig. GI-13 Warning against over-stroke

### Garage jack

Note: When carrying out operations with a garage jack, be sure to support the vehicle with stands in a safe manner.


When jacking up the front end, apply garage jack to front cross-member or center portion of suspension member.

When jacking up the rear end, apply the jack to rear axle case.



G1075

Fig. GI-14 Front lifting point



G1076

Fig. GI-15 Rear lifting point

## SUPPORTABLE POINTS

The front supportable points are under frame side member.

The rear supportable points are under rear axle case.




Fig. GI-16 Front supportable points




Fig. GI-17 Rear supportable points

## TOWING

When the vehicle is to be towed forward, connect a rope securely to the hook under the 1st crossmember. Before towing, make sure the parking brake is released.

To tow another car, connect the rope to rear leaf spring shackle.

### Notes:

- A towing rope should not be connected to any position other than as described above.
- Avoid applying load suddenly to a towing rope, as it may cause damage.




Fig. GI-18 Front towing point




Fig. GI-19 Rear towing point

## Manual transmission

Before towing, make sure the transmission is in neutral gear.

If the rear axle or transmission is inoperative, the vehicle should be towed with its rear wheels off the ground, or the propeller shaft must be removed.

## Automatic transmission

When the vehicle is towed on its rear wheels, make sure the transmission is in "N" (Neutral) position. Don't exceed 30 km/h (20 MPH) and a distance of 10 km (6 miles). If the rear axle or transmission is inoperative, or if the speed exceeds the above conditions, the vehicle must be towed with its rear wheels off the ground, or the propeller shaft must be removed.

Note: When the vehicle is towed with its front wheels on the ground, the steering wheel should be secured to maintain a straight ahead position.

## TIE-DOWN

The front two tie-down hooks are located under the 1st crossmember.

The hook is available as a towing hook. For rear tie-down, the rear leaf spring shackle be used. This point is also used as a towing point.



## General Information

### APPROXIMATE REFILL CAPACITIES

		Liter	U.S. measure	Imper. measure
Fuel tank		45 ℓ	11 ¾ gal.	9 ¾ gal.
Cooling system (with heater)	Manual transmission	8.0 ℓ	8 ½ qt.	7 qt.
	Automatic transmission	7.8 ℓ	8 ½ qt.	6 ¾ qt.
Engine lubrication system	with oil filter	4.3 ℓ	4 ½ qt.	3 ¾ qt.
	without oil filter	3.8 ℓ	4 qt.	3 ¾ qt.
Manual transmission	4-speed transmission	1.7 ℓ	3 ¾ pt.	3 pt.
	5-speed transmission	2.0 ℓ	4 ½ pt.	3 ¾ pt.
Automatic transmission		5.5 ℓ	5 ¾ qt.	4 ¾ qt.
Steering gear box		0.33 ℓ	¾ pt.	¾ pt.
Differential carrier		1.0 ℓ	2 ½ pt.	1 ¾ pt.


### RECOMMENDED FUEL

Use an unleaded or low-lead gasoline with a minimum octane rating of 91 RON (Research Octane Number). For California models, use

only unleaded gasoline to protect the catalytic converter from contamination.

### RECOMMENDED LUBRICANTS

#### RECOMMENDED SAE VISCOSITY NUMBER



**LUBRICANT SPECIFICATIONS**

Item		Specifications	Remarks
Gasoline engine oil		SAE Classification SD or SE	Furthermore refer to SAE recommended viscosity table. See Page GI-8.
Gear oil	Transmission and steering	API GL-4	
	Differential	API GL-5	
Automatic T/M fluid		Type DEXRON	
Multipurpose grease		NLGI 2	Lithium soap base
Brake and clutch fluid		DOT 3	
Antifreeze		—	Permanent anti-freeze (Ethylene glycol base)

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

## SECTION ET

ET

## ENGINE TUNE-UP


ENGINE TUNE-UP.....	ET- 2
BASIC MECHANICAL SYSTEM.....	ET- 7
IGNITION AND FUEL SYSTEM .....	ET- 9
EMISSION CONTROL SYSTEM .....	ET-13
SERVICE DATA AND SPECIFICATIONS .....	ET-25
TROUBLE DIAGNOSES AND CORRECTIONS .....	ET-27

## ENGINE TUNE-UP

### CONTENTS

LOCATION OF EMISSION CONTROL SYSTEM COMPONENTS (Non-California models) .....	ET-2	EMISSION CONTROL SYSTEM PIPING (Non-California models) .....	ET-4
LOCATION OF EMISSION CONTROL SYSTEM COMPONENTS (California models) .....	ET-3	EMISSION CONTROL SYSTEM PIPING (California models) .....	ET-5
		EMISSION CONTROL DEVICES .....	ET-6


### LOCATION OF EMISSION CONTROL SYSTEM COMPONENTS (Non-California models)



ET365

Fig. ET-1 Location of emission control system components  
(Non-California models)


## LOCATION OF EMISSION CONTROL SYSTEM COMPONENTS (California models)



ET366

Fig. ET-2 Location of emission control system components  
(California models)

## EMISSION CONTROL SYSTEM PIPING (Non-California models)




- 1 Vacuum tube to distributor (yellow)
- 2 Vacuum tube to carbon canister (yellow)
- 3 Vacuum tube to thermal vacuum valve (white)
- 4 Vacuum tube
- 5 Vacuum tube to carburetor (yellow)
- 6 Thermal vacuum valve to E.G.R. control valve (white)
- 7 Vacuum tube to carburetor (white)
- 8 A.B. valve to vacuum connector (green)
- 9 Vacuum tube to carbon canister (yellow)
- 10 S.D.V. to distributor (yellow)
- 11 Vacuum tube to S.D.V. (yellow)

ET367

Fig. ET-3 Emission control system piping (Non-California models)

## EMISSION CONTROL SYSTEM PIPING (California models)



ET368

Fig. ET-4 Emission control system piping (California models)

# EMISSION CONTROL DEVICES

Engine model		A14										L20R	
		B210				F10		620					
Car model		California models		Non-California models (except for Canada)		Canada		California models		Non-California models			
Part name		M/T	A/T	M/T	A/T	M/T	A/T	M/T	A/T	M/T	A/T		
AIR CLEANER	A.T.C. air cleaner (with air pump relief valve)	-	-	X	X	-	-	X	X	-	-	X	X
	A.T.C. air cleaner (without air pump relief valve, with altitude compensator valve)	X	X	-	-	-	-	-	-	-	-	-	-
	A.T.C. air cleaner (with air pump relief valve, with altitude compensator valve)	-	-	-	-	-	-	-	-	-	-	-	-
	Idle compensator (dual type)	X	X	X	X	X	X	X	X	X	X	X	X
	Fresh air duct (for introducing outside air)	X	X	X	X	X	X	X	X	X	X	**X	**X
ENGINE PROPER	Early fuel evaporative system (exhaust heating)	X	X	X	X	X	X	X	X	X	X	X	X
	P.T.C. auto choke	X	X	X	X	X	X	X	X	X	X	X	X
CARBURETOR	B.C.D.D. (with control valve)	-	-	-	-	-	-	-	-	-	-	-	-
	B.C.D.D. (without control valve, control valve attached to body)	-	-	-	-	-	-	-	-	-	-	-	-
	Throttle opener (with control valve)	X	X	X	X	X	X	X	X	X	X	X	X
	Dash pot	X	X	X	X	X	X	X	X	X	X	X	X
	*Altitude compensator (with pipe for use in air bleed)	X	X	-	-	-	-	-	-	-	-	-	-
IGNITION SYSTEM	Ignition transistor unit, Distributor (1 pick-up)	X	X	-	-	-	-	-	-	-	-	-	-
	T.C.S. (Switching valve for decompression except Top)	X	X	-	-	-	-	-	-	-	-	-	-
	S.D.V. (Spark delay valve)	-	-	-	-	-	-	-	-	-	-	-	-
	T.V.V. (Thermal vacuum valve-T.C.S.)	X	X	X	X	X	X	X	X	X	X	X	X
	Air pump, A/P air cleaner, Check valve, A.B. valve	X	X	X	X	X	X	X	X	X	X	X	X
A.I.S.	*C.A.C. valve (Air control valve + E.A.R. valve + Relief valve)	X	X	-	-	-	-	-	-	-	-	-	-
	Air control valve	-	-	-	-	-	-	-	-	-	-	-	-
	E.A.R. valve	-	-	-	-	-	-	-	-	-	-	-	-
	Relief valve	-	-	-	-	-	-	-	-	-	-	-	-
	*E.G.R. valve (B.P.T. system)	X	X	X	X	X	X	X	X	X	X	X	X
E.G.R. SYSTEM	E.G.R. valve (VC system)	-	-	-	-	-	-	-	-	-	-	-	-
	T.V.V. (Thermal vacuum valve-E.G.R.)	X	X	X	X	X	X	X	X	X	X	X	X
	T.C.E. (Top cut E.G.R.)	-	-	-	-	-	-	-	-	-	-	-	-
	Warning device (every 12,500 mile maintenance)	-	-	-	-	-	-	-	-	-	-	-	-
	Catalytic converter	X	X	-	-	-	-	-	-	-	-	-	-
CATALYZER	Fluor temperature warning system (with floor sensor)	X	X	-	-	-	-	-	-	-	-	-	-
		X	X	-	-	-	-	-	-	-	-	-	-

\*: Newly equipped unit on 1977 models  
 \*\*: Except for Canada  
 Remarks: X ... Available  
 - ... Not available  
 M/T: Manual transmission  
 A/T: Automatic transmission  
 A.T.C.: Automatic temperature control  
 P.T.C.: Positive temperature coefficient  
 T.V.V.: Thermal vacuum valve  
 C.A.C.: Combined air control  
 B.C.D.D.: Boost controlled deceleration device  
 T.C.S.: Transmission controlled vacuum advance system  
 S.D.V.: Spark delay valve  
 T.C.E.: Transmission controlled exhaust gas recirculation system  
 B.P.T.: Back pressure transducer  
 V.C.: Vacuum  
 A.I.S.: Air injection system  
 A.B. valve: Anti-back fire valve  
 E.A.R. valve: Emergency air relief valve  
 E.G.R.: Exhaust gas recirculation  
 V.D.V.: Vacuum delay valve  
 T.C.E.: Top cut E.G.R.



# BASIC MECHANICAL SYSTEM

## CONTENTS

ADJUSTING INTAKE AND EXHAUST VALVE CLEARANCE .....	ET-7	PERMANENT ANTI-FREEZE COOLANT .....	ET-8
CHECKING AND ADJUSTING DRIVE BELT .....	ET-7	CHECKING COOLING SYSTEM HOSES AND CONNECTIONS .....	ET-8
RETIGHTENING CYLINDER HEAD BOLTS, MANIFOLD NUTS AND CARBURETOR SECURING NUTS .....	ET-7	INSPECTION OF RADIATOR CAP .....	ET-8
CHECKING ENGINE OIL .....	ET-8	COOLING SYSTEM PRESSURE TEST .....	ET-8
REPLACING OIL FILTER .....	ET-8	CHECKING VACUUM FITTINGS, HOSES, AND CONNECTIONS .....	ET-8
CHANGING ENGINE COOLANT .....	ET-8	CHECKING ENGINE COMPRESSION .....	ET-9
		COMPRESSION PRESSURE TEST .....	ET-9
		TEST RESULT .....	ET-9

## ADJUSTING INTAKE AND EXHAUST VALVE CLEARANCE

**Note:** After tightening cylinder head bolts, adjust intake and exhaust valve clearances.

Valve clearance adjustment is impossible when the engine is in operation:

1. Loosen pivot locking nut and turn pivot screw until the specified clearance is obtained while cold.

Using service tool, tighten pivot locking nut securely after adjustment, and recheck the clearance.

2. Warm up engine for at least several minutes and stop it. Measure valve clearance while hot. If out of specifications, adjust.

Unit: mm (in)

Cold	Intake	0.20 (0.008)
	Exhaust	0.25 (0.010)
Warm	Intake	0.25 (0.010)
	Exhaust	0.30 (0.012)





Fig. ET-5 Adjusting valve clearance

## CHECKING AND ADJUSTING DRIVE BELT

1. Check for cracks or damage. Replace if necessary.

2. Normal drive belt deflection is 8 to 12 mm (0.315 to 0.472 in), when moderate thumb pressure is applied midway between pulleys.



AC456

Fig. ET-6 Drive belt tension

## RETIGHTENING CYLINDER HEAD BOLTS, MANIFOLD NUTS AND CARBURETOR SECURING NUTS

Refer to the following tightening torque specifications.

**Tightening torque:**  
 Cylinder head bolts  
 1st turn  
 4.0 kg-m (29 ft-lb)  
 2nd turn  
 6.0 kg-m (43 ft-lb)  
 3rd turn  
 6.5 to 8.5 kg-m  
 (47 to 61 ft-lb)

## Engine Tune-up

- Manifold nuts  
1.2 to 1.6 kg-m  
(8.7 to 11.6 ft-lb)
- Carburetor nuts  
0.5 to 1.0 kg-m  
(3.6 to 7.2 ft-lb)




Fig. ET-7 Tightening sequence

## CHECKING ENGINE OIL

1. Check if oil is diluted with water or gasoline. Drain and refill oil if necessary.

### Notes:

- a. A milky oil indicates the presence of cooling water. Isolate the cause and take corrective measure.
- b. An oil with extremely low viscosity indicates dilution with gasoline.

2. Check oil level. If below the specified level, raise it up to the H level.

Engine oil capacity  
(including oil filter)

Maximum (H level)  
4.3 liters  
(4 1/2 US qt, 3 1/2 Imp qt)

Minimum (L level)  
3.3 liters  
(3 1/2 US qt, 2 1/2 Imp qt)

## REPLACING OIL FILTER

The oil filter is a cartridge type and can be removed using Oil Filter Wrench ST19320000.

1. Check for oil leaks past gasketed flange. If leakage is found, retighten just enough to stop leakage. If retightening is no longer effective, replace filter as an assembly.

2. When installing oil filter, tighten by hand.

Note: Do not overtighten oil filter, lest leakage should occur.

## CHANGING ENGINE COOLANT

### PERMANENT ANTI-FREEZE COOLANT

Permanent anti-freeze coolant is an ethylene glycol base product containing chemical inhibitors to protect the cooling system against corrosion.

The anti-freeze does not contain any glycerine, ethyl or methyl alcohol. It will not evaporate or boil away and can be used with either high or low temperature thermostat.

It flows freely, transfers heat efficiently, and will not clog passages in the cooling system.

The anti-freeze must not be mixed with other products.

This coolant can be used throughout the seasons of the year.

Whenever coolant is changed, the cooling system should be flushed and refilled with a new coolant.


Check the level. See the instructions furnished by the manufacturer for the mixture ratio of anti-freeze to water.

## CHECKING COOLING SYSTEM HOSES AND CONNECTIONS

Check hoses and fittings for loose connections or deterioration. Retighten or replace if necessary.

### INSPECTION OF RADIATOR CAP

Apply reference pressure [0.9 kg/cm<sup>2</sup> (13 psi)] to radiator cap by means of a cap tester to see if it is satisfactory. Replace cap assembly if necessary.



ET012

Fig. ET-8 Testing radiator cap

### COOLING SYSTEM PRESSURE TEST

With radiator cap removed, apply reference pressure [1.6 kg/cm<sup>2</sup> (23 psi)] to the cooling system by means of a tester to detect any leakage.

### Water capacity

Without heater:


7.4 liters

(7 1/2 US qt, 6 1/2 Imp qt)

With heater:

8.0 liters

(8 1/2 US qt, 7 Imp qt)



ET013

Fig. ET-9 Cooling system pressure test

## CHECKING VACUUM FITTINGS, HOSES, AND CONNECTIONS

Check the condition of fittings and hoses. Retighten or replace if necessary.

All vacuum hoses can be identified by colors.

### White line

- Vacuum tube to carburetor (E.G.R. Tube)
- Vacuum tube to thermal vacuum valve
- Thermal vacuum valve to E.G.R. control valve

## Yellow line

- Spark delay valve to distributor
- Spark delay valve to vacuum tube
- Distributor to vacuum tube
- Vacuum tube to carburetor
- Vacuum tube to canister

## Green line

- Anti-backfire valve to intake manifold
- Air control valve to emergency air relief valve
- Intake manifold to vacuum hose connector
- Intake manifold to canister

## CHECKING ENGINE COMPRESSION

### COMPRESSION PRESSURE TEST

1. Warm up engine sufficiently.
2. Disconnect all spark plugs.
3. Disconnect anti-dieseling solenoid valve connector.
4. Properly attach a compression tester to spark plug hole in cylinder being tested.




Fig. ET-10 Testing compression pressure

5. Depress accelerator pedal to open throttle and choke valves.

Note: Do not "pump" pedal.

6. Start engine as quickly as possible.

7. Compression pressure  
kg/cm<sup>2</sup> (psi)/at rpm

Standard:  
12.0 (171)/350

Minimum:  
9.0 (128)/350

8. Cylinder compression in cylinders should not be less than 80% of highest reading.

Different compression in two or more cylinders usually indicates an improperly seated valve or broken piston ring.

9. Low compression in cylinders can result from worn piston rings. This condition may usually be accompanied by excessive fuel consumption.

## TEST RESULT

If compression in one or more cylinders is low, pour a small quantity of engine oil into cylinders through the spark plug holes and retest compression.

1. If adding oil increases the compression pressure, the chances are that rings are faulty.
2. If pressure stays low, probable cause is that valve is sticking or seating improperly.
3. If cylinder compression in any two adjacent cylinders is low, and if adding oil does not help the compression, there is leakage past the gasket surface.

Oil and water in combustion chambers can result from leakage.

## IGNITION AND FUEL SYSTEM

### CONTENTS

CHECKING BATTERY .....	ET- 9	CHECKING DISTRIBUTOR CAP, ROTOR AND CONDENSER .....	ET-11
CHECKING AND ADJUSTING IGNITION TIMING .....	ET-10	CONDENSER .....	ET-11
ADJUSTING IGNITION TIMING .....	ET-10	ADJUSTING CARBURETOR IDLE RPM AND MIXTURE RATIO .....	ET-11
CHECKING AND REPLACING SPARK PLUG ..	ET-10	IDLE LIMITER CAP .....	ET-12
CHECKING DISTRIBUTOR OPERATING PARTS AND IGNITION WIRING .....	ET-10	CHECKING CARBURETOR RETURN SPRING ..	ET-12
BREAKER POINTS (Non-California models) ....	ET-10	CHECKING CHOKE MECHANISM (Choke plate and linkage) .....	ET-13
AIR GAP (California models) .....	ET-11	CHECKING FUEL LINES (Hoses, pipings, connections, etc.) .....	ET-13
DISTRIBUTOR .....	ET-11	REPLACING FUEL FILTER .....	ET-13
IGNITION WIRING .....	ET-11		


## CHECKING BATTERY

Check electrolyte level in each battery cell.

1. Unscrew each filler cap and inspect fluid level. If the fluid is low, add distilled water to bring the level up approximately 10 to 20 mm (0.39

to 0.79 in) above the plates. Do not overfill.

2. Measure the specific gravity of battery electrolyte.



ET002

Fig. ET-11 Checking specific gravity of battery electrolyte

Clean top of battery and terminals with a solution of baking soda and

water. Rinse off and dry with compressed air. Top of battery must be clean to prevent current leakage between terminals and from positive terminal to hold-down clamp.

In addition to current leakage, prolonged accumulation of acid and dirt on top of battery may cause blistering of the material covering connector straps and corrosion of straps. After tightening terminals, coat them with petrolatum (vaseline) to protect them from corrosion.

	Permissible value	Full charge value [at 20°C (68°F)]
Frigid climates	Over 1.22	1.28
Tropical climates	Over 1.18	1.23
Other climates	Over 1.20	1.26


## CHECKING AND ADJUSTING IGNITION TIMING

### ADJUSTING IGNITION TIMING

1. Check spark plugs and distributor breaker points for condition.
2. Thoroughly remove dirt and dust from timing mark on crank pulley and timing indicator on front cover.
3. Warm up engine sufficiently.
4. Install a timing light on No. 1 cylinder spark plug wire, and install a tachometer.
5. Set idling speed to approximately 750 rpm.
6. Check ignition timing with a timing light if it is specified value.


If necessary, adjust it as follows:

- (1) Loosen setscrew until distributor can be moved by hand.
- (2) Adjust ignition timing to specified value.
- (3) Lock distributor setscrew, and make sure that timing is correct.



EC352

Fig. ET-12 Adjusting ignition timing



ET159

Fig. ET-13 Checking ignition timing

Ignition timing:

Manual transmission

12°/750 rpm

(Non-California models)

10°/750 rpm

(California models)

Automatic transmission

12°/650 rpm

(in "D" position)

## CHECKING AND REPLACING SPARK PLUG

1. Remove and clean plugs in a sand blast cleaner.
2. Inspect insulator for cracks or chips.
3. Check both center and ground electrodes.

If they are excessively worn, replace with new spark plugs.

4. Spark plug gap:

Breaker points type

0.8 to 0.9 mm

(0.031 to 0.035 in)

Transistor ignition type


1.0 to 1.1 mm

(0.039 to 0.043 in)

Tightening torque:

1.5 to 2.0 kg-m

(11 to 14 ft-lb)



EE080

Fig. ET-14 Checking spark plug point gap

## CHECKING DISTRIBUTOR OPERATING PARTS AND IGNITION WIRING

### BREAKER POINTS (Non-California models)

Check the distributor breaker points for abnormal pitting and wear. Replace if necessary. Make sure they are properly aligned and that point dwell and gap are correct. Clean and apply distributor grease to the cam lobes.

**Note:** Do not apply grease excessively.


Point gap:

0.45 to 0.55 mm

(0.018 to 0.022 in)

Dwell angle

49 to 55 degrees



EE322

Fig. ET-15 Checking distributor point gap

## AIR GAP

### (California models)

For inspection procedures and reference data, refer to the topic Air Gap in Section EE (page EE-29).

## DISTRIBUTOR

Check centrifugal advance unit for loose connection or improper operation. If it is not operating properly, the problem may be due to a sticky spring or excessively worn parts. This operation needs a distributor tester.

For inspection procedures and reference data, refer to relative topic under Distributor in Section EE.

If vacuum advance mechanism does not properly operate, check for the following items and correct the problem as required.

1. Check vacuum inlet for signs of leakage at connection. If necessary, retighten or replace.
2. Check vacuum diaphragm for air leak.

If necessary, replace diaphragm.

3. Inspect breaker plate for smooth movement.

If plate does not move smoothly, this condition could be due to sticky steel balls. If necessary, replace breaker plate assembly.


## IGNITION WIRING

Use an ohmmeter to check resistance of secondary cables. Disconnect cables from spark plugs and install a proper adapter between cable and spark plug. Remove distributor cap and secondary cables as an assembly. Do not remove cables from cap.

Check resistance of one cable at a time.

Connect ohmmeter between spark plug adapter and corresponding electrode inside cap. If resistance is more than 30,000 ohms, remove cable from

cap and check cable resistance only. If resistance is still more than 30,000 ohms, replace cable assembly.



EF125

Fig. ET-16 Checking high tension cable

## CHECKING DISTRIBUTOR CAP, ROTOR AND CONDENSER

**Note:** This operation is to be performed while checking distributor points. Inspect distributor cap for cracks and flashover.

External surfaces of all parts of secondary system must be cleaned to reduce possibility of voltage loss. All wires should be removed from distributor cap and coil so that terminals can be inspected and cleaned. Burned or corroded terminals indicate that wires are not fully seated, which causes arcing between end of wire and terminal. When replacing wires in terminal, be sure they are fully seated before pushing rubber nipple down over tower. Check distributor rotor for damage, and distributor cap for cracks.

### CONDENSER

1. Clean outlet of condenser lead wire, and check for loose setscrew. Retighten if necessary.
2. Check condenser with a condenser tester.

Condenser capacity

0.20 to 0.24  $\mu$ F

(Micro Farad)

Condenser insulation resistance

5M $\Omega$  (Mega ohms)

## ADJUSTING CARBURETOR IDLE RPM AND MIXTURE RATIO

### Cautions:

- a. On automatic transmission equip-

ped models, check should be performed in the "D" position.

Be sure to engage parking brake and to lock both front and rear wheels with wheel chocks.

- b. Keep your foot down on the brake pedal while depressing the accelerator pedal. Otherwise vehicle surges forward dangerously.

### Notes:

- a. Do not attempt to screw the idle adjusting screw down completely. Doing so could cause damage to tip which in turn will tend to cause malfunctions.
- b. If idle limiter cap obstructs proper adjustment, remove it. To install idle limiter cap, refer to Idle Limiter Cap.
- c. After idle adjustment has been made, shift the lever to the "N" or "P" position (for automatic transmission).
- d. When measuring CO percentage, insert probe into tail pipe more than 40 cm (15.7 in).

### "CO" idle adjustment with CO-meter

Idle mixture adjustment requires the use of a CO-meter (especially for California models). When preparing to adjust idle mixture, it is essential to have the meter thoroughly warmed up and calibrated.

1. Check carburetor pipes for proper connection.
2. Warm up engine until water temperature indicator points to the middle of gauge. The procedure to warm up engine is not specifically recommended. Either driving vehicle or operating engine at no load will be good.
3. Make sure that water temperature indicator points to the middle. Further keep engine running at about 2,000 rpm for about 5 minutes without applying load to engine in order to stabilize engine condition. Engine hood should be open.
4. Run engine for about 10 minutes at idling speed. During this 10 minutes, proceed as described in steps 5 to 9 below.
5. Remove air hose between 3-way connector (5-way connector for California models) and air check valve as shown in Figure ET-17. Plug the dis-

connected hose to prevent dust from entering.




Fig. ET-17 Disconnect air hose from air check valve

6. Race engine (1,500 to 2,000 rpm) two or three times under no load, then run engine for one minute at idling speed.

7. Adjust throttle adjusting screw until engine is at specified speed.

Engine speed:

Manual transmission

750 rpm

Automatic transmission

(in "D" position)

650 rpm

8. Check ignition timing. If necessary, adjust it to specifications.

This operation need not be carried out at 1,600 km (1,000 miles) service.

Ignition timing:

Manual transmission

12°/750 rpm (Non-California)

10°/750 rpm (California)

Automatic transmission

(in "D" position)

12°/650 rpm

9. At about 10 minutes after engine is run at idling speed, adjust idle adjusting screw so that CO percentage is at specified level.

CO percentage:

Manual transmission

2 ± 1% at 750 rpm

Automatic transmission

(in "D" position)

2 ± 1% at 650 rpm

10. Repeat procedures as described in steps 6, 7 and 9 above so that CO percentage is at specified level. Checking idle CO in step 9 can be carried out right after step 7.

11. Race engine (1,500 to 2,000 rpm) two or three times under no load and make sure that specified CO percentage is obtained.

12. Connect air hose to air check valve.

If engine speed increases, readjust it to the specified speed with throttle adjusting screw.

## "CO" Idle adjustment without CO-meter

If CO-meter is not available, the following procedures may be used.

1. Check carburetor pipes for proper connection.

2. Warm up engine until water temperature indicator points to the middle of gauge. The procedure to warm up engine is not specifically recommended. Either driving vehicle or operating engine at no load will be good.

3. Make sure that water temperature indicator points to the middle. Further keep engine running at about 2,000 rpm for about 5 minutes without applying load to engine in order to stabilize engine condition. Engine hood should be open.

4. Run engine for about 10 minutes at idling speed. During this 10 minutes, proceed as described in steps 5 to 9 below.

5. Remove air hose between 3-way connector (5-way connector for California models) and air check valve shown in Figure ET-17. Plug the disconnected hose to prevent dust from entering.

6. Race engine (1,500 to 2,000 rpm) two or three times under no load, then run engine for one minute at idling speed.

7. Adjust throttle adjusting screw so that engine speeds are as indicated below.

Engine speed:

Manual transmission

815 rpm

Automatic transmission

(in "D" position)

670 rpm

8. Check ignition timing, if necessary adjust it to the value required by specifications. This operation need not be carried out at 1,600 km (1,000 miles) service.

9. At about 10 minutes after engine is run at idling speed, adjust idle adjusting screw until maximum rpm is obtained.

10. Repeat procedures as described in steps 6, 7 and 9 above until engine speed, at best idle mixture, is 815 rpm for manual transmission models and 670 rpm for automatic transmission models (in "D" position). Adjustment in step 9 can be carried out right after step 7.

11. Turn the idle adjusting screw clockwise until engine speed drops off below specified rpm.

Engine speed drops off:

Manual transmission

60 to 70 rpm

Automatic transmission

(in "D" position)

15 to 25 rpm

12. Connect air hose to air check valve.

If engine speed increases, readjust it to the specified speed with throttle adjusting screw.

## IDLE LIMITER CAP

Do not remove this idle limiter cap unless necessary. If this unit is removed, it is necessary to readjust it at the time of installation. To adjust proceed as follows.

1. After adjusting throttle or idle speed adjusting screws, check to be sure that the amount of "CO" contained in exhaust gases meets the established standard.

2. Install idle limiter cap in position, making sure that the adjusting screw further turn 1/8 rotation in the "CO-RICH" direction.




Fig. ET-18 Setting idle limiter cap

## CHECKING CARBURETOR RETURN SPRING

Check throttle return spring for cracks, squareness or deformation, if necessary, replace with a new one.

## CHECKING CHOKE MECHANISM (Choke plate and linkage)

1. Check choke valve and mechanism for free operation, and clean or replace if necessary. A binding can result from petroleum gum formation on choke shaft or from damage.
2. Check bimetal cover setting. Index mark on bimetal cover is usually set at center of scale.

**Note:** Always align the index mark on bimetal cover with the center index mark on choke housing.

3. Every day, before starting engine, depress the accelerator pedal to see if choke valve is closed automatically.

If it fails to be closed, the chances are that link movement is unsmooth,

or that bimetal is out of order. Refer to Carburetor in Section EF.


## CHECKING FUEL LINES (Hoses, pipings, connections, etc.)

Check fuel lines for loose connections, cracks and deterioration. Retighten loose connections and replace any damaged or deformed parts.

## REPLACING FUEL FILTER

Check for a contaminated filter and water deposit.

All engines use a replaceable cartridge type fuel filter as an assembly.



ET011

Fig. ET-19 Fuel filter

# EMISSION CONTROL SYSTEM

## CONTENTS

CHECKING CRANKCASE EMISSION CONTROL SYSTEM .....	ET-13	ADJUSTMENT OF SET PRESSURE OF BOOST CONTROLLED DECELERATION DEVICE (B.C.D.D.) .....	ET-18
REPLACING P.C.V. VALVE AND FILTER .....	ET-13	CHECKING B.C.D.D. SOLENOID VALVE ....	ET-20
CHECKING VENTILATION HOSE .....	ET-14	CHECKING AMPLIFIER (Manual transmission models) .....	ET-20
CHECKING EXHAUST MANIFOLD HEAT CONTROL VALVE .....	ET-14	REPLACING AIR PUMP AIR CLEANER ELEMENT .....	ET-20
CHECKING SPARK TIMING CONTROL SYSTEM .....	ET-14	CHECKING EXHAUST GAS RECIRCULATION (E.G.R.) CONTROL SYSTEM .....	ET-20
SPARK DELAY VALVE (Automatic transmission models only) .....	ET-14	CHECKING EVAPORATIVE EMISSION CONTROL SYSTEM .....	ET-22
INSPECTION .....	ET-15	CHECKING CATALYTIC CONVERTER .....	ET-23
CHECKING AUTOMATIC TEMPERATURE CONTROL AIR CLEANER .....	ET-15	INSPECTION .....	ET-23
OPERATING PRESSURE OF BOOST CONTROLLED DECELERATION DEVICE (B.C.D.D.) ADJUSTMENT .....	ET-17	CHECKING FLOOR TEMPERATURE WARNING SYSTEM .....	ET-23
CHECKING B.C.D.D. CIRCUIT WITH FUNCTION TEST CONNECTOR .....	ET-17	INSPECTION .....	ET-23

## CHECKING CRANKCASE EMISSION CONTROL SYSTEM

### REPLACING P.C.V. VALVE AND FILTER

Check P.C.V. valve in accordance

with the following method.

With engine running at idle, remove ventilator hose from P.C.V. valve. If the valve is properly working, a hissing

noise will be heard as air passes through the valve and a strong vacuum should be felt immediately when a finger is placed over valve inlet.




Fig. ET-20 Crankcase emission control system

## CHECKING VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and blow them out with compressed air.

If any hose cannot be free of obstructions, replace.

Ensure that flame arrester is surely inserted in the hose, between air cleaner and rocker cover.

## CHECKING EXHAUST MANIFOLD HEAT CONTROL VALVE

1. Run engine and visually check counterweight to see if it operates properly.

(1) For some time after starting engine in cold weather, counterweight turns counterclockwise until it comes into contact with stopper pin installed to exhaust manifold.

Counterweight gradually moves down clockwise as engine warms up and ambient temperature goes higher around exhaust manifold.

(2) When engine speed is increased, discharge pressure of exhaust gases causes counterweight to move downward clockwise.

- (3) When heat control valve is in the full open position, counterweight moves further clockwise exceeding the position described in 1-(1) above, and stops again coming into contact with stopper pin.




Fig. ET-21 Cold operation of counterweight




Fig. ET-22 Hot operation of counterweight

2. With engine stopped, visually check E.F.E. system for the following items.

- (1) Thermostat spring for dismounting
- (2) Stopper pin for bend, and counter weight stop position for dislocation
- (3) Check heat control valve for malfunction due to break of key that locates counterweight to valve shaft.
- (4) Check axial clearance between heat control valve and exhaust manifold. Correct clearance is 0.7 to 1.5 mm (0.028 to 0.059 in).
- (5) Check welded portion of heat control valve and valve shaft for any indication of crack or flaking.
- (6) Rotate heat control valve shaft with a finger, and check for binding between shaft and bushing in closing and opening operation of heat control valve. If any binding is felt in rotating operation, move valve shaft in the rotation direction several times. If this operation does not correct binding condition, it is due to seizure between shaft and bushing, and exhaust manifold should be replaced as an assembly.

## CHECKING SPARK TIMING CONTROL SYSTEM

This system is installed on non-California automatic transmission models.

## SPARK DELAY VALVE (Automatic transmission models only)

This valve delays vacuum spark advance during rapid acceleration; it also cuts off the vacuum spark advance immediately upon deceleration. The valve is designed for one-way operation and consists of a one-way umbrella valve and sintered steel fluidic restrictor.






Fig. ET-23 Spark delay valve

When installing this valve, ensure that it properly oriented. This valve should be replaced periodically. Refer to "Maintenance Schedule".




Fig. ET-24 Operation of spark delay valve




Fig. ET-25 Checking spark delay valve

## INSPECTION

1. Remove spark delay valve.
2. Blow air through port on carburetor side, then through the other port (on distributor side). Spark delay valve is in good condition if, when finger is placed over port on distributor side, air flow resistance is greater than that on the other side. See Figure ET-25.
3. If a considerable air flow resistance is felt at port on distributor side in step 2 above and if the condition of spark delay valve is questionable, dip port (on carburetor side) into a cup filled with water. Blow air through the other port. Small air bubbles should appear.




Fig. ET-26 Checking spark delay valve

Note: Be careful to avoid entry of oil or dirt into valve.

## CHECKING AUTOMATIC TEMPERATURE CONTROL AIR CLEANER

### 1. Air cleaner element

Viscous paper type air cleaner element does not require any cleaning operation until it is replaced periodically. Brushing or blasting operation will cause clogging and result in enrichment of carburetor mixture, and should never be conducted. For replacement interval of air cleaner element, refer to Maintenance Schedule.

### 2. Hot air control system

In warm weather, it is difficult to find out malfunction of hot air control system. In cold weather, however, malfunction of air control valve due to disconnection or deterioration of vacuum hose between intake manifold and vacuum motor and insufficient durability of air control valve will cause insufficient automatic control operation for intake air, and result in engine disorder including:

- 1) Stall or hesitation of engine operation
- 2) Increase in fuel consumption
- 3) Lack of power


These phenomena reveal malfunction of hot air control system. If these phenomena should occur, check hot air control system as described in the following before carrying out inspection of carburetor.

#### 2-1 Vacuum hoses

(Intake manifold to 3-way connector, 3-way connector to temperature sensor, 3-way connector to idle compensator, temperature sensor to vacuum motor)

1. Check that vacuum hoses are securely connected in correct position.
2. Check each hose for cracks or distortion, hose clip for condition.

**Note:** Vacuum hose position: R.H. side of "Nissan" mark on the top of sensor is for intake manifold; L.H. side of the mark is for vacuum motor.




EF217

*Fig. ET-28 Inspecting valve position*

### 2-2 Vacuum motor

1. With engine stopped, disconnect fresh air duct.

Place a mirror at the end of air cleaner inlet pipe as shown, and check to see if air control valve is in correct position.



EF213

*Fig. ET-27 Inspecting valve position*

Air control valve is in correct position if its under hood air inlet is open and hot air inlet is closed. Check air control valve linkage for condition.

2. Disconnect vacuum motor inlet vacuum hose, and connect another hose to the inlet to apply vacuum to vacuum motor. Vacuum can be applied by breathing in the hose end as shown.

Place a mirror at the end of air cleaner inlet pipe, and check to see if air control valve is in correct position.

Correct position of air control valve is the reverse of paragraph 1 above. Air control valve is in correct position if under hood air inlet is closed, and hot air inlet is open.

3. With hot air inlet is open position, as described in paragraph 2 above, pinch vacuum hose with fingers and cut off air from vacuum hose. In this condition, check that air control valve maintains the condition described in step 2 for more than 30 seconds, and that hot air inlet is open. If diaphragm spring actuates the air control valve by its spring force to open under hood air inlet within 30 seconds, replace vacuum motor as an assembly since this may be resulted from air leak at vacuum motor diaphragm.

### 2-3 Temperature sensor

Check temperature sensor for function by proceeding as follows. Be sure to keep engine cold before starting test.

1. With engine off, check air control valve for condition. In this case, under hood air inlet is open. Use a mirror for inspection as 2-2-1 above.


2. Start engine and keep idling.

Immediately after engine starting, check air control valve for correct position as described above. In this case, correct position of air control valve is the reverse of 2-2-1; under hood air inlet is closed, and hot air inlet is open.

3. Check that air control valve gradually opens to under hood air inlet side as engine warms up. When environmental temperature around temperature sensor is low, spend more time for engine warming up operation to facilitate smooth operation of air control valve.

If the above test reveals any problem in the operation of air control valve, carry out the following test:

4. Remove air cleaner cover. Set temperature sensing element of thermistor or thermometer to a position where temperature around sensor can be measured. In this case, fix wiring of thermistor or thermometer on the bottom surface of air cleaner with adhesive tape in such a manner that the set position of temperature sensing element will not be affected by airflow. Then install air cleaner cover.



EF221

*Fig. ET-29 Checking temperature sensor*

5. Carry out test as described in steps 1, 2 and 3 above. When air control valve begins to open to under hood air inlet side several minutes after engine starting, read the indication of thermistor or thermometer. If reading falls within the working temperature range of temperature sensor, the sensor is normal. If reading exceeds the range, replace the sensor with new one.

**Note:** Before replacing temperature sensor, check idle compensator as described in Section EF (Page EF-8).

# **OPERATING PRESSURE OF BOOST CONTROLLED DECELERATION DEVICE (B.C.D.D.) ADJUSTMENT**

## **CHECKING B.C.D.D. CIRCUIT WITH FUNCTION TEST CONNECTOR**

### **Manual transmission models**

1. Check for continuity between (A) and (B) (at a speed of zero km). Refer to Figure ET-30.

B.C.D.D. circuit is functioning properly if continuity exists and voltmeter reading is 0 volt (d-c) in step 2 below.

If continuity does not exist, check for disconnected connector and/or faulty amplifier, speed detecting switch or B.C.D.D. solenoid valve.

2. Check for presence of voltage across (A) and (B) [at a speed of more than 16 km/h\* (10 MPH)]. Refer to Figure ET-31.

\* Conduct this test by one of the following two methods.

1) Raising up rear axle housing with stand.

2) Chassis dynamometer test

• If voltmeter reading is 0 volt at a speed of more than 16 km/h (10 MPH), circuit is functioning properly.

• If voltmeter reading is not 0 volt, check for disconnected connector, burned fuse, faulty amplifier, B.C.D.D. solenoid valve or speed detecting switch.

3. If, by above checks, faulty part or unit is located, it should be removed and tested again. If necessary, replace.

### **Automatic transmission models**

1. With inhibitor switch "ON" ("N" or "P" position), check for presence of voltage across (A) and (B). Refer to Figure ET-30.


• If voltmeter reading is 12 volts (d-c), B.C.D.D. circuit is functioning properly.

- If voltmeter reading is zero, check for disconnected connector, faulty solenoid valve or inhibitor switch.
- 2. With inhibitor switch "OFF" ("1", "2", "D" or "R" position), check for resistance between (A) and (B). Refer to Figure ET-31.
- If ohmmeter reading is 25 ohms or below, circuit is functioning properly.

erly.


- If ohmmeter reading is 32 ohms or above, check for poor connection of connector, faulty B.C.D.D. solenoid valve or inhibitor relay.

3. If, by above checks, faulty part or unit is located, it should be removed and tested again. If necessary, replace.



EF711

Fig. ET-30 B.C.D.D. circuit with function test connector (Manual transmission models)



EF712

Fig. ET-31 Checking B.C.D.D. circuit with function test connector (Automatic transmission models)

## ADJUSTMENT OF SET PRESSURE OF BOOST CONTROLLED DECELERATION DEVICE (B.C.D.D.)

Generally, it is unnecessary to adjust the B.C.D.D., however, if it should become necessary to adjust it, the procedure is as follows:


### Prepare the following tools

1. Tachometer to measure the engine speed while idling, and a screwdriver.
2. A vacuum gauge connecting pipe.

**Note:** A quick-response type boost gauge such as Bourdon's type is recommended; a mercury-type manometer should not be used.

To properly set the B.C.D.D. set pressure, proceed as follows:


1. Remove the harness of solenoid valve.



EF262

Fig. ET-32 Removing harness of solenoid valve

2. Connect rubber hose between vacuum gauge and intake manifold as shown.



EF092

Fig. ET-33 Connecting vacuum gauge

3. Warm up the engine until it is heated to operating temperature.

Then adjust the engine at normal

idling setting. (Refer to the item Idling Adjustment in page ET-11.)

Idling engine speed  
Manual transmission  
750 rpm  
Automatic transmission  
(in "D" position)  
650 rpm

4. Run the engine under no load. Increase engine speed to 3,000 to 3,500 rpm, then quickly close throttle valve.

5. At the time, the manifold vacuum pressure increases abruptly to -600 mmHg (-23.62 inHg) or above and then gradually decreases to the level set at idling.

6. Check that the B.C.D.D. set pressure is within the specified pressure.

Specified pressure (0 m, sea level and 760 mmHg (30 inHg), atmospheric pressure)

Manual transmission  
-510 to -550 mmHg  
(-20.1 to -21.7 inHg)

Automatic transmission  
-490 to -530 mmHg  
(-19.3 to -20.9 inHg)

**Note:** When checking the set pressure of B.C.D.D., find the specified set pressure in Figure ET-36 from the atmospheric pressure and altitude of the given location.

For example, if a manual transmission model vehicle is located at an altitude of 1,000 m (3,280 ft), the specified set pressure for B.C.D.D. is -445 mmHg (-17.5 inHg).

7. If it is higher than the set level, turn the adjusting screw (counter-clockwise) or nut (clockwise) until correct adjustment is made.

Non-California models:


Adjusting screw type

California models:

Adjusting nut type

**Note:** When adjusting B.C.D.D. for California models, turn adjusting nut in or out with lock spring in place. Always set lock spring properly to prevent changes in set pressure.


Non-California models



- 1 Adjusting screw "S"
- 2 Cover "C"

ET037

California models



- 1 Adjusting nut
- 2 Lock spring

EC692

Fig. ET-34 Adjusting set pressure

8. Race the engine and check for adjustment.
9. If it is lower than the set level, turn the adjusting screw or nut until correct adjustment is made.
10. Race the engine and check for adjustment.

If engine speed cannot be decreased to idling when checking B.C.D.D. set pressure, proceed as follows:

When the engine speed does not fall to idling speed, it is necessary to reduce the negative idling pressure of the manifold to lower than the set pressure of the B.C.D.D. (The engine speed will not drop to idling speed when the negative idling pressure is higher than the set pressure of the B.C.D.D.).

In this case, the engine must be labored by (1) road test or (2) chassis dynamometer or (3) by raising up rear suspension member on a stand, accelerating the vehicle to 64 to 80 km/h (40 to 50 MPH) in top gear (manual transmission) or in "D" position (automatic transmission), and then releasing the accelerator pedal and letting the vehicle decelerate. After doing this, check whether the B.C.D.D. set pressure is at the predetermined value or not.

## Engine Tune-up




Fig. ET-35 Testing set pressure of the B.C.D.D.




Fig. ET-36 Changes in set pressure versus changes in atmospheric pressure and altitude

## CHECKING B.C.D.D. SOLENOID VALVE

1. Turn on engine key. (Do not start engine.)
2. Ensure that solenoid valve clicks when intermittently electrified as shown in Figure ET-37.




Fig. ET-37 Checking solenoid valve


3. If a click is heard, solenoid valve is normal.
4. If a click is not heard at all, check for continuity with a circuit tester. If discontinuity is detected, replace solenoid valve.

## CHECKING AMPLIFIER (Manual transmission models)


The amplifier is installed at the rear of the speedometer. To check, proceed as follows:

1. Set circuit tester in d-c ampere range (1A min, full scale), connect test probes of tester as shown in Figure ET-38.

Do not confuse positive line with negative line.



EF264




- 1 Ignition key
- 2 Amplifier
- 3 Speed detecting switch
- 4 B.C.D.D. solenoid valve

Fig. ET-38 Checking amplifier

## REPLACING AIR PUMP AIR CLEANER ELEMENT

Remove air hose, then detach air cleaner from hoodledge. Air cleaner element and air cleaner lower body are built into a unit construction. Replace air cleaner element and lower body as an assembly.



EC323

Fig. ET-39 Replacing air cleaner element

## CHECKING EXHAUST GAS RECIRCULATION (E.G.R.) CONTROL SYSTEM

### Checking E.G.R. control system in its mounted condition

1. Make a thorough visual check of E.G.R. control system. If necessary, wipe away oil to facilitate inspection. If hoses are cracked or broken, replace.
2. With engine running, check E.G.R. warning system for proper function. Make sure that E.G.R. warning lamp lights when ignition switch is turned to START-position (starter motor runs). If E.G.R. warning lamp does not light, inspect harnesses and connectors or replace warning lamp. Then turn ignition switch to ON position, and check the following items:

- (1) If odometer of detector drive counter has not reached 50,000 counts, make sure that E.G.R. warning lamp does not light.
- (2) If odometer of detector drive counter has attained 50,000 counts, make sure that E.G.R. warning lamp lights.

If warning lamp does not light, check harnesses, connectors, and detector drive counter; replace warning lamp or detector drive counter if necessary.

**Note:** Operation of E.G.R. warning lamp is as follows:

2. Turn ignition key to "ON" position.
3. Ensure that tester pointer deflects when ignition key is turned on.
4. If tester pointer does not deflect when solenoid valve and speed detecting switch circuits are functioning properly, amplifier is faulty.

## Engine Tune-up

Ignition Switch Position	START	ON	
Detector Drive Counter	—	Below 50,000 counts	Above 50,000 counts
E.G.R. Warning Lamp	ON	OFF	ON

a. After completing inspection of E.G.R. control system, be sure to reset odometer of detector drive counter to zero.

b. This item applies to 620 models except those bound for California and Canada.


3. With engine stopped, inspect E.G.R. control valve for any indication of binding or sticking by moving diaphragm of control valve upwards with fingers.

4. With engine running, inspect E.G.R. control valve and thermal vacuum valve for normal operation.

(1) When engine coolant temperature is low:

Make sure that E.G.R. control valve does not operate when engine speed is increased from idling to 3,000 to 3,500 rpm.

Place fingers on the diaphragm of E.G.R. control valve to check for valve operation.



EC253

Fig. ET-40 Checking E.G.R. control valve

(2) When engine coolant temperature is high:

1) Make sure that E.G.R. control valve operates when engine speed is increased from idling to 3,000 to 3,500 rpm. Place fingers on the diaphragm of E.G.R. control valve to check for valve operation.


2) If E.G.R. control valve does not operate, check as follows:

- Disconnect one end (E.G.R. control valve side) of vacuum hose connecting thermal vacuum valve to E.G.R.

control valve.

- Increase engine speed from idling to 3,000 to 3,500 rpm.
- Make sure that thermal vacuum valve is open, and that carburetor vacuum is present at the end (E.G.R. control valve side) of vacuum hose.

If vacuum is weak or not present at all, replace thermal vacuum valve. If vacuum is present, replace E.G.R. control valve.



EC254

Fig. ET-41 Checking thermal vacuum valve


If any difficulty is encountered in judging the condition of any component during above inspection, check the questionable component independently as follows:

### E.G.R. control valve

Dismount E.G.R. control valve from engine.

1. Apply vacuum to E.G.R. control valve, referring to the following figure. If the valve moves to full position, it is normal.

E.G.R. control valve will remain open for more than 30 seconds after vacuum has cut off.




ET152

Fig. ET-42 Checking E.G.R. control valve

2. Visually check E.G.R. control valve for damage, wrinkle or deformation.

3. Clean the seating surface of E.G.R. control valve with a brush and compressed air, and remove foreign matter from around the valve and port.



EC350

Fig. ET-43 Cleaning E.G.R. control valve

## Thermal vacuum valve


Dismount thermal vacuum valve from engine.

**Note:** Before dismounting, drain engine coolant from engine.

Apply vacuum to thermal vacuum valve and check to be sure that thermal vacuum valve opens or closes in response to engine coolant temperature as specified.

Thermal vacuum valve should open at a temperature of 57 to 63°C (134 to 145°F) completing the vacuum passage.

**Note:** Do not allow water to get inside the thermal vacuum valve.



EC242

Fig. ET-44 Checking thermal vacuum valve

## CHECKING EVAPORATIVE EMISSION CONTROL SYSTEM

### Vapor lines and fuel vapor control valve

Checking fuel tank, vapor liquid separator and vapor vent line

1. Check all hoses and fuel tank filler cap.
2. Disconnect the vapor vent line connecting carbon canister to vapor-liquid separator.
3. Connect a 3-way connector, a manometer and a cock (or an equivalent 3-way charge cock) to the end of the vent line.
4. Supply fresh air into the vapor vent line through the cock little by

little until pressure becomes 368 mmH<sub>2</sub>O (14.5 inH<sub>2</sub>O).

5. Shut the cock completely and leave it unattended.


6. After 2.5 minutes, measure the height of the liquid in the manometer.

7. Variation of height should remain with 25 mmH<sub>2</sub>O (0.98 inH<sub>2</sub>O).

8. When filler cap does not close completely, the height should drop to zero in a short time.

9. If the height does not drop to zero in a short time when filler cap is removed, it is the cause of a stuffy hose.

**Note:** In case the vent line is stuffy, the breathing in fuel tank is not thoroughly made, thus causing insufficient delivery of fuel to engine or vapor lock. It must, therefore, be repaired or replaced.



EC786


Fig. ET-45 Checking evaporative emission control system

### Checking carbon canister purge control valve

Check for fuel vapor leakage, in the distributor VC line, at diaphragm of carbon canister purge control valve.

To check for leakage, proceed as follows:

1. Disconnect rubber hose, in the line, between T-connector and carbon canister at T-connector.
2. Inhale air into the opening of rubber hose running to VC hole in carbon canister and ensure that there is no leak.



ET349

Fig. ET-46 Checking carbon canister purge control valve



3. If there is a leak, remove top cover from purge control valve and check for dislocated or cracked diaphragm. If necessary, replace diaphragm kit (which is made up of a retainer, diaphragm and spring).




Fig. ET-47 Carbon canister purge control valve

## Carbon canister filter

Check for a contaminated element.

Element can be removed at the bottom of canister installed on vehicle body.




Fig. ET-48 Replacing carbon canister filter

## Fuel tank vacuum relief valve operation

Remove fuel filler cap and see it functions properly.

1. Wipe clean valve housing and have it in your mouth.
2. Inhale air. A slight resistance accompanied by valve indicates that valve is in good mechanical condition. Note also that, by further inhaling air, the resistance should be disappeared with valve clicks.

3. If valve is clogged, or if no resistance is felt, replace cap as an assembled unit.




Fig. ET-49 Fuel filler cap

## CHECKING CATALYTIC CONVERTER

### INSPECTION

#### Preliminary inspection

Visually check condition of all component parts including hoses; tubes, and wires, replace if necessary.

Refer to Inspection of A.I.S. on page EC-17.

#### Catalytic converter

Whether catalytic converter is normal or not can be checked by observing variation in CO percentage. The checking procedure is as follows:

Apply parking brake. Shift gears into Neutral (for manual transmission) and Neutral or Park (for automatic transmission).

1. Visually check catalytic converter for damage or cracks.
2. Remove air hose between 5-way connector and air check valve. Plug the disconnected hose to prevent dust from entering. Refer to page ET-12.
3. Check carburetor pipes for proper connection.
4. Warm up engine sufficiently.
5. Race engine (1,500 to 2,000 rpm) two or three times under no-load, then run engine for one minute at idling speed.
6. Adjust throttle adjusting screw until engine attains to specified speed. Refer to page ET-12.
7. Check ignition timing. If necessary, adjust it to specifications. Refer to page ET-10.

8. Adjust idle adjusting screw until specified CO percentage is obtained. Refer to page ET-12.

9. Repeat the adjustment process as described in steps 5 to 8 above until specified CO percentage is obtained.

Note: Adjustment in step 9 should be made ten minutes after engine has warmed up.

10. Race engine (1,500 to 2,000 rpm) two or three times under no-load and make sure that specified CO percentage is obtained.

11. Remove cap and connect air hose to air check valve.

If idling speed increases, readjust it to specified speed with throttle adjusting screw.

12. Warm up engine for about four minutes at 2,000 rpm under no-load.

13. Measure CO percentage at idling speed. After step 12 has been completed, wait for one minute before making CO percentage measurement.

14. If CO percentage measured in step 13 is less than 0.3%, the catalytic converter is normal.

15. If CO percentage measured in step 13 is over 0.3%, recheck A.I.S. and replace air check valve. Then, perform inspection steps 12 and 13.

16. If CO percentage is still over 0.3% in step 15, catalytic converter is malfunctioning. Replace catalytic converter.

## CHECKING FLOOR TEMPERATURE WARNING SYSTEM

### INSPECTION

#### Floor warning temperature system

Apply parking brake. Shift gears into Neutral (for manual transmission) and Neutral or Park (for automatic transmission).

1. Ensure that floor temperature warning lamp lights when ignition switch is turned to the "S" position.

If not, check lamp for burned bulbs.

## Engine Tune-up

Replace bulb if bulb is burned out.

If bulb is not burned, trace wire(s) back to ignition switch. Repair or replace if necessary.

2. Be sure that floor temperature is cool [below 80°C (176°F)] before carrying out the following procedure:

- (1) Remove rear seat.
- (2) Ignition switch is turned to the

"IG" position.

(3) Ensure that floor temperature warning lamp goes out.

(4) Heat surrounding areas of floor temperature sensing switch with a proper heater to ensure that floor temperature warning lamp glows when floor is heated to the specifications as shown in the table below.

Temperature sensing switch	Temperature warning lamp	Floor temperature
Contact close	Off	Below 105°C (221°F)
Contact open	On	Above 105°C (221°F)

**Note:** Avoid heating floor temperature sensing switch directly.

If lamp does not glow, check floor temperature sensing switch connector for continuity with a circuit tester.

If continuity should exist after heated surrounding areas of floor temperature sensing switch, replace temperature sensing switch.

If continuity does not exist, trace the wiring back to relay or check the following step 3. Repair or replace wire(s) if necessary.

**Note:** The floor temperature sensing switch may be heated through the floor by a proper heater.

3. Turn ignition switch to the "IG" position, and disconnect floor temperature sensing connector. The lamp should remain on. If not, check floor

temperature relay for continuity with a circuit tester.

Referring to the following floor temperature relay, if relay is normal, trace wire(s) back to ignition switch. Repair faulty wiring.

### Floor temperature relay

To check floor temperature relay, remove it and proceed as follows:

1. Check for continuity between ④ and ⑤. Continuity should exist.  
Check for continuity between ① and ③. Continuity should exist.  
Check for continuity between ① and ②. Continuity should not exist.
2. Apply a 12-volt d-c across ④ and ⑤ to ensure that continuity exists between ① and ② and that continuity does not between ① and ③. If test

results do not satisfy the above, replace the floor temperature relay.

### When floor temperature warning lamp lights

Check floor temperature warning lamp.

1. Open or short circuit in wiring harness.




2. Check fuel system with regard to the following items: (Refer to "Inspection of Fuel System".)

- 1) Float level
- 2) Choke
- 3) Normal fuel supply system (Primary and secondary)
- 4) Accelerator pump
- 5) Power valve
- 6) B.C.D.D.
- 7) Fuel strainer
- 8) Air cleaner

3. Check ignition system with regard to the following items: (Refer to "Inspection of Ignition System".)

- 1) Ignition AMP.
- 2) Distributor
- 3) Ignition coil
- 4) High tension code
- 5) Spark plug
4. Check idle CO adjustment. (Refer to "Inspection of Idle CO Adjustment")

**Note:** Even if there is nothing wrong with engine, warning lamp may come on if vehicle is being driven on a steep slope continuously in lower gears at high engine speeds.



- 1 To floor temperature warning lamp
- 2 From "S" position
- 3 From "IG" position
- 4 From ignition switch
- 5 To floor temperature sensing switch

EC343

Fig. ET-50 Checking floor temperature relay

# SERVICE DATA AND SPECIFICATIONS

## Ignition timing and idling

Manual transmission	degree/rpm	12° B.T.D.C./750 (Non-Calif. models) 10° B.T.D.C./750 (California models)
---------------------	------------	--

Automatic transmission  
(in "D" position)

degree/rpm	12° B.T.D.C./650
------------	------------------

## Valve clearance

Cold	Intake	mm (in)	0.20 (0.008)
	Exhaust	mm (in)	0.25 (0.010)
Hot	Intake	mm (in)	0.25 (0.010)
	Exhaust	mm (in)	0.30 (0.012)

## Belt tension

Fan	mm (in)	8 to 12 (0.315 to 0.472)
Air pump	mm (in)	8 to 12 (0.315 to 0.472)
Air con. compressor	mm (in)	8 to 12 (0.315 to 0.472)
Pressure	kg (lb)	10 (22) is applied

## Compression pressure at 350 rpm

Standard	kg/cm <sup>2</sup> (psi)	12.0 (171)
Minimum	kg/cm <sup>2</sup> (psi)	9.0 (128)

Radiator cap relief pressure	kg/cm <sup>2</sup> (psi)	0.9 (13)
------------------------------	--------------------------	----------

## Cooling system

Leakage testing pressure	kg/cm <sup>2</sup> (psi)	1.6 (23)
--------------------------	--------------------------	----------

Battery specific gravity at 20°C (68°F)	1.26
---	------

## Distributor

Point gap	mm (in)	0.45 to 0.55 (0.018 to 0.022)
Air gap	mm (in)	0.2 to 0.4 (0.008 to 0.016)
Dwell angle	degree	49° to 55°
Condenser capacity	μF	0.20 to 0.24
Condenser insulation resistance	MΩ	5

## Spark plug

Gap	mm (in)	0.8 to 0.9 (0.031 to 0.035) (Breaker points type) 1.0 to 1.1 (0.039 to 0.043) (Transistor ignition type)
-----	---------	---

## Checking "CO" percent at idling speed (No air)

Manual transmission model	%/rpm	2 ± 1/750
Automatic transmission model	%/rpm	2 ± 1/650

## Adjustment of operating pressure of B.C.D.D.

B.C.D.D. set pressure		
Manual transmission	mmHg (in Hg)	.....-510 to -550 (-20.1 to -21.7)
Automatic transmission	mmHg (in Hg)	.....-490 to -530 (-19.3 to -20.9)

## Engine Tune-up

---

### A.T.C. air cleaner

Operating temperature      °C (°F) ..... 30 to 54 (86 to 129)

### Tightening torque

#### Cylinder head bolts

1st turn	kg-m (ft-lb) .....	4.0 (29)
2nd turn	kg-m (ft-lb) .....	6.0 (43)
3rd turn	kg-m (ft-lb) .....	6.5 to 8.5 (47 to 61)

Manifold nuts	kg-m (ft-lb) .....	1.2 to 1.6 (8.7 to 11.6)
---------------	--------------------	--------------------------

Carburetor nuts	kg-m (ft-lb) .....	0.5 to 1.0 (3.6 to 7.2)
-----------------	--------------------	-------------------------

Spark plugs	kg-m (ft-lb) .....	1.5 to 2.0 (11 to 14)
-------------	--------------------	-----------------------

## TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
<b>CANNOT CRANK ENGINE OR SLOW CRANKING</b>	Improper grade oil. Discharged battery. Faulty battery. Loose fan belt. Malfunction in charge system. Wiring connection loose in starting circuit. Faulty ignition switch. Faulty starter motor.	Replace with proper grade oil. Charge battery. Replace. Adjust. Inspect. Correct. Repair or replace. Repair or replace.

(Trouble-shooting procedure on starting circuit)

Switch on the starting motor with light "ON"

When light goes off or dims considerably,

- Check battery.
- Check connection and cable.
- Check starter motor.

When light stays bright,

- Check wiring connection between battery and starter motor.
- Check ignition switch.
- Check starter motor.

### ENGINE WILL CRANK NORMALLY BUT WILL NOT START

In this case, the following trouble causes may exist, but in many cases ignition system or fuel system is in trouble.

*Ignition system in trouble*

*Fuel system in trouble*

*Valve mechanism does not work properly*

*Low compression*

(Trouble-shooting procedure)

Check spark plug firstly by following procedure.

Disconnect high tension cable from one spark plug and hold it about 10 mm (0.39 in) from the engine metal part and crank the engine.

Good spark occurs.

- Check spark plug.
- Check ignition timing.
- Check fuel system.
- Check cylinder compression.

No spark occurs.

Very high current.

Check the current flow in primary circuit.

Inspect primary circuit for short.

Check breaker point operation (except transistor ignition system).

## Engine Tune-up

Condition	Probable cause	Corrective action
<b>Ignition system out of order</b>	Low or no current.	Check for loose terminal or disconnection in primary circuit. Check for burned points *
	Burned distributor point.	Repair or replace. *
	Improper point gap.	Adjust. *
	Faulty condenser.	Replace. *
	Leak at rotor cap and rotor.	Clean or replace.
	Faulty spark plug.	Clean, adjust plug gap or replace.
	Improper ignition timing.	Adjust.
	Faulty ignition coil.	Replace.
<b>Fuel system out of order</b>	Disconnection of high tension cable.	Replace.
	Loose connection or disconnection in primary circuit.	Repair or replace.
	Lack of fuel.	Supply.
	Dirty fuel strainer.	Replace.
	Dirty or clogged fuel pipe.	Clean.
	Fuel pump will not work properly.	Repair or replace.
	Carburetor choke will not work properly.	Check and adjust.
	Improper adjustment of float level.	Correct.
<b>Low compression</b>	Improper idling.	Adjust.
	Dirty or clogged carburetor.	Disassemble and clean.
	Clogged breather pipe of fuel tank.	Repair and clean.
	Malfunctioning anti-dieseling solenoid valve.	Check for loose terminal or wire harness.
	Incorrect spark plug tightening or faulty gasket.	Tighten to normal torque or replace gasket.
	Improper grade engine oil or low viscosity.	Replace with proper grade oil.
	Incorrect valve clearance.	Adjust.
	Compression leak from valve seat.	Remove cylinder head and lap valves.
	Sticky valve stem.	Correct or replace valve and valve guide.
	Weak or damaged valve springs.	Replace valve springs.
	Compression leak at cylinder head gasket.	Replace gasket.
	Sticking or damaged piston ring.	Replace piston rings.
	Worn piston ring or cylinder.	Overhaul engine.
(Trouble shooting procedure)		
Pour the engine oil from plug hole, and then measure cylinder compression.		
Compression increases.		Malfunctiong cylinder or piston ring.
Compression does not change.		Compression leaks from valve, cylinder head or head gasket.

\* Except transistor ignition system

## Engine Tune-up

Condition	Probable cause	Corrective action
<b>IMPROPER ENGINE IDLING</b>		
<b>Fuel system out of order</b>	<p>Clogged or damaged carburetor jets.</p> <p>Incorrect idle adjustment.</p> <p>Clogged air cleaner filter.</p> <p>Damaged manifold gaskets or carburetor insulator.</p> <p>Improper float level adjustment.</p> <p>Loose air hoses or air-fuel mixture hoses of carburetor.</p> <p>Malfunctioning carburetor choke.</p> <p>Malfunctioning anti-backfire valve.</p> <p>Malfunctioning automatic temperature control air cleaner.</p> <p>Inoperative idle compensator.</p> <p>Carbon canister purge line hose damaged or disconnected.</p> <p>Stick E.F.E. valve shaft.</p>	<p>Clean or replace.</p> <p>Adjust.</p> <p>Replace element.</p> <p>Replace gasket or insulator.</p> <p>Adjust.</p> <p>Check for loose connections.</p> <p>Check and adjust.</p> <p>Check for loose connection of vacuum hose.</p> <p>Check A.T.C. air cleaner.</p> <p>Check for connection of idle compensator hose or replace idle compensator.</p> <p>Connect or replace.</p>
<b>Low compression</b>		<p>Repair.</p> <p>Previously mentioned.</p>
<b>Others</b>	<p>Incorrect valve clearance.</p> <p>Extremely low revolution.</p> <p>Faulty malfunction of the ignition system (spark plug, high tension cable, breaker point, ignition coil, etc.).</p> <p>Incorrect basic ignition timing.</p> <p>Malfunction of choke valve or linkage.</p> <p>Malfunction of vacuum motor, sensor or hoses of air cleaner.</p> <p>Incorrect idle adjustment.</p> <p>Clogged air cleaner filter.</p> <p>Malfunction of idle compensator of air cleaner.</p> <p>Malfunction of E.G.R. control valve.</p> <p>Loose manifold and cylinder head bolts.</p>	<p>Adjust.</p> <p>Adjust.</p> <p>Replace.</p> <p>Adjust.</p> <p>Adjust.</p> <p>Check for loose hoses. Replace system components if necessary.</p> <p>Adjust idle speed.</p> <p>Replace air cleaner filter.</p> <p>Replace.</p> <p>Clean or replace.</p> <p>Retighten bolts.</p>
<b>High engine idle speed.</b>	<p>Dragged accelerator linkage.</p> <p>Incorrect idle adjustment.</p> <p>Malfunction of B.C.D.D. system.</p> <p>Malfunction of speed switch and harness.</p>	<p>Check and correct accelerator linkage.</p> <p>Adjust idle speed.</p> <p>Check for loose vacuum hose and harness connections.</p> <p>Adjust or replace if necessary.</p> <p>Check for loose connections. Repair or replace if necessary.</p>

## Engine Tune-up

Condition	Probable cause	Corrective action
<b>ENGINE POWER NOT UP TO NORMAL</b>		
<b>Low compression</b>		Previously mentioned.
<b>Ignition system out of order</b>	Incorrect ignition timing. Damaged spark plugs. Worn distributor points. *	Adjust. Clean, adjust or replace plugs. Dress, or replace points. Also check condenser.
<b>Fuel system out of order</b>	Malfunction of choke system. Clogged fuel pipe or floating valve. Dirty or clogged fuel strainer. Fuel pump will not work properly. Clogged carburetor jets. Malfunction of altitude compensator.	Adjust. Clean. Replace. Repair or replace. Disassemble and clean. Check and replace.
<b>Air intake system out of order</b>	Clogged air cleaner. Air inhaling from manifold gasket or carburetor gasket.	Replace element. Replace gasket.
<b>Emission control</b>	Malfunction of E.G.R. valve. Stick E.F.E. valve shaft.	Check and replace. Repair.
<b>Overheating</b>	Insufficient coolant. Loose fan belt. Worn or oiled fan belt. Inoperative thermostat. Worn water pump. Clogged or leaky radiator. Worn radiator filler cap. Air in cooling system. Improper engine oil grade Incorrect ignition timing. Clogged carburetor (lean mixture). Disconnected altitude compensator hose.	Replenish. Adjust fan belt. Replace. Replace. Replace. Flush, repair or replace. Replace. Retighten each part of cooling system. Replace with proper grade oil. Adjust. Overhaul carburetor. Connect.
<b>Overcooling</b>	Inoperative thermostat.	Replace.
<b>Others</b>	Improper octane fuel. Improper tire pressure. Dragging brake. Clutch slipping.	Replace with specified octane fuel. Inflate to specified pressure. Adjust. Adjust.

\* Except transistor ignition system



## Engine Tune-up

Condition	Probable cause	Corrective action
<b>NOISY ENGINE</b> <b>Car knocking</b>	Overloaded engine. Carbon knocking.  Timing knocking. Fuel knocking. Preignition (misusing of spark plug).	Use right gear in driving. Disassemble cylinder head and remove carbon. Adjust ignition timing. Use specified octane fuel. Use specified spark plug.
<b>Mechanical knocking</b>  <b>Crankshaft bearing knocking.</b>	This strong dull noise increases when engine is accelerated. To locate the place, cause a misfire on each cylinder. If the noise stops by the misfire, this cylinder generates the noise.	This is caused by worn or damaged bearings, or unevenly worn crankshaft. Renew bearings and adjust or change crankshaft. Check lubrication system.
<b>Connecting rod bearing knocking.</b>	This is a little higher-pitched noise than the crankshaft knocking, and also increases when engine is accelerated. Cause a misfire on each cylinder and if the noise diminishes almost completely, this crankshaft bearing generates the noise.	Same as the case of crankshaft bearings.
<b>Piston and cylinder noise.</b>	When you hear an overlapping metallic noise which increases its magnitude with the revolution of engine and which decreases as engine is warmed up, this noise is caused by piston and cylinder. To locate the place, cause a misfire on each cylinder.	This may cause an abnormal wearing of cylinder and lower compression which in turn will cause a lower out-put power and excessive consumption of oil.  Overhaul engine.
<b>Piston pin noise.</b>	This noise is heard at each highest and lowest dead end of piston. To locate the place, cause a misfire on each cylinder.	This may cause a wear on piston pin, or piston pin hole. Renew piston and piston pin assembly.
<b>Water pump noise.</b>	This noise may be caused by worn or damaged bearings, or by the uneven surface of sliding parts.	Replace water pump with a new one.
<b>Air pump noise</b>	Damaged air pump.	Repair or replace.
<b>Others.</b>	An improper adjustment of valve clearance. Noise of timing chain. An excessive end-play on crankshaft. Noisy E.F.E. valve shaft.  Wear on clutch pilot bushing. Note: This noise will be heard when clutch is disengaged.	Adjust. Adjust the tension of chain. Disassemble engine and renew main bearing. Repair.  Renew bush and adjust drive shaft.

## Engine Tune-up

Condition	Probable cause	Corrective action
<b>ABNORMAL COMBUSTION</b> (backfire, afterfire run-on etc.)		
<b>Improper ignition timing</b>	Improper ignition timing. Improper heat range of spark plugs.	Adjust ignition timing. Use specified spark plugs.
<b>Fuel system out of order</b>	Damaged carburetor or manifold gasket. (backfire, afterfire) Clogged carburetor jet. Improper function of the float. Uneven idling. (Run on) Improperly adjusted B.C.D.D. set pressure. Malfunction of anti-dieseling solenoid valve. Malfunction of auto-choke.	Replace them with new parts. Disassemble carburetor and check it. Adjust the level, and check needle valve. Adjust. Adjust. Check or replace. Adjust.
<b>Faulty cylinder head, etc.</b>	Improperly adjusted valve clearance. Excess carbon in combustion chamber. Damaged valve spring (backfire, afterfire).	Adjust. Remove head and get rid of carbon. Replace it with a new one.
<b>Others</b>	Malfunction of A.T.C. air cleaner. Inoperative anti-backfire valve.	Check for loose vacuum hoses. Replace if necessary. Replace.
<b>EXCESSIVE OIL CONSUMPTION</b>		
<b>Oil leakage</b>	Loose oil drain plug. Loose or damaged oil pan gasket. Loose or damaged chain cover gasket. Worn oil seal in front and rear of crankshaft. Loose or damaged locker cover gasket. Improper tightening of oil filter. Loose or damaged oil pressure switch.	Tighten it. Renew gasket or tighten it. Renew gasket or tighten it. Renew oil seal. Renew gasket or tighten it (but not too much). Renew gasket and tighten it with the proper torque. Renew oil pressure switch or tighten it.
<b>Excessive oil consumption</b>	Cylinder and piston wear. Improper location of piston ring gap or reversely assembled piston ring. Damage piston rings. Worn piston ring groove and ring. Fatigue of valve oil seal lip. Worn valve stem.	Overhaul cylinder and renew piston. Remount piston rings. Renew rings. Repair or renew piston and cylinder. Renew piston and piston ring. Replace seal lip with a new one. Renew valve or guide.
<b>Others</b>	Inadequate quality of engine oil. Engine overheat.	Use the designated oil. Previously mentioned.

## Engine Tune-up

Condition	Probable cause	Corrective action
<b>POOR FUEL ECONOMY</b> <b>See the explanation of the power decrease</b> <b>Others</b>	Exceeding idling revolution. Inoperative acceleration recovery. Fuel leakage. Malfunction of B.C.D.D. Malfunction of A.T.C. air cleaner.	Adjust it to the designated rpm. Adjust it. Repair or tighten the connection of fuel pipes. Adjust. Check and replace.
<b>PROBLEM IN OTHER FUNCTIONS</b> <b>Decreased oil pressure</b>	Inadequate oil quality. Overheat. Worn oil pump regulator valve. Functional deterioration of oil pump. Blocked oil filter. Increased clearance in various sliding parts. Blocked oil strainer. Inoperative oil gauge pressure switch.	Use the designated oil. Previously mentioned. Disassemble oil pump and repair or renew it. Repair or replace it with a new one. Renew it. Disassemble and replace the worn parts with new ones. Clean it. Replace it with a new one.
<b>Excessive wear on the sliding parts</b>	Oil pressure decreases. Improper quality or contamination of oil. Damaged air cleaner. Overheat or overcool. Improper fuel mixture.	Previously mentioned. Exchange the oil with proper one and change element. Change element. Previously mentioned. Check the fuel system.
<b>Scuffing of sliding parts</b>	Decrease of oil pressure. Insufficient clearances. Overheat. Improper fuel mixture.	Previously mentioned. Readjust to the designated clearances. Previously mentioned. Check the fuel system.
<b>Floor temperature too high (California only)</b>	Problem in fuel system (Refer to "Inspection of Fuel System"). Problem in ignition system (Refer to "Inspection of Ignition System").	Check and repair. Check and repair.

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

## SECTION EM

EM

# ENGINE MECHANICAL

GENERAL DESCRIPTION .....	EM- 2
ENGINE DISASSEMBLY .....	EM- 4
INSPECTION AND REPAIR .....	EM- 8
ENGINE ASSEMBLY .....	EM-21
SERVICE DATA AND SPECIFICATIONS .....	EM-27
TROUBLE DIAGNOSES AND CORRECTIONS .....	EM-31
SPECIAL SERVICE TOOLS .....	EM-33

# GENERAL DESCRIPTION

## CONTENTS


MODEL L20B ENGINE .....	EM-2	CAMSHAFT .....	EM-3
CYLINDER BLOCK .....	EM-3	VALVE MECHANISM .....	EM-3
CRANKSHAFT .....	EM-3	CAMSHAFT DRIVE .....	EM-3
PISTON AND CONNECTING ROD .....	EM-3	MANIFOLDS .....	EM-3
CYLINDER HEAD .....	EM-3		

## MODEL L20B ENGINE

The L20B engine features O.H.C. valves, wedge-shaped combustion chamber, aluminum head and a fully balanced 5-bearing crankshaft to turn

out smooth, dependable power.

The cylinder block is cast as a single unit, and features deep skirting. This engine is equipped with a single, 2-barrel downdraft carburetor that incorporates a special device to control emissions.



EM535

Fig. EM-1 Cross sectional view

### Main specifications

		L20B
Displacement	cc (cu in)	1,952 (119.1)
Bore x stroke	mm (in)	85 x 86 (3.35 x 3.39)
Compression ratio		8.5
Ignition timing Degree B.T.D.C./rpm	M/T	12/750 (Non-California model) 10/750 (California model)
	A/T	12/650 in "D" position


M/T: Manual Transmission

A/T: Automatic Transmission

## CYLINDER BLOCK

The cylinder block, a monoblock special casting structure, employs a five-bearing-support system for quietness and higher durability.

The cylinder bores are surrounded by cooling jackets and machined directly in the block. The oil ways in the block are arranged so that the full-flow oil filter is directly attached to the right hand side of the block.



EM536


Fig. EM-2 Cylinder block

## CRANKSHAFT

The crankshaft is a special steel forging. Fully balanced, it turns out smooth, dependable power at high speed.

The L20B engine uses eight balance weights.

Main bearings are lubricated by oil pumped through the main oil gallery and the oil holes which run in parallel with cylinder bores. There are oilways drilled in the crankshaft for the lubricating oil. The center main bearing is equipped with thrust washers to take up end thrust of the crankshaft.




EM079  
Fig. EM-3 Crankshaft

## PISTON AND CONNECTING ROD

The pistons are of a special aluminum casting and have struts to control thermal expansion, two compression rings and one combined oil ring. The piston heads are slightly dished. The piston pins are a special hollow steel shaft. They are full-floating fit to the piston and press fit to the connecting rods.


The connecting rods are of a special forged steel. Oil is sprayed to the connecting rod small ends through drilled passages in the large ends of rod. Oil holes in the connecting rods are located so as to insure optimum lubrication under heavy load.



EM080  
Fig. EM-4 Piston and connecting rod

## CYLINDER HEAD

The cylinder head is made of a light, strong aluminum alloy with good cooling efficiency; it contains wedge type combustion chambers. A special aluminum bronze valve seat is used on the intake valve, while a heat resistant steel valve seat is installed on the exhaust valve. These parts are all hot press-fitted.




EM407  
Fig. EM-5 Cylinder head

## CAMSHAFT

The camshaft is made of a special cast iron and is located inside the rocker cover. Four aluminum alloy brackets support it. Camshaft bearings are lubricated from oil holes which lead to the main oil gallery of the cylinder head.

Concentric passages are drilled in the front and rear parts of the camshaft.

Oil to each cam lobe is supplied through an oil hole drilled in the base circle of each lobe. Lubricant is supplied to the front oil gallery from the 2nd camshaft bearing and to the rear oil gallery from the 3rd camshaft bearing. These holes on the base circle of the lobe supply lubricant to the cam pad surface of the rocker arm and to the valve tip end. The cams feature a long-overlap profile to reduce NOx emission.




EM082  
Fig. EM-6 Camshaft

## VALVE MECHANISM

The valve system has the pivot type rocker arms that are activated directly by the cam mechanism; this has made its moving parts considerably lighter and provides ideal high speed performance.


Dual type valve springs are installed.



Exhaust Intake EM084  
Fig. EM-7 Valve mechanism

## CAMSHAFT DRIVE

The camshaft is driven by a double row roller chain driven by the crankshaft. The tension of the chain is controlled by a chain tensioner which is operated by spring and oil pressure. The rubber shoe type tensioner damps vibration of the chain and controls its tension.




EM537  
Fig. EM-8 Chain driving system

## MANIFOLDS

The intake manifold is of an aluminum cast alloy.

The exhaust manifold is of a dual design and incorporates a heat control valve in it. The heat control valve is used to warm the intake manifold.

A plate is installed on the outer face of the manifold to draw hot intake air out through it. The exhaust pipe is connected to the flanged surface of the exhaust manifold.



EM530  
Fig. EM-9 Intake and exhaust manifolds

# ENGINE DISASSEMBLY

## CONTENTS

PRELIMINARY CLEANING AND INSPECTION .....	EM-4
DISASSEMBLY .....	EM-4

PISTONS AND CONNECTING RODS .....	EM-7
CYLINDER HEAD .....	EM-7

## PRELIMINARY CLEANING AND INSPECTION

Before disassembling engine, note the following:

1. Fuel, oil or water may leak past cylinder head and block. Prior to disassembling, check cylinder head,

front chain cover, oil pan and oil filter gaskets and crankshaft and water pump seals for signs of leakage past their gasketed surfaces.

2. Check carburetor and fuel pump for condition; fuel hoses for deterioration, cracks or leakage of fuel past their jointed or connected surfaces.


6. Remove air pump drive belt, cooler compressor and idler pulley (if so equipped).

7. Remove starter motor from transmission.

8. Visually inspect cylinder head, cylinder block, rocker cover, front chain cover, oil pan and all other outer parts for oil, water and fuel leaks, breakage or missing parts such as bolts and nuts.

9. Check piping and electrical circuits for deterioration, breakage, fittings, discontinuity or insulation.

- 1 Thermal vacuum valve
- 2 Check valve
- 3 Altitude compensator (in air cleaner)
- 4 Air gallery pipe
- 5 Auto-choke
- 6 Automatic temperature control air cleaner
- 7 Anti-Backfire valve (A.B. valve)
- 8 Boost Controlled Deceleration Device (B.C.D.D.)
- 9 P.C.V. valve
- 10 Air relief valve
- 11 E.G.R. control valve
- 12 B.C.D.D. control valve and solenoid valve
- 13 Emergency air relief valve
- 14 Air pump air cleaner
- 15 Carbon canister
- 16 Air control valve
- 17 Air pump



ET366

Fig. EM-10 Emission control devices (California models)

3. Remove carburetor air cleaner.
  - Remove fresh air duct.
  - Disconnect hot air duct from air cleaner.
  - Disconnect air cleaner-to-air pump hose at air cleaner.
  - Disconnect air cleaner-to-rocker cover hose at rocker cover.
  - Disconnect air cleaner-to-air control valve hose at air cleaner (California models only).

- Disconnect air cleaner-to-A.B. valve hose at air cleaner.
- Disconnect air cleaner-to-related part vacuum hoses at air cleaner.
- Loosen air cleaner band bolt and remove carburetor air cleaner assembly from carburetor.

4. Plug up carburetor air-horn to prevent entry of foreign matter.

5. Remove alternator drive belt, alternator and alternator bracket.

## DISASSEMBLY

To remove engine from vehicle, refer to the instructions under the "Engine Removal and Installation" (ER) section.

1. Remove transmission from engine.

2. Remove clutch assembly from flywheel.

3. Thoroughly drain engine oil and coolant by removing drain plugs.

Store engine oil and coolant, if they are to be used again.

4. Place engine assembly on engine stand.

- (1) Remove cooling fan.

- (2) Remove right engine mounting bracket.

- (3) Remove oil filter with Oil Filter Wrench ST19320000.


- (4) Remove oil pressure switch.

- (5) Install engine attachment to cylinder block utilizing bolt holes in alternator bracket and water drain hole.

- (6) Set engine on stand.


"Engine Attachment  
ST05260001"

"Engine Stand  
ST0501S000"




**Fig. EM-11 Engine on engine stand**

5. Remove oil level gauge.
6. Remove carburetor from intake manifold.
- (1) Disconnect cylinder block-to-P.C.V. valve hose at P.C.V. valve.
- (2) Disconnect A.B. valve-to-E.G.R. passage hose at E.G.R. passage.
- (3) Disconnect vacuum tube-to-carburetor hoses (white and yellow) at vacuum tube.
- (4) Disconnect fuel hose from carburetor.
- (5) Remove dash pot bracket from intake manifold.
- (6) Remove carburetor attaching bolts and remove carburetor assembly and gasket.
7. Disconnect distributor high tension cables from spark plugs.
8. Disconnect vacuum hose from distributor and remove distributor assembly.
9. Disconnect fuel hose from fuel pump and remove fuel and vacuum hoses (combined) from cylinder head.
10. Remove fuel pump assembly from cylinder head.




**Fig. EM-12 Removing fuel pump**

11. Remove intake and exhaust manifold assembly from cylinder head.
- (1) Disconnect vacuum hose from air control valve and remove air control valve (for California) and air hoses as an assembly.




**Fig. EM-13 Removing air control valve (California models)**

- (2) Remove carburetor air cleaner bracket.
- (3) Disconnect vacuum hose from E.G.R. valve.
- (4) Remove check valve from air gallery pipe.
- (5) Disconnect E.G.R. tube from E.G.R. passage and exhaust manifold.
- (6) Remove E.G.R. passage and E.G.R. valve from intake manifold.



**Fig. EM-14 Removing E.G.R. tube and passage**


- (7) Remove F.I.C.D. bracket from cylinder head (if so equipped).
- (8) Disconnect vacuum hoses from thermal vacuum valve and remove thermostat housing and gasket from cylinder head.



**Fig. EM-15 Removing thermostat housing**

- (9) Remove cylinder block-to-P.C.V. valve hose (blow-by gas hose) from cylinder block.


- (10) Remove manifold attaching bolts and remove intake and exhaust manifold assembly and gasket from cylinder head.



**Fig. EM-16 Removing intake and exhaust manifold assembly**

- (11) Remove intake and exhaust manifold attaching bolts and separate intake manifold from exhaust manifold.
- (12) Remove air gallery pipes from exhaust manifold.
12. Remove left engine mounting bracket from cylinder block.
13. Remove air pump and cooler compressor bracket.
14. Remove crankshaft pulley installing bolt and washer and then remove pulley with a two-jaw puller.
15. Remove water pump assembly.
16. Remove rocker cover.
17. Remove spark plugs.
18. Remove fuel pump drive cam.
19. Remove camshaft sprocket.

Refer to the following note during operation when removing camshaft sprocket from engine installed on car.



**Fig. EM-17 Removing camshaft sprocket**



28. Remove cylinder head assembly. Use Cylinder Head Bolt Wrench ST10120000 to remove cylinder head bolts. Loosen bolts from ① to ⑩ as shown in Figure EM-18.




Fig. EM-18 Cylinder head bolt loosening sequence

Notes: When removing cylinder head from engine installed on car, follow the instructions below.

- Turn crankshaft until No. 1 piston is at T.D.C. on its compression stroke.
  - Remove rocker cover and fuel pump.
  - To facilitate assembling operation, scribe a mark on timing chain and camshaft sprocket with paint before removal.
  - Loosen camshaft bolt and remove fuel pump drive cam.
  - Support timing chain by utilizing Chain Stopper ST17420001 between timing chains as shown in Figure EM-19.
- This operation eliminates the problem of realigning timing marks on timing chain and crankshaft sprocket.




Fig. EM-19 Supporting timing chain

- Remove camshaft sprocket.
- Loosen cylinder head bolts and remove cylinder head.

- Invert engine.
- Remove oil pan and oil strainer.




Fig. EM-20 Removing oil strainer and oil pump

- Remove oil pump and its drive spindle. See Figure EM-20.
- Remove front cover.
- Remove chain tensioner and chain slack side guide.




Fig. EM-21 Removing chain tensioner and timing chain

- Remove timing chain. See Figure EM-21.
- Remove oil thrower, crankshaft worm gear and chain drive sprocket.




Fig. EM-22 Removing chain drive sprocket

36. Remove piston and connecting rod assembly. Extract connecting rod bearings, keeping them in order.




Fig. EM-23 Removing piston and connecting rod assembly

37. Remove flywheel and rear plate. Be careful not to drop them.




Fig. EM-24 Removing flywheel

38. Remove main bearing caps. Use Crankshaft Main Bearing Cap Puller KV101041S0 to remove center and rear main bearing caps. Keep them in order.




Fig. EM-25 Removing rear main bearing cap

- Remove two side seals from rear main bearing cap.
- Remove rear oil seal.




Fig. EM-26 Removing rear oil seal

41. Remove crankshaft.
42. Remove baffle plate and cylinder block net.




Fig. EM-27 Removing baffle plate and net

## PISTONS AND CONNECTING RODS

1. Remove piston rings with a ring remover.




Fig. EM-28 Removing piston rings

2. Press piston pin out with Piston Pin Press Stand ST13030001.




Fig. EM-29 Removing piston pin

3. Keep disassembled parts in order.

## CYLINDER HEAD

1. Remove valve rocker springs. Loosen valve rocker pivot lock nut and remove rocker arm by pressing valve spring down.




Fig. EM-30 Removing rocker arms

2. Remove locate plate, and remove camshaft.




Fig. EM-31 Removing camshaft

Note: Be careful not to damage camshaft bearings and cam lobes.

3. Remove valves using Valve Lifter ST12070000.





Fig. EM-32 Removing valves

### Notes:

- a. Take care not to lose valve spring seat, oil seal, valve collet, and valve rocker guide.
- b. Be sure to keep camshaft bearings intact, or the bearing center is liable to come out of alignment.



Exhaust Intake

Fig. EM-33 Valve components

# INSPECTION AND REPAIR

## CONTENTS

PREPARATION FOR INSPECTION .....	EM- 8	PISTONS, PISTON PINS AND	
CYLINDER HEAD AND VALVE .....	EM- 8	PISTON RINGS .....	EM-15
CHECKING CYLINDER HEAD MATING		CONNECTING ROD .....	EM-16
FACE .....	EM- 8	CRANKSHAFT .....	EM-16
VALVE ASSEMBLY .....	EM- 8	BUSHING AND BEARING .....	EM-17
VALVE SPRING .....	EM- 9	MEASUREMENT OF MAIN BEARING	
ROCKER ARM AND VALVE ROCKER		CLEARANCE .....	EM-17
PIVOT .....	EM-10	MEASUREMENT OF CONNECTING ROD	
VALVE GUIDE .....	EM-10	BEARING CLEARANCE .....	EM-18
VALVE SEAT INSERTS .....	EM-11	FITTING BEARINGS .....	EM-18
CAMSHAFT AND CAMSHAFT BEARING ....	EM-12	MISCELLANEOUS COMPONENTS .....	EM-19
CAMSHAFT BEARING CLEARANCE .....	EM-12	CRANKSHAFT AND CAMSHAFT	
VALVE TIMING .....	EM-12	SPROCKETS .....	EM-19
CAMSHAFT ALIGNMENT .....	EM-13	CHAIN TENSIONER AND CHAIN GUIDE .	EM-20
CYLINDER BLOCK .....	EM-13	FLYWHEEL .....	EM-20
HOW TO MEASURE CYLINDER BORE ...	EM-13	FRONT COVER AND REAR OIL SEAL ...	EM-20
CYLINDER BORING .....	EM-14		

## PREPARATION FOR INSPECTION

1. Before cleaning, check for signs of water and oil leaks in cylinder block and head.
2. Clean oil, carbon deposits and sealant from all parts. Remove gasket.
3. Clean all oil holes with solvent and dry with compressed air. Make sure that they are not restricted.

Note: Never remove camshaft bearings unless you have a suitable machine for boring camshaft bearing in line. If you once remove camshaft bearings, bearing centers will come out of alignment; reconditioning is very difficult without center borings.


1. Make a visual check for cracks and flaws.
2. Measure the surface of cylinder head (on cylinder block side) for warpage. If it is found to be beyond the limit designated below, regrind the affected surface with a surface grinder.

### Head surface flatness

Standard	Maximum
less than 0.05 mm (0.0020 in)	0.1 mm (0.0039 in)


## CYLINDER HEAD AND VALVE

### CHECKING CYLINDER HEAD MATING FACE



EM407

Fig. EM-34 Cylinder head




EM108

Fig. EM-35 Checking cylinder head surface

### VALVE ASSEMBLY

1. Check each intake and exhaust valve for worn, damaged or deformed valve caps or stems. Correct or replace any valve that is faulty.
2. Valve face or valve stem end surface should be refaced with a valve grinder.



EM109

Fig. EM-36 Intake and exhaust valve dimensions

H	Valve head diameter mm (in)	In.	42.0 to 42.2 (1.654 to 1.661)
		Ex.	35.0 to 35.2 (1.378 to 1.386)
L	Valve length mm (in)	In.	114.9 to 115.2 (4.524 to 4.535)
		Ex.	115.7 to 116.0 (4.555 to 4.567)
D	Valve stem diameter mm (in)	In.	7.965 to 7.980 (0.3136 to 0.3142)
		Ex.	7.945 to 7.960 (0.3128 to 0.3134)
$\alpha$	Valve seat angle Intake and Exhaust	In.	45°30'
		Ex.	45°30'




Fig. EM-37 Checking valve stem diameter




Fig. EM-38 Regrinding valve face

Note: When valve head has been worn down to 0.5 mm (0.0197 in) in thickness, replace the valve. Grinding allowance for valve stem end surface is 0.5 mm (0.0197 in) or less.

## VALVE SPRING

1. Check valve spring for squareness using a steel square and surface plate. If spring is out of square more than 1.6 mm (0.063 in), replace.
2. Measure the free length and tension of each spring. If the measured value exceeds specified limit, replace spring.




Fig. EM-39 Measuring spring squareness




Fig. EM-40 Measuring spring tension

## Spring specifications

Valve spring free length	mm (in)	
Intake and exhaust		
Outer		49.98 (1.968)
Inner		44.85 (1.766)
Valve spring pressured length (valve open)	mm/kg (in/lb)	
Intake and exhaust		
Outer		29.5/49.0 (1.161/108)
Inner		24.5/25.5 (0.965/56.2)
Valve spring assembled height (valve close)	mm/kg (in/lb)	
Intake and exhaust		
Outer		40.0/21.3 (1.575/47.0)
Inner		35.0/12.3 (1.378/27.1)

## ROCKER ARM AND VALVE ROCKER PIVOT

Check pivot head and cam contact and pivot contact surfaces of rocker arm for damage or wear. If damage is found, replace them. A faulty pivot must be replaced together with its corresponding rocker arm.

## VALVE GUIDE

Measure clearance between valve guide and valve stem. If clearance exceeds designated limit, replace worn parts or both valve and valve guide. In this case, it is essential to determine if such a clearance has been caused by a worn or bent valve stem or by a worn valve guide.




Fig. EM-41 Service valve guide


	Intake valve	Exhaust valve
Stem to guide clearance mm (in)	0.020 to 0.053 (0.0008 to 0.0021)	0.040 to 0.073 (0.0016 to 0.0029)
Maximum limit of above clearance mm (in)	0.1 (0.0039)	

## Replacement of valve guide

1. To remove old guides, use a drift and a press (under a 2-ton pressure) or a hammer.

Drive them out from combustion chamber side toward rocker cover. Heated cylinder head will facilitate the operation.

2. Ream cylinder head side guide hole at room temperature.




Unit: mm (in)

EM116

Fig. EM-43 Valve guide hole

As an emergency expedient, a valve can be pushed into valve guide and moved to the right and left. If its tip deflects about 0.2 mm (0.0079 in) or more, it indicates that the clearance between stem and guide exceeds the maximum limit of 0.1 mm (0.0039 in).

Note: Valve should be moved in parallel with rocker arm. (Generally, a large amount of wear occurs in this direction.)



EM115

Fig. EM-42 Measuring clearance between valve stem and valve guide

Guide hole inner diameter "a" mm (in)	For factory standard valve guide	11.985 to 11.996 (0.4718 to 0.4723)
	For service valve guide	12.185 to 12.196 (0.4797 to 0.4802)


3. Carefully press new valve guide into valve so that it will fit smoothly after heating cylinder head to 150 to 200°C (302 to 392°F).

Valve guide of 0.2 mm (0.0079 in) oversize diameter is available for service as indicated above.

Interference fit of valve guide to guide hole:  
0.027 to 0.049 mm  
(0.0011 to 0.0019 in)

Reaming bore:

8.000 to 8.018 mm  
(0.3150 to 0.3157 in)



EM419

Fig. EM-44 Reaming valve guide

4. Ream bore with valve guide pressed in, using Valve Guide Reamer Set KV101039S0.

- Correct valve seat surface with new valve guide as the axis.

## VALVE SEAT INSERTS

Check valve seat inserts for any evidence of pitting at valve contact surface, and reseal or replace if worn excessively.

Valve seat insert of 0.5 mm (0.0197 in) oversize is available for service as shown below.




Fig. EM-45 Correcting valve seat

## Replacing valve seat insert

- Old insert can be removed by boring it out until it collapses. The machine depth stop should be set so that boring cannot continue beyond the bottom face of the insert recess in cylinder head.
- Select a suitable valve seat insert and check its outside diameter.
- Machine cylinder head recess to the concentric circles in valve guide center so that insert will have the correct fit.
- Heat cylinder head to a temperature of 150 to 200°C (302 to 392°F).
- Fit insert ensuring that it beds on the bottom face of its recess, and caulk more than 4 points.
- Newly fitted valve seats should be cut or ground at the specified dimensions as shown in Figure EM-47.
- Apply small amount of fine grinding compound to valve contacting face and put valve into guide. Lap valve against its seat until proper valve seating is obtained. Remove valve and then clean valve and valve seat.

Intake	
Unit: mm (in)	EM573
Exhaust	
Unit: mm (in)	

Fig. EM-46 Service valve seat dimensions

## Cylinder head recess diameter

Unit: mm (in)

Intake	For factory standard insert	45.000 to 45.016 (1.7717 to 1.7723)
	For service insert	45.500 to 45.516 (1.7913 to 1.7920)
Exhaust	For factory standard insert	37.000 to 37.016 (1.4567 to 1.4573)
	For service insert	37.500 to 37.516 (1.4764 to 1.4770)

Interference fit mm (in)	Intake	0.081 to 0.113 (0.0032 to 0.0044)
	Exhaust	0.064 to 0.096 (0.0025 to 0.0038)





Fig. EM-47 Standard valve seat dimensions

## CAMSHAFT AND CAMSHAFT BEARING

### CAMSHAFT BEARING CLEARANCE

Measure inside diameter of camshaft bearing with an inside dial gauge and outside diameter of camshaft journal with a micrometer. If wear is found inside of bracket, replace cylinder head assembly.



EM119


Fig. EM-48 Checking camshaft bearing

### Camshaft journal to bearing clearance

	Standard	Wear limit
Oil clearance mm (in)	0.038 to 0.067 (0.0015 to 0.0026)	0.1 (0.0039)
Inner diameter of camshaft bearing mm (in)	48.000 to 48.016 (1.8898 to 1.8904)	—

## VALVE TIMING

This diagram applies to all cylinders. If any valve is found out of specifications, one possibility is that cam lobe is worn or damaged. This calls for replacement of camshaft.



EM421

Fig. EM-49 Valve timing diagram

	Standard	Bend limit
Camshaft bend mm (in)	0.02 (0.0008)	0.05 (0.0020)

## CAMSHAFT ALIGNMENT

1. Check camshaft, camshaft journal and cam surface for bend, wear or damage. If damage is beyond limits, replace affected parts.
2. A bend value is one-half of the reading obtained when camshaft is turned one full revolution with a dial gauge applied to 2nd and 3rd journals.




Fig. EM-50 Checking camshaft bend

Standard height of cam mm (in)	Intake	40.30 to 40.35 (1.5866 to 1.5886)
	Exhaust	
Wear limit of cam height	mm (in)	0.25 (0.0098)
Allowable difference in diameter between max. worn and min. worn parts of camshaft journal	mm (in)	0.05 (0.0020)
Maximum tolerance in journal diameter	mm (in)	0.1 (0.0039)
Camshaft end play	mm (in)	0.08 to 0.38 (0.0031 to 0.0150)

	Standard	Maximum tolerance
Surface flatness mm (in)	less than 0.05 (0.0020)	0.10 (0.0039)

## CYLINDER BLOCK

1. Visually check cylinder block for cracks or flaws.
2. Measure top of cylinder block (cylinder head mating face) for warpage. If warpage exceeds limits, correct it.




Fig. EM-51 Checking cylinder block surface

3. Using a bore gauge, measure cylinder bore for out-of-round or taper. If out-of-round or taper is excessive, re-bore cylinder walls with a boring machine. Measurement should be taken along bores for taper and around bores for out-of-round. See Figure EM-52.




Fig. EM-52 Measuring cylinder bore diameter

4. When wear, taper or out-of-round is minor and within limits, remove step at topmost portion of cylinder using a ridge reamer or other similar tool.

## HOW TO MEASURE CYLINDER BORE

A bore gauge is used. Measure cylinder bore at top, middle and bottom positions toward A and B directions as shown in Figure EM-53 and record the measured values.




Fig. EM-53 Cylinder bore measuring positions



		Standard	Wear limit
Cylinder bore mm (in)	Inner diameter	85.000 to 85.050 (3.3465 to 3.3484)	0.2 (0.0079)
	Out-of-round	0.015 (0.0006)	
	Taper	0.015 (0.0006)	
Difference in cylinder bore mm (in)		0.05 (0.0020)	0.2 (0.0079)

## CYLINDER BORING

1. When any cylinder needs boring, all other cylinders must also be bored at the same time.
2. Determine piston oversize according to amount of wear of cylinder.

### Oversize pistons specifications

Piston diameter mm (in)	
Service standard	84.985 to 85.035 (3.3459 to 3.3478)
0.50 (0.0197) Oversize	85.465 to 85.515 (3.3648 to 3.3667)
1.00 (0.0394) oversize	85.965 to 86.015 (3.3844 to 3.3864)




Fig. EM-55 Measuring piston skirt diameter

### Rebored size calculation

$$D = A + B - C = A + [0.005 \text{ to } 0.025 \text{ mm (0.0002 to 0.0010 in)}]$$

where,

D: Honed diameter

A: Skirt diameter as measured

B: Piston-to-wall clearance

C: Machining allowance (0.02 mm (0.0008 in))

Standard clearance	mm (in)	0.025 to 0.045 (0.0010 to 0.0018)
Feeler gauge	mm (in)	0.04 (0.0016)
Extracting force	kg (lb)	0.2 to 1.5 (0.44 to 3.31)

### Notes:

- a. To prevent strain due to cutting heat, bore the cylinders in the order of 2-4-1-3.
- b. Before boring any cylinder, install main bearing caps in place and tighten to the specification so that the crankshaft bearing bores will not become distorted from the boring operation.

4. Do not cut too much out of cylinder bore at a time. Cut only 0.05 mm (0.0020 in) or so in diameter at a time.


5. Measurement of a just machined cylinder bore requires utmost care since it is expanded by cutting heat.

6. As a final step, cylinders should be honed to size.

7. Measure the finished cylinder bore for out-of-round or tapered part.

8. Measure piston-to-cylinder clearance.

This clearance can be checked easily by using a feeler gauge and a spring balance hooked on feeler gauge, measuring the amount of force required to pull gauge out from between piston and cylinder.



EM126

Fig. EM-54 Measuring piston diameter

## Notes:

- a. When measuring clearance, slowly pull feeler gauge straight upward.
- b. It is recommended that piston and cylinder be heated to 20°C (68°F).

## PISTONS, PISTON PINS AND PISTON RINGS

1. Remove carbon from piston and ring grooves with a carbon scraper and a curved steel wire. Clean out oil slots in bottom land of oil ring groove.
2. Check for damage, scratches and wear. Replace if necessary.
3. Measure side clearance of rings in ring grooves as each ring is installed. Side clearance should be as follows.




Fig. EM-56 Measuring piston fit in cylinder




Fig. EM-57 Measuring piston ring side clearance




Fig. EM-58 Measuring ring gap

## Notes:

- a. When piston ring only is to be replaced, without cylinder bore being corrected, measure gap at bottom of cylinder where wear is minor.
- b. Oversize piston rings are available for service.

## Oversize:

0.5 mm (0.0197 in) and  
1.0 mm (0.0394 in)

5. Measure piston pin hole in relation to outer diameter of pin. If wear exceeds limit, replace each piston pin together with the piston on which it is installed.
6. Determine the fitting of piston pin into piston pin hole to such an extent that it can be finger pressed at room temperature. This piston pin must be a tight press fit into connecting rod.




Fig. EM-59 Piston pin fitting

4. Push ring into cylinder with piston so as to place it squarely in cylinder; measure ring gap with a

feeler gauge.

Ring should be placed to diameter at upper or lower limit of ring travel.

## Side clearance

Unit: mm (in)

	Standard	Wear limit
Top ring	0.040 to 0.073 (0.0016 to 0.0029)	0.1 (0.0039)
Second ring	0.030 to 0.070 (0.0012 to 0.0028)	
Oil ring	—	—

## Ring gap

Unit: mm (in)

	Standard	Wear limit
Top ring	0.25 to 0.40 (0.0098 to 0.0157)	1.0 (0.0394)
Second ring	0.30 to 0.50 (0.0118 to 0.0197)	
Oil ring	0.30 to 0.90 (0.0118 to 0.0354)	




Fig. EM-60 Measuring piston pin diameter

Unit: mm (in)

## CRANKSHAFT

1. Whenever crankshaft is removed from engine, it should be cleaned thoroughly in a suitable solvent. After cleaning, check crankshaft journal and crank pin for score, bias wear or cracks. Repair or replace as required. If damage is minor, dress with fine crocus cloth.


2. Check journals and crank pins for taper and out-of-round with a micrometer. Measurement should be taken along journals for taper and around journals for out-of-round. See Figure EM-63 for detailed information.

If journals or crank pins are tapered or out-of-round beyond limits, replace with a new shaft.

## CONNECTING ROD

1. If a connecting rod has any flaw on either side of the thrust face or the large end, correct or replace it.

2. Check connecting rod for bend or torsion using a connecting rod aligner. If bend or torsion exceeds the limit, correct or replace.



EM133


Fig. EM-61 Checking rod alignment

	Standard	Maximum
Connecting rod bend or torsion (per 100 mm or 3.94 in length) mm (in)	0.03 (0.0012)	0.05 (0.0020)

3. When replacing connecting rod, select rod so that weight difference between new and old ones is within 7 gr (0.25 oz).

Do not use a combination of new and former connecting rod big end nuts and connecting rod bolts which affect specified weight variations.


4. Install connecting rods with bearings on to corresponding crank pins and measure thrust clearance. If measured value exceeds limit, replace.



EM134


Fig. EM-62 Checking big end play

	Standard	Maximum
Big end play mm (in)	0.2 to 0.3 (0.0079 to 0.0118)	0.6 (0.0236)



Out-of-round  
Taper

X-Y  
A-B



EM424

Fig. EM-63 Crankshaft and journal dimensions

	Standard	Maximum
Taper and out-of-round of journal and crank pin mm (in)	less than 0.01 (0.0004)	0.025 (0.0010)

3. Crankshaft bend can be checked by placing it on V-blocks and using a dial gauge with its indicating finger resting on center journal.




Fig. EM-64 Checking crankshaft bend

	Standard	Maximum
Crankshaft bend mm (in)	less than 0.05 (0.0020)	0.10 (0.0039)

**Note:** When measuring bend, use a dial gauge. Bend value is half of the reading obtained when crankshaft is turned one full revolution with a dial gauge attached to its center journal.

4. After regrounding crankshaft, finish it to the necessary size indicated on page EM-18 by using an adequate undersize bearing according to the extent of required repair.

5. Install crankshaft in cylinder block and measure crankshaft free end play.




Fig. EM-65 Checking crankshaft end play

	Standard	Wear limit
Crankshaft free end play mm (in)	0.05 to 0.18 (0.0020 to 0.0071)	0.3 (0.0118)

6. At the rear end of crankshaft, check crankshaft pilot bushing for wear or damage. Replace it if any fault is detected.

To replace crankshaft rear pilot bushing, proceed as follows:  
(1) Pull out bushing using Pilot Bushing Puller ST16610001.




Fig. EM-66 Pulling out pilot bushing

(2) Before installing a new bushing, thoroughly clean bushing hole. Press fit bushing so that its height above flange end is 4.5 to 5.0 mm (0.177 to 0.197 in). Do not oil bushing.




Fig. EM-67 Press-fitting new pilot bushing

## BUSHING AND BEARING

### MEASUREMENT OF MAIN BEARING CLEARANCE

1. Thoroughly clean all bearings and check for scratches, melting score or wear.

Replace bearings if any fault is detected.

2. Crankshaft journals and bearings should be clean and free from dust and dirt before oil clearance is measured.

3. Set main bearing on cap block.

4. Cut a plastigage to width of bearing and place it in parallel with crank pin, getting clear of the oil hole. Install cap on the assembly and tighten them together to the specified torque.

Tightening torque:

4.5 to 5.5 kg-m (33 to 40 ft-lb)




Fig. EM-68 Plastigage

Note: Do not turn crankshaft while plastigage is being inserted.

5. Remove cap, and compare width of the plastigage at its widest part with the scale printed in plastigage envelope.




Fig. EM-69 Measuring bearing clearance

## MEASUREMENT OF CONNECTING ROD BEARING CLEARANCE

1. Measure connecting rod bearing clearance in the same manner as above.

Tightening torque:  
4.5 to 5.5 kg-m (33 to 40 ft-lb)

## Bearing oil clearance

	Standard	Wear limit
Main bearing clearance mm (in)	0.020 to 0.062 (0.0008 to 0.0024)	0.12 (0.0047)
Connecting rod bearing clearance mm (in)	0.025 to 0.055 (0.0010 to 0.0022)	0.12 (0.0047)

2. If clearance exceeds specified value, replace bearing with an under-size bearing and grind crankshaft journal adequately.

3. Then, measure bearing crush "H" with a feeler gauge. See Figure EM-70. The standard bearing crush value is listed below.

## FITTING BEARINGS

Bearings are manufactured with crush to make bearing snug down into its bore. To measure this, proceed as follows:

1. Set main bearing in main bearing cap recess or cylinder block bearing recess correctly.
2. Lock one side of bearing and press other side until bearing back surface touches the recess.




Fig. EM-70 Checking bearing crush

## Bearing crush

All main bearings mm (in)	0 to 0.03 (0 to 0.0012)
All connecting rod bearings mm (in)	0.015 to 0.045 (0.0006 to 0.0018)

4. Handle connecting rod bearing in the same manner as above.

## Main bearing undersize

Unit: mm (in)

	Bearing top thickness	Crank journal diameter
STD	1.827 to 1.835 (0.0719 to 0.0722)	59.942 to 59.955 (2.3599 to 2.3604)
0.25 (0.0098) Undersize	1.952 to 1.960 (0.0769 to 0.0772)	59.692 to 59.705 (2.3501 to 2.3506)
0.50 (0.0197) Undersize	2.077 to 2.085 (0.0818 to 0.0821)	59.442 to 59.455 (2.3402 to 2.3407)
0.75 (0.0295) Undersize	2.202 to 2.210 (0.0867 to 0.0870)	59.192 to 59.205 (2.3304 to 2.3309)

## Connecting rod bearing undersize

Unit: mm (in)

	Bearing top thickness	Crank pin diameter
STD	1.493 to 1.506 (0.0588 to 0.0593)	49.961 to 49.974 (1.9670 to 1.9675)
0.25 (0.0098) Undersize	1.618 to 1.631 (0.0637 to 0.0642)	49.711 to 49.724 (1.9571 to 1.9576)
0.50 (0.0197) Undersize	1.743 to 1.756 (0.0686 to 0.0691)	49.461 to 49.474 (1.9473 to 1.9478)
0.75 (0.0295) Undersize	1.868 to 1.881 (0.0735 to 0.0741)	49.211 to 49.224 (1.9374 to 1.9379)


## MISCELLANEOUS COMPONENTS

### CRANKSHAFT AND CAMSHAFT SPROCKETS

1. Check tooth surface for flaws or wear. Replace sprocket if fault is found.
2. Install camshaft sprocket in position and check for runout. If it exceeds 0.1 mm (0.0039 in) total indicator reading, replace camshaft sprocket. Also check for end play.

Camshaft end play:

0.08 to 0.38 mm  
(0.0032 to 0.0150 in)




EM144

Fig. EM-72 Checking camshaft end play

3. Check chain for damage, excessive wear or stretch at roller links. Replace if faulty.


4. To properly adjust chain tension (or valve timing), camshaft sprocket has a cam locating plate and three location holes (Nos. 1, 2 and 3).

Camshaft sprocket is preset at No. 1 hole at the factory. If chain becomes loose, adjust it by setting camshaft sprocket at No. 2 hole. If chain is too loose, adjust it by setting camshaft sprocket at No. 3 hole.



EM148


Fig. EM-71 Checking camshaft sprocket runout



EM311

Fig. EM-73 Adjusting camshaft sprocket location

(1) Turn engine until No. 1 piston is at T.D.C. on its compression stroke. Determine whether camshaft sprocket location notch comes off the left end of the oblong groove on camshaft locating plate. (If the location notch is off the left end of the oblong groove, chain stretch is beyond limits.)



EM146


Fig. EM-74 Camshaft locating plate

(2) Turn engine until No. 1 piston is at T.D.C. on its compression stroke, setting camshaft on No. 2 location hole in camshaft sprocket. This No. 2 notch should then be on the right end of the oblong groove. When No. 2 hole is used, No. 2 timing mark must also be used. The amount of the modification is a 4° rotation of crankshaft.

(3) When modification becomes impossible even by transferring camshaft location hole, replace chain assembly.

## CHAIN TENSIONER AND CHAIN GUIDE

Check for wear and breakage. Replace if necessary.




EM147

Fig. EM-75 Camshaft drive mechanism

## FLYWHEEL

1. Check clutch disc contact surface with flywheel for damage or wear. Repair or replace if necessary.

2. Measure runout of clutch disc contact surface with a dial gauge. If it exceeds 0.15 mm (0.0059 in) total indicator reading, replace it.



EM426

Fig. EM-76 Checking flywheel deviation


3. Check tooth surfaces of ring gear for flaws or wear.

Replace if necessary.

## FRONT COVER AND REAR OIL SEAL

First check front cover and rear oil seal for worn or folded over sealing lip or oil leakage. If necessary, install a new seal. When installing a new seal, pay attention to mounting direction.

Note: It is good practice to replace oil seal whenever engine is overhauled.



EM150

Fig. EM-77 Oil seals of crankshaft

# ENGINE ASSEMBLY

## CONTENTS

PRECAUTIONS .....	EM-21	PISTON AND CONNECTING ROD .....	EM-22
CYLINDER HEAD .....	EM-21	ENGINE ASSEMBLY .....	EM-22


## PRECAUTIONS

1. Use thoroughly cleaned parts. Especially, make sure that oil holes are clear of foreign matter.
2. When installing sliding parts such as bearings, be sure to apply engine oil to them.
3. Use new packings and oil seals.
4. Do not reuse lock washers.
5. Keep tools and work benches clean.
6. Keep necessary parts and tools near at hand.
7. Be sure to follow specified tightening torque and order.
8. Applying sealant

Use sealant to eliminate water and oil leaks. Parts requiring sealant are:


- (1) Front cover and corners of cylinder block: See Figure EM-78.

Apply sealant at these points.



**Fig. EM-78 Applying sealant (Front cover and cylinder block)**


- (2) Main bearing cap and cylinder block: Each side of rear main bearing cap and each corner of cylinder block. See Figure EM-79.



**Fig. EM-79 Applying sealant (Main bearing cap and cylinder block)**

- (3) Cylinder block: Step portions at four mating surfaces (cylinder block to front chain cover and cylinder block to rear main bearing cap). See Figure EM-80.

**Note: Do not apply too much sealant.**




**Fig. EM-80 Applying sealant (Cylinder block)**

## CYLINDER HEAD

1. Valve assembly and valve spring  
Using Valve Lifter ST12070000, set valve spring seat in position, and fit valve guide with oil seal.

Assemble valve in the order shown below: valve, inner and outer valve springs, spring retainer, valve collet and valve rocker guide.



**Fig. EM-81 Installing valves**

**Notes:**

- a. Ensure that valve face is free from foreign matter.
- b. The L20B engine uses double type valve springs.

2. Valve rocker pivot assembly  
Screw valve rocker pivots joined with lock nuts into pivot bushing.
3. Camshaft assembly

Set locating plate and carefully install camshaft in cylinder head. Do not damage the bearing inside. Oblong groove of locating plate must be directed toward front side of engine.

Camshaft bracket tightening torque:


1.8 to 2.0 kg-m (13 to 15 ft-lb)

4. Install camshaft sprocket on camshaft and tighten it together with fuel pump drive cam to specified torque.

Tightening torque:

12 to 16 kg-m (87 to 116 ft-lb)


At this time, check camshaft end play.



**Fig. EM-82 Installing camshaft sprocket**



5. Install rocker arms by pressing valve springs down with a screwdriver.
6. Install valve rocker springs.
7. After assembling cylinder head, turn camshaft until No. 1 piston is at T.D.C. on its compression stroke.



EM155

Fig. EM-83 Assembling cylinder head


- b. Arrange so that oil jet of connecting rod big end is directed toward right side of cylinder block.
- c. Be sure to install piston in cylinders with notch mark of piston head toward front of engine.

## 2. Install piston rings

Install top and second rings in right position, with marked side up.

### Notes:

- a. Top ring is chromium-plated on liner contacting face.
- b. Second ring has larger taper surface than top ring.
- c. In the combined oil ring, upper rail is the same as lower one.



EM158

Fig. EM-86 Installing piston rings

3. Fix bearings on connecting rod and connecting rod cap.


Note: Clean back side of bearing carefully.

## ENGINE ASSEMBLY

1. The first step in engine assembly is to bolt Engine Attachment ST05260001 to right hand side of cylinder block. Next, install block on another Engine Stand ST0501S000 with engine bottom up.
2. Set main bearings at the proper portion of cylinder block.

Rear

Front



EM159

Fig. EM-87 Main bearings

3. Install baffle plate including cylinder block net.

### Notes:


- a. Only center bearing (No. 3) is a flanged type.
- b. All inter-bearings (No. 2 and No. 4) are the same type.
- c. Front bearing (No. 1) is also the same type as rear bearing (No. 5). The difference is that an oil hole is provided in the front bearing.
- d. All upper and lower bearings are interchangeable.
4. Apply engine oil to main bearing surfaces on both sides of cylinder block and cap and then install crankshaft.
5. Install main bearing cap and tighten bolts to specified torque.

Tightening torque:

4.5 to 5.5 kg-m (33 to 40 ft-lb)

### Notes:

- a. Apply sealant to each side of rear main bearing cap and each corner of cylinder block as shown in Figure EM-79.
- b. Arrange parts so arrow mark on bearing cap faces toward front of engine.
- c. Prior to tightening bearing cap bolts, place bearing cap in proper position by shifting crankshaft in the axial direction.
- d. Tighten bearing cap bolts gradually, in two to three stages outwardly from center bearing in the sequence as shown in Figure EM-88.
- e. After securing bearing cap bolts, ascertain that crankshaft turns smoothly.




EM543

Fig. EM-88 Torque sequence of cap bolts


## PISTON AND CONNECTING ROD

1. Assemble pistons, piston pins and connecting rods on the designated cylinder.



EM156

Fig. EM-84 Installing piston pin



EM157

Fig. EM-85 Assembling piston and connecting rod

### Notes:

- a. Piston is pressed into connecting rod, with fitting force of 0.5 to 1.5 tons; aid of Piston Pin Press Stand ST13030001 is necessary. When pressing piston pin into connecting rod, apply engine oil to pin and small end of connecting rod.

6. Make sure that crankshaft has proper end play.

Crankshaft end play:  
0.05 to 0.18 mm  
(0.0020 to 0.0071 in)




Fig. EM-89 Checking crankshaft end play

7. Install side oil seals into rear main bearing cap. Prior to installing, apply sealant to seals.




Fig. EM-90 Driving side oil seal

8. Install rear oil seal using Crankshaft Rear Oil Seal Drift ST15310000.




Fig. EM-91 Installing rear oil seal

Note: When installing oil seal, give coating of engine oil to mating shaft to prevent scratches and folded lip. Also give coating of oil to periphery of oil seal.

9. Install rear end plate.  
10. Install flywheel securely, and tighten bolts to specified torque.

Tightening torque:  
14 to 16 kg-m  
(101 to 116 ft-lb)

11. Insert pistons in corresponding cylinder using Piston Ring Compressor EM03470000.




Fig. EM-92 Installing piston-rod assembly

## Notes:

- Apply engine oil to sliding parts.
- Arrange so that notch mark on piston head faces to front of engine.
- Install piston rings at 180° to each other, avoiding their fit in the thrust and piston pin directions.




Fig. EM-93 Piston ring direction

12. Install connecting rod caps.

Tightening torque:  
4.5 to 5.5 kg-m (33 to 40 ft-lb)




Fig. EM-94 Installing connecting rod cap

Note: Install connecting rods and connecting rod caps so that their assigned numbers are positioned on the same side and in the same direction with respect to cylinders.

13. Make sure that connecting rod big end has proper end play.




Fig. EM-95 Checking big end play

Big end play:  
0.2 to 0.3 mm  
(0.008 to 0.012 in)

14. Install cylinder head assembly.




Fig. EM-96 Tightening sequence of cylinder head bolts

- (1) Thoroughly clean cylinder block and head surface.

Do not apply sealant to any other part of cylinder block and head surface.

(2) Turn crankshaft until No. 1 piston is at T.D.C. on its compression stroke.

(3) Make sure that camshaft sprocket location notch and plate oblong groove are aligned at their correct positions.

(4) When installing cylinder head, make sure that all valves are apart from heads of pistons.

(5) Do not rotate crankshaft and camshaft separately, or valves will hit heads of pistons.

(6) Temporarily tighten two bolts ①, ② shown in Figure EM-96.

Tightening torque:

2 kg-m (14 ft-lb)


15. Install crankshaft sprocket and oil pump drive gear, and fit oil thrower.

**Note:** Make sure that mating marks of crankshaft sprocket face to front.

16. Install timing chain.

**Notes:**

a. Make sure that crankshaft and camshaft keys point upwards.



- 1 Fuel pump drive cam
- 2 Chain guide
- 3 Chain tensioner
- 4 Crank sprocket
- 5 Cam sprocket
- 6 Chain guide

EM439

Fig. EM-97 Installing timing chain

b. Set timing chain by aligning its mating marks with those of crankshaft sprocket and camshaft sprocket at the right hand side. There are forty-four chain links between two mating marks of timing chain.


c. No. 2 hole is factory adjusted. When chain stretches excessively, adjust camshaft sprocket at No. 3 hole.

d. Use a set of timing marks and location hole numbers.

17. Install chain slack side guide to cylinder block.

18. Install chain tensioner.

**Note:** Adjust protrusion of chain tensioner spindle to 0 mm (0 in).



EM170

Fig. EM-98 Installing chain tensioner

19. Press new oil seal in front cover.


**Notes:**

a. Front cover oil seal should be replaced when front cover is disassembled.

b. Before pressing oil seal into front cover, give coating of engine oil to periphery of oil seal.

c. This oil seal is a threaded seal type which has improved sealing characteristics. Do not apply grease to sealing lip.

20. Install front cover with gasket in place.



- 1 Timing mark
- 2 Timing mark

EM545

Fig. EM-99 Installing front cover

**Notes:**


a. Apply sealant to front cover and corners of upper section of cylinder block as shown in Figure EM-78.

b. Install front cover with head gasket in place.

c. Check height difference between cylinder block upper face and front cover upper face. Difference must be less than 0.15 mm (0.0059 in).

d. Note that different types of bolts are used.

e. Before installing front cover on cylinder block, apply coating of engine oil to sealing lip of oil seal.



EM511

Fig. EM-100 Front cover bolts

Tightening torque:

Size M8 (0.315 in)

1.0 to 1.3 kg-m (7.2 to 9.4 ft-lb)

Size M6 (0.236 in)


0.4 to 0.6 kg-m (2.9 to 4.3 ft-lb)

21. Install crankshaft pulley and water pump assembly, then set No. 1 piston at T.D.C. on its compression stroke.

Crankshaft pulley nut

tightening torque:

12 to 16 kg-m (87 to 116 ft-lb)



EM546

Fig. EM-101 Installing crankshaft pulley and water pump

22. Finally, tighten head bolts to the specified torque in three steps according to the tightening sequence shown in Figure EM-96.

**Note:** that two types of bolts are used.

Special tool Cylinder Head Bolt Wrench ST10120000

Tightening torque:

1st turn

4.0 kg-m (29 ft-lb)

2nd turn

6.0 kg-m (43 ft-lb)

3rd turn

6.5 to 8.5 kg-m  
(47 to 61 ft-lb)




Fig. EM-102 Cylinder head bolts

Notes:

- Be sure to tighten two small bolts.
- After engine has been operated for several minutes retighten if necessary.

23. Install oil pump and distributor driving spindle in front cover.

Tightening torque:

1.1 to 1.5 kg-m  
(8.0 to 10.8 ft-lb)


Notes:

- Assemble oil pump and drive spindle, aligning driving spindle face with oil pump hole.
- Install oil pump together with drive spindle so that the projection on its top is located at the 11:25 a.m. position. At this point, the smaller bow-shape will be facing toward the front.
- Do not forget to install gasket.



EL009

Fig. EM-103 Setting distributor driving spindle



EL011

Fig. EM-104 Installing oil pump

24. Install fuel pump, water inlet elbow and front engine slinger in their positions.

Fuel pump tightening torque:

1.2 to 1.8 kg-m  
(8.7 to 13.0 ft-lb)

**Note:** Do not forget to install fuel pump spacer and packing between spacer and block, spacer and fuel pump.

25. Install oil strainer, oil pan gasket and oil pan.

Tightening torque:

Oil strainer bolts

0.8 to 1.1 kg-m (5.8 to 8.0 ft-lb)

Oil pan bolts

0.6 to 0.9 kg-m (4.3 to 6.5 ft-lb)

Notes:

- Apply sealant to the step portions at four mating surfaces as shown in Figure EM-80.

- Oil pan should be tightened in criss-cross pattern to a final torque of 0.6 to 0.9 kg-m (4.3 to 6.5 ft-lb).

26. Adjust valve clearance to the specified dimensions.

Special tool

Pivot Adjuster ST10640001

Tightening torque:

5.0 to 6.0 kg-m (36 to 43 ft-lb)

Notes:

- First set clearance to the cold specifications.




Fig. EM-105 Adjusting valve clearance

- After engine has been assembled, run it for at least several minutes, and finally adjust clearance to the warm specifications.

Valve clearance mm (in)	Cold	Intake	0.20 (0.008)
		Exhaust	0.25 (0.010)
	Warm	Intake	0.25 (0.010)
		Exhaust	0.30 (0.012)

27. Install rocker cover to cylinder head.

**Note:** Make sure that one of the rocker cover bolts is longer than the others. It secures F.I.C.D. assist bracket.

28. Install air pump bracket and cooler compressor to cylinder block.

29. Install intake manifold to exhaust manifold. The intake manifold face which comes into contact with gasket should be even with that of exhaust manifold. Note that two different sizes of attaching bolts are used.

Tightening torque:

2.5 kg-m (18.0 ft-lb)

30. Install heatshield plate on manifold assembly.
31. Install air gallery pipe on exhaust manifold.
32. Install manifold gasket and manifold assembly on cylinder head.

Tightening torque:


1.2 to 1.6 kg-m  
(8.7 to 11.6 ft-lb)

33. Install blow-by gas pipe on cylinder block and tighten with rear engine slinger.
34. Install thermostat housing gasket, thermostat housing and thermostat.
35. Install thermal vacuum valve on thermostat housing. Before installing, apply a liquid packing slightly to the threads.
36. Install F.I.C.D. bracket on cylinder head.
37. Install E.G.R. passage and E.G.R. valve on intake manifold.
38. Connect E.G.R. tube to E.G.R. tube and exhaust manifold.
39. Install check valve on air gallery pipe.
40. Install air cleaner bracket on intake manifold.
41. Install air control valve on air cleaner bracket (California models).
42. Install vacuum and fuel tubes (combined) on cylinder head.
43. Install distributor assembly.
44. Install heatshield plate, joint seat and carburetor.

Carburetor tightening torque:

0.5 to 1.0 kg-m (3.6 to 7.2 ft-lb)

Note: When installing joint seat, be sure to put the duct into primary hole in intake manifold.



- |                    |                  |
|--------------------|------------------|
| 1 Heatshield plate | 4 Joint seat     |
| 2 Primary hole     | 5 Secondary hole |
| 3 Duct             |                  |

EM534

Fig. EM-106 Installing carburetor joint seat

45. Install dash pot bracket and dash pot to intake manifold.
46. Connect all air, vacuum and fuel hoses and then secure with clamps.
  - (1) Cylinder block-to-P.C.V. valve hose
  - (2) A.B. valve-to-E.G.R. passage vacuum hose
  - (3) A.B. valve-to-E.G.R. passage air hose
  - (4) Vacuum tube-to-carburetor vacuum hoses
  - (5) Fuel tube-to-carburetor fuel hose
  - (6) Fuel tube-to-fuel pump fuel hose
  - (7) Distributor-to-vacuum switch (or spark delay valve) vacuum hose
  - (8) Air control valve vacuum hose
  - (9) Check valve-to-air control valve hose
  - (10) Thermal vacuum valve-to-E.G.R. valve vacuum hose
  - (11) Thermal vacuum valve-to-vacuum tube hose


47. Install carburetor air cleaner on carburetor and then connect air and vacuum hoses as follows:

- (1) Air cleaner-to-exhaust manifold hot air duct
- (2) Air cleaner-to-air pump hose
- (3) Air cleaner-to-rocker cover hose
- (4) Air cleaner-to-air control valve hose
- (5) Air cleaner-to-A.B. valve hose
- (6) Other vacuum hoses

48. Install spark plugs in place.
49. Connect all distributor high tension cables to spark plugs.
50. Install air pump, drive belt, cooler compressor and idler pulley.
51. Install left engine mounting bracket.
52. Install clutch assembly on flywheel with Clutch Aligning Bar KV30100200.

Tightening torque:

1.2 to 2.2 kg-m  
(8.7 to 15.9 ft-lb).



EM440

Fig. EM-107 Installing clutch assembly

53. Using an overhead hoist and lifting cable, hoist engine away from engine stand and then down onto engine carrier.

54. Install right engine mounting bracket, oil filter, oil pressure switch, oil level gauge and water drain plug. When installing oil filter, fasten it to cylinder block by hand.


Note: Do not overtighten filter, or oil leakage may occur.

55. Install alternator bracket adjusting bar, alternator, cooling fan and belt.

56. Adjust the deflection of drive belts when thumb pressure is applied midway between pulleys [A pressed force is above 10 kg (22.0 lb).]

Deflection of drive belts

8 to 12 mm  
(0.315 to 0.472 in)



EM613

Fig. EM-108 Fan belt tension

57. Fill engine oil up to specified level.

## SERVICE DATA AND SPECIFICATIONS

### GENERAL SPECIFICATIONS

Engine model .....	L20B
Cylinder arrangement .....	4, in-line
Displacement           cc (cu in) .....	1,952 (119.1)
Bore and stroke       mm (in) .....	85 x 86 (3.35 x 3.39)
Valve arrangement .....	O.H.C.
Firing order .....	1-3-4-2
Engine idle           rpm	
Manual transmission .....	750
Automatic transmission (in "D" range) .....	650
Compression ratio .....	8.5
Oil pressure (Warm at 2,000 rpm)	
kg/cm <sup>2</sup> (psi) .....	3.5 to 4.0 (50 to 57)

### SPECIFICATIONS

#### a) Valve mechanism

Valve clearance (Warm)	mm (in)	
Intake .....		0.25 (0.010)
Exhaust .....		0.30 (0.012)
Valve clearance (Cold)	mm (in)	
Intake .....		0.20 (0.008)
Exhaust .....		0.25 (0.010)
Valve head diameter	mm (in)	
Intake .....		42.0 to 42.2 (1.654 to 1.661)
Exhaust .....		35.0 to 35.2 (1.378 to 1.386)
Valve stem diameter	mm (in)	
Intake .....		7.965 to 7.980 (0.3136 to 0.3142)
Exhaust .....		7.945 to 7.960 (0.3128 to 0.3134)
Valve length	mm (in)	
Intake .....		114.9 to 115.2 (4.524 to 4.535)
Exhaust .....		115.7 to 116.0 (4.555 to 4.567)
Valve lift	mm (in)	
Intake and exhaust .....		10.5 (0.413)
Valve spring out-of-square	mm (in) .....	less than 1.6 (0.063)
Valve spring free length	mm (in)	
Intake and exhaust   Outer .....		49.98 (1.968)
Inner .....		44.85 (1.766)

## Engine Mechanical

Valve spring pressured length (valve open)	mm/kg (in/lb)	
Intake and exhaust		
Outer .....		29.5/49.0 (1.161/108)
Inner .....		24.5/25.5 (0.965/56.2)
Valve spring assembled height (valve close)	mm/kg (in/lb)	
Intake and exhaust		
Outer .....		40.0/21.3 (1.575/47.0)
Inner .....		35.0/12.3 (1.378/27.1)
Valve guide length	mm (in)	
Intake and exhaust .....		59.0 (2.323)
Valve guide height from head surface	mm (in)	10.6 (0.417)
Valve guide inner diameter	mm (in)	
Intake and exhaust .....		8.000 to 8.018 (0.3150 to 0.3157)
Valve guide outer diameter (service parts)	mm (in)	
Intake and exhaust .....		12.223 to 12.234 (0.4812 to 0.4817)
Valve guide to stem clearance	mm (in)	
Intake .....		0.020 to 0.053 (0.0008 to 0.0021)
Exhaust .....		0.040 to 0.073 (0.0016 to 0.0029)
Valve seat width	mm (in)	
Intake .....		1.4 to 1.6 (0.0551 to 0.0630)
Exhaust .....		1.8 to 2.2 (0.0709 to 0.0866)
Valve seat angle		
Intake and exhaust .....		45°
Valve seat interference fit	mm (in)	
Intake .....		0.081 to 0.113 (0.0032 to 0.0044)
Exhaust .....		0.064 to 0.096 (0.0025 to 0.0038)
Valve guide interference fit	mm (in)	0.027 to 0.049 (0.0011 to 0.0019)
<b>b) Camshaft and timing chain</b>		
Camshaft end play	mm (in)	0.08 to 0.38 (0.0032 to 0.0150)
Camshaft lobe lift	mm (in)	
Intake and exhaust .....		7.0 (0.276)
Camshaft journal diameter	mm (in)	
1st, 2nd, 3rd and 4th .....		47.949 to 47.962 (1.8877 to 1.8883)
Camshaft bend	mm (in)	0.02 (0.0008)
Camshaft journal to bearing clearance	mm (in)	0.038 to 0.067 (0.0015 to 0.0026)
Camshaft bearing inner diameter	mm (in)	
1st, 2nd, 3rd and 4th .....		48.000 to 48.016 (1.8898 to 1.8904)

## Engine Mechanical

### c) Connecting rod

Center distance	mm (in)	146 (5.748)
Bearing thickness (Standard)	mm (in)	1.493 to 1.506 (0.0588 to 0.0593)
Big end play	mm (in)	0.20 to 0.30 (0.008 to 0.012)
Connecting rod bearing clearance	mm (in)	0.025 to 0.055 (0.0010 to 0.0022)
Connecting rod bend or torsion (per 100 mm or 2.937 in)	mm (in)	less than 0.03 (0.0012)

### d) Crankshaft and main bearing

Journal diameter	mm (in)	59.942 to 59.955 (2.3599 to 2.3604)
Journal taper & out-of-round	mm (in)	less than 0.01 (0.0004)
Crankshaft free end play	mm (in)	0.05 to 0.18 (0.0020 to 0.0071)
Wear limit of dittoed play	mm (in)	0.3 (0.0118)
Crank pin diameter	mm (in)	49.961 to 49.974 (1.9670 to 1.9675)
Crank pin taper & out-of-round	mm (in)	less than 0.01 (0.0004)
Main bearing thickness (Standard)	mm (in)	1.827 to 1.835 (0.0719 to 0.0722)
Main bearing clearance	mm (in)	0.020 to 0.062 (0.0008 to 0.0024)
Wear limit of dittoed clearance	mm (in)	0.12 (0.0047)
Crankshaft bend	mm (in)	0.05 (0.0020)
Flywheel runout at clutch disc contact face	mm (in)	less than 0.15 (0.0059)

### e) Piston

Piston diameter (Service standard)	mm (in)	84.985 to 85.035 (3.3459 to 3.3478)
0.50 (0.0197) Oversize	mm (in)	85.465 to 85.515 (3.3648 to 3.3667)
1.00 (0.0394) Oversize	mm (in)	85.965 to 86.015 (3.3844 to 3.3864)
Ring groove width	mm (in)	
Top		2.030 to 2.050 (0.0799 to 0.0807)
Second		2.020 to 2.040 (0.0795 to 0.0803)
Oil		4.015 to 4.040 (0.1581 to 0.1591)
Piston to bore clearance	mm (in)	0.025 to 0.045 (0.0010 to 0.0018)
Piston pin hole off-set	mm (in)	0.95 to 1.05 (0.0374 to 0.0413)
Piston pin hole diameter	mm (in)	21.001 to 21.008 (0.8268 to 0.8271)

### f) Piston pin

Pin diameter	mm (in)	20.993 to 20.998 (0.8265 to 0.8267)
Pin length	mm (in)	72.25 to 73.00 (2.8445 to 2.8740)
Piston pin to piston clearance	mm (in)	0.008 to 0.010 (0.0003 to 0.0004)
Interference fit of piston pin to connecting rod bushing	mm (in)	0.015 to 0.035 (0.0006 to 0.0014)



## Engine Mechanical

### g) Piston ring

Ring height	mm (in)	
Top and second	.....	1.977 to 1.990 (0.0778 to 0.0783)
Side clearance	mm (in)	
Top	.....	0.040 to 0.073 (0.0016 to 0.0029)
Second	.....	0.030 to 0.070 (0.0012 to 0.0028)
Ring gap	mm (in)	
Top	.....	0.25 to 0.40 (0.0098 to 0.0157)
Second	.....	0.30 to 0.50 (0.0118 to 0.0197)
Oil	.....	0.30 to 0.90 (0.0118 to 0.0354)

### h) Cylinder block

Cylinder bore inner diameter	mm (in)	85.000 to 85.050 (3.3465 to 3.3484)
Wear limit of dittoed inner diameter	mm (in)	0.2 (0.0079)
Cylinder bore taper and out-of-round	mm (in)	0.015 (0.0006)
Difference in cylinder bore	mm (in)	0.05 (0.0020)
Surface flatness	mm (in)	less than 0.05 (0.0020)

### i) Cylinder head

Surface flatness	mm (in)	less than 0.05 (0.0020)
------------------	---------	-------------------------

## TIGHTENING TORQUE

Cylinder head bolts	kg-m (ft-lb)	6.5 to 8.5 (47 to 61)
Connecting rod big end nuts	kg-m (ft-lb)	4.5 to 5.5 (33 to 40)
Flywheel fixing bolts	kg-m (ft-lb)	14 to 16 (101 to 116)
Main bearing cap bolts	kg-m (ft-lb)	4.5 to 5.5 (33 to 40)
Camshaft bracket bolts	kg-m (ft-lb)	1.8 to 2.0 (13 to 15)
Camshaft sprocket bolt	kg-m (ft-lb)	12 to 16 (87 to 116)
Oil pan bolts	kg-m (ft-lb)	0.6 to 0.9 (4.3 to 6.5)
Oil pump bolts	kg-m (ft-lb)	1.1 to 1.5 (8.0 to 10.8)
Oil strainer bolts	kg-m (ft-lb)	0.8 to 1.1 (5.8 to 8.0)
Oil pan drain plug	kg-m (ft-lb)	2.0 to 3.0 (14 to 22)
Rocker pivot lock nuts	kg-m (ft-lb)	5.0 to 6.0 (36 to 43)
Camshaft locating plate bolts	kg-m (ft-lb)	0.6 to 0.9 (4.3 to 6.5)
Carburetor nuts	kg-m (ft-lb)	0.5 to 1.0 (3.6 to 7.2)
Manifold bolts	kg-m (ft-lb)	1.2 to 1.6 (8.7 to 11.6)
Fuel pump nuts	kg-m (ft-lb)	1.2 to 1.8 (8.7 to 13.0)
Crank pulley bolt	kg-m (ft-lb)	12 to 16 (87 to 116)
Water pump bolts	kg-m (ft-lb)	0.4 to 0.5 (2.9 to 3.6)
Front cover bolts	kg-m (ft-lb)	
	8 mm (0.315 in) dia.	1.0 to 1.3 (7.2 to 9.4)
	6 mm (0.236 in) dia.	0.4 to 0.6 (2.9 to 4.3)

## TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
<b>I. Noisy engine</b> Knocking of crankshaft and bearing	Loose main bearing. Seized bearing. Bent crankshaft. Uneven wear of journal. Excessive crankshaft end play.	Replace. Replace. Repair or replace. Correct. Replace center bearing.
Knocking of piston and connecting rod	Loose bearing. Seized bearing. Loose piston pin. Loose piston in cylinder. Broken piston ring. Improper connecting rod alignment.	Replace. Replace. Replace pin or bushing. Recondition cylinder. Replace. Realign.
Camshaft knocking	Loose bearing. Excessive axial play. Rough gear teeth. Broken cam gear.	Replace. Replace bearing thrust plate. Repair. Replace.
Timing chain noise	Improper chain tension. Worn and/or damaged chain. Worn sprocket. Worn and/or broken tension adjusting mechanism. Excessive camshaft and bearing clearance.	Adjust. Replace. Replace. Replace. Replace.
Camshaft and valve mechanism knocking	Improper valve clearance. Worn adjusting screw. Worn rocker face. Loose valve stem in guide. Weakened valve spring. Seized valve.	Adjust. Replace. Replace. Replace guide. Replace. Repair or replace.
Water pump knocking	Improper shaft end play. Broken impeller.	Replace. Replace.
<b>II. Other mechanical troubles</b> Stuck valve	Improper valve clearance. Insufficient clearance between valve stem and guide. Weakened or broken valve spring. Biting or damage of valve stem. Poor quality of fuel.	Adjust. Clean stem or ream guide. Replace. Replace or clean. Use good fuel.

## Engine Mechanical

Condition	Probable cause	Corrective action
Seized valve seat	Improper valve clearance. Weakened valve spring. Thin valve head edge. Narrow valve seat. Overheating. Over speeding. Stuck valve guide.	Adjust. Replace. Replace valve. Reface. Repair or replace. Drive at proper speeds. Repair.
Excessively worn cylinder and piston	Shortage of engine oil. Dirty engine oil.  Poor quality of oil. Overheating. Wrong assembly of piston with connecting rod. Improper piston ring clearance. Broken piston ring. Dirty air cleaner. Mixture too rich. Engine over run. Stuck choke valve. Overchoking.	Add or replace oil. Clean crankcase, replace oil and oil filter element. Use right oil. Repair or replace. Repair or replace.  Adjust. Replace. Clean. Adjust. Drive at proper speeds. Clean and adjust. Start correct way.
Faulty connecting rod	Shortage of engine oil. Low oil pressure. Poor quality of engine oil. Rough surface of crankshaft. Clogged oil passage. Bearing worn or eccentric. Bearing improperly assembled. Loose bearing. Connecting rod alignment incorrect.	Add oil. Correct. Use proper oil. Grind and replace bearing. Clean. Replace. Correct. Replace. Repair or replace.
Faulty crankshaft bearing	Shortage of engine oil. Low oil pressure. Poor quality of engine oil. Crankshaft journal worn or out-of-round. Clogged oil passage in crankshaft. Bearing worn or eccentric. Bearing improperly assembled. Eccentric crankshaft or bearing.	Add or replace. Correct. Use proper oil. Repair. Clean. Replace. Correct. Replace.

# FORREST DATSUN IMPORTS

## Custom Sales & Service

"WHIPPLE AT VETERANS" TELEPHONE 365-6390  
480 VETERANS BLVD. • REDWOOD CITY, CALIFORNIA 94063

0526

NAME \_\_\_\_\_

DATE \_\_\_\_\_

5-9

19

**ADDRESS**

CUST. ORDER NO.



CHARGE

RETD. GOODS

## RETAIL

**WHOLESALE****SALESMAN**

CODE

QUAN.

PART NO.

**DESCRIPTION**

## LIST

NET

AMOUNT

1	77	0207	manus
---	----	------	-------

12	9.5
----	-----

PAID

check # 857  
FOREST DATSUM

✓ 788477

1295

78

## TAX

**TOTAL**

1375

**NO REFUND AFTER 30 DAYS.**

**NO REFUND ON ELECTRICAL OR CARBURETOR PARTS.**


**10% RESTOCKING CHARGE ON REFUNDED MERCHANDISE.**

HL 503 CUST, C-1361





**NO REFUND**

**WITHOUT THIS INVOICE**




REC'D BY







## SPECIAL SERVICE TOOL

No.	Tool number & tool name	Description  Unit: mm (in)	For use on	Reference page or Figure No.
1.	<b>ST0501S000</b>  Engine stand assembly  — ST05011000 Engine stand  — ST05012000 Base	This engine stand assembly is used for disassembling or assembling engine block or differential carrier throughout 360° in all directions.    SE 184	All models	Fig. EM-11
2.	<b>ST05260001</b>  Engine attachment	This engine attachment is installed to engine stand ST0501S000 in disassembling or assembling engine.    SE 185	L16 L18 L20B	Fig. EM-11
3.	<b>ST10120000</b>  Cylinder head bolt wrench	Special hollow set bolts are used in tightening cylinder heads in L-series engines. This wrench is used to torque cylinder head bolts and its head can be inserted into the torque wrench.    SE 186	All L-series	Fig. EM-18
4.	<b>ST10640001</b>  Pivot adjuster	This tool is used together with a torque wrench in tightening pivot lock nut for valve clearance adjustment.    SE 187	All L-series	Fig. EM-105

# Engine Mechanical





No.	Tool number & tool name	Description  Unit: mm (in)	For use on	Reference page or Figure No.
5.	<b>KV101039S0</b>  <b>Valve guide reamer set</b> — ST11081000 Reamer (12.2 mm dia.) — ST11032000 Reamer (8.0 mm dia.) — ST11320000 Drift	<p>This guide is used for:</p> <ul style="list-style-type: none"> <li>o Pressing used guide out of place.</li> <li>o Driving a new guide into place.</li> <li>o Finishing the bore of new guide.</li> </ul>  <p>SE 192</p>	All L-series and A-series	Fig. EM-44
6.	<b>ST11650001</b>  <b>Valve seat cutter set</b>	<p>This valve seat cutter set is used to or refinish a valve seat.</p>  <p>SE 193</p>	All L-series	Fig. EM-45
7.	<b>ST12070000</b>  <b>Valve lifter</b>	<p>This tool is used to compress valve spring by the combined action of its cam and lever, thereby facilitating the removal or installation of valve collet (for general use).</p>  <p>SE 194</p>	All models	Fig. EM-32 Fig. EM-81

# Engine Mechanical

No.	Tool number & tool name	Description Unit: mm (in)	For use on	Reference page or Figure No.
8.	ST13030001 Piston pin press stand	<p>This tool is used with a press to drive pin into, or out of, connecting rod:</p>  <p>SE 188</p>	All L-series	Fig. EM-29 Fig. EM-84
9.	ST15310000 Crankshaft rear oil seal drift	<p>This tool is used to push a lip type rear oil seal for L-series engine into place by giving hammer blows.</p>  <p>SE 189</p>	All L-series	Fig. EM-91
10.	KV101041S0 Crankshaft main bearing cap puller  KV10104110 Body  ST16512001 Adapter	<p>This tool is used to remove the cap from main bearing. When using this tool, turn its adapter into the threaded hole in main bearing cap.</p>  <p>SE 190</p>	All L-series	Fig. EM-25
11.	ST16610001 Pilot bushing puller	<p>This tool is used to pull pilot bushing out of place.</p>  <p>SE 191</p>	All L-series	Fig. EM-66



# Engine Mechanical

No.	Tool number & tool name	Description Unit: mm (in)	For use on	Reference page or Figure No.
12.	ST17420001 Chain stopper	<p>This tool is used to prevent chains from falling out of place in removing cylinder heads or cam gears and shafts.</p>  <p>SE195</p>	All L-series	Fig. EM-19
13.	ST19320000 Oil filter wrench	<p>This tool is used to take oil filter out of place. In tightening the filter, do not use this tool, to prevent excess tightening.</p>  <p>SE197</p>	All models	Page EM-4
14.	KV30100200 Clutch aligning bar	<p>This tool is used to install clutch assembly to engine.</p>  <p>SE001</p>	All L-series	Fig. EM-107
15.	EM03470000 Piston ring compressor	<p>This tool is used to compress piston rings while piston is being inserted into cylinder.</p>  <p>SE199</p>	All models	Fig. EM-92

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES

## SECTION EL

### ENGINE LUBRICATION SYSTEM

EL

ENGINE LUBRICATION SYSTEM .....	EL- 2
SERVICE DATA AND SPECIFICATIONS .....	EL- 5
TROUBLE DIAGNOSES AND CORRECTIONS .....	EL- 5
SPECIAL SERVICE TOOLS .....	EL- 6




**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

# ENGINE LUBRICATION SYSTEM

## ENGINE LUBRICATION SYSTEM

### CONTENTS

LUBRICATION CIRCUIT .....	EL-2	Inspection .....	EL-3
OIL PUMP .....	EL-2	OIL PRESSURE REGULATOR VALVE .....	EL-4
Removal .....	EL-2	OIL FILTER .....	EL-4
Installation .....	EL-2	RELIEF VALVE .....	EL-4
Disassembly and assembly .....	EL-3		




EL049

Fig. EL-1 Lubricating circuit

### LUBRICATION CIRCUIT

The pressure lubrication of the engine is accomplished by a trochoid-type oil pump. This pump draws the oil through the oil strainer into pump housing and then forces it through the full flow type oil filter into the main oil gallery. Part of the oil is supplied to all crankshaft bearings, chain tensioner and timing chain. Oil supplied to crankshaft bearings is fed to connecting rod bearings through the drilled passages in the crankshaft. Oil injected from jet holes on connecting rods lubricates the cylinder walls and piston pins. The other part of the oil is brought to the oil gallery in the

cylinder head to provide lubrication of the valve mechanism and timing chain as shown in Figure EL-2.



EL050

Fig. EL-2 Lubricating valve mechanism

From this gallery, oil holes go directly to all camshaft bearings through cam brackets.

Oil supplied through the No. 2 and No. 3 camshaft bearings is then fed to the rocker arm, valve and cam lobe through the oil gallery in the camshaft and the small channel at the base circle portion of each cam.

### OIL PUMP

The oil pump is secured on the bottom of the front cover with four bolts and driven by the oil pump drive spindle assembly which is driven by the helical gear on the crankshaft.

The oil pump assembly consists of an oil pressure regulator valve and outer and inner rotors.

The spring-loaded oil pressure regulator valve limits the oil pressure to a maximum of 5.6 kg/cm<sup>2</sup> (80 psi).

### Removal


1. Remove distributor.
2. Drain engine oil, if necessary.
3. Remove oil pump body with drive spindle assembly.

### Installation

1. Before installing oil pump on engine, turn crankshaft so that No. 1 piston is at T.D.C.

# ENGINE LUBRICATION SYSTEM


2. Fill pump housing with engine oil, then align punch mark of spindle with hole in oil pump as shown in Figure EL-3.



EL009


Fig. EL-3 Aligning punch mark and oil hole

3. Using a new gasket, install oil pump and drive spindle assembly so that the projection on its top is located in 11:25 a.m. position, at this time, the smaller bow-shape will be placed toward the front as shown in Figure EL-4.



EL010

Fig. EL-4 Setting drive spindle



EL011


Fig. EL-5 Installing oil pump

Ascertain whether or not the engagement is in order by checking the top of spindle through distributor fitting hole.

4. Tighten bolts securing oil pump to front cover.

## Disassembly and assembly

1. Remove pump cover attaching bolts, pump cover and cover gasket, and slide out pump rotors.
2. Remove regulator cap, regulator valve and spring.
3. Install pressure regulator valve and related parts.
4. Install outer rotor, inner rotor and shaft in pump body and do not turn cover gasket up.



EL012

- 1 Oil pump body
- 2 Inner rotor and shaft
- 3 Outer rotor
- 4 Oil pump cover
- 5 Regulator valve
- 6 Regulator spring
- 7 Washer
- 8 Regulator cap
- 9 Cover gasket

Fig. EL-6 Oil pump


## Inspection

Wash all parts in cleaning solvent and dry with compressed air.

1. Inspect pump body and cover for cracks or excessive wear.
2. Inspect pump rotors for excessive

wear.

3. Check inner rotor shaft for looseness in pump body.
4. Inspect regulator valve for wear or scoring.
5. Check regulator spring to see that it is not worn on its side or collapsed.
6. Using a feeler gauge, check tip clearance (2) and outer rotor-to-body clearance (1) shown in Figure EL-7.



EL059

- 1 Outer rotor to body clearance
- 2 Tip clearance
- 3 Gap between rotor and straight edge
- 4 Gap between body and straight edge

Fig. EL-7 Checking rotor clearances

7. Place a straight edge across the face of pump and depress it slightly as shown in Figure EL-7. Check gap (4) between body and straight edge or gap (3) between rotor and straight edge.

The gap should be  $-0.03$  to  $0.06$  mm ( $-0.0012$  to  $0.0024$  in), then rotor side clearance (rotor to bottom cover clearance) with gasket should satisfy the specifications.


	Standard	Wear limit
Rotor side clearance (rotor to bottom cover) mm (in)	0.04 to 0.08 (0.0016 to 0.0032)	0.20 (0.0079)
Rotor tip clearance ② mm (in)	Less than 0.12 (0.0047)	0.20 (0.0079)
Outer rotor to body clearance ① mm (in)	0.15 to 0.21 (0.0059 to 0.0083)	0.5 (0.0197)

# ENGINE LUBRICATION SYSTEM

Note: Pump rotors and body are not serviced separately. If pump rotors or body are damaged or worn, replacement of the entire oil pump assembly is necessary.

## OIL PRESSURE REGULATOR VALVE

The oil pressure regulator valve is not adjustable. At the released position, the valve permits the oil to by-pass through the passage in the pump cover to the inlet side of the pump. Check regulator valve spring to ensure that spring tension is correct.



EL014

Fig. EL-8 Regulator valve

### Tightening torque

Oil pump mounting bolts	kg-m (ft-lb) .....	1.1 to 1.5 (8.0 to 11)
Oil pump cover bolts	kg-m (ft-lb) .....	0.7 to 1.0 (5.1 to 7.2)
Regulator valve cap nut	kg-m (ft-lb) .....	4 to 5 (29 to 36)

### Specifications

Oil pressure at idling	kg/cm <sup>2</sup> (psi) .....	0.8 to 2.8 (11 to 40)
Regulator valve spring		
Free length	mm (in) .....	52.5 (2.067)
Pressured length	mm (in) .....	34.8 (1.370)
Regulator valve opening pressure	kg/cm <sup>2</sup> (psi) .....	3.5 to 5.0 (50 to 71)

## OIL FILTER


The oil filter is a cartridge type. The oil filter element should be replaced periodically, with the use of Oil Filter Wrench ST19320000.

When installing an oil filter, fasten it to cylinder block by hand.

Note: Do not overtighten filter, or oil leakage may occur.

## RELIEF VALVE


The relief valve located at the center portion securing oil filter to the cylinder block by-passes the oil into the main gallery when the oil filter element is excessively clogged.



EL015

Fig. EL-9 Removing oil filter

With oil filter removed, check valve unit for operation. Inspect for a cracked or broken valve. If replacement is necessary, remove valve by prying it out with a screwdriver. Install a new valve in place by tapping it.



EL016

Fig. EL-10 Relief valve

## ENGINE LUBRICATION SYSTEM

### SERVICE DATA AND SPECIFICATIONS

#### Oil pump

		Standard	Wear limit
Rotor side clearance (rotor to bottom cover)	mm (in) .....	0.04 to 0.08 (0.0016 to 0.0032)	0.20 (0.0079)
Rotor tip clearance	mm (in) .....	less than 0.12 (0.0047)	0.20 (0.0079)
Outer rotor to body clearance	mm (in) .....	0.15 to 0.21 ~ (0.0059 to 0.0083)	0.5 (0.0197)

#### Oil pressure regulator valve

Oil pressure at idling	kg/cm <sup>2</sup> (psi) .....	0.8 to 2.8 (11 to 40)
Regulator valve spring:		
Free length	mm (in) .....	52.5 (2.067)
Pressured length	mm (in) .....	34.8 (1.370)
Regulator valve opening pressure	kg/cm <sup>2</sup> (psi) .....	3.5 to 5.0 (50 to 71)

#### Tightening torque:


Oil pump bolt	kg-m (ft-lb) .....	1.1 to 1.5 (8.0 to 10.8)
Oil pump cover bolt	kg-m (ft-lb) .....	0.7 to 1.0 (5.1 to 7.2)
Regulator valve cap nut	kg-m (ft-lb) .....	4 to 5 (29 to 36)

### TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable causes	Corrective actions
Oil leakage	Damaged or cracked body cover. Oil leakage from gasket. Oil leakage from regulator valve. Oil leakage from blind plug.	Replace. Replace. Tighten or replace. Replace.
Decreased oil pressure	Leak of oil in engine oil pan. Dirty oil strainer. Damaged or worn pump rotors. Faulty regulator. Use of poor quality engine oil.	Correct. Clean or replace. Replace. Replace. Replace.
Warning light remains "on"-engine running	Decreased oil pressure. Oil pressure switch unserviceable. Electrical fault.	Previously mentioned. Replace. Check circuit.
Noise	Excessive backlash in pump rotors.	Replace.

## ENGINE LUBRICATION SYSTEM

### SPECIAL SERVICE TOOL

No.	Tool number & tool name	Description  Unit: mm (in)	For use on	Reference page or Figure No.
1.	ST19320000  Oil filter wrench	<p data-bbox="493 554 1135 617">This tool is used to take oil filter out of place. In tightening the filter, do not use this tool, to prevent excess tightening.</p>  <p data-bbox="1064 932 1127 953">SE197</p>	All models	Fig. EL-9

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES

## SECTION CO

### COOLING SYSTEM

CO

COOLING SYSTEM .....	CO- 2
SERVICE DATA AND SPECIFICATIONS .....	CO- 6
TROUBLE DIAGNOSES AND CORRECTIONS .....	CO- 7



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN



# COOLING SYSTEM

## CONTENTS

DESCRIPTION .....	CO-2	DISASSEMBLY .....	CO-4
COOLANT LEVEL .....	CO-2	INSPECTION .....	CO-4
DRAINING AND FLUSHING THE COOLING SYSTEM .....	CO-2	TEMP-COUPLING .....	CO-4
WATER PUMP .....	CO-2	INSPECTION .....	CO-5
REMOVAL AND INSTALLATION .....	CO-3	THERMOSTAT .....	CO-5
DISASSEMBLY .....	CO-3	REMOVAL AND INSTALLATION .....	CO-5
INSPECTION AND ADJUSTMENT .....	CO-3	INSPECTION .....	CO-5
TORQUE COUPLING .....	CO-3	RADIATOR .....	CO-5
REMOVAL AND INSTALLATION .....	CO-4	REMOVAL AND INSTALLATION .....	CO-5
		INSPECTION .....	CO-6

## DESCRIPTION

The cooling system is of the conventional pressure type. A centrifugal pump installed on the timing chain cover serves to circulate the coolant.

The pressure type radiator filler cap installed on the radiator operates the cooling system at higher than atmospheric pressure.

The higher pressure raises the boiling point of the coolant and in-

creases the cooling efficiency of the radiator.

When the thermostat is closed, the coolant remains in the cylinder head and block for swift warming up of the engine. After it reaches normal operating temperature, the coolant circulates through the radiator.

The cooling fan drive is of a coupling type.

If it is necessary to remove radiator cap when radiator is hot, turn cap slowly counterclockwise to the first step. After all pressure in the cooling system is released, turn cap passing the stop and remove it.




Fig. CO-1 Cooling system

## DRAINING AND FLUSHING THE COOLING SYSTEM

To drain the cooling system, remove radiator cap, release drain cock at the bottom of radiator and drain plug on the right side of cylinder block. If the heater system is installed, set heater temperature control valve to open position. After the coolant is drained completely, close drain cock and plug and refill the system with clean soft water.

## COOLANT LEVEL

The coolant level should be checked and maintained at 50 mm (1.97 in) below the upper face of filler neck, when the engine is cold.

**Caution:** To avoid serious personal injury, never remove radiator cap quickly when engine is hot. Sudden release of cooling system pressure is very dangerous.

## WATER PUMP

The water pump, cooling fan pulley and torque coupling are a unitized construction.


The water pump is of a centrifugal type, which is mounted on the engine front cover.

## Cooling System

The pump shaft is supported by a double row of ball bearings press fit in an aluminum die cast pump body. The bearings are permanently lubricated and sealed to prevent loss of lubricant and entry of dirt.

The pump is provided with an impeller which turns on a steel shaft. The steel shaft rotates together with the torque coupling wheel. The volute chamber is built in the engine front cover assembly.

The inlet of the pump is connected to the radiator's lower tank by a hose.




CO047

Fig. CO-2 Water pump and engine front cover

### REMOVAL AND INSTALLATION

#### Removal

1. Drain coolant into a clean container.
2. Remove upper and lower radiator shrouds.
3. Remove fan blade.
4. Loosen fan belt.
5. Remove water pump assembly and gasket from front cover.



CO048

Fig. CO-3 Removing water pump

#### Installation

1. Be sure to clean the gasket surfaces in contact with pump and front cover. Always use new gaskets when installing pump assembly. Be sure to tighten bolts.

#### Tightening torque:

0.4 to 0.5 kg-m  
(3.0 to 3.6 ft-lb)

2. Fill cooling system and check for leaks at pump.
3. Install fan blade, and tighten attaching bolts securely. Install belt and adjust for specified tension.
4. Operate the engine at fast idling and recheck for leaks.
5. Install fan shrouds.

**Note:** Ensure that clearance between shroud and fan is even at any place.

### DISASSEMBLY

Water pump is made of aluminum and its bearing outer race is of a press fit type. For this reason, water pump should not be disassembled.

### INSPECTION AND ADJUSTMENT

#### Inspection

Inspect pump assembly for the following conditions and replace if necessary.

1. Badly rusted or corroded body assembly and vane
2. Excessive end play or roughness of bearings in operation
3. Reduced cooling efficiency due to deteriorated silicone oil
4. Oil leakage in torque coupling

### Adjustment

Fan belt should be properly adjusted at all times. A tight belt causes wear of alternator and water pump bearings. A loose belt brings about improper cooling fan, water pump, and alternator operation.

Check the belt slack between alternator and fan pulley by force of 10 kg (22 lb).

Slackness of fan belt:


8 to 12 mm  
(0.31 to 0.47 in)

If adjustment is necessary, loosen bolt retaining alternator adjusting bar to alternator. Move alternator toward or away from engine until the correct tension is obtained.

### TORQUE COUPLING (Except air conditioner equipped models)

The torque coupling keeps the fan speed at 2,500 rpm (rated) or below to conserve horsepower at high engine speed. It also helps reduce fan noise to a minimum during high speed operation.

This unit is filled with a special silicone oil used as a fluid coupling which controls the fan speed. (Silicone oil can not be replenished.)



- 1 Torque coupling wheel
- 2 Torque coupling cover
- 3 Torque coupling bearing
- 4 Pulley
- 5 Water pump

CO060

Fig. CO-4 Sectional view of torque coupling and water pump

## REMOVAL AND INSTALLATION

To replace the torque coupling, follow the same procedure as in the water pump. The torque coupling can not be separated from the water pump.


## DISASSEMBLY

The torque coupling is so designed that it can not be disassembled.

## INSPECTION

Inspect torque coupling for oil leakage. If necessary, replace.

## TEM-COUPLING (For air conditioner equipped models)



- 1 Bi-metal thermostat
- 2 Slide valve
- 3 Reserve chamber for "OFF"
- 4 Bearing
- 5 Driving chamber for "ON"
- 6 Coupling part (labyrinth)

CO077

Fig. CO-5 Cross-sectional view of Tem-coupling

Tem-coupling is a type of fan coupling which is provided with a temperature control system.

The conventional coupling always slips the fan at a high speed under a constant ratio regardless of the engine cooling requirement.

The slipping ratio of the Tem-coupling, however, is properly changed with the cooling requirement.

"ON" denotes that cooling is required and the fan operates up to about 2,150 rpm. When high cooling is not required (during cold season, with the engine warmed up, etc.), the oper-

ation is placed under "OFF" condition and the fan slips at about 1,650 rpm.


The coiled bimetal thermostat installed on the front center portion of the Tem-coupling detects temperature of air passing through the radiator (The air temperature is directly relative to the engine coolant temperature.) and the inside slide valve is opened or closed as required, and thus, the ON-OFF control is performed. When the air temperature rises, the bimetal is expanded, and the valve is opened, silicon oil is forwarded to the groove that transmits torque, and the

system is placed under "ON" condition.

When the valve closes, silicone oil is not supplied to the driving chamber, oil in the driving chamber is accumulated on periphery due to the centrifugal force, and led into the reserve chamber. Now, oil is eliminated from the driving chamber, and the system is placed under "OFF" condition.

With this system, when fan cooling is not required, the output loss is minimized and noise can be far reduced.

## Cooling System



CO029  
Fig. CO-6 Characteristic of  
Tem-coupling

### INSPECTION

Check Tem-coupling for oil leakage or bend of bimetal.

If the above symptoms are found, replace it with a new one as an assembly.


### THERMOSTAT

A wax pellet type thermostat is mounted in the thermostat housing at the cylinder head water outlet.

The function of the thermostat is to control the flow of coolant, facilitating fast engine warm up and regulating coolant temperature. The thermostat is designed to open and close at predetermined temperatures and, if not operating properly, should be removed and tested as described below.

### REMOVAL AND INSTALLATION

1. Drain coolant partially.
2. Disconnect upper radiator hose at water outlet.
3. Remove bolts and remove water outlet, gasket, and thermostat from thermostat housing.



CO010  
Fig. CO-7 Removing thermostat


4. After checking thermostat, re-install with a new housing gasket in place.
5. Reinstall water outlet.
6. Replenish coolant and check for leaks.

### INSPECTION

A sticking thermostat will prevent the cooling system from functioning properly. If the thermostat sticks in the open position, the engine warms up very slowly. If the thermostat sticks in the closed position, overheating will result. Therefore, the ther-

mostat should be inspected to make sure that it is in good condition.

1. Measure coolant temperature when thermostat valve starts to open.
2. Measure the maximum lift of thermostat valve.



CO011  
Fig. CO-8 Inspecting thermostat

	Temperate type	Frigid type	Tropical type
Valve opening temperature °C (°F)	80.5 to 83.5 (177 to 183)	86.5 to 89.5 (187 to 193)	75 to 78 (167 to 172)
Maximum valve lift mm/°C (in/°F)	8/95 (0.31/203)	8/100 (0.31/212)	8/90 (0.31/194)

If thermostat does not operate at the above specified temperature, it must be replaced because it cannot be repaired.

On models equipped with automatic transmission, the oil cooler is combined with the radiator to cool transmission fluid.

### REMOVAL AND INSTALLATION

1. Drain coolant into a clean container.
2. Disconnect radiator upper and lower hoses. On models with automatic transmissions, disconnect cooler inlet and outlet lines from radiator.
3. Remove fan shroud retaining bolts and remove fan shroud.
4. Remove front grille.
5. Remove radiator retaining bolts and then remove radiator upward.
6. Install radiator in the reverse sequence of removal. Note the following:

- (1) Insert hoses in their positions until they bottom.
- (2) Ensure that arrow marks on hoses are clearly visible from upper

### RADIATOR

The radiator is a conventional down flow type having top and bottom tanks to distribute the coolant flow uniformly through the vertical tube of radiator core.

The radiator filler cap is designed to maintain a pre-set pressure (0.9 kg/cm<sup>2</sup>, 13 psi) above atmospheric pressure.

The relief valve consisting of a blow-off valve and a vacuum valve, helps to prevent the coolant from boiling by giving pressure to it. However, when the pressure is reduced below atmospheric pressure, the vacuum valve allows air to re-enter the radiator preventing the formation of a vacuum in the cooling system.

## Cooling System

direction when hoses are assembled.

(3) Ensure that clearance between radiator hose and any adjacent parts is 30 mm (1.181 in) minimum. On models equipped with air conditions, a minimum clearance of 18 mm (0.709 in) should exist between compressor and hose.


(4) Ensure that clearance between shroud and fan is even at any place.

**Note:** Be careful not to damage radiator fins and core tube when installing.

### INSPECTION

Radiator cap should be checked for working pressure at regular tune-up intervals. First, check rubber seal on cap for tears, cracks or deterioration

after cleaning it. Then, install radiator cap on a tester. If cap does not hold or will not release at the specified pressure, replace cap.




ET012

*Fig. CO-9 Testing radiator cap*

Also, inspect radiator for leakage using cap tester and applying a pressure of 1.6-kg/cm<sup>2</sup> (22.8 psi).

If a leakage is detected, repair or replace radiator.



ET013

*Fig. CO-10 Testing cooling system pressure*

## SERVICE DATA AND SPECIFICATIONS

### Thermostat

		Temperate type	Frigid type	Tropical type
Valve opening temperature	°C (°F) .....	80.5 to 83.5 (177 to 183)	86.5 to 89.5 (187 to 193)	75 to 78 (167 to 172)
Maximum valve lift	mm/°C (in/°F) .....	8/95 (0.31/203)	8/100 (0.31/212)	8/90 (0.31/194)

### Radiator

Type		
Manual transmission .....	Corrugated fin type	
Automatic transmission .....	Corrugated fin type equipped with oil cooler	
Cap relief pressure	kg/cm <sup>2</sup> (psi) .....	0.9 (1.3)

### Cooling system

Leakage testing pressure	kg/cm <sup>2</sup> (psi) .....	1.6 (22.8)
Capacity		with heater      without heater
Manual transmission	liters (US qt, Imp qt) .....	8.0 (8 1/4, 7)      7.4 (7 1/4, 6 1/4)
Automatic transmission	liters (US qt, Imp qt) .....	7.8 (8 1/4, 6 1/4)      7.2 (7 1/4, 6 1/4)

### Fan

Number of blades x outer diameter		
Without air conditioner	mm (in) .....	7 x 380 (15)
With air conditioner	mm (in) .....	8 x 380 (15)

## TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
Loss of water	Damaged radiator seams. Leaks at heater connections or plugs. Leak at water temperature gauge. Loose joints. Damaged cylinder head gasket.  Cracked cylinder block.  Cracked cylinder head. Loose cylinder head bolts.	Repair. Repair. Tighten. Tighten. Replace. Check engine oil for contamination and refill as necessary. Replace. Check engine oil in crankcase for mixing with water by pulling oil level gauge. Replace. Tighten.
Poor circulation	Restriction in system.  Insufficient coolant. Inoperative water pump. Loose fan belt. Inoperative thermostat.	Check hoses for crimps, and clear the system of rust and sludge by flushing radiator. Replenish. Replace. Adjust. Replace.
Corrosion	Excessive impurity in water.  Infrequent flushing and draining of system.	Use soft, clean water. (Rain water is satisfactory.) Cooling system should be drained and flushed periodically. Permanent anti-freeze (Ethylene glycol base) can be used throughout the seasons of the year, and change periodically at intervals recommended.
Overheating	Inoperative thermostat. Radiator fin choked with mud, chaff, etc.  Incorrect ignition and valve timing. Dirty oil and sludge in engine. Inoperative water pump. Loose fan belt. Restricted radiator. Inaccurate temperature gauge. Impurity in water.	Replace. Clean out air passage thoroughly by using air pressure from engine side of radiator. Adjust. Refill. Replace. Adjust. Flush radiator. Replace. Use soft, clean water.
Overcooling	Inoperative thermostat. Inaccurate temperature gauge.	Replace. Replace.

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES

## SECTION EF

## ENGINE FUEL

EF

AUTOMATIC TEMPERATURE-  
CONTROL (A.T.C.) ..... EF- 2  
AIR CLEANER

IDLE COMPENSATOR ..... EF- 7

FUEL FILTER ..... EF- 8

MECHANICAL FUEL PUMP ..... EF- 9

ELECTRIC FUEL PUMP ..... EF-11

CARBURETOR ..... EF-14



NISSAN MOTOR CO., LTD.  
TOKYO, JAPAN

# AUTOMATIC TEMPERATURE CONTROL (A.T.C.) AIR CLEANER

## CONTENTS

DESCRIPTION .....	EF-2	VACUUM MOTOR AND AIR	
OPERATION .....	EF-3	CONTROL VALVE .....	EF-5
A.T.C. AIR CLEANER HOT AIR		REMOVAL AND INSTALLATION .....	EF-5
OPERATION .....	EF-3	TEMPERATURE SENSOR .....	EF-5
A.T.C. AIR CLEANER COLD AIR		VACUUM MOTOR .....	EF-5
OPERATION .....	EF-4	FRESH AIR DUCT .....	EF-5
A.T.C. AIR CLEANER COLD AND		AIR CLEANER .....	EF-6
HOT AIR OPERATION .....	EF-4	INSPECTION .....	EF-6
TEMPERATURE SENSOR .....	EF-5	1 AIR CLEANER ELEMENT .....	EF-6
		2 HOT AIR CONTROL SYSTEM .....	EF-6

## DESCRIPTION

The air cleaner removes dust and dirt from the air before it enters the carburetor and engine. It also muffles noise resulting from the intake of air into the engine.

The air cleaner especially designed for improved exhaust emission control is referred to as "Automatic Temperature Control Air Cleaner". In order to reduce HC emission, when the under hood temperature is below 30°C (86°F), the automatic temperature control system maintains the temperature of air to be sucked in the carburetor at 30 to 54°C (86 to 129°F), thereby enabling lean setting for carburetor calibration. In addition to this, the automatic temperature control system is effective to improve warm-up characteristics of the engine

and to remove carburetor icing.

The A.T.C. air cleaner system consists of the following devices:

### 1. Air cleaner element

The air cleaner element employed is a viscous paper type. It requires only periodical replacement and should not be cleaned.

### 2. Automatic temperature control air cleaner.

In the A.T.C. air cleaner, the air control valve is actuated by intake manifold vacuum to control the intake air flow circuit. The temperature sensor detects the temperature inside the air cleaner, and opens or closes the vacuum passage.

### 3. Hot air duct

The hot air duct is mounted on the exhaust manifold. The air warmed up

between the exhaust manifold and hot air duct is led to the air cleaner through the hose.

### 4. Blow-by gas filter

The blow-by gas filter removes dirt and oil from the blow-by gas sucked in the air cleaner from the engine rocker cover.

### 5. Fresh air duct (Except for Canada)

The fresh air duct leads the outside fresh air directly to the air cleaner.


### 6. Idle compensator

See paragraph "Idle Compensator" (Page EF-7).

### 7. Altitude compensator (California models)

See paragraph "Altitude Compensator" (Page EF-20).





EF713

Fig. EF-1 Automatic temperature control air cleaner

## OPERATION

The automatic temperature control system of the air cleaner is controlled by the inlet air temperature and the

load condition of the engine. The inlet air temperature is detected by the sensor, and the vacuum motor is actu-

ated by the engine intake vacuum.

Under hood air temperature	Sensor vacuum at vacuum motor side	Air control valve operation	Sensor operation
Below 30°C (86°F)	Below 60 mmHg (2.36 inHg)	Open (cold air)	Close
	Above 210 mmHg (8.27 inHg)	Close (hot air)	
30 to 54°C (86 to 129°F)	—————	Half-open (cold air + hot air)	Open
Above 55°C (131°F)	—————	Open (cold air)	Open

## A.T.C. AIR CLEANER HOT AIR OPERATION

When the under hood air temperature is low, the sensor air bleed valve remains in the closed position, and establishes vacuum passage between

the intake manifold and vacuum motor. With this condition, the vacuum at the intake manifold side actuates the air control valve attached to

the vacuum motor diaphragm to introduce hot air into the air cleaner through the hot air duct on the exhaust manifold.


## A.T.C. AIR CLEANER COLD AIR OPERATION

1. When under hood air temperature is low:

The sensor air bleed valve remains in the closed position, and vacuum passage is established between the intake manifold and the vacuum motor, and the intake manifold vacuum is applied to the vacuum motor diaphragm. When the vacuum is small, or when the engine is operating under heavy load, the air control valve opens widely, irrespective of the temperature around the sensor, to introduce the under hood air (cold air) for increased power of the engine.


2. When under hood air temperature is high:

The sensor air bleed valve opens fully to shut off the vacuum passage between the intake manifold and the vacuum motor. Due to the force of the vacuum motor diaphragm spring, the air control valve closes the hot air pipe of the air cleaner, and introduces the under hood air (cold air).




EF714

Fig. EF-2 Hot air delivery mode (During cold engine operation)




EF205

Fig. EF-3 Cold air delivery mode (During cold engine operation)



EF715

Fig. EF-4 Cold air delivery mode (During hot engine operation)



EF716

Fig. EF-5 Regulating air delivery mode

## TEMPERATURE SENSOR

The temperature sensor is attached to the inside of the air cleaner. The bimetal built in the sensor detects the under hood air temperature and opens or closes the vacuum passage in the sensor.

The construction of the temperature sensor is shown in the following.




Fig. EF-6 Temperature sensor

## VACUUM MOTOR AND AIR CONTROL VALVE

The vacuum pressure which varies with opening of the carburetor throttle acts upon the vacuum motor diaphragm. The valve shaft attached to the diaphragm is then moved up or down in response to the vacuum on the diaphragm. This movement of the valve shaft actuates the air control valve to control the temperature of the air to be introduced into the air cleaner.




Fig. EF-7 Vacuum motor

## REMOVAL AND INSTALLATION

### TEMPERATURE SENSOR

#### Removal

1. Using pliers, flatten clip con-

necting vacuum hose to sensor vacuum tube.




Fig. EF-8 Removal of sensor

2. Disconnect hose from sensor.
3. Take off clip from sensor vacuum tube, and dismount sensor body from air cleaner.

**Note:** The gasket between sensor and air cleaner is bonded to the air cleaner side, and should not be removed.

#### Installation

1. Mount sensor on the specified position.

For mounting position of sensor, see the following.




Fig. EF-9 Installing sensor

2. Insert clip into vacuum tube of sensor. After installing each vacuum hose, secure hose with the clip.

**Note:** Be sure to install vacuum hose correctly. Correct position is: R.H. side to "Nissan" mark at the top face of sensor for intake manifold; L.H. side for vacuum motor.

## VACUUM MOTOR

1. Remove screws securing vacuum motor to air cleaner.
2. Disconnect valve shaft attached to vacuum motor diaphragm from air control valve, and remove vacuum motor assembly from air cleaner.
3. To install, reverse the removal procedure.

## FRESH AIR DUCT

1. Disconnect fresh air duct at air cleaner.
2. Fresh air duct is provided with projections on its air inlet side end. Hold fresh air duct with a hand, and carefully pull out from radiator core support while turning it in either direction.
3. To install, reverse the removal procedure. Be sure to insert projections of fresh air duct securely into mounting hole in radiator core support.




Fig. EF-10 Removal of fresh air duct

## AIR CLEANER

1. Loosen bolts securing air cleaner to air cleaner bracket.
2. Loosen air cleaner lock bolt and remove air cleaner from carburetor. Disconnect the following hoses when dismantling air cleaner.

- Under hood air inlet hose
  - Hot air inlet hose
  - Vacuum hose (Sensor to intake manifold)
  - Vacuum hose (Sensor to vacuum motor)
  - Vacuum hose (Idle compensator to intake manifold)
  - Hose (Air pump to air cleaner)
  - Hose (AB valve to air cleaner)
  - Hose (Carburetor to air cleaner)
  - Blow-by hose (Air cleaner to rocker cover)
  - Hose (Air control valve to air cleaner, California models only)
3. To install, reverse the removal procedure.

## INSPECTION

### 1 AIR CLEANER ELEMENT

Viscous paper type air cleaner element does not require any cleaning operation until it is replaced periodically. Brushing or blasting operation will cause clogging and result in enrichment of carburetor mixture, and should never be conducted. For replacement interval of air cleaner element, refer to "Maintenance Schedule".

### 2 HOT AIR CONTROL SYSTEM

In warm weather, it is difficult to find out malfunction of hot air control system. In cold weather, however, malfunction of air control valve due to disconnection or deterioration of vacuum hose between intake manifold and vacuum motor and insufficient durability of air control valve will cause insufficient automatic control operation for intake air, and result in engine disorder including:

1. Stall or hesitation of engine operation
2. Increase in fuel consumption
3. Lack of power

These phenomena reveal malfunction of hot air control system. If these phenomena should occur, check hot air control system as described in the following before carrying out inspection of carburetor.

#### 2-1 Vacuum hoses

(Intake manifold to 3-way connector, 3-way connector to temperature sensor, 3-way connector to idle compensator, temperature sensor to vacuum motor)


1. Check that vacuum hoses are securely connected in correct position.
2. Check each hose for cracks or distortion, hose clip for condition.

**Note:** Vacuum hose position: R.H. side of "Nissan" mark on the top of sensor is for intake manifold; L.H. side of the mark is for vacuum motor.

#### 2-2 Vacuum motor

1. With engine stopped, disconnect fresh air duct.

Place a mirror at the end of air cleaner inlet pipe as shown, and check to see if air control valve is in correct position.




EF213

Fig. EF-11 Inspecting valve position

Air control valve is in correct position if its under hood air inlet is open and hot air inlet is closed. Check air control valve linkage for condition.

2. Disconnect vacuum motor inlet vacuum hose, and connect another hose to the inlet to apply vacuum to vacuum motor. Vacuum can be applied by breathing in the hose end as shown.

Place a mirror at the end of air cleaner inlet pipe, and check to see if air control valve is in correct position.



EF217

Fig. EF-12 Inspecting valve position

Correct position of air control valve is the reverse of paragraph 1 above. Air control valve is in correct position if under hood air inlet is closed, and hot air inlet is open.

3. With hot air inlet in open position, as described in paragraph 2 above, pinch vacuum hose with fingers and cut off air from vacuum hose. In this condition, check that air control valve maintains the condition described in step 2 for more than 30 seconds, and that hot air inlet is open. If diaphragm spring actuates the air control valve by its spring force to open under hood air inlet within 30 seconds, replace vacuum motor as an assembly since this may be resulted from air leak at vacuum motor diaphragm.

#### 2-3 Temperature sensor

Check temperature sensor for function by proceeding as follows. Be sure to keep engine cold before starting test.

1. With engine off, check air control valve for condition. In this case, under hood air inlet is open. Use a mirror for inspection as 2-2-1 above.
2. Start engine and keep idling.

Immediately after engine starting, check air control valve for correct position as described above. In this case, correct position of air control valve is the reverse of 2-2-1; under hood air inlet is closed, and hot air inlet is open.

3. Check that air control valve gradually opens to under hood air inlet side as engine warms up. When environmental temperature around temperature sensor is low, spend more time for engine warming up operation

to facilitate smooth operation of air control valve.

If the above test reveals any problem in the operation of air control valve, carry out the following test:

4. Remove air cleaner cover. Set temperature sensing element of thermistor or thermometer to a position where temperature around sensor can be measured. In this case, fix wiring of thermistor or thermometer on the bottom surface of air cleaner with adhesive tape in such a manner that the set position of temperature sensing

element will not be affected by air flow. Then install air cleaner cover.




Fig. EF-13 Checking temperature sensor

5. Carry out test as described in steps 1, 2 and 3 above. When air control valve begins to open to under hood air inlet side several minutes after engine starting, read the indication of thermistor or thermometer. If reading falls within the working temperature range of temperature sensor, the sensor is normal. If reading exceeds the range, replace the sensor with new one.

**Note:** Before replacing temperature sensor, check idle compensator as described in "Idle compensator".

## IDLE COMPENSATOR

### CONTENTS

DESCRIPTION .....	EF-7	REMOVAL AND INSTALLATION .....	EF-8
OPERATION .....	EF-7	INSPECTION .....	EF-8

### DESCRIPTION

The idle compensator is basically a thermostatic valve which functions to introduce the air directly from the air cleaner to the intake manifold to compensate for abnormal enrichment of mixture in high idle temperature.

The bi-metal attached to the idle compensator detects the temperature of intake air, and opens or closes the valve. Two idle compensators having different temperature characteristics are installed; one opens at an intake air temperature of 60 to 70°C (140 to 158°F), and the other at 70 to 90°C (158 to 194°F).




Fig. EF-14 Structure of idle compensator


The idle compensator operates in response to the under hood air temperature as shown below:

### OPERATION

The construction of the idle compensator is shown in the following.

Bi-metal	Intake air temperature	Idle compensator operation
No. 1	Below 60°C (140°F)	Fully closed
	60 to 70°C (140 to 158°F)	Close to open
	Above 70°C (158°F)	Fully open
No. 2	Below 70°C (158°F)	Fully closed
	70 to 90°C (158 to 194°F)	Close to open
	Above 90°C (194°F)	Fully open

## REMOVAL AND INSTALLATION



EF718

Fig. EF-15 Location of idle compensator


1. Remove air cleaner cover.
2. Remove hose connecting idle compensator and 3-way connector.
3. Loosen screws securing idle compensator to air cleaner, then remove idle compensator.

### Notes:

- a. When removing idle compensator, remove gasket and plate.
- b. When removing screw securing idle compensator to air cleaner, be careful not to miss the screw.

4. To install, reverse the removal procedure.

air. If excessive air leakage is found at the valve, replace idle compensator as an assembly. Note that two idle compensators are mounted to air cleaner, and that it is necessary to plug the valve of one of these idle compensators so as to prevent air leak while checking the other one.



EF225


Fig. EF-16 Checking idle compensator

## INSPECTION

1. Check that valve is in closed position when bi-metal temperature is lower than operating temperature. To check, breathe air into tube or suck

Note: When checking idle compensator on vehicle, disconnect hose leading to idle compensator, and connect other hose, then carry out check as described above.

2. When bi-metal temperature is above the specified operating temperature, visually check to see if the valve is in open position. If valve is not open, replace idle compensator as an assembly.



EF226

Fig. EF-17 Checking idle compensator


### 3. Others

- 1) Check hoses for correct installation, distortion, or cracks.
- 2) Check rubber valve seat of idle compensator for sticking or any other faulty conditions.

## FUEL FILTER

### DESCRIPTION

The fuel filter is a cartridge type. It uses a paper element which can be checked for condition from the outside.



EF005

Fig. EF-18 Sectional view of cartridge type fuel filter

### REMOVAL

Disconnect inlet and outlet fuel lines from fuel filter, and remove fuel filter.

Note: Before disconnecting fuel lines, use a container to receive the fuel remaining in lines.

# MECHANICAL FUEL PUMP

## CONTENTS


DESCRIPTION .....	EF- 9	REMOVAL AND DISASSEMBLY .....	EF-10
FUEL PUMP TESTING .....	EF- 9	INSPECTION .....	EF-10
STATIC PRESSURE TEST .....	EF- 9	ASSEMBLY .....	EF-11
CAPACITY TEST .....	EF-10		

## DESCRIPTION

The fuel pump transfers fuel from the tank to the carburetor in sufficient quantity to meet the engine requirements at any speed or load.

The fuel pump is a pulsating type designed for easy maintenance. It consists of a body, a rocker arm assembly, a fuel diaphragm, a fuel diaphragm spring, seal inlet and outlet valves. Figure EF-19 shows a cross-sectional view of the pump.

The fuel diaphragm consists of specially treated rubber, which is not affected by gasoline and held in place by two metal discs and a pull rod.



- 1 Outlet-valve
- 2 Diaphragm
- 3 Diaphragm spring
- 4 Inlet-valve
- 5 Rocker arm

EF006

*Fig. EF-19 Schematic view of fuel pump*

## FUEL PUMP TESTING

A fuel pump is operating properly when its pressure is within specifications and its capacity is equal to the engine's requirements at all speeds. Pressure and capacity must be determined by two tests, while the pump is still mounted on the engine. Be sure there is fuel in the tank when carrying out the tests.

### STATIC PRESSURE TEST

The static pressure test should be made as follows:

1. Disconnect fuel line between carburetor and fuel pump.
2. Connect a rubber hose to each open end of a T-connector, and connect this connector-hose assembly between carburetor and fuel pump.

**Note:** Locate this T-connector as close to carburetor as possible.

3. Connect a suitable pressure gauge to the opening of T-connector, and fasten hose between carburetor and T-connector with a clip securely.

## Engine Fuel

4. Run the engine at varying speeds.
5. The pressure gauge indicates static fuel pressure in the line. The gauge reading should be within the following range.

0.21 to 0.27 kg/cm<sup>2</sup>  
(3.0 to 3.8 psi)

**Note:** If the fuel in carburetor float chamber has run out and engine has stopped, remove clip and pour fuel into carburetor. Fasten clip securely and repeat static pressure test.

Pressure below the lower limit indicates extreme wear on one part or a small amount of wear on each working part. It also indicates ruptured diaphragm; worn, warped, dirty or gumming valves and seats, or a weak diaphragm return spring. Pressure above the upper limit indicates an excessively strong tension of diaphragm return spring or a diaphragm that is too tight. Both of these conditions require the removal of pump assembly for replacement or repair.

### CAPACITY TEST

The capacity test is made only when static pressure is within the specifications. To make this test, proceed as follows:

1. Disconnect pressure gauge from T-connector and, in its vacant place, install a suitable container as a fuel sump.
2. Run engine at 1,000 rpm.
3. The pump should deliver 1,000 cc (2.11 US pt) of fuel in one minute or less.


If little or no fuel flows from the open end of pipe, it is an indication that fuel line is clogged or pump is malfunctioning.

### REMOVAL AND DISASSEMBLY

Remove fuel pump assembly by unscrewing two mounting nuts and disassemble in the following order.

1. Separate upper body and lower body by unscrewing body set screws.


2. Take off cap and cap gasket by removing cap screws.
3. Unscrew elbow and connector.
4. Take off valve retainer by unscrewing two retainer screws and remove two valves.
5. To remove diaphragm, press down its center against spring force. With diaphragm pressed down, tilt it until the end of pull rod touches the inner wall of body. Then, release diaphragm to unhook push rod. Be careful during this operation not to damage diaphragm or oil seal.



EF007

Fig. EF-20 Removing pull rod

6. Drive rocker arm pin out with a press or hammer.



- 1 Fuel pump cap
- 2 Cap gasket
- 3 Valve packing
- 4 Fuel pump valve assembly
- 5 Valve retainer
- 6 Diaphragm assembly
- 7 Diaphragm spring
- 8 Pull rod
- 9 Lower body seal washer
- 10 Lower body seal
- 11 Inlet connector
- 12 Outlet connector
- 13 Rocker arm spring
- 14 Rocker arm
- 15 Rocker arm side pin
- 16 Fuel pump packing
- 17 Spacer-fuel pump to cylinder block

EF510

Fig. EF-21 Structure of fuel pump

### INSPECTION

1. Check upper body and lower body for cracks.

2. Check valve assembly for wear on valve and valve spring. Blow valve assembly with breath to examine its function.



3. Check diaphragm for small holes, cracks or wear.
4. Check rocker arm for wear at the mating portion with camshaft.
5. Check rocker arm pin for wear. A worn pin may cause oil leakage.
6. Check all other components for any abnormalities and replace if necessary.

## ASSEMBLY

Reverse the order of disassembly. Closely observe the following instructions.

1. Use new gaskets.
2. Lubricate rocker arm, rocker arm link and rocker arm pin before installation.

3. To test the function, proceed as follows:

Position fuel pump assembly about 1 meter (3.3 ft) above fuel level of fuel strainer and connect a pipe from strainer to fuel pump.

Operate rocker arm by hand. If fuel is drawn up soon after rocker arm is released, fuel pump is functioning properly.

## ELECTRIC FUEL PUMP

### CONTENTS


DESCRIPTION .....	EF-11	DISASSEMBLY .....	EF-12
INSPECTION .....	EF-11	ASSEMBLY .....	EF-12
REMOVAL AND INSTALLATION .....	EF-12	TROUBLE DIAGNOSES AND CORRECTIONS .....	EF-13

### DESCRIPTION


The electric fuel pump is adopted on air conditioner equipped models.

The silicon transistor type fuel pump consists of a transistor, diodes, a sole-

noid, a pump mechanism and filter parts.



- |               |                 |
|---------------|-----------------|
| 1 Transistor  | 6 Outlet valve  |
| 2 Plunger     | 7 Return spring |
| 3 Diaphragm   | 8 Filter        |
| 4 Diode       | 9 Magnet        |
| 5 Magnet coil | 10 Inlet valve  |



- |                |
|----------------|
| 1 Transistor   |
| 2 Resistor (1) |
| 3 Diode        |
| 4 Signal coil  |
| 5 Main coil    |
| 6 Resistor (3) |
| 7 Zener diode  |
| 8 Resistor (2) |

EF719

Fig. EF-22 Construction of electric fuel pump

### INSPECTION

1. Disconnect fuel hose at pump outlet.
2. Connect a suitable hose [approximately 6 mm (0.24 in) inner diameter] to pump outlet.

Note: If diameter is too small, the following proper delivery capacity cannot be obtained even if pump functions properly.

3. With hose outlet in a higher position than pump, operate pump and check delivery capacity for more than 15 seconds.
4. The capacity should be 1,400 cc

(85.4 cu in) in one minute or less.

If no gasoline, or only a little flows from open end of pipe with pump operated, or if pump does not work, perform the following diagnosis.

Notes:

- a. Do not connect battery in reverse polarity which, if left for a long time, would damage transistor circuit and disable pump.

- b. Do not let fall pump, as it may damage electronic components.
- c. Do not apply overvoltage (max. 1.8V). Overvoltage starting by quick charge or overvoltage running would deteriorate or damage electronic components.

Fuel pressure (maximum):  
0.32 kg/cm<sup>2</sup> (4.6 psi)

## REMOVAL AND INSTALLATION




Fig. EF-23 Electric fuel pump

Electric fuel pump is installed on bracket with two bolts. This bracket is located on R.H. side member adjacent to fuel tank.

1. Remove inlet hose from fuel pump. Also remove outlet hose running to engine. Receive fuel remaining in fuel hose in a suitable container.
2. Disconnect harness at connector.
3. Remove bolts securing fuel pump to bracket, and detach fuel pump.
4. Installation is the reverse order of removal.

## DISASSEMBLY

Do not disassemble unless pump is faulty.

1. Remove cover with wrench and take out cover gasket, magnet, and filter from pump body.
2. When removing plunger, take out spring retainer from plunger tube.
3. Then, take out washer, O-ring, inlet valve, return spring and plunger from tube.

Note: Do not disassemble electronic components. If necessary, replace with new ones.

## ASSEMBLY

1. Before assembly, clean all parts with gasoline and compressed air completely.

Notes:

- a. If gasket and filter are faulty, replace.
- b. Clean magnet and cover for fault.
- c. Take care not to deform thin tube.
- d. Assemble plunger, return spring, inlet valve, O-ring, washer and set spring retainer in that order.
- e. Assemble filter, gasket and cover with magnet.
- f. Tighten cover with wrench to the stopper.

If component parts are dirty after disassembly, clean as follows:


- Wash filter and strainer with clean gasoline and blow with compressed air. When cleaning parts, check filter for fault. If faulty, replace.
  - Wash plunger, plunger cylinder and inlet valve with clean gasoline, and blow dust off with compressed air.
2. Check component parts for wear or damage.

If they are found faulty, replace them.

3. Insert plunger assembly into plunger cylinder of body and apply electric current to it.

Move the assembly up and down.

If the assembly does not move, it shows that the electric unit is faulty, and it must be replaced.



EF721

Fig. EF-24 Exploded view of electric fuel pump

**TROUBLE DIAGNOSES AND CORRECTIONS**

Condition	Probable cause	Corrective action
Fuel pump fails to operate.	Terminals or connections loose. Rust on terminals or grounding metal. Frozen liquid in plunger or pump.	Retighten. Clean. Clean plunger assembly. Replace pump if plunger is stuck or seized.
Fuel pump fails to discharge sufficient flow.	Clogged filter. Insufficient fuel.	Clean pump interior. Clean and, if necessary, replace filter. Replenish.
Insufficient fuel discharge during high speed travelling.	Air in fuel hose through connections.	Apply a coating of end sealing compound to connections, and retighten.
Low float level at idling.	Hose necked down or bent. Fuel tank breather tube bent or necked down. Weakened return spring.	Check and correct. Check and correct. Replace.
Fuel pump is actuated more frequently than under normal condition.	Air sucked through connection (fuel hose and fuel pump joint). Fuel hose (on suction side) bent. Clogged filter.	Apply a coating of end sealing compound to connection, and retighten. Check and correct. Clean or replace filter.
Rattling noise	Mounting bolts loose.	Retighten.

# CARBURETOR

## CONTENTS

DESCRIPTION .....	EF-14	CHOKE UNLOADER .....	EF-23
STRUCTURE AND OPERATION .....	EF-14	ELECTRIC AUTOMATIC CHOKE .....	EF-24
PRIMARY SYSTEM .....	EF-15	INTERLOCK OPENING OF PRIMARY AND	
SECONDARY SYSTEM .....	EF-16	SECONDARY THROTTLE VALVE .....	EF-24
ANTI-DIESELING SYSTEM .....	EF-17	DASH POT .....	EF-25
FLOAT SYSTEM .....	EF-18	ACCELERATING PUMP .....	EF-25
BOOST CONTROLLED DECELERATION		ANTI-DIESELING SOLENOID VALVE .....	EF-25
DEVICE (B.C.D.D.) .....	EF-18	B.C.D.D. CIRCUIT WITH FUNCTION	
ELECTRIC AUTOMATIC CHOKE .....	EF-20	TEST CONNECTOR .....	EF-25
DASH POT SYSTEM .....	EF-20	ALTITUDE COMPENSATOR	
ALTITUDE COMPENSATOR		(California models) .....	EF-29
(California models) .....	EF-20	MAJOR SERVICE OPERATION .....	EF-29
ADJUSTMENT AND INSPECTION .....	EF-21	REMOVAL .....	EF-29
CARBURETOR IDLE-RPM AND		DISASSEMBLY AND ASSEMBLY .....	EF-30
MIXTURE RATIO .....	EF-21	CLEANING AND INSPECTION .....	EF-34
FUEL LEVEL .....	EF-22	SERVICE DATA AND SPECIFICATIONS .....	EF-35
FAST IDLE .....	EF-22	TROUBLE DIAGNOSES AND	
VACUUM BREAK .....	EF-23	CORRECTIONS .....	EF-36

## DESCRIPTION

The carburetors are of down-draft two-barrel types which produce the optimum air-fuel mixture under all operating conditions.

They present several distinct features of importance to the vehicle owners.

A summary of the features is as follows:

1. A slow economizer to make a smooth connection with acceleration or deceleration during light load running.

It also assures stable low speed performance.

2. An idle limiter to reduce harmful exhaust emissions to a minimum.

3. A B.C.D.D. device for reducing hydrocarbon (H.C.) emissions.

4. An electric automatic choke to facilitate cold starting and to reduce exhaust emissions.

5. An anti-dieseling solenoid to eliminate dieseling (run-on).

6. A power valve, or vacuum actuated booster, to ensure smooth high-speed operation.

7. The carburetor comes equipped with dash pot, which ensures smooth deceleration, without engine stall under all operating conditions.

8. The hand operated altitude compensator is installed in the California models.


## STRUCTURE AND OPERATION

These carburetors consist of a primary system for normal running and a secondary system for full load running.

A float system common to both primary and secondary systems, a secondary switch-over mechanism, an accelerating mechanism, etc. are also attached.

An anti-dieseling solenoid valve and a power valve mechanism are also installed.

The hand operated altitude compensator corrects air-fuel mixture to an optimum ratio.



Note: Do not remove the parts marked with an asterisk "\*".

EF722

Fig. EF-25 Sectional view of carburetor

## PRIMARY SYSTEM

### Primary main system

The primary main system is a Stromburg type. Fuel flows as shown in Figure EF-25 through the main jet, mixing with air which comes in from the main air bleed and passes through the emulsion tube, and is pulled out into the venturi through the main nozzle.

### Idling and slow system

During low engine speed, as shown in Figure EF-25, fuel flows through the slow jet located on rear right side of main nozzle, mixing with air coming from the 1st slow air bleed, again mixing with air coming from the 2nd slow air bleed and then is pulled out

into the engine through the idle hole and bypass hole.

Adoption of the submerged type of slow jet eliminates such hesitation as occurs on sudden deceleration of the vehicle.

Slow economizer system obtains smooth deceleration at high speeds.

Small opening of the throttle valve at idling or partial load creates a large vacuum pressure in the intake manifold.


By this vacuum pressure, fuel is measured through the slow jet located behind the main jet. And air coming from the 1st slow air bleed is mixed with fuel in the emulsion hole.

This mixture is further mixed and atomized with air coming from the 2nd slow air bleed. The atomized mixture is supplied to the engine from

the idle hole and bypass hole via the slow system passage.

### Accelerating mechanism

The carburetor is equipped with the piston type accelerating mechanism linked to the throttle valve. When the primary throttle valve, shown in Figure EF-26, is closed, the piston goes up, and fuel flows from the float chamber through the inlet valve into the space under the piston. When the throttle valve is opened, the piston goes down, opening the outlet valve, and fuel is forced out through the injector.



- 1 Pump injector
- 2 Piston
- 3 Spring
- 4 Weight
- 5 Damper spring
- 6 Piston return spring
- 7 Inlet valve
- 8 Outlet valve


EF023

Fig. EF-26 Acceleration mechanism

## Power valve mechanism

The power valve mechanism, so-called vacuum piston type, utilizes the vacuum below the throttle valve.

When the throttle valve is slightly opened during light load running, high vacuum is created in the intake manifold. This vacuum pulls the vacuum piston upward against the spring, leaving the power valve closed. When the vacuum below the throttle valve is lowered during full load or accelerating running, the spring pushes the vacuum piston downward, opening the power valve to furnish fuel.



- 1 Vacuum piston
- 2 Power valve

ET024

Fig. EF-27 Sectional view of power valve

## SECONDARY SYSTEM

### Secondary main system


The secondary main system is a Stromburg type.

Fuel-air mixture produced by the functions of the main jet, main air bleed and emulsion tube, in the same manner as in the primary system, is

pulled out through the main nozzle into the small venturi.

Due to the double venturi of the secondary system, the higher velocity air current passing through the main nozzle promotes the fuel atomization.

The structure is almost the same as the primary side.



- 1 Primary vacuum port
- 2 Secondary vacuum port
- 3 Diaphragm chamber cover
- 4 Diaphragm spring
- 5 Diaphragm
- 6 Secondary throttle valve
- 7 Primary throttle valve

EF512

Fig. EF-28 Full throttle at high speed

## Step system

The construction of this system may correspond to the idling and slow system of the primary system.

This system aims at the proper filling up of the gap when fuel supply is transferred from the primary system to the secondary one. The step port is located near the secondary throttle valve edge in its fully closed state.

## Secondary switchover mechanism

The secondary throttle valve is linked to the diaphragm which is actuated by the vacuum created in the venturi. A vacuum jet is provided at each of the primary and secondary venturies, and the composite vacuum of these jets actuates the diaphragm.

As the linkage causes the secondary throttle valve to close until the primary throttle valve opening reaches approximately  $50^\circ$ , fuel consumption during normal operation is not excessive.

During high speed running, as shown in Figure EF-28, as the vacuum at the venturi is increased, the diaphragm is pulled against the diaphragm spring force, and then secondary throttle valve is opened.

The other side, during low speed running (as the primary throttle valve opening does not reach  $50^\circ$ ), the secondary throttle valve is locked to close completely by the locking arm which is interlocked with primary throttle arm by linkage.


When the primary throttle valve opening reaches wider position than  $50^\circ$ , the secondary throttle valve is ready to open, because the locking arm revolves and leaves from the secondary throttle arm.

## High speed circuit

The high speed circuit improves high engine output performance during high speed driving.

This circuit operates only when driving at high speed. It consists of a

richer jet, high speed enricher air bleed, and richer nozzle. When the velocity of suction air flowing through the carburetor secondary bore increases, additional fuel is drawn out of the richer nozzle.



EF234

- 1 Richer jet
- 2 High speed enricher air bleed
- 3 Richer nozzle


Fig. EF-29 High speed circuit

## ANTI-DIESELING SYSTEM

The carburetor is equipped with an anti-dieseling solenoid valve. As the ignition switch is turned off, the valve

is brought into operation, shutting off the supply of fuel to the slow circuit.

The following figure shows a sectional view of this control.



EF230

- 1 Anti-dieseling solenoid valve
- 2 Ignition switch
- 3 Battery

Fig. EF-30 Schematic drawing of anti-dieseling system

### FLOAT SYSTEM

There is only one float chamber, while two carburetor systems, primary and secondary, are provided.

Fuel fed from the fuel pump flows through the filter and needle valve into the float chamber. A constant fuel level is maintained by the float and needle valve.

Because of the inner air vent type of the float chamber ventilation, the fuel consumption will not be influenced by some dirt accumulated in the air cleaner.

The needle valve includes special hard steel ball and will not wear for all its considerably long use. Besides, the insertion of a spring will prevent the flooding at rough road running.

### BOOST CONTROLLED DECELERATION DEVICE (B. C. D. D.)

A Boost Controlled Deceleration Device (B.C.D.D.) serves to reduce the hydrocarbons (HC) emitted from engine during coasting.

The high manifold vacuum during coasting prevents the mixture from complete combustion because of the reduced amount of mixture per cylinder per rotation of engine, with the result that a large amount of hydrocarbons is emitted into the atmosphere.

The B.C.D.D. has been designed to correct this problem.

It operates as follows: when the manifold vacuum exceeds a pre-

determined value, the B.C.D.D. introduces an additional mixture of optimum mixture ratio and quantity into the manifold by opening a separate mixture passage in the carburetor. Complete combustion of fuel is assisted by this additional mixture, and the amount of H.C. contained in exhaust gases is dramatically reduced.

During the transition period from coasting to idling, the transmission produces a signal which turns on the vacuum control solenoid valve. As this takes place, the valve is lifted off its seat, opening the vacuum chamber to the atmosphere. The mixture control valve is then closed, returning the engine to the predetermined idling speed.

On manual transmission models, this system consists of B.C.D.D., vacuum control solenoid valve, speed detecting switch and amplifier.

On automatic transmission models, it consists of B.C.D.D., vacuum control solenoid valve and inhibitor switch.

### B.C.D.D. operation

Diaphragm I ① monitors the manifold vacuum and, when the vacuum exceeds a pre-determined value, acts so as to open the vacuum control valve ⑩. This causes the manifold vacuum to be introduced into the second vacuum chamber and actuates diaphragm II ②.

When diaphragm II operates, the mixture control valve ③ opens the passage and introduces the additional mixture into the manifold.

The amount of the mixture is controlled by the servo-action of the mixture control valve ③ and vacuum control valve ⑩ so that the manifold vacuum may be kept at the pre-determined value.

The amount of mixture depends mainly upon the coasting air bleed II ④, while the mixture ratio is determined by the coasting jet ⑬ and coasting air bleed ⑭. See Figure EF-31.

### Vacuum control solenoid valve operation

#### Manual transmission models:

The vacuum control solenoid valve is controlled by a speed detecting switch that is actuated by the speedometer needle.

As the vehicle speed falls below 10 MPH, this switch is activated, producing a signal. This signal actuates the amplifier to open the vacuum control solenoid valve.


#### Automatic transmission models:

When the shift lever is in "N" or "P" position, the inhibitor switch mounted on the transmission turns on to open the vacuum control solenoid valve.



# Engine Fuel

- |                                 |  |
|---------------------------------|--|
| 1 Air jet                       | 12 Secondary main jet                    |
| 2 Diaphragm II                  | 13 Coasting jet                          |
| 3 Mixture control valve         | 14 Coasting air bleed I                  |
| 4 Coasting air bleed II         | 15 Inhibitor switch "N", "P"             |
| 5 Mixture air passage           | : ON (for automatic transmission)        |
| 6 Secondary barrel              | 16 Amplifier                             |
| 7 Intake manifold               | 17 Speed detecting switch below          |
| 8 Boost passage                 | 10 M.P.H. : ON (for manual transmission) |
| 9 Vacuum control solenoid valve | 18 Ignition switch                       |
| 10 Vacuum control valve         |  |
| 11 Diaphragm I                  |  |




Note: Broken line applies only to Automatic Transmission.

EF231

Fig. EF-31 Schematic drawing of B.C.D.D. (Non-California models)

- |  |
|--|
| 1 Ignition switch                        |
| 2 Amplifier                              |
| 3 Speed detecting switch below           |
| 10 M.P.H. : ON (for manual transmission) |
| 4 Inhibitor switch "N", "P"              |
| : ON (for automatic transmission)        |
| 5 Solenoid valve                         |
| 6 Vacuum control valve                   |
| 7 Altitude corrector                     |



Note: Broken line applies only to Automatic Transmission.

EF235

Fig. EF-32 Schematic drawing of B.C.D.D. (California models)

## ELECTRIC AUTOMATIC CHOKE

An electric heater warms a bi-metal interconnected to the choke valve, and controls the position of choke valve and throttle valve in accordance with the time elapsed, the warm-up condition of the engine, and the outside ambient temperature.

When outside ambient temperature is above operating temperature, the automatic choke control serves to further reduce exhaust gas emission during warm-up by automatically selecting one of the two choke operation modes, fast-acting or slow-acting.

### Slow-acting choke operation

When ambient temperature is low, electric current flows through the automatic choke relay to the P.T.C. heater A, and gradually warms the bi-metal. This causes the choke valve to open slowly.

### Fast-acting choke operation

When ambient temperature is high, the bi-metal switch is in on. This causes electric current to flow through the automatic choke relay to the P.T.C. heater A and heater B, resulting in quick opening of the choke valve.

The construction and function of each part of this carburetor are as follows:

1. Bi-metal and heater in choke cover

Electric current flows through the heater as the engine starts, and warms the bi-metal. The deflection of the bi-metal is transmitted to the choke valve through the choke valve lever.

2. Fast idle cam

The fast idle cam determines the opening of the throttle valve so that the proper amount of mixture corresponding to the opening of the choke valve will be obtained. The opening of the choke valve is dependent upon the warm-up condition of the engine.

3. Fast idle adjusting screw

This screw adjusts the opening of the throttle valve of the fast idle cam.

4. Unloader

When accelerating the engine during the warm-up period, that is, before the choke valve opens sufficiently, this unloader forces the choke valve open a little so as to obtain an adequate air-fuel mixture.

5. Vacuum diaphragm

After the engine has been started by cranking, this diaphragm forces the choke valve open to the predetermined extent so as to provide the proper air-fuel ratio.

6. Bi-metal case index mark

The bi-metal case index mark is used for setting the moment of the

bi-metal which controls the air-fuel mixture ratio required for starting.

## DASH POT SYSTEM

These carburetors are equipped with a dash pot interlocked with the primary throttle valve through a link mechanism. The dash pot is intended to prevent engine stall resulting from quick application of the brake, or from the quick release of the accelerator pedal after treading it slightly.

In such a situation, a throttle lever strikes against the dash pot stem and makes the primary throttle valve close gradually, thus keeping the engine running.

## ALTITUDE COMPENSATOR (California models)

The higher the altitude, the richer the air-fuel mixture ratio and therefore, the higher exhaust gas emissions, even though the engine is properly adjusted for low altitude driving.

The altitude compensator is designed to meet Emission Standards for driving in both low and high altitudes. At high altitudes, additional air is supplied to the carburetor by the altitude compensator. When the altitude compensator lever is set at "H," air is conducted through an air passage to the carburetor. The air passage is closed when the lever is set at "L."

### H-L Lever

When operating the H-L lever, follow these instructions:

"H" position:

Should be used for general driving in those areas designated by law as High Altitude Counties.

"L" position:

For use outside those areas designated as High Altitude Counties.





Fig. EF-33 Schematic drawing of electric automatic choke heater

## Notes:

a. The idle rpm and CO% vary according to the altitude. Therefore, they should be properly adjusted when the position of the H-L lever is changed.

b. Counties 1,219 m (4,000 ft) or more above sea level have been designated by law as High Altitude Counties. For further details, refer to 1977 DATSUN PICK-UP Service Bulletin Pub. No. 257.



EF729

Fig. EF-34

## ADJUSTMENT AND INSPECTION

### CARBURETOR IDLE-R.P.M. AND MIXTURE RATIO

#### Cautions:

- On automatic transmission equipped models, check should be performed in the "D" position. Be sure to engage parking brake and to lock both front and rear wheels with wheel chocks.
- Keep your foot down on the brake pedal while depressing the accelerator pedal. Otherwise vehicle surges forward dangerously.

#### Notes:

- Do not attempt to screw the idle adjusting screw down completely. Doing so could cause damage to tip which in turn will tend to cause malfunctions.
- If idle limiter cap obstructs proper adjustment, remove it. To install idle limiter cap, refer to Idle Limiter Cap.
- After idle adjustment has been made, shift the lever to the "N" or "P" position (for automatic transmission).
- When measuring CO percentage, in-


sert probe into tail pipe more than 40 cm (15.7 in).

### "CO" Idle adjustment with CO-meter

Idle mixture adjustment requires the use of a CO-meter (especially for California models). When preparing to adjust idle mixture, it is essential to have the meter thoroughly warmed up and calibrated.

- Check carburetor pipes for proper connection.
- Warm up engine until water temperature indicator points to the middle of gauge. The procedure to warm up engine is not specifically recommended. Either driving vehicle or operating engine at no load will be good.
- Make sure that water temperature indicator points to the middle. Further keep engine running at about 2,000 rpm for about 5 minutes without applying load to engine in order to stabilize engine condition. Engine hood should be open.
- Run engine for about 10 minutes at idling speed. During this 10 minutes, proceed as described in steps 5 to 9 below.
- Remove air hose between 3-way connector (5-way connector for California models) and air check valve as

shown in Figure EF-35. Plug the disconnected hose to prevent dust from entering.



EF259

Fig. EF-35 Disconnecting air hose from air check valve

- Race engine (1,500 to 2,000 rpm) two or three times under no load, then run engine for one minute at idling speed.
- Adjust throttle adjusting screw until engine is at specified speed.

#### Engine speed:

Manual transmission

750 rpm

Automatic transmission

(in "D" position)

650 rpm

- Check ignition timing. If necessary, adjust it to specifications.

This operation need not be carried out at 1,600 km (1,000 miles) service.

#### Ignition timing:

Manual transmission

12°/750 rpm (Non-California)

10°/750 rpm (California)

Automatic transmission

(in "D" position)

12°/650 rpm

- At about 10 minutes after engine is run at idling speed, adjust idle adjusting screw so that CO percentage is at specified level.

#### CO percentage:

Manual transmission

2 ± 1% at 750 rpm

Automatic transmission

(in "D" position)

2 ± 1% at 650 rpm

- Repeat procedures as described in steps 6, 7 and 9 above so that CO percentage is at specified level. Checking idle CO in step 9 can be carried out right after step 7.

- Race engine (1,500 to 2,000

rpm) two or three times under no load and make sure that specified CO percentage is obtained.

12. Connect air hose to air check valve.

If engine speed increases, readjust it to the specified speed with throttle adjusting screw.

## "CO" idle adjustment without CO-meter

If CO-meter is not available, the following procedures may be used.

1. Check carburetor pipes for proper connection.

2. Warm up engine until water temperature indicator points to the middle of gauge. The procedure to warm up engine is not specifically recommended. Either driving vehicle or operating engine at no load will be good.

3. Make sure that water temperature indicator points to the middle. Further keep engine running at about 2,000 rpm for about 5 minutes without applying load to engine in order to stabilize engine condition. Engine hood should be open.

4. Run engine for about 10 minutes at idling speed. During this 10 minutes, proceed as described in steps 5 to 9 below.

5. Remove air hose between 3-way connector (5-way connector for California models) and air check valve shown in Figure EF-35. Plug the disconnected hose to prevent dust from entering.

6. Race engine (1,500 to 2,000 rpm) two or three times under no load, then run engine for one minute at idling speed.

7. Adjust throttle adjusting screw so that engine speeds are as indicated below.

Engine speed:

Manual transmission

815 rpm

Automatic transmission

(in "D" position)

670 rpm

8. Check ignition timing, if necessary adjust it to the value required by specifications. This operation need not be carried out at 1,600 km (1,000 miles) service.

9. At about 10 minutes after engine

is run at idling speed, adjust idle adjusting screw until maximum rpm is obtained.

10. Repeat procedures as described in steps 6, 7 and 9 above until engine speed, at best idle mixture, is 815 rpm for manual transmission models and 670 rpm for automatic transmission models (in "D" position). Adjustment in step 9 can be carried out right after step 7.

11. Turn the idle adjusting screw clockwise until engine speed drops off below specified rpm.

Engine speed drops off:

Manual transmission

60 to 70 rpm

Automatic transmission

(in "D" position)

15 to 25 rpm

12. Connect air hose to air check valve.

If engine speed increases, readjust it to the specified speed with throttle adjusting screw.

## Idle limiter cap

Do not remove this idle limiter cap unless necessary. If this unit is removed, it must be readjusted at time of installation. To adjust proceed as follows:

1. After adjusting throttle or idle speed adjusting screw, check to be sure that the amount of "CO" contained in exhaust gases meets the established standard.

2. Install idle limiter cap in position, making sure that the adjusting screw can rotate another 1/8 turn in the "CO-RICH" direction.




Fig. EF-36 Setting idle limiter cap

## FUEL LEVEL

1. Turn down float chamber to allow float to come into contact with needle valve, and measure "H" shown

in Figure EF-37.

When "H" is approximately 7.2 mm (0.283 in), top float position is correct.

The top float position can be adjusted by bending float seat.

Upon completion of the adjustment, check fuel level with attached level gauge.




Fig. EF-37 Adjusting float level

2. Adjust bottom float position so that clearance "h" between float seat and needle valve stem is 1.3 to 1.7 mm (0.051 to 0.067 in) when float is fully raised. Bend float stopper as required.

3. After adjustments in steps 1 and 2 above have been made, make sure that when fuel is delivered to the float chamber, the fuel level is maintained within the range of 23 mm (0.91 in) as shown in Figure EF-38.





Fig. EF-38 Checking fuel level

## FAST IDLE

1. With carburetor assembly removed from engine, measure throttle valve clearance "A" with a wire gauge, placing the upper side of fast idling screw on the first step on fast idling cam.



EC527

View from the bottom  
of carburetor

**Fig. EF-39** Measuring throttle valve  
clearance

Fast idling cam steps



EC528


**Fig. EF-40** Fast idling cam steps

2. The clearance should be specified  
value in the following table. If not, ad-  
just the clearance by turning fast  
idling screw.

	Clearance "A" mm (in)	Fast idling cam
M/T	1.33 to 1.47 (0.0524 to 0.0579)	1st step
A/T	1.58 to 1.72 (0.0622 to 0.0677)	

3. To check fast idling cam setting  
by engine speed, proceed as follows:  
Warm up engine sufficiently. Set

fast idling cam at 2nd step, and read  
engine speed. Fast idling cam is prop-  
erly set if engine speed is within



ET033


**Fig. EF-41** Adjusting the clearance  
of throttle valve

specifications below. Clearance "A" in  
2nd step is reference value.

	Engine speed (rpm)	Fast idling cam	Clearance "A" mm (in)
M/T	1,900 to 2,800	2nd step	0.94 to 1.18 (0.0370 to 0.0465)
A/T	2,200 to 3,200		1.16 to 1.40 (0.0457 to 0.0551)

## VACUUM BREAK

1. Close choke valve completely.
2. Hold choke valve by stretching a rubber band between choke piston lever and stationary part of carburetor.
3. Grip vacuum break rod with pliers, and pull straight out.
4. Under this condition, adjust the clearance between choke valve and carburetor body ("B" in Figure EF-42) to specified value by bending vacuum brake rod.



EF516

- |                    |                      |
|--------------------|----------------------|
| 1 Choke piston rod | 4 Diaphragm cover    |
| 2 Choke spring     | 5 Choke piston lever |
| 3 Choke piston     | 6 Choke valve        |

**Fig. EF-42** Adjusting vacuum break

## CHOKE UNLOADER

1. Close choke valve completely.
2. Hold choke valve by stretching a rubber band between choke piston lever and stationary part of carburetor.
3. Pull throttle lever until full open.

Under this condition, adjust clear-  
ance between choke valve and carbure-  
tor body to 2.45 mm (0.096 in) by  
bending unloader tongue.

**Note:** Make sure that throttle valve  
opens when carburetor is mounted  
on the vehicle.

If throttle valve fails to open, un-  
loader becomes inoperative, result-  
ing in poor acceleration after engine  
is started.

## ELECTRIC AUTOMATIC CHOKE

### Checking automatic choke heater circuit with function test connector


**Caution:** Do not attach test leads of a circuit tester to those other than designated. Refer to Figure EF-43.

1. With engine not running, check for continuity between A and B as shown in Figure EF-43.
  - If continuity exists, heater is functioning properly.
  - If continuity does not exist, check for disconnected connector or open P.T.C. heater circuit.
2. With engine running at idle, check for presence of voltage across A and B as shown in Figure EF-43.
  - If voltmeter reading is 12 volts (d-c), heater circuit is functioning properly.
  - If voltmeter reading is zero, check for disconnected connector, open circuit, or faulty automatic choke relay.
3. Replace faulty parts.

### Automatic choke

1. Before starting engine, fully depress accelerator pedal to ensure that choke valve closes properly.
2. Push choke valve with a finger, and check for binding.
3. Check to be sure that bi-metal cover index mark is set at the center of choke housing index mark as shown in Figure EF-44.

**Note:** Do not set bi-metal cover index mark at any position except the center of choke housing index mark.



- 1 Thermostat cover (Bi-metal chamber)
- 2 Thermostat housing
- 3 Groove


ET034

Fig. EF-44 Bi-metal setting

2. Make an operational check of automatic choke relay as shown in Figure EF-46.

Apply 12 volts (d-c) across terminals "1" and "3" to ensure that continuity exists between terminals "2" and "4".

Check that continuity does not exist between terminals "2" and "4" when no voltage is applied across them. If results satisfies the above, automatic choke relay is functioning properly; if not, replace choke relay.




EF723

Fig. EF-46 Checking automatic choke relay

### Automatic choke heater

1. Measure resistance of choke heater as shown in Figure EF-47. Specified resistance is 3.7 to 8.9 ohms.



EF261


Fig. EF-47 Automatic choke heater check

4. Check automatic choke heater source wiring for proper connection, then start engine.
5. After warming up the engine, see that choke valve is fully open.
6. If automatic choke heater source wiring is normal and choke valve does not operate after warm-up, replace bi-metal cover.

### Automatic choke relay



1. Remove automatic choke relay.

Auto choke heater relay



EF278

Fig. EF-45 Location of automatic choke relay



EF710

Fig. EF-43 Checking automatic choke heater circuit with function test connector

2. If measured value is not within the specification, replace bi-metal cover.


## INTERLOCK OPENING OF PRIMARY AND SECONDARY THROTTLE VALVE

Figure EF-48 shows primary throttle valve opened 50°. When primary throttle valve is opened 50° the adjust plate integrated with throttle valve is in contact with return plate at A.

When throttle valve is opened further, locking arm is detached from secondary throttle arm, permitting secondary system to start operation.

Linkage between primary and secondary throttles will function properly if distance between throttle valve and inner wall of throttle chamber is 7.4 mm (0.291 in).

Adjustment is made by bending connecting link.



- |                    |                    |
|--------------------|--------------------|
| 1 Roller           | 4 Adjust plate     |
| 2 Connecting lever | 5 Throttle chamber |
| 3 Return plate     | 6 Throttle valve   |

Fig. EF-48 Adjusting interlock opening

## DASH POT

1. Idling speed of engine and mixture must be well tuned up and engine sufficiently warm.
2. Turn throttle valve by hand, and read engine speed when dash pot just touches stopper lever.
3. Adjust position of dash pot by turning nut until engine speed is in the specified range.

Specified engine speed


Manual transmission

1,900 to 2,100 rpm

Automatic transmission

1,650 to 1,850 rpm

4. Tighten lock nuts.
5. Make sure that engine speed drops smoothly from 2,000 to 1,000 rpm in about three seconds.



EF107

Fig. EF-49 Adjusting dash pot

## ACCELERATING PUMP

1. Visually inspect accelerating pump cover for any sign of fuel leaks.
2. If fuel leaks are found, check gasket, and replace if necessary.


## ANTI-DIESELING SOLENOID VALVE

If engine does not stop when ignition switch is turned off, this indicates that a striking (closed) solenoid valve is shutting off supply of fuel to engine.

If harness is in good condition, replace solenoid valve as a unit.

Notes:

- a. Tightening torque is 1.8 to 3.5 kg-m (13 to 25 ft-lb).
- b. After replacement, start engine and check to be sure that fuel is not leaking, and that anti-dieseling solenoid is in good condition.



- |   |                         |
|---|-------------------------|
| 1 | Ignition key            |
| 2 | Fuse                    |
| 3 | Amplifier               |
| 4 | Speed detecting switch  |
|   | Above 10 mph: OFF       |
|   | Below 10 mph: ON        |
| 5 | Function test connector |
| 6 | B.C.D.D. solenoid valve |

## B.C.D.D. CIRCUIT WITH FUNCTION TEST CONNECTOR

Caution: Do not attach test leads of a circuit tester to those other than designated. Refer to Figure EF-50.

### Manual transmission models

1. Check for continuity between A and B when vehicle is brought to a complete stop. Refer to Figure EF-50.

B.C.D.D. circuit is functioning properly if continuity exists and voltmeter reading is 0 volt (d-c) in step 2 below.

If continuity does not exist, check for disconnected connector and/or faulty amplifier, speed detecting switch or B.C.D.D. solenoid valve.

2. Check for presence of voltage across A and B [at a speed of more than 16 km/h\* (10 MPH)]. Refer to Figure EF-50.

\* Conduct this test by one of the following two methods.

- 1) Raising up rear axle housing with stand.
  - 2) Chassis dynamometer test
- If voltmeter reading is 0 volt at a speed of more than 16 km/h (10 MPH), circuit is functioning properly.
  - If voltmeter reading is not 0 volt, check for disconnected connector, burned fuse, faulty amplifier, B.C.D.D. solenoid valve or speed detecting switch.
3. If, by above checks, faulty part or unit is located, it should be removed and tested again. If necessary, replace.

EF711

Fig. EF-50 Checking B.C.D.D. circuit with function test connector (for manual transmission)

## Engine Fuel

### Automatic transmission models

1. With inhibitor switch "ON" ("N" or "P" position), check for presence of voltage across A and B. Refer to Figure EF-51.

- If voltmeter reading is 12 volts (d-c), B.C.D.D. circuit is functioning properly.
- If voltmeter reading is zero, check for disconnected connector, faulty solenoid valve or inhibitor switch.

2. With inhibitor switch "OFF" ("1", "2", "D" or "R" position),

check for resistance between A and B. Refer to Figure EF-51.

- If ohmmeter reading is 25 ohms or below, circuit is functioning properly.
- If ohmmeter reading is 32 ohms or above, check for poor connection of connector, faulty B.C.D.D. solenoid valve or inhibitor relay.

3. If, by above checks, faulty part or unit is located, it should be removed and tested again. If necessary, replace.

3. Warm up the engine until it is heated to operating temperature.

Then adjust the engine at normal idling setting. (Refer to the item "Idling Adjustment" in page EF-21.)

Idling engine speed

Manual transmission

750 rpm

Automatic transmission

(in "D" position)

650 rpm

4. Run the engine under no load. Increase engine speed to 3,000 to 3,500 rpm, then quickly close throttle valve.

5. At the time, the manifold vacuum pressure increases abruptly to -600 mmHg (-23.62 inHg) or above and then gradually decreases to the level set at idling.

6. Check that the B.C.D.D. set pressure is within the specified pressure.

Specified pressure (0 m, sea level and 760 mmHg (30 inHg), atmospheric pressure)

Manual transmission


-510 to -550 mmHg

(-20.1 to -21.7 inHg)

Automatic transmission

-490 to -530 mmHg

(-19.3 to -20.9 inHg)



EF712

Fig. EF-51 Checking B.C.D.D. circuit with function test connector (for automatic transmission)

### Set pressure of Boost Controlled Deceleration Device (B.C.D.D.)

Generally, it is unnecessary to adjust the B.C.D.D., however, if it should become necessary to adjust it, the procedure is as follows:


#### Prepare the following tools

1. Tachometer to measure the engine speed while idling, and a screwdriver.
2. A vacuum gauge and connecting pipe.

Note: A quick-response type boost gauge such as Bourdon's type is recommended; a mercury-type manometer should not be used.

To properly set the B.C.D.D. set pressure, proceed as follows:


1. Remove the harness of solenoid valve.



EF262

Fig. EF-52 Removing harness of solenoid valve

2. Connect rubber hose between vacuum gauge and intake manifold as shown.



EF092

Fig. EF-53 Connecting vacuum gauge

#### Notes:

a. When atmospheric pressure is known, operating pressure will be found by tracing the arrow line "A". See Figure EF-56. When altitude is known, operating pressure will be found by tracing the arrow line "B". See Figure EF-56.

b. When checking the set pressure of B.C.D.D., find the specified set pressure in Figure EF-56 from the atmospheric pressure and altitude of the given location.

For example, if an automatic transmission model vehicle is located at an altitude of 1,000 m (3,280 ft), the specified set pressure for B.C.D.D. is -445 mmHg (-17.5 inHg).

7. If it is higher than the set level, turn the adjusting screw or nut until correct adjustment is made.



## Engine Fuel


Non-California models:

Adjusting screw  
Counterclockwise

California models:

Adjusting nut  
Clockwise


Non-California models



- 1 Adjusting screw "S"
- 2 Cover "C"

ET037

California models



- 1 Adjusting nut
- 2 Lock spring

EC692

Fig. EF-54 Adjusting set pressure

**Note:** When adjusting B.C.D.D. for California models, turn adjusting nut in or out with lock spring in place. Always set lock spring properly to prevent changes in set pressure.

8. Race the engine and check for adjustment.
9. If it is lower than the set level, turn the adjusting screw or nut until correct adjustment is made.
10. Race the engine and check for adjustment.

If engine speed cannot be decreased to idling when checking B.C.D.D. set pressure, proceed as follows:

When the engine speed does not fall to idling speed, it is necessary to reduce the negative idling pressure of the manifold to lower than the set pressure of the B.C.D.D. (The engine speed will not drop to idling speed when the negative idling pressure is higher than the set pressure of the B.C.D.D.).

In this case, the engine must be labored by (1) road test or (2) chassis dynamometer or (3) by raising up rear suspension member on a stand, accelerating the vehicle to 64 to 80 km/h (40 to 50 MPH) in top gear (manual transmission) or in "D" position (automatic transmission), and then releasing the accelerator pedal and letting the vehicle decelerate. After doing this, check whether the B.C.D.D. set pressure is at the predetermined value or not.





Fig. EF-55 Testing set pressure of the B.C.D.D.

## Engine Fuel




EF558

Fig. EF-56 Changes in set pressure versus changes in atmospheric pressure and altitude

### B.C.D.D. solenoid valve

1. Turn on engine key. (Do not start engine.)
2. Ensure that solenoid valve clicks when intermittently electrified as shown in Figure EF-57.



EF262

Fig. EF-57 Checking solenoid valve

3. If a click is heard, solenoid valve is normal.
4. If a click is not heard at all, check for continuity with a circuit tester. If discontinuity is detected, replace solenoid valve.

### Amplifier (Manual transmission models)


The amplifier is installed at the rear of the speedometer. To check, proceed as follows:

## Engine Fuel

1. Set circuit tester in d-c ampere range (1A min, full scale), connect test probes of tester as shown in Figure EF-58.

Do not confuse positive line with negative line.

2. Turn ignition key to "ON" position.



EF264

- 1 Ignition key
- 2 Amplifier
- 3 Speed detecting switch
- 4 B.C.D.D. solenoid valve


Fig. EF-58 Checking amplifier

### Inhibitor switch (Automatic transmission models)

Refer to the AT section.

### Inhibitor relay (Automatic transmission models)

1. Remove inhibitor relay under the relay cover.



EF724

Fig. EF-59 Location of inhibitor relay

2. Make an inhibitor relay check as shown in Figure EF-60.


Apply 12 volts (d-c) across terminals 1 and 4 to ensure that continuity exists between terminals 2 and 3.

Check that continuity does not exist between terminals 2 and 3 when no voltage is applied across them.

3. Ensure that tester pointer deflects when ignition key is turned on.

4. If tester pointer does not deflect when solenoid valve and speed detecting switch circuits are functioning properly, amplifier is faulty.

If results satisfy the above, inhibitor relay is functioning properly; if not, replace inhibitor relay.



EF287

Fig. EF-60 Checking inhibitor relay

### ALTITUDE COMPENSATOR (California models)

1. Make sure that altitude compensator to carburetor hoses are connected properly, and that they are not cracked and obstructed.


2. Check that altitude compensator is properly set.

- At low altitudes . . . Close
- At high altitudes . . . Open

#### Notes:

a. The idle rpm and CO% vary according to the altitude. Therefore, they should be properly adjusted when the position of the H-L lever is changed.

b. Counties 1,219 m (4,000 ft) or more above sea level have been designated by law as High Altitude Counties. For further details, refer to 1977 DATSUN PICK-UP Service Bulletin Pub. No. 257.



EF733

Fig. EF-61 Checking altitude compensator

## MAJOR SERVICE OPERATION

The perfectly adjusted carburetor delivers the proper fuel and air ratios at all speeds for the particular engine for which it was designed. By completely disassembling which will allow cleaning of all parts and passages, the carburetor can be maintained its original condition and will continue to deliver the proper ratios.

To maintain accurate carburetion of passages and discharge holes, extreme care must be taken in cleaning.

Use only carburetor solvent and compressed air to clean all passages and discharge holes. Never use wire or other pointed instrument to clean or carburetor calibration will be affected.

### REMOVAL

Remove carburetor from engine, taking sufficient care to the following:

#### Precautions:

- a. When disconnecting fuel lines, do not spill fuel from fuel pipe.
- b. When removing carburetor, do not drop any nut or bolt into intake manifold.
- c. Be careful not to bend or scratch any part.


## DISASSEMBLY AND ASSEMBLY

- A Choke chamber
- B Center body
- C Throttle chamber

- 1 Lock lever
- 2 Filter set screw
- 3 Fuel filter
- 4 Fuel nipple
- 5 Needle valve body
- 6 Needle valve
- 7 Fuel chamber parts
- 8 Accelerating pump parts
- 9 Altitude compensator pipe (California models)
- 10\* Coasting air bleed adjusting screw

- 11\* High speed enricher air bleed
- 12\* Choke valve
- 13 Accelerating pump lever
- 14 Throttle return spring
- 15 Accelerating pump rod
- 16 Automatic choke cover
- 17\* Automatic choke body and diaphragm chamber
- 18\* Richer jet
- 19\* Coasting air bleed I
- 20 Primary main jet
- 21 Secondary main jet
- 22 Secondary slow air bleed
- 23 Secondary slow jet
- 24 Plug
- 25\* Air bleed
- 26 Coasting jet
- 27 Secondary main air bleed
- 28 Power valve
- 29 Primary main air bleed
- 30 Plug
- 31 Primary slow jet
- 32 No. 2 primary slow air bleed
- 33\* Primary and secondary small venturi
- 34\* Venturi stopper screw
- 35 Choke connecting rod
- 36 Anti-dieseling solenoid valve
- 37 Fast idle cam
- 38 Diaphragm chamber parts
- 39 Idle limiter cap
- 40 Idle adjust screw
- 41 Idle adjust screw spring
- 42 Throttle adjust screw
- 43 Throttle adjust screw spring
- 44\* Primary and secondary throttle valve
- 45 B.C.D.D. (California models)
- 46 Vacuum control solenoid valve
- 47 B.C.D.D. (Non-California models)

Note: Do not remove the parts marked with an asterisk "\*".



### Disassembly

1. Properly fitting wrenches and screwdrivers must be used on the nozzles and jets as well as on the

screws and nuts, and care must be exercised not to damage any parts.


2. Clean the carburetor thoroughly before disassembly.

3. Do not attempt to remove any parts marked with an asterisk (\*) in Figures EF-62, EF-63, EF-64 and EF-66.

### Choke chamber parts

- 1\* Coasting air bleed adjusting screw
- 2\* High speed enricher air bleed
- 3\* Choke valve
- 4 Accelerating pump lever
- 5 Throttle return spring
- 6 Accelerating pump rod
- 7 Automatic choke cover
- 8\* Richer jet
- 9\* Automatic choke body and diaphragm chamber
- 10\* Coasting air bleed

Note: Do not remove the parts marked with an asterisk “\*.”




EF225

Fig. EF-63 Removing choke chamber parts

## Engine Fuel

### Center body parts Sets




- 1 Vacuum control solenoid valve
- 2 B.C.D.D.
- 3 Coasting jet
- 4 Secondary slow jet
- 5 Plug
- 6\* Air bleed
- 7 Secondary slow air bleed
- 8 Secondary main air bleed
- 9 Power valve
- 10 Primary main air bleed
- 11 Weight and outlet valve
- 12 Plug
- 13 Primary slow jet
- 14 Primary slow air bleed
- 15 Accelerator pump assembly
- 16 Anti-dieseling solenoid valve
- 17 Fast idle cam
- 18 Choke connecting rod
- 19\* Fast idle cam shaft
- 20\* Venturi stopper screw
- 21\* Primary and secondary small venturi

Note: Do not remove the parts marked with an asterisk "\*"

EF726

Fig. EF-64 Removing jets

### Float




- 1 Secondary main jet
- 2 Primary main jet
- 3 Float chamber parts
- 4 Fuel inlet assembly
- 4-1 Lock lever
- 4-2 Filter set screw
- 4-3 Fuel filter
- 4-4 Fuel nipple
- 4-5 Needle valve body
- 4-6 Needle valve
- 5 Diaphragm chamber assembly

EF227

Fig. EF-65 Removing float

## Throttle chamber parts



EF827

Fig. EF-66 Removing throttle chamber parts

## Assembly

To assemble, reverse the disassembly procedure, taking care to the following:

1. Thoroughly wash all the parts before assembling.
2. Inspect gaskets to see if they

appear hard or brittle or if edges are torn or distorted.

If any of such undesirable conditions is noted, they must be replaced.

3. Install jet and air bleed having the same size number as that of original

one.

4. After reassembling carburetor, check each rotating portion or sliding portion for smooth operation.

### CLEANING AND INSPECTION

Dirt, gum, water or carbon contamination in or on exterior moving parts of a carburetor are often responsible for unsatisfactory performance. For this reason, efficient carburetion depends upon careful cleaning and inspection while servicing.

1. Blow all passages and castings with compressed air and blow off all parts until dry.

**Note:** Do not pass drills or wires through calibrated jets or passages as this may enlarge orifice and seriously affect carburetor calibration.

2. Check all parts for wear. If wear is noted, damaged parts must be replaced. Note especially the following:

(1) Check float needle and seat for wear. If wear is noted, assembly must be replaced.

(2) Check throttle and choke shaft bores in throttle chamber and choke chamber for wear or out-of-roundness.

(3) Inspect idle adjusting needle for burrs or ridges. Such a condition requires replacement.

3. Inspect gaskets to see if they appear hard or brittle or if edges are torn or distorted. If any such condition is noted, they must be replaced.

4. Check filter screen for dirt or lint. Clean, and if screen is distorted or remains plugged, replace.

5. Check linkage for operating condition.

6. Inspect operation of accelerating pump. Pour fuel into float chamber and make throttle lever operate. Check condition of fuel injection from the

accelerating nozzle.

7. Push connecting rod of diaphragm chamber and block passage of vacuum with finger. When connecting rod becomes free, check for leakage of air or damage to diaphragm.

### Jets

Carburetor performance depends on jets and air bleeds. That is why these components must be fabricated with utmost care. To clean them, use cleaning solvent and blow air on them. Larger inner numbers stamped on the jets indicate larger diameters. Accordingly, main and slow jets with larger numbers provide richer mixture; the smaller the numbers the leaner the mixture. Conversely, the main and slow air bleeds, through which air to passes through, make the fuel leaner if they bear larger numbers; the smaller the numbers the richer the fuel.



## SERVICE DATA AND SPECIFICATIONS

		Non-California models		California models	
		Manual transmission	Automatic transmission	Manual transmission	Automatic transmission
Air cleaner					
Air control valve partially opens	°C (°F)	30 to 54 (86 to 129)		30 to 54 (86 to 129)	
Air control valve fully opens	°C (°F)	above 55 (131)		above 55 (131)	
Idle compensator partially opens	°C (°F)				
Bi-metal No. 1		60 to 70 (140 to 158)		60 to 70 (140 to 158)	
Bi-metal No. 2		70 to 90 (158 to 194)		70 to 90 (158 to 194)	
Idle compensator fully opens	°C (°F)				
Bi-metal No. 1		above 70 (158)		above 70 (158)	
Bi-metal No. 2		above 90 (194)		above 90 (194)	
Fuel system					
Fuel pressure	kg/cm <sup>2</sup> (psi)	0.21 to 0.27 (2.99 to 3.84)		0.21 to 0.27 (2.99 to 3.84)	
Fuel pump capacity	cc (US pt)/min. at rpm	1,000 (2 1/4)/1,000		1,000 (2 1/4)/1,000	
Carburetor					
Carburetor type		Stromberg type		Stromberg type	
Carburetor model					
		</			

## Engine Fuel

### TROUBLE DIAGNOSES AND CORRECTIONS

In the following table, the symp-

toms and causes of carburetor troubles and remedies for them are listed to facilitate quick repairs.

There are various causes of engine malfunctions. It sometimes happens that a carburetor which has no fault

appears to have some problems, when actually the electric system is at fault. Therefore, whenever the engine is malfunctioning, the electrical system should be checked first, before adjusting carburetor.

Condition	Probable cause	Corrective action
Overflow	Dirt accumulated on needle valve. Fuel pump pressure too high. Needle valve improperly seated.	Clean needle valve. Repair pump. Replace.
Excessive fuel consumption	Fuel overflow. Slow jet too large on each main jet. Main air bleed clogged. Choke valve does not open fully. Outlet valve seat of accelerator pump improper. Linked opening of secondary throttle valve opens too early.	See condition "overflow". Replace. Clean. Adjust. Lap. Adjust.
Power shortage	Main jets clogged. Every throttle valve does not open fully. Idling adjustment incorrect. Fuel strainer clogged. Vacuum jet clogged. Air cleaner clogged. Diaphragm damaged. Power valve operating improperly. Altitude compensator setting incorrect (California models).	Clean. Adjust. Adjust. Repair. Clean. Clean. Replace. Adjust. Correct H-L lever position.
Improper idling	Slow jet clogged. Every throttle valve does not close. Secondary throttle valve operating improperly. Throttle valve shafts worn. Packing between manifold/carburetor faulty.  Manifold/carburetor tightening improper. Fuel overflow. B.C.D.D. adjustment incorrect. Vacuum control solenoid damaged. Stuck anti-stall dash pot.	Clean. Adjust. Overhaul and clean.  Replace. Replace packing.  Correct tightening. See condition "overflow". Adjust. Replace. Replace.

## Engine Fuel

Condition	Probable cause	Corrective action
Engine hesitation	Main jet or slow jet clogged. By pass hole, idle passage clogged. Emulsion tube clogged. Idling adjustment incorrect. Secondary throttle valve operating im- properly. Altitude compensator setting incorrect (Cali- fornia models).	Clean. Clean tube. Clean. Adjust. Overhaul and clean. Correct H-L lever position.
Engine does not start.	Fuel overflows. No fuel. Idling adjustment incorrect. Fast idle adjustment incorrect. Damaged anti-dieseling solenoid.	See condition "overflow". Check pump, fuel pipe and needle valve. Adjust. Adjust. Replace.

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES

## SECTION EC

### EMISSION CONTROL SYSTEM

EC

GENERAL DESCRIPTION .....	EC- 2
CRANKCASE EMISSION CONTROL SYSTEM .....	EC- 2
EXHAUST EMISSION CONTROL SYSTEM .....	EC- 3
EVAPORATIVE EMISSION CONTROL SYSTEM .....	EC-30
SPECIAL SERVICE TOOLS .....	EC-32



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

## GENERAL DESCRIPTION

There are three types of control system. These are:

1. Closed type crankcase emission control system

2. Exhaust emission control system
3. Evaporative emission control system

Periodic inspection and required

servicing of these systems should be carried out to reduce harmful emissions to a minimum.

## CRANKCASE EMISSION CONTROL SYSTEM

### DESCRIPTION

This system returns blow-by gas to both the intake manifold and carburetor air cleaner.

The positive crankcase ventilation (P.C.V.) valve is provided to conduct crankcase blow-by gas to the intake manifold.

During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the P.C.V. valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the dust side of the carburetor air cleaner, through the tube connecting carburetor air cleaner to rocker cover, into the crankcase.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve, and its flow goes through the tube connection in the reverse direction.

On vehicles with an excessively high blow-by some of the flow will go through the tube connection to carburetor air cleaner under all conditions.

### INSPECTION

#### P.C.V. VALVE AND FILTER

Checking P.C.V. valve in accordance with the following method.

With engine running at idle, remove the ventilator hose from P.C.V. valve, if the valve is working, a hissing noise will be heard as air passes through the valve and a strong vacuum should be felt immediately when a finger is placed over valve inlet.


Replace P.C.V. valve and filter in accordance with the maintenance schedule.

#### VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air.

If any hose cannot be free of obstructions, replace.

Ensure that flame arrester is surely inserted in hose between air cleaner and rocker cover.



EC716

Fig. EC-1 Crankcase emission control system

# EXHAUST EMISSION CONTROL SYSTEM

## CONTENTS

DESCRIPTION .....	EC- 3	EXHAUST GAS RECIRCULATION	
EARLY FUEL EVAPORATIVE SYSTEM		CONTROL SYSTEM (E.G.R.) .....	EC-19
(E.F.E.) .....	EC- 6	DESCRIPTION .....	EC-19
DESCRIPTION .....	EC- 6	OPERATION .....	EC-19
OPERATION .....	EC- 6	REMOVAL AND INSTALLATION .....	EC-23
REMOVAL AND INSTALLATION .....	EC- 7	INSPECTION .....	EC-24
INSPECTION .....	EC- 7	CATALYTIC CONVERTER .....	EC-26
SPARK TIMING CONTROL SYSTEM .....	EC- 7	DESCRIPTION .....	EC-26
DESCRIPTION .....	EC- 7	OPERATION .....	EC-26
SPARK DELAY VALVE		REMOVAL AND INSPECTION .....	EC-27
(Automatic transmission models only) .....	EC- 7	INSTALLATION .....	EC-27
INSPECTION .....	EC- 8	FLOOR TEMPERATURE WARNING	
AIR INJECTION SYSTEM .....	EC- 8	SYSTEM .....	EC-27
DESCRIPTION .....	EC- 8	DESCRIPTION .....	EC-27
OPERATION .....	EC-12	OPERATION .....	EC-28
REMOVAL AND INSTALLATION .....	EC-14	REMOVAL .....	EC-28
DISASSEMBLY AND ASSEMBLY .....	EC-14	INSTALLATION .....	EC-29
INSPECTION .....	EC-17	INSPECTION .....	EC-29


## DESCRIPTION

The exhaust emission control system is made up of the following:

- 1) Early fuel evaporative system
- 2) Spark timing control system
- 3) Air injection system (A.I.S.)
- 4) Exhaust gas recirculation (E.G.R.) control system
- 5) Catalytic converter (California models)
- 6) Boost controlled deceleration device (B.C.D.D.)
- 7) Altitude compensator (California models)


As regards the last two units, refer to the Engine Fuel section.

## Emission Control System



ET365

Fig. EC-2 Exhaust emission control system (Non-California models)



- 1 Thermal vacuum valve
- 2 Check valve
- 3 Altitude compensator (in air cleaner)
- 4 Air gallery pipe
- 5 Auto-choke
- 6 Automatic temperature control air cleaner
- 7 Anti-Backfire valve (A.B. valve)
- 8 Boost Controlled Deceleration Device (B.C.D.D.)
- 9 P.C.V. valve
- 10 Air relief valve
- 11 E.G.R. control valve
- 12 B.C.D.D. control valve and solenoid valve
- 13 Emergency air relief valve
- 14 Air pump air cleaner
- 15 Carbon canister
- 16 Air control valve
- 17 Air pump

ET368

Fig. EC-3 Exhaust emission control system (California models)




## EARLY FUEL EVAPORATIVE SYSTEM (E.F.E.)

### DESCRIPTION

Construction of the early fuel evaporative system is shown in Figure

EC-4. A control valve welded to the valve shaft is installed on the exhaust manifold through bushing. This control valve is called "Heat control valve". The heat control valve is actuated by the coil spring, thermostat

spring and counterweight which are assembled on the valve shaft projecting to the rear outside of the exhaust manifold. The counterweight is secured to the valve shaft with key, bolt and snap ring.



EC532

Fig. EC-4 Early Fuel Evaporative system (E.F.E.)

The early fuel evaporative system is provided with a chamber above a manifold stove mounted between the intake and exhaust manifolds. During engine warming-up, air-fuel mixture in the carburetor is heated in the chamber by exhaust gases. This results in improved evaporation of atomized fuel droplets in the mixture and in smaller content of hydrocarbons (HC) in the exhaust gas especially in cold weather operation.

The exhaust gas flow from the engine is obstructed by the heat control valve in the exhaust manifold, and

is changed in direction as shown by the solid lines in Figure EC-4. The exhaust gas heats the manifold stove.


Open-close operation of the heat control valve is controlled by the counterweight and thermostat spring which is sensitive to the ambient temperature around the exhaust manifold.

### OPERATION

The counterweight rotates counter-clockwise and stops at the stopper pin mounted on the exhaust manifold while the engine temperature is low.

With this condition, the heat control valve is in the fully closed position, obstructing the flow of exhaust gas. As engine temperature goes up and the ambient temperature becomes high enough to actuate the thermostat spring, the counterweight begins to rotate clockwise, and again comes into contact with the stopper pin. With this condition, the heat control valve is in the full open position, and exhaust gas passes through the exhaust manifold as shown by the dotted lines in Figure EC-4 without heating the manifold stove.

## REMOVAL AND INSTALLATION



EC533

Fig. EC-5 Exploded view of E.F.E. system

Remove snap ring ① and lock bolt ②, and the following parts can be detached from heat control valve shaft.

- Key ③
- Counterweight ④
- Thermostat spring ⑤
- Coil spring ⑥

Note: As previously described, heat control valve ⑦ is welded to valve shaft ⑧ at exhaust manifold, and cannot be disassembled.

To install, reverse the removal procedure.

## INSPECTION

1. Run engine and visually check counterweight to see if it operates properly.

(1) For some time after starting engine in cold weather, counterweight turns counterclockwise until it comes into contact with stopper pin installed to exhaust manifold.

Counterweight gradually moves down clockwise as engine warms up and ambient temperature goes higher around exhaust manifold.

(2) When engine speed is increased, discharge pressure of exhaust gases causes counterweight to move downward clockwise.

(3) When heat control valve is in the full open position, counterweight moves further clockwise exceeding the

position described in 1-(1) above, and stops again coming into contact with stopper pin.




Fig. EC-6 Operation of counterweight when engine is cold




Fig. EC-7 Operation of counterweight when engine is hot

2. With engine stopped, visually check E.F.E. system for the following items.

- (1) Thermostat spring for dismounting
- (2) Stopper pin for bend, and counter weight stop position for dislocation
- (3) Check heat control valve for malfunction due to break of key that locates counterweight to valve shaft.
- (4) Check axial clearance between heat control valve and exhaust manifold. Correct clearance is 0.7 to 1.5 mm (0.028 to 0.059 in).
- (5) Check welded portion of heat control valve and valve shaft for any indication of crack or flaking.
- (6) Rotate heat control valve shaft by a finger, and check for binding between shaft and bushing in closing and opening operation of heat control valve. If any binding is felt in rotating operation, move valve shaft in the rotation direction several times. If this operation does not correct binding condition, it is due to seizure between shaft and bushing, and exhaust manifold should be replaced as an assembly.

## CHECKING SPARK TIMING CONTROL SYSTEM

### DESCRIPTION

The spark timing control system serves to control the distributor vacuum advance under varying travelling conditions so as to reduce HC and NOx emissions.

This system is installed on non-California automatic transmission models.

### SPARK DELAY VALVE (Automatic transmission models only)

This valve delays vacuum spark advance during rapid acceleration; it also cuts off the vacuum spark advance immediately upon deceleration. The valve is designed for one-way operation and consists of a one-way umbrella valve and sintered steel fluidic restrictor.




Fig. EC-8 Spark delay valve

When installing this valve, ensure that it properly oriented. This valve should be replaced periodically. Refer to "Maintenance Schedule".

**Note:** Carburetor side-Black  
Distributor side-Brown

is in good condition if, when finger is placed over port on distributor side, air flow resistance is greater than that on the other side. See Figure ET-10.

3. If a considerable air flow resistance is felt at port on distributor side in step 2 above and if the condition of spark delay valve is questionable, dip port (on carburetor side) into a cup filled with water. Blow air through the other port. Small air bubbles should appear.




Fig. EC-9 Operation of spark delay valve

## INSPECTION

1. Remove spark delay valve.
2. Blow air through port on carburetor side, then through the other port (on distributor side). Spark delay valve




Fig. EC-10 Checking spark delay valve




Fig. EC-11 Checking spark delay valve


**Note:** Be careful to avoid entry of oil or dirt into valve.

## AIR INJECTION SYSTEM

### DESCRIPTION

The Air Injection System (A.I.S.) is designed to inject compressed air (secondary air) coming from the air pump into the exhaust manifold to reduce hydrocarbons and carbon monoxide in exhaust gas through re-combustion. There are two types of A.I.S.: One type is mounted on California models and the other is on non-California models. The non-California type consists of an air pump air cleaner, an air pump, a relief valve, a check valve, an anti-backfire valve, an air gallery and hoses. The California type has, in addition to the components of the non-California type, an air control valve and an emergency air relief valve. These valves prevent abnormal temperature rise of the catalytic converter.


## Emission Control System



- 1 Check valve
- 2 Air gallery pipe
- 3 Automatic temperature control air cleaner
- 4 Air hose (carburetor air cleaner to A.B. valve)
- 5 Anti-backfire valve (A.B. valve)
- 6 Air hose (A.B. valve to intake manifold)
- 7 Air hose (carburetor air cleaner to air hose connector)
- 8 Air hose (check valve to air hose connector)
- 9 3-way connector
- 10 Air hose (air hose connector to air pump)
- 11 Air hose (air pump to air pump air cleaner)
- 12 Air pump air cleaner
- 13 Air pump

EC776

*Fig. EC-12 Non-California type A.I.S.*




- 1 Air control valve
- 2 Check valve
- 3 Air hose (check valve to air hose connector)
- 4 Air gallery pipe
- 5 Automatic temperature control air cleaner
- 6 Air hose (carburetor air cleaner to A.B. valve)
- 7 Anti-backfire valve (A.B. valve)
- 8 Air hose (A.B. valve to intake manifold)
- 9 Air relief valve
- 10 Air hose (carburetor air cleaner to air control valve)
- 11 Air hose (air relief valve to air hose connector)
- 12 Air hose (air hose connector to emergency air relief valve)
- 13 Emergency air relief valve
- 14 Air pump air cleaner
- 15 Air hose (air hose connector to air pump)
- 16 Air hose (air pump to air pump air cleaner)
- 17 Air pump

EC777

*Fig. EC-13 California type A.I.S.*

## Air pump air cleaner

The air cleaner element is a viscous paper type, and requires periodic replacement. The air pump air cleaner is bolted to the left front of the hood-ledge.



EC778

Fig. EC-14 Air pump air cleaner

## Air pump

The air pump is a two-vane type. It has two positive displacement vanes which requires no lubricating service.

The die-cast aluminum air pump assembly attached to the front of the engine is driven by an air pump drive belt. A rotor shaft, drive hub, inlet and outlet tubes are visible on the pump exterior. A rotor, vanes, carbon shoes, and shoe springs make up the rotating unit of the pump. The rotor located in the center of the pump is belt-driven. The vanes rotate freely around the off-center pivot pin, and follow the circular-shaped pump bore. In the two-vane type, the vanes form two chambers in the housing. Each vane completes a pumping cycle in every revolution of the rotor. Air is drawn into the inlet cavity through a tube connected to the air pump air cleaner. Air is sealed between the vanes and moved into a smaller cavity (the compression area).

After compression, a vane passes



the outlet cavity. Subsequently it passes the stripper and a section of the housing that separates the outlet and inlet cavities and again reaches the inlet cavity to repeat the pumping cycle.

Carbon shoes (in the slots of the rotor) support the vanes. They are designed to permit sliding of the vanes and to seal the rotor interior from the air cavities. Leaf springs which are behind the leading-side of the shoes compensate for shoe abrasion.

The rotor ring is a steel bolted to the rotor end. It positions the rotor and holds the carbon shoes.

The vane uses needle bearings. All bearings have been greased.

There are two types of bearing which support the rotor. Ball bearing is used for the front one and the needle bearing is used for the rear.



- 1 Air pump drive hub
- 2 Housing
- 3 Rotor ring
- 4 End cover (with needle bearing)
- 5 Vane
- 6 Carbon shoe

- 7 Shoe spring
- 8 Stripper
- 9 Rotor shaft
- 10 Ball bearing
- 11 Front bearing cover
- 12 Pulley
- 13 Pulley (for air conditioner)


EC560

Fig. EC-15 Sectional view of air pump (two-vane type)

## Air control valve (California models)

The air control valve controls the quantity of secondary air fed from the air pump according to engine speed and load condition, and prevents excessive temperature rise of the catalytic converter.

The construction is as shown in Figure EC-16. The intake manifold vacuum and air pump discharge pressure applied to the diaphragm chamber actuate the valve which is coupled to the diaphragm and control the quantity of secondary air to be fed into the exhaust manifold in response to the engine condition.



EC291

Fig. EC-16 Air control valve

## Anti-backfire valve

This valve is controlled by intake manifold vacuum to prevent backfire in the exhaust system at the initial period of deceleration.

At this period, the mixture in the intake manifold becomes too rich to ignite and burn in the combustion chamber and burns easily in the exhaust system with injected air in the exhaust manifold.

The anti-backfire valve provides air to the intake manifold to make the air-fuel mixture leaner and prevents backfire.


A schematic drawing of the anti-backfire valve is shown in Figure EC-17.

The anti-backfire valve inlet is connected to the air cleaner and the outlet to the intake manifold.

The correct function of this valve reduces hydrocarbon emission during deceleration.

If the valve does not work properly, unburned mixture will be emitted

from the combustion chambers and burns with the aid of high-temperature and injected air which causes backfire.



EC069

Fig. EC-17 Anti-backfire valve


## Check valve

A check valve is located in the air pump discharge lines. The valve prevents the backflow of exhaust gas which occurs in one of the following cases.

1. When the air pump drive belt fails.

2. When relief valve spring fails.

Construction is shown in Figure EC-18.




EC292

Fig. EC-18 Check valve

## Air injection into exhaust port

The secondary air fed from the air pump goes through the check valve to the air gallery where it is distributed to each exhaust port. The secondary air is then injected from the air injection nozzle into the exhaust port near the exhaust valve.



EC293

Fig. EC-19 Air injection into exhaust port

## Air pump relief valve

The air pump relief valve controls the injection of the secondary air into the exhaust system when the engine is


running at high speed under a heavily loaded condition. It accomplishes the following functions without affecting the effectiveness of the exhaust emission control system.

## Emission Control System

1. Minimizes exhaust gas temperature rise.
2. Minimizes horsepower losses resulting from air injection into the exhaust system.
3. Protects pump from excessive back pressure.

The air pump relief valve is installed as shown in Figure EC-20.

The secondary air is discharged from the air pump relief valve to the dust side of the carburetor air cleaner.




EC294

Fig. EC-20 Air pump relief valve

### Emergency air relief valve (E.A.R. Valve) (California models)

The emergency air relief valve controls the quantity of secondary air fed from the air pump according to load condition, and it discharges the secondary air into the atmosphere to prevent overheating of the catalytic converter.

The emergency air relief valve consists of a diaphragm, a spring and a valve which is coupled to diaphragm.



EC536

Fig. EC-21 Emergency air relief valve

### OPERATION

As mentioned previously, there are two types of Air Injection Systems (A.I.S.): a non-California type and a

California type. The California standard type includes a system which controls injection of secondary air so as to assure proper function of the catalytic converter, and a system which controls the supply of secondary air to prevent abnormal temperature rise in the catalytic converter.

The A.I.S. consists of the following systems:


1. A system which allows injection of secondary air into the exhaust port.
2. A system which bypasses secondary air from the air pump relief valve to the carburetor air cleaner during high speed engine operation.
3. A system which supplies air from the carburetor air cleaner to the intake manifold by means of the anti-backfire valve so as to prevent after-fire during deceleration.
4. A system which controls injection of the secondary air by means of the air control valve so as to maintain the catalytic converter at an optimum temperature level under lightly loaded conditions.

(California type only)

5. A system which controls the supply of secondary air through the emergency air relief valve to prevent abnormal temperature rise of the catalytic converter.

(California type only)

A.I.S. operation is as follows:



EC779


Fig. EC-22 Non-California type A.I.S.

## Emission Control System

The non-California type operates as follows: secondary air is sucked through the air pump air cleaner into the air pump driven by the crank pulley. It is then discharged through the check valve to the air gallery where it is distributed to each exhaust port. The secondary air is then injected from the injection nozzle into the exhaust port near the exhaust valve.

The air relief valve opens only when the discharge pressure of the air pump surpasses the spring force of the air relief valve during high speed operation. When the air relief valve opens, the secondary air is discharged into the carburetor air cleaner.

The anti-backfire valve opens when the intake manifold vacuum reaches a predetermined value during deceleration and permits fresh air to flow into the intake manifold from the air cleaner.



EC297


Fig. EC-23 Operation of A.B. valve

The California type includes, in addition to the components of the non-California type, an air control valve and an emergency air relief valve.

The air control valve opens when the sum of the air pump discharge pressure and the intake manifold vacuum applied to the diaphragm reaches a predetermined level, and discharges the secondary air into the air cleaner. When the pressure becomes low, the valve closes with the spring force of

the air control valve, and stops discharging the secondary air (Figure EC-25).

When the intake manifold vacuum applied to the diaphragm reaches a predetermined level, E.A.R. valve operates to discharge the secondary air into the atmosphere. When the pressure becomes high, the valve closes by spring tension of E.A.R. valve, and stops discharging the secondary air.



- 1 Air pump
- 2 Air pump air cleaner
- 3 Emergency air relief valve
- 4 Air relief valve


- 5 Air cleaner
- 6 Check valve
- 7 Air gallery pipe
- 8 Carburetor

- 9 Air control valve
- 10 Injection nozzle
- 11 Exhaust manifold
- 12 Anti-backfire valve

EC780

Fig. EC-24 California type A.I.S.






EC299  
Fig. EC-25 Operation of air control valve

## REMOVAL AND INSTALLATION

### Air pump air cleaner

Remove air hose, then detach air cleaner from hoodledge. Air cleaner element and air cleaner lower body are built into a unit construction. Replace air cleaner element and lower body as an assembly.



EC323

Fig. EC-26 Replacing air cleaner element

### Air pump


1. Remove air hoses from air pump.
2. Loosen air pump adjusting bar mounting bolts and air pump mounting bolts, then remove air pump drive belt.
3. Remove air pump pulley.
4. Remove air pump from bracket.

### Air control valve (California models)

1. Disconnect air hoses and a vacuum hose from air control valve.
2. Remove air control valve from bracket.

### E.A.R. valve (California models)

Remove vacuum pipe and air hose, and dismount E.A.R. valve.



EC781

Fig. EC-27 Location of E.A.R. valve

### Anti-backfire valve

Disconnect air hose and vacuum hose from anti-backfire valve.

### Check valve

Disconnect hose and remove check valve from air gallery pipe.

### Air gallery pipe and injection nozzles

It is very difficult to remove the air gallery from the exhaust manifold without bending the pipe, which could result in fractures or leakage. Therefore, removal of the air gallery pipe and injection nozzles should be undertaken only when they are damaged.

1. Lubricate around the connecting portion of air injection nozzle and air gallery with engine oil.
2. Hold air injection nozzle hexagon head with a wrench and unfasten flare screw connecting air gallery to injection nozzle. Remove air gallery.

### Notes:

- a. Apply engine oil to screws several times during above work.
  - b. Be careful not to damage other parts.
3. Unfasten air injection nozzle from cylinder head applying engine oil to screwed portion several times.
  4. Check air gallery and nozzle for fractures or leakage. Clean air injection nozzle with a wire brush.
  5. At time of installation, hold air injection nozzle hexagon head with a wrench and tighten air gallery flange screw to a torque of 5.0 to 5.9 kg-m (36 to 43 ft-lb).
  6. Check cylinder head, air injection nozzle and air gallery for leaks with engine running.

### Air pump relief valve

Loosen carburetor air cleaner mounting screws, and remove air pump relief valve.

### Installation

Install in the reverse order of removal.


## DISASSEMBLY AND ASSEMBLY

### Disassembly of air pump

1. Remove four pulley drive bolts and remove pulley from hub.
2. Secure air pump drive hub in a vise, as shown in Figure EC-28 and remove four end cover bolts.

## Emission Control System

**Note:** Never clamp on the aluminum housing.



EC302


*Fig. EC-28 Removing cover*

3. Remove end cover by carefully tapping around dowel pin with a plastic mallet and lift up straight.

4. Put match marks "O" on rotor ring and side of rotor to ensure correct reassembly and remove four screws that retain rotor ring to rotor, using a Hexagonal Wrench ST19810000.

### Notes:

a. Generally, match marks are indicated on both rotor ring and rotor by the manufacturer.




EC111

*Fig. EC-29 Removing rotor ring*

b. Discard screws which were removed. Always use new ones when installing.

5. Remove vane from rotor.




EC561

*Fig. EC-30 Removing vanes*

6. Remove four carbon shoes and two shoe springs from rotor using needle nose pliers or tweezers.

**Note:** Carbon shoe "A" is 1 mm (0.039 in) wider than "B". Do not confuse them.



EC539


*Fig. EC-31 Removing shoe springs*

If replacement of front bearing is necessary, proceed as follows:

7. Remove air pump drive hub with standard puller.

8. Remove four screws securing front bearing cover in place, and detach bearing cover.


9. Support the rear end face of air pump housing with Rotor Adapter ST19890000. Drive rotor out by pushing rotor shaft with Bearing Pressing Tool ST19940000.



EC303

*Fig. EC-32 Removing rotor shaft*


10. Support the front end face of housing with Bearing Adapter ST19930000. Attach Bearing Driver ST19910000 to front bearing on the inside of air pump housing, and press out.



EC304

*Fig. EC-33 Removing ball bearing*

11. Keep disassembled parts in order.




EC562

**Fig. EC-34 Components of two-vane type**

## Assembly of air pump

### 1. Front bearing

Support the rear end face of air pump housing with Rotor Adapter ST19890000. Press front bearing into place with a press and Bearing Pressing Tool ST19940000.



**Fig. EC-35 Pressing ball bearing**


### 2. Bearing cover

Torque four bearing cover securing bolts to 0.1 to 0.2 kg-m (0.7 to 1.4 ft-lb).

### 3. Rotor shaft

Support the inward bottom of rotor with Rotor Stand ST19920000.

Press rotor into place with a press and Bearing Drive ST19910000 until the stepped portion of rotor shaft touches front bearing inner race.



**Fig. EC-36 Pressing rotor shaft**

### Notes:


- Be sure to drive front bearing inner race in.
- After rotor is installed in place, ensure that the rotor end is positioned below the end face of air pump housing.

Position of rotor end below air pump housing:  
0.050 to 0.150 mm  
(0.0020 to 0.0059 in)

### 4. Air pump drive hub

Support the inward bottom of rotor with Rotor Stand ST19920000.

Press drive hub into place with a press and Bearing Driver ST19910000 until the end face of drive hub touches front bearing inner race.




EC308

**Fig. EC-37 Pressing air pump drive hub**

### 5. Carbon shoe

- Place air pump drive hub in a vise.
- Clean carbon, dust, etc. from shoe grooves.
- Align rotor with housing properly. Refer to Figure EC-38. Then insert carbon shoes into place, noting their directions.



EC540


Fig. EC-38 Install carbon shoe

## Notes:

- Carbon shoe "A" is 1 mm (0.039 in) wider than "B". Do not confuse them.
- If carbon shoes are exposed beyond the rotor end face, remove carbon shoes and clean shoe grooves. Reassemble carbon shoes.

## 6. Vane

- Pack vane bearing with high melting-point grease (MIL-G-3545 A, Esso ANDOK260 or equivalent), and insert dummy shaft into the vane bearing.



EC563


Fig. EC-39 Vane assembly

- Install vane in place on rotor, using Dummy Shaft ST19900000 as a guide.

**Note:** The vanes may require 6 to 16 km (4 to 10 miles) wear-in running time. In the event a slight squeaking still remains, drive the car about 64 to 80 km/h (40 to 50 MPH). In most cases 6 to 16 km (4 to 10 miles) will be sufficient for wear-in.

## 7. Shoe spring

Place shoe springs in deeper groove of shoe.



EC123

Fig. EC-40 Installing shoe spring

**Note:** When installing a shoe spring, make sure that the outward bending side faces in shoe and that both ends of spring face in the wall of shoe groove.


Be sure to push spring in so that spring end face is flush with rotor.

## 8. Rotor ring

Install rotor ring by correctly aligning the rear end face of rotor with the "O" mark in rotor ring, and tighten four screws to the specified torque with Hexagonal Wrench ST19810000.

Tightening torque:

0.5 to 0.7 kg-m  
(3.6 to 5.1 ft-lb)



EC124

Fig. EC-41 Installing rotor ring

## 9. Removal of dummy shaft

Carefully withdraw dummy shaft from vane.

## 10. Vane shaft

Pack rear bearing with high melting-point grease (MIL-G-3545 A, Esso ANDOK 260 or equivalent). Apply thin coating of grease to vane shaft and rotor ring, and insert vane shaft into its bearing.

## Notes:


- Do not apply an undue stress to vane shaft when inserting.
- If two vanes are dislocated when inserting vane shaft, correctly align vanes by inserting dummy shaft. Then, draw out dummy shaft and insert vane shaft.
- When wear occurs on vane shaft or when replacement of rear bearing is necessary, replace rear cover assembly.

## 11. End cover

Position end cover in place. Snugly tighten the bolt close to the dowel. Then tighten four bolts to the specified torque.

Tightening torque:

0.7 to 0.9 kg-m  
(5.1 to 6.5 ft-lb)



EC302

Fig. EC-42 Installing end cover

## 12. Pulley

Tighten four pulley securing bolts to the specified torque.

Tightening torque:

0.7 to 0.9 kg-m  
(5.1 to 6.5 ft-lb)

## INSPECTION

### Air Injection system hoses

Check air system hoses for loose connections, cracks, or deterioration. Retighten or replace if necessary.

### Air system manifold

Check air gallery pipe and injection nozzles for loose connections and cracks. Retighten or replace if necessary.

## Emission Control System

### Air pump

1. Operate engine until it reaches normal operating temperature.
2. Inspect all hose, hose connections, and air gallery for leaks and correct, if necessary, before checking air injection pump.
3. Check air injection pump belt tension and adjust to specifications if necessary.
4. Disconnect air supply hose at check valve.
5. Disconnect vacuum hose from the air control valve (California type only).
6. Insert open pipe end of Air Pump Test Gauge Adapter ST19870000 in air supply hose. Clamp hose securely to adapter to prevent it from blowing out. Position adapter and test gauge so that air blast emitted through drilled pipe plug will be harmlessly dissipated.
7. Install a tachometer on engine. With engine speed at 2,600 rpm observe pressure produced at test gauge.

Air pressure should be 100 mmHg (3.94 inHg) or more.

8. If air pressure does not meet above specifications, proceed as follows:

- (1) Repeat 2 and 3 above.
- (2) Disconnect air supply hose at anti-backfire valve. Plug air hose opening, and screw with a clamp. Repeat pressure test.
- (3) With engine speed at 1,500 rpm close hole of test gauge with finger. If a leaking sound is heard or leaking air is felt by finger at relief valve, relief valve is malfunctioning. Relief valve should be replaced or repaired.
- (4) If air injection pump does not meet minimum requirement of pressure test, it should be replaced.

### Control valve

The following procedures are recommended for checking and/or ascertaining that the various components of the exhaust emission control system are operating properly.

The engine and all components must be at normal operating temperatures when the tests are performed. Prior to performing any extensive diagnosis of the exhaust control system, it

must be determined that the engine as a unit is functioning properly.

### Check valve

1. Warm up engine thoroughly.
2. Disconnect hose leading to check valve from air hose connector.
3. Check hose opening for any indication of exhaust gas leaks. If leaks are detected, replace check valve.
4. Race the engine lightly (at about 2,000 rpm) and then return it to idling. Visually check the hose for any indication of exhaust gas leaks before the engine returns to idling speed. If leaks are detected, replace check valve.




Fig. EC-43 Checking check valve

### Air pump relief valve

After completing inspection of air pump, check air pump relief valve in the following steps:

1. Disconnect hoses leading to check valve and air control valve from air hose connector, and install blind cap to the connector.
2. With engine running at about 3,000 rpm under no load, place your hand on the air outlet of air pump relief valve to check for discharged air. If no air is felt, replace the air pump relief valve.




Fig. EC-44 Checking air pump relief valve

### Air control valve (California models)

1. Warm up engine thoroughly.
2. Before checking air control valve, check all hoses for loose connection, leaks, etc., and repair or correct if necessary.
3. With engine idling, disconnect the outlet side hose of the air control valve, and place your hand on the air hose outlet to check for air. If no air is felt, replace the air control valve.
4. Pull vacuum hose off from air control valve. If discharge of air from air hose stops, the air control valve is normal. If discharge is still felt, replace the valve.

Plug up the removed vacuum hose to stabilize engine running.





Fig. EC-45 Checking air control valve

### Emergency air relief valve (E.A.R. Valve) (California models)

1. Warm up engine thoroughly.
2. Before checking air control valve, check all hoses for loose connection, leaks, etc., and repair or correct if necessary.
3. Race engine (approximately 2,000 rpm) under no load. Place your hand on air outlet of E.A.R. valve to check for presence of discharged air. If no air is felt, E.A.R. valve is normal.
4. Disconnect vacuum hose from E.A.R. valve as shown in Figure EC-46.

Run engine (approximately 2,000 rpm) under no load. Place your hand on air outlet of E.A.R. valve to check for presence of discharged air. If air is felt, E.A.R. valve is normal.

5. If E.A.R. valve does not function properly at above steps, replace E.A.R. valve.




ET267

Fig. EC-46 Checking E.A.R. valve

## Anti-backfire valve (A.B. valve)

1. Warm up engine thoroughly.
2. Disconnect hose from air cleaner, and place a finger near the outlet.
3. Run engine at about 3,000 rpm under no load, then quickly return it to idling. If you feel a pull or suction force on your finger, the anti-backfire valve is functioning normally. If no suction is felt, replace the anti-backfire valve.



EC313

Fig. EC-47 Checking anti-backfire valve

## EXHAUST GAS RECIRCULATION CONTROL SYSTEM (E.G.R.)

### DESCRIPTION


In the exhaust gas recirculation system, a part of the exhaust gas is returned to the combustion chamber to lower the spark flame temperature during combustion. This results in a reduction of the nitrogen oxide content in the exhaust gas.

The exhaust gas recirculation system consists of an E.G.R. passage, E.G.R. control valve, thermal vacuum valve, E.G.R. tube and hose. A warn-

ing system which indicates when the E.G.R. control system must be inspected is also installed in all 620 models except those bound for California and Canada.

When the E.G.R. control valve is open, some of the exhaust gas is led from the exhaust manifold to the E.G.R. chamber through the E.G.R. passage. The exhaust gas is then controlled in quantity by the E.G.R. valve, and is introduced into the intake manifold.

Open-close operation of the E.G.R. control valve is controlled by the thermal vacuum valve which operates on carburetor vacuum and engine coolant temperature.



- 1 Carburetor
- 2 E.G.R. control valve
- 3 E.G.R. passage
- 4 Intake manifold
- 5 Thermal vacuum valve
- 6 E.G.R. tube
- 7 Exhaust manifold

EC349

Fig. EC-48 Exhaust Gas Recirculation system (E.G.R.)

### OPERATION

Operation of E.G.R. system is as shown below:

E.G.R.	E.G.R. system operating water temperature °C (°F)	Thermal vacuum valve	Intake manifold vacuum	E.G.R. control valve	Remarks
Not actuated	Below 57°C (135°F)	Close	—	Close	—
	Above 57 to 63°C (135 to 145°F)	Open	Above	Close	Idling
			Below		Full throttle
Actuated	Above 57 to 63°C (135 to 145°F)	Open	Above	Open	—


## Emission Control System

### E.G.R. "OFF" operation

1. When engine coolant temperature is low, recirculated exhaust gas causes irregular engine operation. To prevent

this, recirculation of exhaust gas must be cut off for a few minutes after engine has started. The thermal vacuum valve is provided for this purpose.

It remains closed while engine coolant temperature is low and keeps the E.G.R. control valve closed, thereby cutting off the E.G.R. circuit.




2. When engine coolant temperature is above the working temperature of the thermal vacuum valve:

(1) The valve port comes to the top

of the throttle valve during engine idling for improved idling operation.

At this point, vacuum does not actuate the E.G.R. control valve


though intake manifold vacuum is high, and E.G.R. control valve remains closed.



(2) In the full throttle driving position, the suction vacuum on the vacu-

um passage does not surpass the vacuum required to actuate the E.G.R.

control valve.



EC793


Fig. EC-51 E.G.R. not actuated

## E.G.R. "ON" operation

The E.G.R. circuit is completed only when engine coolant temperature

is above the working temperature of the thermal vacuum valve and carburetor

suction vacuum is large enough to open the E.G.R. control valve.



EC794

Fig. EC-52 E.G.R. actuated

## E.G.R. control valve

The E.G.R. control valve controls the quantity of exhaust gas to be led to the intake manifold through vertical movement of the taper valve connected to the diaphragm, to which vacuum


is applied in response to the opening of the carburetor throttle valve. The E.G.R. control valve is installed on the E.G.R. passage through a gasket.

E.G.R. control valve construction and type vary with transmission type

and car destination. For identification purposes, the part number is stamped on the recessed portion at the top of the valve.

The construction of the E.G.R. control valve is shown below.





EC231


Fig. EC-53 E.G.R. control valve

## Thermal vacuum valve

The thermal vacuum valve is mounted in the engine thermostat housing. It detects engine coolant temperature by means of a built-in bi-metal, and opens or closes the vacuum passage in the thermal vacuum valve.

When the vacuum passage is open, the carburetor suction vacuum is applied to the diaphragm of the E.G.R. control valve to actuate the taper valve connected to the diaphragm.

The construction of the thermal vacuum valve is shown below.



EC232

Fig. EC-54 Thermal vacuum valve

## E.G.R. warning system

The E.G.R. warning system, install-

ed independently of the E.G.R. control system, monitors the distance the car has travelled and indicates when

the E.G.R. control system must be checked.

The E.G.R. warning system consists of an odometer switch, detector drive counter, E.G.R. warning lamp and harnesses. When the cam in the odometer switch connected to the speedometer turns once for each 0.4 km (¼ mile), the contact point of the electrical circuit closes, allowing electric current to flow through the magnet coil of the detector drive counter. Thus energized, the magnet coil actuates the latchet to turn the counter wheel by one pitch. When the number of counts reaches 50,000, the latchet drops in a groove provided on the periphery of the counter wheel to activate the detector drive counter switch.

Then the E.G.R. warning lamp comes on, indicating that the E.G.R. control system should be checked.

The detector drive counter is equipped with an odometer which can tell when to service the E.G.R. control system.

After completing periodic check, reset the odometer to zero by hand, proceeding as follows:


1. Remove grommet installed on the side surface of detector drive counter unit.
2. Insert a bar or a screwdriver tip into the hole from which grommet has been removed, and press down knob provided in the detector drive counter for resetting.

The E.G.R. warning lamp comes on under the following circumstances:

- (1) When the number of counts has reached 50,000. In this case, the lamp indicates that E.G.R. control system must be checked.
- (2) When operating starter motor.

### Notes:

- a. It is an indication of problem in the E.G.R. warning lamp, or problems in the point or in the harnesses if the lamp does not light at 50,000 counts.
- b. The E.G.R. warning system is mounted on all 620 models except those bound for California and Canada.



EC233

Fig. EC-55 E.G.R. warning circuit

## REMOVAL AND INSTALLATION

Remove air cleaner before removing E.G.R. control system. For removal and installation of air cleaner, refer to "Air Cleaner" section (Page EF-5).


### Removal

#### 1. E.G.R. control valve

After removing the following parts the E.G.R. control valve can be dismounted.

- Vacuum hose (thermal vacuum valve to E.G.R. control valve)
- E.G.R. control valve mounting nut

**Note:** To remove vacuum hose, flat-ten clip connecting vacuum hose to E.G.R. control valve and pull the hose off with hand.




EC234

Fig. EC-56 Removing E.G.R. control valve.

#### 2. E.G.R. passage

After removing the following parts the E.G.R. passage can be dismounted.

- Exhaust gas return tube (exhaust manifold to E.G.R. passage)
- Blow-by hose (cylinder block to P.C.V. valve)
- Vacuum hose (AB valve to E.G.R. passage)
- E.G.R. passage mounting bolt



EC541


Fig. EC-57 Removing E.G.R. passage

#### 3. Thermal vacuum valve

After removing the following parts the thermal vacuum valve can be dismounted.

- Vacuum hose (carburetor to thermal vacuum valve)
- Vacuum hose (thermal vacuum valve to E.G.R. control valve)

**Note:** Drain engine coolant before dismounting thermal vacuum valve.




EC236

Fig. EC-58 Removing thermal vacuum valve

## Emission Control System

### 4. E.G.R. warning system



EC251

Fig. EC-59 E.G.R. warning system

#### 1. Detector drive counter

Detector drive counter is secured on the top of R.H. hoodledge panel in engine room. To remove detector drive counter, disconnect wire connector and loosen two bolts securing detector drive counter to hoodledge panel.

#### 2. E.G.R. warning lamp


E.G.R. warning lamp is mounted at the top center of instrument pad. To remove E.G.R. warning lamp, proceed as follows:

##### (1) Remove masking panel.

On models equipped with radio, remove warning lamp from under instrument panel.

##### (2) E.G.R. warning lamp is a twist type.

Remove lamp and socket as an assembly. Push and twist lamp off.



EC554

Fig. EC-60 Removing E.G.R. warning lamp

#### 3. Odometer switch


Odometer switch is mounted on the back side of speedometer. Cam in the odometer switch is rotated by the speedometer. To dismount odometer switch, proceed as follows:

##### (1) Dismount combination meter assembly.

##### (2) Remove meter front cover, and take off clips and screws to dismount shadow plate.

##### (3) Loosen screws securing speedometer to printed circuit housing, then remove speedometer.

##### (4) Remove two screws securing odometer switch to the back side of speedometer, and detach odometer switch.



EC239

Fig. EC-61 Removing odometer switch

### Installation

To install, reverse the removal procedure.

### INSPECTION

Checking E.G.R. control system in its mounted conditions.

#### 1. Make a thorough visual check of E.G.R. control system. If necessary, wipe away oil to facilitate inspection. If any hoses are cracked or broken, replace.

2. With engine running, check E.G.R. warning system for proper function. Make sure that E.G.R. warning lamp lights when ignition switch is turned to START-position (starter motor runs). If E.G.R. warning lamp does not light, inspect harnesses and connectors or replace warning lamp. Then turn ignition switch to ON position, and check the following items:

##### (1) If odometer of detector drive counter has not reached 50,000 counts, make sure that E.G.R. warning lamp does not light.

##### (2) If odometer of detector drive counter has attained 50,000 counts, make sure that E.G.R. warning lamp lights.

If warning lamp does not light, check harnesses, connectors, and detector drive counter; replace warning lamp or detector drive counter if necessary.

### Notes:

a. Operation of E.G.R. warning lamp is as follows:

## Emission Control System

Ignition Switch Position	START	ON	
Detector Drive Counter	—	Below 50,000 counts	Above 50,000 counts
E.G.R. Warning Lamp	ON	OFF	ON

b. After completing inspection of E.G.R. control system, be sure to reset odometer of detector drive counter to zero.

c. This item applies to all 620 models except those bound for California and Canada.


3. With engine stopped, inspect E.G.R. control valve for any indication of binding or sticking by moving diaphragm of control valve upwards with a finger.

4. With engine running, inspect E.G.R. control valve and thermal vacuum valve for normal operation.

(1) When engine coolant temperature is low:

Make sure that E.G.R. control valve does not operate when engine speed is increased from idling to 3,000 to 3,500 rpm.

Place a finger on the diaphragm of E.G.R. control valve to check for valve operation.



EC253

Fig. EC-62 Checking E.G.R. control valve

(2) When engine coolant temperature is high:

1) Make sure that E.G.R. control valve operates when engine speed is increased from idling to 3,000 to 3,500 rpm. Place a finger on the diaphragm of E.G.R. control valve to check for valve operation.


2) If E.G.R. control valve does not operate, check as follows:

- Disconnect one end (E.G.R. control valve side) of vacuum hose connecting thermal vacuum valve to E.G.R.

control valve.

- Increase engine speed from idling to 3,000 to 3,500 rpm.
- Make sure that thermal vacuum valve is open, and that carburetor vacuum is present at the end (E.G.R. control valve side) of vacuum hose.

If vacuum is weak or not present at all, replace thermal vacuum valve. If vacuum is present, replace E.G.R. control valve.



EC254

Fig. EC-63 Checking thermal vacuum valve


If any difficulty is encountered in judging the condition of any component during above inspection, check the questionable component independently as follows:

### E.G.R. control valve

Dismount E.G.R. control valve from engine.

1. Apply vacuum to E.G.R. control valve, referring to the following figure. If the valve moves to full position, it is normal.

E.G.R. control valve will remain open for more than 30 seconds after vacuum has cut off.




ET 152

Fig. EC-64 Checking E.G.R. control valve

2. Visually check E.G.R. control valve for damage, wrinkle or deformation.

3. Clean the seating surface of E.G.R. control valve with a brush and compressed air, and remove foreign matter from around the valve and port.



EC350

Fig. EC-65 Cleaning E.G.R. control valve

## Thermal vacuum valve


Dismount thermal vacuum valve from engine.

**Note:** Before dismounting, drain engine coolant from engine.

Apply vacuum to thermal vacuum valve and check to be sure that thermal vacuum valve opens or closes in response to engine coolant temperature as specified.

Thermal vacuum valve should open at a temperature of 57 to 63°C (135 to 145°F) completing the vacuum passage.

**Note:** Do not allow water to get inside the thermal vacuum valve.



EC242


Fig. EC-66 Checking thermal vacuum valve

## CATALYTIC CONVERTER

### DESCRIPTION

The catalytic converter accelerates the chemical reaction of hydrocarbons (HC) and carbon monoxide (CO) in the exhaust gas, and changes them into non-harmful carbon dioxide (CO<sub>2</sub>)

and water (H<sub>2</sub>O). This chemical reaction process requires the proper amount of air, which is supplied by the air pump (Refer to the item "A.I.S."). This air is called "secondary air". The catalytic converter is mounted on the vehicles destined for California. Refer to Figure EC-67.



- |                       |                |
|-----------------------|----------------|
| 1 Front tube          | 4 Main muffler |
| 2 Catalytic converter | 5 Rear tube    |
| 3 Center tube         |                |

EC782


Fig. EC-67 Location of catalytic converter

### OPERATION

Exhaust gas emitted from the engine contains some harmful substances due to incomplete combustion in the combustion chamber. The air injection system is designed to reduce the content of such substances in the exhaust gas. In this system, the secondary air is led from the check valve and injected into the exhaust manifold. With this injection of the secondary air, hydro-

carbons (HC) and carbon monoxide (CO) in the exhaust gas are gradually oxidized with oxygen (O<sub>2</sub>) in the secondary air and converted into non-harmful carbon dioxide (CO<sub>2</sub>) and water (H<sub>2</sub>O).

The catalytic converter further cleans engine exhaust gas. Through catalytic action, it changes residual hydrocarbons and carbon monoxide contained in exhaust gas into carbon dioxide and water before exhaust gas is discharged to the atmosphere.



EC444

Fig. EC-68 Operation of catalytic converter


### REMOVAL AND INSPECTION

Removal and inspection can be done as follows:

#### Removal

##### Catalytic converter

1. Apply parking brake.
2. Place wheel lock under each tire.
3. Jack up the vehicle.
4. Remove lower shelter of catalytic converter.
5. Dismount catalytic converter.



EC453

Fig. EC-69 Removing catalytic converter

#### Inspection

##### Preliminary inspection

Visually check condition of all component parts including hoses; tubes, and wires, replace if necessary.

Refer to Inspection of A.I.S. on page EC-17.

##### Catalytic converter

Whether catalytic converter is normal or not can be checked by observing variation in CO percentage. The checking procedure is as follows:

Apply parking brake. Shift gears into Neutral (for manual transmission) and Neutral or Park (for automatic transmission).

1. Visually check catalytic converter for damage or cracks.

2. Remove air hose between 5-way connector and air check valve. Plug the disconnected hose to prevent dust from entering. Refer to page ET-12.
3. Check carburetor pipes for proper connection.
4. Warm up engine sufficiently.
5. Race engine (1,500 to 2,000 rpm) two or three times under no-load, then run engine for one minute at idling speed.
6. Adjust throttle adjusting screw until engine attains to specified speed. Refer to page ET-10.
7. Check ignition timing. If necessary, adjust it to specifications. Refer to page ET-10.
8. Adjust idle adjusting screw until specified CO percentage is obtained. Refer to page ET-12.
9. Repeat the adjustment process as described in steps 5 to 8 above until specified CO percentage is obtained.

**Note:** Adjustment in step 9 should be made ten minutes after engine has warmed up.

10. Race engine (1,500 to 2,000 rpm) two or three times under no-load and make sure that specified CO percentage is obtained.

11. Remove cap and connect air hose to air check valve.

If idling speed increases, readjust it to specified speed with throttle adjusting screw.

12. Warm up engine for about four minutes at 2,000 rpm under no-load.

13. Measure CO percentage at idling speed. After step 12 has been completed, wait for one minute before making CO percentage measurement.

14. If CO percentage measured in step 13 is less than 0.3%, the catalytic converter is normal.

15. If CO percentage measured in step 13 is over 0.3%, recheck A.I.S. and replace air check valve. Then, perform inspection steps 12 and 13.

16. If CO percentage is still over 0.3% in step 15, catalytic converter is malfunctioning. Replace catalytic converter.

### INSTALLATION

To install, reverse the removal procedure.

Bolt tightening torque specifications:

Tightening torque:

Catalytic converter

2.6 to 3.4 kg-m


(19 to 25 ft-lb)

### FLOOR TEMPERATURE WARNING SYSTEM DESCRIPTION

The floor temperature warning system consists of a floor temperature sensing switch installed on the vehicle's floor, floor temperature relay and a warning lamp on the instrument panel and wires that connect these parts.


When the floor temperature rises to an abnormal level, the warning lamp will light to call the attention of the driver. The wiring diagram of this system, and location of the floor temperature sensing switch are illustrated in Figures EC-70 and EC-71.

## Emission Control System



EC332

Fig. EC-70 Wiring diagram of floor temperature warning system



EC556

Fig. EC-71 Location of floor temperature sensing switch

### OPERATION


Floor temperature will exceed normal level when temperature rise in the exhaust system succeeding the catalytic converter is caused by either an engine malfunction or severe driving conditions. Under this condition the floor temperature sensing switch turns off, causing the starting switch line of the floor temperature relay to turn off

and the ignition switch line to turn on, as a result, the floor temperature warning lamp comes on.


When the floor temperature is lower than the specific temperature, the floor temperature sensing switch turns on. The ignition line of the floor temperature relay turns off, while the starting switch side is in on. The floor temperature warning lamp goes out.

The lamp is functioning satisfactorily, if it remains on while the starting motor is in operation. The lamp goes out when the ignition switch is in "IG" position.

The following chart furnishes the information on the relationship between floor temperatures, warning lamp and sensing switch.



EC340



Contact open

EC341

Fig. EC-72 Operation of floor temperature sensing switch


### REMOVAL

#### Floor temperature sensing switch

1. Remove seat as outlined in the "Seat" section of "Body and Frame" service manual.
2. Remove floor temperature sensing switch.

#### Floor temperature relay

From under relay cover, remove this part. Refer to Figure EC-73.



EC783

Fig. EC-73 Location of floor temperature relay

## Floor temperature warning lamp

Refer to Figure EC-74 for the location of this part.




Fig. EC-74 Location of floor temperature warning lamp

## INSTALLATION

To install, reverse the order of removal.

## INSPECTION

### Floor warning temperature system

Apply parking brake. Shift gears into Neutral (for manual transmission) and Neutral or Park (for automatic transmission).

1. Ensure that floor temperature warning lamp lights when ignition switch is turned to the "S" position.

If not, check lamp for burned bulbs.

Replace bulb if bulb is burned out.

If bulb is not burned, trace wire(s) back to ignition switch. Repair or replace if necessary.

2. Be sure that floor temperature is cool [below 80°C (176°F)] before carrying out the following procedure.

- (1) Remove rear seat.
- (2) Ignition switch is turned to the "IG" position.
- (3) Ensure that floor temperature warning lamp goes out.
- (4) Heat surrounding areas of floor temperature sensing switch with a proper heater to ensure that floor temperature warning lamp glows when floor is heated to the specifications as shown in the table below.

Temperature sensing switch	Temperature warning lamp	Floor temperature
Contact close	Off	Below 105°C (221°F)
Contact open	On	Above 105°C (221°F)

**Note:** Avoid heating floor temperature sensing switch directly.


If lamp does not glow, check floor temperature sensing switch connector for continuity with a circuit tester.

If continuity should exist after heated surrounding areas of floor temperature sensing switch, replace temperature sensing switch.

If continuity does not exist, trace the wiring back to relay or check the following step 3. Repair or replace wire(s) if necessary.

**Note:** The floor temperature sensing switch may be heated through the floor by a proper heater.

3. Turn ignition switch to the "IG" position, and disconnect floor temperature sensing connector. The lamp should remain on. If not, check floor temperature relay for continuity with



a circuit tester.

Referring to the following floor temperature relay, if relay is normal, trace wire(s) back to ignition switch. Repair faulty wiring.

### Floor temperature relay


When checking floor temperature relay for unit, remove it and proceed as follows:

1. Check for continuity between ④ and ⑤. Continuity should exist.

Check for continuity between ① and ③. Continuity should exist.

Check for continuity between ① and ②. Continuity should not exist.

2. Apply a 12-volt d-c across ④ and ⑤ to ensure that continuity exists between ① and ② and that continuity does not between ① and ③. If test results do not satisfy the above, replace the floor temperature relay.



EC344

Fig. EC-75 Checking floor temperature relay

### When floor temperature warning lamp lights

Check floor temperature warning lamp.

1. Open or short circuit in wiring harness.
2. Check fuel system with regard to the following items: (Refer to Inspection of Fuel System.)

- 1) Float level
- 2) Choke
- 3) Normal fuel supply system (Primary and secondary)
- 4) Accelerator pump
- 5) Power valve
- 6) B.C.D.D.
- 7) Fuel strainer
- 8) Air cleaner



## Emission Control System

3. Check ignition system with regard to the following items: (Refer to Inspection of Ignition System.)

- 1) Ignition AMP.
- 2) Distributor

- 3) Ignition coil
- 4) High tension code
- 5) Spark plug

4. Check idle CO adjustment. (Refer to Inspection of Idle CO Adjustment.)

Note: Even if there is nothing wrong with engine, the warning lamp may come on if vehicle is being driven on a steep slope continuously in lower gears at high engine speeds.

## EVAPORATIVE EMISSION CONTROL SYSTEM

### CONTENTS

DESCRIPTION .....	EC-30	CARBON CANISTER PURGE CONTROL	
OPERATION .....	EC-30	VALVE .....	IEC-32
INSPECTION .....	EC-31	CARBON CANISTER FILTER .....	IEC-32
FUEL TANK, VAPOR LIQUID SEPARATOR		FUEL TANK VACUUM RELIEF VALVE ...	EC-32
AND VAPOR VENT LINE .....	EC-31		

### DESCRIPTION

The evaporative emission control system is used to reduce hydrocarbons emitted to the atmosphere from the fuel system. This reduction of hydro-

carbons is accomplished by activated charcoals in the carbon canister.

This system is made up to the following:

- 1) Fuel tank with positive sealing filler cap
- 2) Vapor-liquid separator
- 3) Vapor vent line
- 4) Carbon canister
- 5) Vacuum signal line
- 6) Canister purge line




Fig. EC-76 Schematic drawing of evaporative emission control system

EF274


### OPERATION

Fuel vapors from the sealed fuel tank are led into the carbon canister.

The canister is filled with activated charcoals to absorb the fuel vapors

when the engine is at rest or at idling. See Figure EC-77.

## Emission Control System




EC784

*Fig. EC-77 Evaporative emission control system  
(Fuel vapor flow when engine is at rest or idling.)*

As the throttle valve opens and vehicle speed increases, vacuum pressure in the vacuum signal line forces

the purge control valve to open, and admits an orifice to intake manifold and fuel vapor is then drawn into the

intake manifold through the canister purge line. See Figure EC-78.



EC785

*Fig. EC-78 Evaporative emission control system  
(Fuel vapor flow when engine is running.)*

## INSPECTION

### FUEL TANK, VAPOR LIQUID SEPARATOR AND VAPOR VENT LINE

1. Check all hoses and fuel tank filler cap.
2. Disconnect the vapor vent line connecting carbon canister to vapor-liquid separator.
3. Connect a 3-way connector, a

manometer and a cock (or an equivalent 3-way charge cock) to the end of the vent line.

4. Supply fresh air into the vapor vent line through the cock little by little until pressure becomes 368 mmH<sub>2</sub>O (14.5 inH<sub>2</sub>O).
5. Shut the cock completely and leave it unattended.

6. After 2.5 minutes, measure the height of the liquid in the manometer.
7. Variation of height should remain

with 25 mmH<sub>2</sub>O (0.98 inH<sub>2</sub>O).

8. When filler cap does not close completely, the height should drop to zero in a short time.

9. If the height does not drop to zero in a short time when filler cap is removed, it is the cause of a stuffy hose.

**Note:** In case the vent line is stuffy, the breathing in fuel tank is not thoroughly made, thus causing in-

sufficient delivery of fuel to engine or vapor lock. It must, therefore, be

repaired or replaced.





Fig. EC-79 Checking evaporative emission control system

## CARBON CANISTER PURGE CONTROL VALVE

Check for fuel vapor leakage, in the distributor vacuum line, at diaphragm of carbon canister purge control valve.

To check for leakage, proceed as follows:


1. Disconnect rubber hose, in the line, between T-connector and carbon canister at T-connector.
2. Inhale air into the opening of rubber hose running to vacuum hole in carbon canister and ensure that there is no leak.



ET349

Fig. EC-80 Checking carbon canister purge control valve

3. If there is a leak, remove top cover from purge control valve and check for dislocated or cracked diaphragm. If necessary, replace diaphragm kit (which is made up of a retainer, a diaphragm and a spring).




ET350

Fig. EC-81 Carbon canister purge control valve

## CARBON CANISTER FILTER

Check for a contaminated element.

Element can be removed at the bottom of canister installed on vehicle body.




ET370

Fig. EC-82 Replacing carbon canister filter

## FUEL TANK VACUUM RELIEF VALVE

Remove fuel filler cap and see it functions properly.





1. Wipe clean valve housing and have it in your mouth.
2. Inhale air. A slight resistance accompanied by valve indicates that valve is in good mechanical condition. Note also that, by further inhaling air, the resistance should be disappeared with valve clicks.
3. If valve is clogged, or if no resistance is felt, replace cap as an assembled unit.



ET369





Fig. EC-83 Fuel filler cap

## SPECIAL SERVICE TOOLS

No.	Tool number & tool name	Description	For use on	Reference page or Figure No.
1.	*ST19810000  Hexagon wrench	For removing and installing the rotor ring assembly.    SE 279	L20B A14	Fig. EC-29 Fig. EC-41
2.	ST19900000  Dummy shaft	For assembling the vanes.    SE 284	L20B A14	Fig. EC-39
3.	ST19890000  Rotor adapter	Used as a mount when rotor is removed and when bearing is installed.    SE 347	L20B A14	Fig. EC-32 Fig. EC-35
4.	ST19940000  Bearing Pressing tool	Used when rotor is removed and when front bearing installed.    SE 348	L20B A14	Fig. EC-32 Fig. EC-35

\* This service tool is designed for use in disassembly and assembly of the air pump.

# Emission Control System

No.	Tool number & tool name	Description	For use on	Reference page or Figure No.
5.	ST19930000  Bearing adapter	Used as a mount when front bearing is removed.   SE349	L20B A14	Fig. EC-33
6.	ST19910000  Bearing driver	Used as a drift when front bearing is installed. Also used as a support when rotor is installed.   SE350	L20B A14	Fig. EC-33 Fig. EC-36 Fig. EC-37
7.	ST19920000  Rotor stand	Used as a drift when rotor is installed.   SE351	L20B A14	Fig. EC-36 Fig. EC-37
8.	ST19870000  Air pump test gauge adapter	Used as a adapter when air injection pump pressure is tested.   SE389	L20B A14	Page EC-18

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

## SECTION EE

### ENGINE ELECTRICAL SYSTEM

EE

BATTERY.....	EE- 2
STARTING MOTOR.....	EE- 4
CHARGING CIRCUIT.....	EE-12
ALTERNATOR.....	EE-15
REGULATOR .....	EE-20
IGNITION CIRCUIT.....	EE-26
DISTRIBUTOR .....	EE-30
(Non-California models)	
DISTRIBUTOR (California models).....	EE-33
TRANSISTOR IGNITION UNIT .....	EE-36
(California models)	
IGNITION COIL .....	EE-46
SPARK PLUG .....	EE-47

# BATTERY

## CONTENTS

REMOVAL .....	EE-2	BATTERY FREEZING .....	EE-3
CHECKING ELECTROLYTE LEVEL .....	EE-2	CHARGING .....	EE-3
CHECKING SPECIFIC GRAVITY .....	EE-2	INSTALLATION .....	EE-3



## REMOVAL

1. Disconnect negative and positive cables.
2. Remove nuts from battery clamps; take off clamps.
3. Remove battery.

## CHECKING ELECTROLYTE LEVEL

Remove six vent plugs and check for electrolyte level in each cell.

If necessary, pour distilled water.



1 Thermal gauge  
2 Hydrometer EE001

Fig. EE-1 Checking specific gravity

$$S_{20} = St + 0.0007 (t - 20)$$

Where

St: Specific gravity of electrolyte at t°C

S<sub>20</sub>: Specific gravity of electrolyte corrected at 20°C (68°F)

t: Electrolyte temperature

For example: A hydrometer reading of 1.260 at 30°C (86°F) would be 1.267 corrected to 20°C (68°F), indicating fully charged battery. On the other hand, a hydrometer reading of 1.220 at -10°C (14°F) would be 1.199 corrected to 20°C (68°F), indicating a partially charged battery.


The state of charge of battery can be determined by the following table if the specific gravity of electrolyte is known. Before checking, be sure that cells are filled to correct level.

## CHECKING SPECIFIC GRAVITY

Specific gravity of battery electrolyte is tested by a hydrometer. If the state of charge of battery is 60% or specific gravity reading is below 1.20 [as corrected at 20°C (68°F)], battery must be recharged or battery-electrolyte concentration adjusted.

Add or subtract gravity points according to whether the electrolyte temperature is above or below 20°C (68°F) standard.


The gravity of electrolyte changes 0.0007 for every 1°C (1.8°F) temperature. A correction can then be made by using the following formula:



EE002

Fig. EE-2 Charging condition

Converted specific gravity (S<sub>20</sub>)



EE003


Fig. EE-3 Specific gravity at electrolyte temperature

## BATTERY FREEZING

Battery electrolyte freezing point varies with acid concentration or its specific gravity. A battery with an insufficient charge will freeze at lower temperatures. If specific gravity of a battery falls below 1.1, this is an

indication that battery is completely discharged and will freeze readily when temperatures fall below freezing.

**Note:** Use extreme caution to avoid freezing battery since freezing will generally ruin the battery.



EE004

Fig. EE-4 Freezing point of electrolyte

## CHARGING

If electrolyte level is satisfactory, battery must be charged when electrolyte-gravity reading falls below 1.20. If battery on car is quick-charged to

bring it up to full charge, the operation should be carried out with negative cable removed.

Prior to charging, corroded terminals

should be cleaned with a brush and common baking-soda solution. In addition, the following items should be observed while battery is being charged.

1. Be sure that electrolyte level is above top of each plate.
2. Keep removed plugs in a safe place.
3. Do not allow electrolyte temperature to go over 45°C (113°F).
4. After charging, check to be certain that specific gravity does not exceed 1.260 [at 20°C (68°F)]. Correction can be made by adding distilled water into cells as necessary.
5. Keep battery away from open flame while it is being charged.
6. After all vent plugs have been tightened, clean all sprayed electrolyte off upper face of battery.

## INSTALLATION

1. Install and tighten clamps securely.
2. After clamps have been tightened, clean battery cable terminals and apply grease to retard formation of corrosion.




# STARTING MOTOR

## CONTENTS

DESCRIPTION .....	EE- 4	OVERRUNNING CLUTCH ASSEMBLY .....	EE- 9
OPERATION .....	EE- 6	BRUSH HOLDER TEST FOR GROUND .....	EE- 9
CONSTRUCTION .....	EE- 7	BEARING METAL .....	EE- 9
REMOVAL .....	EE- 7	MAGNETIC SWITCH ASSEMBLY .....	EE- 9
DISASSEMBLY .....	EE- 7	ASSEMBLY .....	EE- 9
CLEANING AND INSPECTION .....	EE- 8	TEST .....	EE- 9
TERMINAL .....	EE- 8	PERFORMANCE TEST .....	EE- 9
FIELD COIL .....	EE- 8	MAGNETIC SWITCH ASSEMBLY TEST .....	EE-10
BRUSHES AND BRUSH LEAD WIRE .....	EE- 8	SERVICE DATA AND SPECIFICATIONS .....	EE-11
BRUSH SPRING TENSION .....	EE- 8	TROUBLE DIAGNOSES AND CORRECTIONS ..	EE-11
ARMATURE ASSEMBLY .....	EE- 8		

## DESCRIPTION

The function of the starting system which consists of the battery, ignition switch, starting motor and solenoid, is to crank the engine. The electrical energy is supplied from the battery, the solenoid completes the circuit to operate the starting motor, and then the motor carries out the actual cranking of the engine.



- 1 Brush
- 2 Field coil
- 3 Magnetic switch
- 4 Plunger
- 5 Torsion spring
- 6 Shift lever
- 7 Overrunning clutch
- 8 Pinion
- 9 Armature

EE315

Fig. EE-5 Sectional view of starting motor (S114-180B)

# Engine Electrical System




Fig. EE-6 Circuit diagram of starting system

## OPERATION

When the ignition switch is turned fully clockwise to the START position, battery current flows through "series" and "shunt" coils of the solenoid, magnetizing the solenoid. The plunger is pulled into the solenoid so that it operates the shift lever to move the drive pinion into the flywheel ring gear. Then the solenoid switch contacts close after the drive pinion is partially engaged with the ring gear.


Closing of the solenoid switch contacts causes the motor to crank the engine and also cut out the "series" coil of the solenoid, the magnetic pull of the "shunt" coil being sufficient to hold the pinion in mesh after the shifting has been performed.

After the engine starts running, the driver releases the ignition key and it automatically returns to the ON position.

The torsion spring then actuates the shift lever to pull the pinion, which allows the solenoid switch contacts to open. Consequently, the starting motor stops.

More positive meshing and demeshing of the pinion and the ring gear teeth are secured by means of the overrunning clutch. The overrunning clutch employs a shift lever to slide the pinion along the armature shaft,

into or out of mesh with the ring gear teeth. The overrunning clutch is designed to transmit driving torque from the motor armature to the ring gear, but prevent the armature from overrunning after the engine has started.




EE274

- |                      |                    |
|----------------------|--------------------|
| 1 Ring gear          | 8 Shunt coil       |
| 2 Shift lever guide  | 9 Plunger          |
| 3 Armature           | 10 Ignition switch |
| 4 Battery            | 11 Series coil     |
| 5 Field coil         | 12 Torsion spring  |
| 6 Stationary contact | 13 Shift lever     |
| 7 Movable contactor  | 14 Pinion          |

Fig. EE-7 Starting motor circuit

## CONSTRUCTION



EE316


Fig. EE-8 Exploded view of starting motor

## REMOVAL

### 1. Disconnect battery ground cable.

Disconnect black wire with yellow stripe from magnetic switch terminal, and black battery cable from battery terminal of magnetic switch.

2. Remove two bolts securing starting motor to transmission case. Pull starter assembly forward and remove starting motor.




EE317

Fig. EE-9 Removing dust cover, E-ring and thrust washer(s)

## DISASSEMBLY

1. Disconnect connecting plate from "M" terminal of magnetic switch. Remove two screws securing magnetic switch and remove magnetic switch assembly.

2. Remove dust cover, E-ring and thrust washer(s).



EE318

Fig. EE-10 Removing brush holder setscrews


4. Remove two through bolts and rear cover.

5. Remove brushes from their holder by moving each brush spring away from brush with a hook.

Remove brush holder.

6. Remove yoke assembly and withdraw armature assembly and shift lever.

7. Remove pinion stopper located at the end of armature shaft. To remove stopper, first move stopper toward pinion and after removing stopper clip, remove stopper with overrunning clutch assembly from armature shaft.



EE277

Fig. EE-11 Removing pinion stopper

## CLEANING AND INSPECTION

Clean all disassembled parts, but do not use grease dissolving solvents for cleaning overrunning clutch, armature assembly, magnetic switch assembly and field coils since such a solvent would dissolve grease packed in clutch mechanism and would damage coils or other insulators.

Check them for excessive damage or wear, and replace if necessary.

## TERMINAL

Check terminal for damage and wear, and replace magnetic switch assembly if necessary.


## FIELD COIL

Check field coil for insulation. If the insulation of coil is damaged or worn it should be replaced.

### Testing field coil for continuity:

Connect the probe of a circuit tester or an ohmmeter to field coil positive terminal and positive brush holder.

If tester shows no continuity, field circuit or coil is open.




EE016

Fig. EE-12 Testing field coil for continuity

### Testing field coil for ground:

Place one probe of circuit tester onto yoke and the other onto field coil lead (positive terminal).

If very little resistance is read, field coil is grounded.



EE017

Fig. EE-13 Testing field coil for ground

Check brush holders and spring clip to see if they are not deformed or bent, and will properly hold brushes against the commutator.

If brushes or brush holders are dirty, they should be cleaned.

## BRUSH SPRING TENSION

Check brush spring tension by a spring scale as shown in Figure EE-13. The reading should be 1.6 kg (3.5 lb). Replace spring if tension is lower than 1.4 kg (3.1 lb).

## ARMATURE ASSEMBLY

Check external appearance of armature and commutator.

1. Inspect commutator. If the surface of commutator is rough, it must be sanded lightly with a No. 500 emery cloth. If the depth of insulating mica is less than 0.2 mm (0.0079 in) from commutator surface, insulating mica should also be undercut so that its depth is 0.5 to 0.8 mm (0.0197 to 0.0315 in).


The wear limit of commutator diameter is 2 mm (0.0787 in). If the diameter of commutator is less than 31 mm (1.220 in), replace armature assembly.

## BRUSHES AND BRUSH LEAD WIRE

Check the surface condition of brush contact and wear of brush. If a loose contact is found it should be replaced.

If brush is worn so that its length is less than 12 mm (0.472 in), replace.

Check the connection of lead clip and lead wire.



EE018

Fig. EE-14 Inspecting brush spring tension




Fig. EE-15 Undercutting insulating mica

2. Inspect soldered connection of armature lead and commutator. If loose connection is found, solder it using resin flux.

## 3. Armature test for ground

Using a circuit tester, place one test probe onto armature shaft and other onto each commutator bar.

If tester shows continuity, armature is grounded and must be replaced.




Fig. EE-16 Testing armature for ground

4. Check armature for short by placing it on armature tester (growler) with a piece of iron over armature core, rotating armature. If the plate vibrates, armature is shorted.




Fig. EE-17 Testing armature for short

5. Check armature for continuity by placing probes of tester on two segments side by side. If tester shows no continuity, the circuit is open.

## OVERRUNNING CLUTCH ASSEMBLY

Inspect pinion assembly and screw sleeve. Screw sleeve must slide freely along armature shaft splines. If damage is found or resistance is felt when sliding, it must be repaired. Inspect pinion teeth. If excessive rubbing is found on teeth, replace. Flywheel ring gear also must be inspected.




Fig. EE-18 Overrunning clutch assembly

## BRUSH HOLDER TEST FOR GROUND

Using a circuit tester, place one test probe onto negative side of brush holder and another onto positive side. If tester shows continuity, brush holder is shorted to ground. Replace brush holder.




Fig. EE-19 Testing brush for ground

## BEARING METAL

Inspect bearing metal for wear or side play. If the clearance between bearing metal and armature shaft is more than 0.2 mm (0.0079 in), replace metal.

## MAGNETIC SWITCH ASSEMBLY

1. Using a circuit tester, check continuity between "S" terminal of magnetic switch and switch body metal. If continuity does not exist, shunt coil is opened.

Replace switch assembly.

2. In the same manner as above, check continuity between terminals "S" and "M". If continuity does not exist, series coil is opened.

Replace switch assembly.

## ASSEMBLY

Reassemble starting motor in reverse sequence of disassembly.

When assembling, be sure to apply grease to gear case and rear cover bearing metal, and apply oil lightly to pinion.

## TEST


### PERFORMANCE TEST

Starter motor should be subjected to a "no-load" test whenever it has been overhauled to ensure that its performance will be satisfactory when installed on engine. Starter motor should also be subjected to the test when the cause of abnormal operation is to be determined. A brief outline of the test is given below.

## No-load test

Connect starting motor in series with specified (12 volts) battery and an ammeter capable of indicating 1,000 amperes.

Specified current draw and revolution in these test are shown in "Specifications".



EE026

Fig. EE-20 No-load testing


## Diagnoses of test

1. Low speed with no-load and high current draw may result from the following :
  - (1) Tight, dirty or worn bearings.
  - (2) Bent armature shaft or loosened field probe.
  - (3) Shorted armature; Check armature further.
  - (4) A grounded armature or field;
    - a. Remove input terminal.
    - b. Raise two negative side brushes from commutator.
    - c. Using a circuit tester, place one probe onto input terminal and the other onto yoke.
    - d. If tester indicates continuity, raise the other two brushes and check field and armature separately to determine whether field or armature is grounded.
2. Failure to operate with high current draw may be caused by the

following:

- (1) A grounded or open field coil: Inspect the connection and trace circuit with a circuit tester.
- (2) Armature coil does not operate: Inspect commutator for excessive burning. In this case, arc may occur on damaged commutator when motor is operated with no-load.
- (3) Burned out commutator bar: Weak brush spring tension, broken brush spring, rubber bush, thrust out of mica in commutator or a loose contact between brush and commutator would cause commutator bar to burn.
3. Low current draw and low no-load speed would cause high internal resistance due to loose connections, damaged leads, dirty commutator and causes listed on item 2-(3).

## MAGNETIC SWITCH ASSEMBLY TEST




EE351

Fig. EE-21 Circuit of magnetic switch assembly test

If the starting motor check is "OK", check magnetic switch assembly. Connect cables between "negative" battery terminal and starting motor "M" terminal, "positive" battery terminal and starting motor "S" terminal connecting a switch in series as shown in Figure EE-21.

With the switch on, push pinion back to remove all slack and measure the clearance " $\ell$ " between pinion front edge and pinion stopper. The clearance should be held within 0.3 to 1.5 mm (0.012 to 0.059 in). If necessary, adjust it by changing or adding adjusting washer(s). Adjusting washers are available into two different sizes, 0.5 mm (0.020 in) and 0.8 mm (0.031 in).



EE028

Fig. EE-22 Measuring clearance " $\ell$ "

## SERVICE DATA AND SPECIFICATIONS

		Manual transmission	Automatic transmission (Optional for manual transmission)
Type .....		S114-170B	S114-180B
System voltage	V .....	12	
No load			
Terminal voltage	V .....	12	
Current	A .....	Less than 60	
Revolution	rpm .....	More than 7,000	More than 6,000
Outer diameter of commutator	mm (in) .....	More than 39 (1.54)	
Brush length	mm (in) .....	More than 12 (0.47)	
Brush spring tension	kg (lb) .....	1.4 to 1.8 (3.1 to 4.0)	
Clearance between bearing metal and armature shaft	mm (in) .....	Less than 0.2 (0.008)	
Clearance "L" between pinion front edge and pinion stopper	mm (in) .....	0.3 to 1.5 (0.012 to 0.059)	

## TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
Starting motor will not operate.	Discharged battery. Damaged solenoid switch. Loose connections of terminal. Damaged brushes. Starting motor inoperative.	Charge or replace battery. Repair or replace solenoid switch. Clean and tighten terminal. Replace brushes. Remove starting motor and make test.
Noisy starting motor.	Loose securing bolt. Worn pinion gear. Poor lubrication. Worn commutator. Worn brushes.	Tighten. Replace. Add oil. Replace. Replace.
Starting motor cranks slowly.	Discharged battery. Loose connection of terminal. Worn brushes. Locked brushes.	Charge. Clean and tighten. Replace. Inspect brush spring tension or repair brush holder.



## Engine Electrical System

Condition	Probable cause	Corrective action
Starting motor cranks slowly.	Dirty or worn commutator. Armature rubs field coil. Damaged solenoid switch.	Clean and repair. Replace assembly. Repair or replace.
Starting motor operates but does not crank engine.	Worn pinion. Locked pinion guide. Worn ring gear.	Replace. Repair. Replace.
Starting motor will not disengage even if ignition switch is turned off.	Damaged solenoid switch. Damaged gear teeth.	Repair or replace. Replace damaged gear.

## CHARGING CIRCUIT

The charging circuit consists of the battery, alternator, regulator and necessary wiring to connect these parts. The purpose of this system is to convert mechanical energy from the engine into electrical energy which is used to operate all electrically operated units and to keep the battery fully charged.

When the ignition switch is set to "ON", current flows from the battery to ground through the ignition switch, voltage regulator IG terminal, primary side contact point "P1," movable contact point "P2", voltage regulator "F" terminal, alternator "F" terminal, rotor (field) coil and alternator "E" terminal, as shown in Figure EE-23 by full line arrow marks. Then the rotor in the alternator is excited. On the other hand, current flows from the battery to ground through the ignition switch, warning lamp, voltage regulator "L" terminal, lamp side contact point "P4", movable contact point "P5", and voltage regulator "E" terminal, as shown by dotted line arrow

marks. Then, the warning lamp lights.

When the alternator begins to operate, three-phase alternating current is induced in the stator (armature) coil. This alternating current is rectified by the positive and negative silicon diodes. The rectified direct current output reaches the alternator "A" and "E" terminals.

On the other hand, the neutral point voltage reaches "N" and "E" terminals (nearly a half of the output voltage), and current flows from voltage regulator "N" terminal to "E" terminal or ground through the coil "VC1" as shown in Figure EE-24 by the dotted line arrow marks. Then, the coil "VC1" is excited, and the movable contact point "P5" comes into contact with voltage winding side contact point "P6". This action causes to turn off the warning lamp and complete the voltage winding circuit, as shown by the full line arrow marks.

When the alternator speed is increased or the voltage starts to rise excessively, the movable contact point

"P2" is separated from the primary side contact "P1" by the magnetic force of coil "VC2". Therefore, resistor "R1" is applied into the rotor circuit and output voltage is decreased. As the output voltage is decreased, the movable contact point "P2", and primary side contact "P1" comes into contact once again, and the alternator voltage increases. Thus, the rapid vibration of the movable contact point "P2", maintains an alternator output voltage constant.

When the alternator speed is further increased or the voltage starts to rise excessively, the movable contact point "P2" comes into contact with secondary side contact point "P3". Then, the rotor current is shut off and alternator output voltage is decreased immediately. This action causes movable contact "P2" to separate from secondary contact "P3". Thus, the rapid vibration of the movable contact point "P2", or breaking and completing the rotor circuit, maintains an alternator output voltage constant.




2



**Fig. EE-24 Charging circuit (II)**

# Engine Electrical System



EE492

Fig. EE-25 Circuit diagram of charging system

# ALTERNATOR

## CONTENTS

DESCRIPTION .....	EE-15	INSPECTION OF DIODE .....	EE-17
REMOVAL .....	EE-16	INSPECTION OF BRUSH .....	EE-18
DISASSEMBLY .....	EE-16	SPRING PRESSURE TEST .....	EE-18
INSPECTION AND REPAIR .....	EE-16	ASSEMBLY .....	EE-18
ROTOR INSPECTION .....	EE-17	ALTERNATOR TEST .....	EE-19
INSPECTION OF STATOR .....	EE-17	SERVICE DATA AND SPECIFICATIONS .....	EE-19

## DESCRIPTION

In the alternator, a magnetic field is produced by the rotor which consists of alternator shaft, field coil, pole pieces, and slip rings. The slip rings pressed in the shaft conduct only a small field current. Output current is generated in the armature coils located in the stator. The stator has three windings and generates three-phase alternating current. Silicon diodes act

like a one-way valve for electricity so that charging current passes easily but reverse current is shut out.

In this alternator, pack type silicon diodes are used.


Six diodes (three negative and three positive), are installed in positive and negative plates as an assembly.

These diodes are direct-soldered at their tips, and constructed with posi-

tive and negative conjunction.

They are mounted on the two plates which combine the function of heat-dissipating plate and positive/negative terminals and are light in weight and easy to service.

The pulley mounted on the air conditioner models is different from that on the standard models (without air conditioner).



EE345


Fig. EE-26 Exploded view

## REMOVAL

1. Disconnect negative battery terminal.
2. Disconnect two lead wires and connector from alternator.
3. Loosen adjusting bolt.
4. Remove alternator drive belt.
5. Remove parts associated with alternator from engine.
6. Remove alternator from vehicle.

## DISASSEMBLY

1. Remove pulley nut and pulley assembly.



EE033

Fig. EE-27 Removing pulley and fan

2. Remove brush holder fixing screws, and remove brush holder cover. Pull brush holder forward, and remove brushes together with brush holder.

**Note:** Do not disconnect N terminal from stator coil lead wire.





Fig. EE-28 Removing brush


3. Remove through bolts. Separate front cover with rotor from rear cover with stator by lightly tapping front bracket with a wooden mallet.



EE035

Fig. EE-29 Separating front cover with rotor from rear cover


4. Remove three set screws from bearing retainer, and separate rotor from front cover.



EE036

Fig. EE-30 Removing rotor

5. Pull rear bearing out from rotor assembly with a press or bearing puller.




EE037

EE038

Fig. EE-31 Pulling out of rear bearing

6. Remove diode cover fixing screw, and remove diode cover. Disconnect three stator coil lead wires from diode terminal with a soldering iron.
7. Remove A terminal nut and diode installation nut, and remove diode assembly.



EE039


Fig. EE-32 Removing diode assembly

**Note:** Use care in handling diode assembly to prevent an undue stress on it.

## INSPECTION AND REPAIR

Remove alternator from car and connect a circuit tester between F terminal and E terminal.

When the resistance is approximately  $5\Omega$ , the condition of brush and field coil is satisfactory. When no continuity exists in brush or field coil, or when resistance differs significantly between those parts, disassemble and inspect.



EE040


Fig. EE-33 Inspecting alternator

## ROTOR INSPECTION

### 1. Continuity test of rotor coil

Apply tester between slip rings of rotor as shown in Figure EE-34. If there is no continuity field coil is open.

Replace rotor assembly.




EE041

Fig. EE-34 Continuity test of rotor coil

### 2. Ground test of rotor coil

Check continuity between slip ring and rotor core. If continuity exists, replace rotor assembly, because rotor coil or slip ring may be grounded.



EE042


Fig. EE-35 Testing rotor coil for ground

## INSPECTION OF STATOR

### 1. Continuity test

Stator is normal when there is continuity between individual stator coil terminals. When there is no continuity between individual terminals, cable is broken.

Replace with stator assembly.




EE043

Fig. EE-36 Testing stator for continuity

### 2. Ground test

If each lead wire of stator coil (including neutral wire) is not conductive with stator core, condition is satisfactory. If there is continuity, stator coil is grounded.




Stator core

EE044

Fig. EE-37 Testing stator for ground

## INSPECTION OF DIODE


Perform a continuity test on diodes in both directions, using an ohmmeter. A total of six diodes are used; three are mounted on the positive  $\oplus$  plate, and other three are on the negative  $\ominus$  plate. The continuity test should be performed on each diode, between the terminal and plate.



EE045

Fig. EE-38 Conductive direction of diode

Diode installed on  $\oplus$  plate is a positive diode which allows current flowing from terminal to  $\oplus$  plate only. In other words, current does not flow from  $\oplus$  plate to terminal.




1 (+) plate  
2 Terminal

EE046

Fig. EE-39 Inspecting positive diode

Diode installed on  $\ominus$  plate is a negative diode which allows current flowing from  $\ominus$  plate to terminal only. In other words, current does not flow from terminal to  $\ominus$  plate.



1 (-) plate  
2 Terminal

EE047

Fig. EE-40 Inspecting negative diode

## Engine Electrical System

If current flows in both positive and negative directions, diode is short-circuited. If current flows in one direction only, diode is in good condition.

If there is a faulty diode, replace all diodes (six diodes) as an assembly. (See table below.) These diodes are unserviceable.


Test probe of a circuit tester		Conduction
$\ominus$	$\oplus$	
terminal	$\oplus$ plate	0
$\oplus$ plate	terminal	—
terminal	$\ominus$ plate	—
$\ominus$ plate	terminal	0
$\ominus$ plate	$\oplus$ plate	0
$\oplus$ plate	$\ominus$ plate	—

### INSPECTION OF BRUSH

Check movement of brush and if movement is not smooth, check brush holder and clean if necessary.

Check brush for wear. If it is worn down to less than the specified limit, replace brush assembly.

Check brush pig tail and, if damaged, replace.




EE127

Fig. EE-41 Brush wear limit

### SPRING PRESSURE TEST

With brush projected approximately 2 mm (0.079 in) from brush holder, measure brush spring pressure by the use of a spring balance. Normally, the rated pressure of a new brush spring is 255 to 345 gr (9.0 to 12.2 oz).

Moreover, when brush is worn, pressure decreases approximately 20 g (0.7 oz) per 1 mm (0.0039 in) wear.




EE049

Fig. EE-42 Measuring spring pressure

## ASSEMBLY

Reassemble alternator in the reverse sequence of disassembly noting the following:

1. When soldering each stator coil lead wire to diode assembly terminal, carry out the operation as fast as possible.
2. When installing diode A terminal, install insulating bush correctly.




- 1 Insulating bush
- 2 "A" terminal bolt
- 3 Diode cover
- 4 Rear cover
- 5 Diode assembly

EE347

Fig. EE-43 Sectional view of diode and A terminal

3. Tighten pulley nut with tightening torque of 3.5 to 4.0 kg-m (25.3 to 29.0 ft-lb). When pulley is tightened, make sure that deflection of V-groove is less than 0.3 mm (0.0118 in).



EE051

Fig. EE-44 Tightening pulley nut

## ALTERNATOR TEST

Before conducting an alternator test, make sure that the battery is fully charged.

A 30-Volt voltmeter and suitable test probes are necessary for the test. Set up a test circuit as shown in

Figure EE-45 and test alternator in the manner indicated in the flow chart below:

1. Disconnect connectors at alternator.
2. Connect "A" terminal to "F" terminal.
3. Connect one test probe from voltmeter positive terminal to "A" terminal. Connect the other test probe to ground. Make sure that voltmeter registers battery voltage.
4. Turn on headlights and switch to High Beam.
5. Start engine.
6. Increase engine speed gradually until it is approximately 1,100 rpm, and take the voltmeter reading.

Measured value: Below 12.5 Volts  
Alternator is in trouble. remove and check it for condition.

Measured value: Over 12.5 Volts  
Alternator is in good condition.




Fig. EE-45 Testing alternator

### Notes:

- a. Do not run engine at the speed of more than 1,100 rpm while test is being conducted on alternator.
- b. Do not race engine.

## SERVICE DATA AND SPECIFICATIONS

Type .....	LT135-36B	LT138-01B (For air conditioner)
Nominal rating	V-A .....	12-35
Ground polarity .....	Negative	Negative
Minimum revolution when generating 14V with no load	rpm .....	1,000
Hot output current	A/rpm .....	28/2,500 35/5,000
Pulley ratio .....	2.25	2.25
Brush		
Length	mm (in) .....	More than 7.5 (0.295)
Spring pressure	gr (oz) .....	255 to 345 (9.0 to 12.2)
Slip ring outer diameter	mm (in) .....	More than 30 (1.181)



# REGULATOR

## CONTENTS

DESCRIPTION .....	EE-20	CHARGING RELAY .....	EE-23
MEASUREMENT OF REGULATOR		SERVICE DATA AND SPECIFICATIONS .....	EE-24
VOLTAGE .....	EE-20	TROUBLE DIAGNOSES AND	
ADJUSTMENT .....	EE-23	CORRECTIONS (Including alternator) .....	EE-25
VOLTAGE REGULATOR .....	EE-23		


## DESCRIPTION

The regulator consists basically of a voltage regulator and a charge relay. The voltage regulator has two sets of contact points, a lower set and an upper set, to control alternator voltage. An armature plate placed between the two sets of contacts moves upward or downward or vibrates. The lower contacts, when closed, complete the

field circuit direct to ground; and the upper contacts, when closed, complete the field circuit to ground through a resistance (field coil), and produce alternator output.

The charge relay is similar in construction to the voltage regulator.


When the upper contacts are closed, charge warning lamp goes on.



EE285


Fig. EE-46 View of removing cover

As regards the construction, the voltage regulator is very similar to the charge relay as shown in Figure EE-47.



- |                      |                              |
|----------------------|------------------------------|
| 1 Connecting spring  | 9 3mm (0.118 in) dia. screw  |
| 2 Yoke gap           | 10 4mm (0.157 in) dia. screw |
| 3 Armature           | 11 Coil                      |
| 4 Core gap           | 12 Lock nut                  |
| 5 Low speed contact  | 13 Adjusting screw           |
| 6 Point gap          | 14 Adjusting spring          |
| 7 High speed contact | 15 Yoke                      |
| 8 Contact set        |                              |

(a) Construction of voltage regulator



EE397

- |                        |                              |
|------------------------|------------------------------|
| 1 Point gap            | 9 Adjusting screw            |
| 2 Charge relay contact | 10 Lock nut                  |
| 3 Core gap             | 11 Coil                      |
| 4 Armature             | 12 4mm (0.157 in) dia. screw |
| 5 Connecting spring    | 13 3mm (0.118 in) dia. screw |
| 6 Yoke gap             | 14 Contact set               |
| 7 Yoke                 | 15 Voltage regulator contact |
| 8 Adjusting spring     |                              |

(b) Construction of charge relay


Fig. EE-47 Structural view

## MEASUREMENT OF REGULATOR VOLTAGE

Regulator voltage is measured with regulator assembled with alternator. When measuring voltage with regulator mounted on car, it is necessary to rotate engine at high speed.

Connect DC voltmeter (15-30V), DC ammeter (15-30A), battery and a  $0.25\Omega$  resistor (rated at 25W) with cables as shown.

1. Check to be sure that all electrical loads such as lamps, air conditioner, radio etc. are turned off.
2. Before starting engine, be sure to make short circuit with a cable between fuse side terminal of resistor ( $0.25\Omega$ ) and negative side terminal of ammeter. Failure to follow this precaution will cause needle of ammeter to swing violently, resulting in a damaged ammeter.




EE055

Fig. EE-48 Measuring regulator voltage with regulator on vehicle

3. Refer to the following chart to determine if regulator and relative parts are in good condition:

## Engine Electrical System



### Regulator type TL1Z-85C

Temperature °C (°F)	Voltage V
-10 (14)	14.75 to 15.75
0 (32)	14.60 to 15.60
10 (50)	14.45 to 15.45
20 (68)	14.30 to 15.30
30 (86)	14.15 to 15.15
40 (104)	14.00 to 15.00

speed.

- c. Voltage may be approximately 0.3 V higher than rated for two to three minutes after engine is started, or more specifically, when regulator becomes self-heated. Measurements should then be made within one minute after starting engine, or when regulator is cold.
- d. The regulator is of a temperature-compensating type. Before measuring voltage, be sure to measure surrounding temperature and correct measurements according to the table at left.

#### Notes:

a. Do not measure voltage immediately after driving. Do this while

regulator is cold.  
b. To measure voltage, raise engine speed gradually from idling to rated

## ADJUSTMENT

### VOLTAGE REGULATOR

When regulating voltage, as measured above, deviates from rated value, adjust regulator in accordance with the following instructions.

1. Inspect contact surface, and if rough, lightly polish with fine emery paper (#500 or 600).
2. Measure each gap, and adjust if necessary. Adjust core gap and point gap in that order. No adjustment is required for yoke gap.
3. Adjusting core gap.

Loosen screw [4 mm (0.157 in) diameter] which is used to secure contact set on yoke, and move contact upward or downward properly. (See Figure EE-49.)

Core gap:  
0.6 to 1.0 mm  
(0.024 to 0.039 in)





Fig. EE-49 Adjusting core gap

#### 4. Adjusting point gap

Loosen screw [3 mm (0.118 in) diameter] used to secure upper contact, and move upper contact upward or downward as necessary. (See Figure EE-50.)

Point gap:  
0.35 to 0.45 mm  
(0.014 to 0.018 in)



EE399

- 1 Thickness gauge
- 2 3 mm (0.118 in) dia. screw
- 3 Crosshead screwdriver
- 4 Upper contact

Fig. EE-50 Adjusting point gap

#### 5. Adjusting voltage

Adjust regulating voltage as follows:

Loosen lock nut securing adjusting screw. Turn this screw clockwise to increase, or counterclockwise to decrease, regulating voltage. (See Figure EE-51.)




Fig. EE-51 Adjusting regulating voltage

### CHARGE RELAY

Normal relay operating voltage is 8 to 10V as measured at alternator "A" terminal. Relay itself, however, operates at 4 to 5V.

Use a DC voltmeter, and set up a circuit as shown in Figure EE-52.

Adjust charge relay in the same manner as that for voltage regulator.

1. Connect positive terminal of voltmeter to regulator lead connector "N" terminal with negative terminal grounded.
2. Start engine and keep it idle.
3. Take voltmeter reading.

#### 0 Volt

1. Check for continuity between "N" terminals of regulator and alternator.
2. Alternator circuit inoperative if continuity exists.

#### Below 5.2 Volts


- (Charge warning lamp on.)
1. Check fan belt tension.
  2. If correct, remove regulator and adjust as necessary.

#### Over 5.2 Volts

- (Charge warning lamp on.)
- Charge relay coil or contact points out of order.  
Replace regulator.

#### Over 5.2 Volts

- (Charge warning lamp off.)
- Charge relay assembly is in good condition.



EE348

Fig. EE-52 Testing charging relay

## SERVICE DATA AND SPECIFICATIONS

### Voltage regulator

Type	.....	TL1Z-85C
Regulating voltage (with fully charged battery)	V .....	*14.3 to 15.3 [at 20°C (68°F)]
Voltage coil resistance	Ω .....	10.5 [at 20°C (68°F)]
Rotor coil inserting resistance	Ω .....	10
Voltage coil series resistance	Ω .....	31
Smoothing resistance	Ω .....	40
Core gap	mm (in) .....	0.6 to 1.0 (0.024 to 0.039)
Point gap	mm (in) .....	0.35 to 0.45 (0.014 to 0.018)

### Charge relay

Release voltage	V .....	4.2 to 5.2 at "N" terminal
Voltage coil resistance	Ω .....	37.8 [at 20°C (68°F)]
Core gap	mm (in) .....	0.8 to 1.0 (0.031 to 0.039)
Point gap	mm (in) .....	0.4 to 0.6 (0.016 to 0.024)

\*Standard temperature gradient: -0.015V/°C

## TROUBLE DIAGNOSES AND CORRECTIONS (Including alternator)

Condition	Probable cause	Corrective action
No output	Sticking brushes. Dirty brushes and slip rings. Loose connections or broken leads.  Open stator winding. Open rotor winding. Open diodes. Shorted rotor. Shorted stator. Grounded "A" terminal. Broken fan belt.	Correct or replace brushes and brush springs. Clean. Retighten or solder connections. Replace leads if necessary. Repair or replace stator. Replace rotor. Replace. Replace rotor. Repair or replace. Replace insulator. Replace.
Excessive output	Broken neutral wire (color of wire is yellow.) Voltage regulator breakdown.  Poor grounding of alternator and voltage regulator "E" terminal. Broken ground wire (color of wire is black.)	Replace. Check regulator operation and repair or replace as required. Retighten terminal connection.  Replace.
Low output	Loose or worn fan belt. Sticking brushes.  Low brush spring tension. Voltage regulator breakdown.  Dirty slip rings. Partial short, ground, or open in stator winding. Partially shorted or grounded rotor winding. Open or damaged diode.	Retighten or replace. Correct or replace brushes and springs if necessary. Replace brush springs. Check regulator operation and repair or replace as required. Clean. Replace stator.  Replace rotor. Replace diode.
Noisy alternator	Loose mounting. Loose drive pulley. Broken ball bearing. Improperly seated brushes.	Retighten bolts. Retighten. Replace. Seat correctly.

# IGNITION CIRCUIT

## CONTENTS

NON-CALIFORNIA MODELS ..... EE-26

CALIFORNIA MODELS ..... EE-28

### NON-CALIFORNIA MODELS

The ignition circuit consists of the ignition switch, coil, distributor, wiring, spark plugs and battery.

The circuit is equipped with a resistor. During cranking, electrical current bypasses the resistor, thereby connecting the ignition coil directly to battery. This provides full battery voltage available at coil and keeps ignition voltage as high as possible.

The low voltage current is supplied by the battery or alternator and flows through the primary circuit. It consists of the ignition switch, resistor, primary winding of the ignition coil, distributor contact points, condenser and all connecting low tension wiring.

The high voltage current is produced by the ignition coil and flows through the secondary circuit, resulting in high voltage spark between the electrodes of the spark plugs in engine cylinders. This circuit contains the

secondary winding of the ignition coil, high tension wiring, distributor rotor and cap.

When the ignition switch is turned on and the distributor contact points are closed, the primary current flows through the primary winding of the coil and through the contact points to ground.

When the contact points are opened by the revolving distributor cam, the magnetic field built up in the primary winding of the coil moves through the secondary winding of the coil inducing high voltage. The high voltage is produced every time the contact points open. The high voltage current flows through the high tension wire to the distributor cap. Then the rotor distributes the current to one of the spark plug terminals in the distributor


cap.

Then the spark obtains while the high voltage current jumps the gap between the insulated electrode and the ground side electrode of the spark plug. This process is repeated for each power stroke of the engine.

The distributor contact point and spark plugs should be inspected, cleaned and regapped at tune up. They should also be replaced periodically as specified in the "Maintenance Schedule". In addition, apply grease (NLGI consistency No. 1 containing MoS<sub>2</sub> or equivalent) to distributor shaft and grease (MIL-G-10924B containing MoS<sub>2</sub> or equivalent) to cam as required.

The remainder of the ignition component parts should be inspected for only their operation, tightness of electrical terminals, and wiring condition.


The ignition circuit is shown below:



EE060

Fig. EE-53 Ignition system circuit diagram

# Engine Electrical System



EE493

Fig. EE-54 Circuit diagram of ignition system (Non-California models)



## CALIFORNIA MODELS

The ignition circuit consists of ignition switch, transistor ignition unit, distributor, wiring, spark plugs and battery.

The distributor is of the contactless type and is equipped with a pick-up coil which electrically detects the ignition timing signal in place of the circuit breaker of the conventional distributor. The transistor ignition unit is a new addition, which generates the signal required for the make and break of the primary electric current for the ignition coil.

The circuit is equipped with a resistor. During cranking, electrical current bypasses the secondary resistor, thereby connecting the ignition coil through the primary resistor. This makes battery voltage available at efficiently and keeps ignition voltage as high as possible.

The primary resistor serves to protect transistor ignition circuit.

The low voltage current is supplied by the battery or alternator and flows through the primary circuit.

It consists of the ignition switch,

resistor, primary winding of the ignition coil, transistor ignition unit and all connecting low tension wiring.

The high voltage current is produced by the ignition coil and flows through the secondary circuit, resulting in high voltage spark between the electrodes of the spark plugs in engine cylinders.

This circuit contains the secondary winding of the ignition coil, distributor high tension wires to coil and spark plugs, distributor rotor and cap.

When the ignition switch is turned on and the distributor reluctor rotates, the primary current flows through the primary winding of the coil and through transistor ignition unit to ground.

When the primary circuit is opened by circuit of transistor ignition unit, the magnetic field built up in the primary winding of the coil moves through the secondary winding of the coil, inducing high voltage. This high

voltage is produced every time the primary circuit opens.


The high voltage current flows through the high tension wire to the distributor cap, then the rotor distributor cap, then the rotor distributes the current to one of the spark plug terminals in the distributor cap.

Then the spark occurs while the high voltage current jumps the gap between the insulated electrode and the ground side electrode of the spark plug. This process is repeated for each power stroke of the engine.

The spark plug should be inspected, cleaned and regapped at tune up. Spark plugs should also be replaced periodically as specified in the "Maintenance Schedule".

The remainder of the ignition component parts should be inspected for only their operation, air gap of distributor, tightness of electrical terminals, and wiring condition.


Apply grease (NLGI consistency No. 1 containing MoS<sub>2</sub> or equivalent) to distributor rotor shaft as required.



EE287

Fig. EE-55 Ignition system circuit diagram

# Engine Electrical System



EE494

Fig. EE-56 Circuit diagram of ignition system (California models)

# DISTRIBUTOR (Non-California models)


## CONTENTS

CONSTRUCTION .....	EE-30
CHECKING AND ADJUSTMENT .....	EE-31
CAP AND ROTOR HEAD .....	EE-31
CONTACT POINT.....	EE-31
CONDENSER .....	EE-31

ADVANCE MECHANISMS .....	EE-31
DISASSEMBLY .....	EE-32
ASSEMBLY.....	EE-32
SERVICE DATA AND SPECIFICATIONS .....	EE-33

## CONSTRUCTION

The distributor consists of breaker plate with contact points, centrifugal advance mechanism, vacuum controller, distributor shaft, and rotor.



EE320

Fig. EE-57

## CHECKING AND ADJUSTMENT

### CAP AND ROTOR HEAD

Cap and rotor head should be inspected periodically as specified in the "Maintenance Schedule". Remove cap and clean all dust and carbon deposits from cap and rotor. If cap is cracked or is leaking, replace with a new one.

### CONTACT POINT

Contact point should be replaced in accordance with the "Maintenance-Schedule".

Standard point gap is 0.45 to 0.55 mm (0.018 to 0.022 in). In case size is off the standard, adjustment is made by loosening point screws. Gap gauge is required for adjustment.

When point surface is rough, take off any irregularities with fine sand paper of No. 500 or 600 or with oil stone.

When wear on contact points is noticeable, replace points together with contact arm. To replace, proceed as follows:





Fig. EE-58 Adjusting point gap



- 1 Primary lead terminal
- 2 Ground lead wire
- 3 Set screw
- 4 Adjuster
- 5 Screw

Fig. EE-59 Breaker

First turn out set screws 1 to 1.5 turns at contact arm and primary lead wire connection just for enough to pull out primary lead terminal.

Referring to Figure EE-59, unscrew two contact set fixing screws and remove lead wire.

While holding contact arm by fingers, pull out contact set toward you by raising it slightly. Contact point and arm can then be removed together.

Install new contact point and arm assembly in reverse sequence of removal. Coat cam with a light coating of grease.

## ADVANCE MECHANISMS

### « Specifications »

Item \ Type	D4A4-06, *D4A6-07	D4A4-07, *D4A6-08
Application	Automatic transmission	Manual transmission
Vacuum advance [Distributor degrees/distributor mmHg (inHg)]	0°/150 (5.91) 3°/250 (9.84)	0°/170 (6.69) 6.5°/300 (11.81)
Centrifugal advance [Distributor degrees/ distributor rpm]	0°/550 11°/2,300	0°/600 11°/1,950

\*: For Canada

### « Vacuum advance mechanism mechanical parts »

If vacuum advance mechanism fails to operate properly, check for the following items and correct the malfunction as required.

1. Check vacuum inlet for signs of leakage at its connection. If necessary, retighten or replace with a new one.
2. Check vacuum diaphragm for air leak.

If leak is found, replace vacuum controller assembly.

3. Inspect breaker plate for smooth moving.

If plate does not move smoothly, this condition could be due to sticky steel balls or pivot. Apply grease to steel balls or, if necessary, replace breaker plate as an assembly.

## CONDENSER

Satisfactory performance of condenser depends on capacity and degree of insulation, requiring attention to be sure that terminals are clean and set screws are tight.

Checking of condenser is made by a condenser tester.

### « Centrifugal advance mechanical parts »

When cause of engine malfunction is traced to centrifugal advance mechanical part, use distributor tester to check its characteristic.

See the specifications above.

When nothing is wrong with its characteristic, conceivable causes are break-down abnormal wearing-out of driving part or others. So do not disassemble it.


In case of improper characteristic, take off contact breaker assembly and check closely cam assembly, governor weight, shaft and governor spring, etc.

In case centrifugal advance mechanical part is reassembled, be sure to check advance characteristic by distributor tester.

## DISASSEMBLY

To disassemble, follow the below procedure.

1. Take off cap and disconnect rotor head.
2. Remove vacuum controller.




EE291

Fig. EE-60 Removing vacuum controller


3. Remove contact set.

Refer to Page EE-31, when contact set is removed.



EE323

Fig. EE-61 Removing contact set




EE324

Fig. EE-62 Removing breaker plate


4. When breaker plate is removed, be careful not to lose steel balls between breaker spring and breaker plate.

5. Pull roll pin out and disconnect collar to remove the entire rotating parts.



EE325

Fig. EE-63 Removing roll pin



EE075

Fig. EE-65 Removing cam

7. When governor weight and spring are disconnected, be careful not to stretch or deform governor spring.

After disassembling, apply grease to governor weights.

## ASSEMBLY

To assemble, reverse the order of disassembly. Carefully observe the following instructions.

1. Align match marks so that parts are assembled to their original positions.
2. Apply grease to the top of cam assembly as required.
3. Check the operation of governor before installing distributor on engine.
4. Adjust ignition timing after distributor is installed on engine.

6. Remove packing from the top of cam assembly and unscrew cam assembly setscrew. Put match mark across cam and shaft so that original combination can be restored at assembly.

## SERVICE DATA AND SPECIFICATIONS

Type .....		D4A4-06, *D4A6-07	D4A4-07, *D4A6-08
Firing order .....		1-3-4-2	1-3-4-2
Rotating direction .....		Counterclockwise	Counterclockwise
Dwell angle	degree .....	49° to 55°	49° to 55°
Point gap	mm (in) .....	0.45 to 0.55 (0.018 to 0.022)	0.45 to 0.55 (0.018 to 0.022)
Point pressure	kg (lb) .....	0.40 to 0.55 (0.88 to 1.21)	0.40 to 0.55 (0.88 to 1.21)
Condenser capacity	μF .....	0.20 to 0.24	0.20 to 0.24
Condenser isolate resistance	MΩ .....	5	5
Cap isolate resistance	MΩ .....	50	50
Rotor head isolate resistance	MΩ .....	50	50
Cap carbon point length	mm (in) .....	10 (0.39)	10 (0.39)

\*: For Canada

## DISTRIBUTOR (California models)

### CONTENTS

CONSTRUCTION .....	EE-33	ADVANCE MECHANISMS .....	EE-33
CHECKING AND ADJUSTMENT .....	EE-33	DISASSEMBLY .....	EE-35
CAP AND ROTOR HEAD .....	EE-33	ASSEMBLY .....	EE-35
AIR GAP .....	EE-33	SERVICE DATA AND SPECIFICATIONS .....	EE-36

### CONSTRUCTION


In the conventional distributor the ignition timing is detected by the cam and breaker arm, while in this transistor ignition unit it is detected by the reluctor on the shaft and the pick-up coil provided in place of the breaker. The pick-up coil consists of a magnet, coil, etc. The amount of magnetic flux passing through the pole piece in the coil is changed at the moment the pole

piece faces the protrusion of the reluctor, and then the electrical signal is generated in the pick-up coil.

This electric signal is conducted into the transistor ignition unit, which in turn breaks the primary coil current running through the ignition coil and generates high voltage in the secondary winding. Also, this transistor ignition

unit utilizes this electric signal to restore the primary coil to the original state after cutting off the primary current for a fixed time.

The centrifugal and vacuum advance mechanisms employ the conventional mechanical type. The contactor is used to eliminate vacuum and centrifugal advance hysteresis.



EE327

Fig. EE-66 Exploded view of distributor

## CHECKING AND ADJUSTMENT

### CAP AND ROTOR HEAD

Cap and rotor head must be inspected periodically as specified in the "Maintenance Schedule". Remove cap and clean all dust and carbon deposits from cap and rotor from time to time. If cap is cracked or is leaking, replace with a new one.




Fig. EE-67 Checking air gap

To remove pick-up coil, disconnect distributor harness at terminal block and remove screw securing pick-up coil

assembly and distributor harness to their positions.




Fig. EE-68 Removing pick-up coil

### AIR GAP

Standard air gap is 0.2 to 0.4 mm (0.008 to 0.016 in).

If the gap is off the standard, adjustment should be made by loosening pick-up coil screws.

Gap gauge is required for adjustment. Air gaps must be checked from time to time.

Air gap: 0.2 to 0.4 mm  
(0.008 to 0.016 in)

### ADVANCE MECHANISMS

< Specifications >

Item	Type	D4F4-04	D4F4-03
		Manual	Automatic
Vacuum advance [Distributor degrees/ Distributor mmHg (inHg)]		0°/150 (5.91) 3°/250 (9.84)	
Centrifugal advance [Distributor degrees/ Distributor rpm]		0°/550 11°/2,300	0°/600 11°/1,950

## << Vacuum advance mechanism mechanical parts >>

If vacuum advance mechanism fails to operate properly, check for the following items and correct the problem as required.

1. Check vacuum inlet for signs of leakage at its connection. If necessary, retighten or replace with a new one.
2. Check vacuum diaphragm for air leak.

If leak is found, replace vacuum controller assembly.

3. Inspect breaker plate for smooth moving.

If plate does not move smoothly, this condition could be due to sticky steel balls or pivot. Apply grease to steel balls or, if necessary, replace distributor assembly.

## << Centrifugal advance mechanical parts >>

When cause of engine malfunction is traced to centrifugal advance mechanical parts, use distributor tester to check its characteristics. See the specifications above.

If nothing is wrong with its characteristics, conceivable causes are faulty or abnormal wear of driving part or others. So do not disassemble it.


In the event of improper characteristics, check closely rotor shaft assembly, governor weight and shaft.

If any of above parts are malfunctioning, replace distributor assembly.

## DISASSEMBLY


To disassemble, follow the procedure below.

1. Take off cap and remove rotor head.
2. Remove two screws shown in Figure EE-69 and detach vacuum controller.



EE291


Fig. EE-69 Removing vacuum controller



EE075

Fig. EE-72 Removing rotor shaft


3. Remove pick-up coil assembly.
4. Using two pry bars, pry reluctor from shaft. Be careful not to distort or damage the teeth of reluctor.  
Remove roll pin.
5. Remove breaker plate setscrews and remove breaker plate assembly.



EE330

Fig. EE-70 Removing breaker plate setscrews

6. Pull roll pin out and remove collar.
7. Remove rotor shaft and drive shaft assembly.



EE331

Fig. EE-71 Removing rotor shaft and drive shaft assembly

8. Mark rotor shaft and drive shaft.  
Remove packing from the top of rotor shaft and unscrew rotor shaft setscrew.

EE-35


9. Mark one of the governor springs and its bracket. Also mark one of the governor weights and its pivot pins.
10. Carefully unhook and remove governor springs.
11. Remove governor weights.

Apply grease to governor weights after disassembling.

## ASSEMBLY

To assemble, reverse the order of disassembly. Carefully observe the following instructions.

1. Align match marks so that parts are assembled to their original positions.
2. If, for any reason, contactor is removed from breaker plate, adjust cam-to-contactor clearance to 0.3 mm (0.012 in) as shown in Figure EE-73 after installation.



EE298

Fig. EE-73 Cam-to-contactor clearance

3. Ensure that reluctor is properly oriented when installing on shaft.  
Always drive in roll pin with its slit toward the outer end of shaft. See Figure EE-74. Be sure to use a new roll pin.






Fig. EE-74 Driving in roll pin

4. Apply grease to the top of rotor shaft as required.
5. Check the operation of governor before installing distributor on engine.
6. Adjust ignition timing after distributor is installed on engine.

## SERVICE DATA AND SPECIFICATIONS

Type .....	D4F4-03, D4F4-04
Firing order .....	1-3-4-2
Rotating direction .....	Counterclockwise
Duty .....	70% (20 to 40% at idling)
Air gap                      mm (in) .....	0.2 to 0.4 (0.008 to 0.016)
Cap insulation resistance      MΩ .....	More than 50
Rotor head insulation resistance MΩ .....	More than 50
Cap carbon point length      mm (in) .....	10 (0.39)

## TRANSISTOR IGNITION UNIT (California models)

### CONTENTS

DESCRIPTION .....	EE-36	2. CONTINUITY CHECK OF PRIMARY CIRCUIT .....	EE-38
TRANSISTOR IGNITION UNIT .....	EE-36	3. PICK-UP COIL CONTINUITY CHECK ....	EE-38
REMOVAL AND INSTALLATION .....	EE-37	4. PICK-UP COIL POWER SIGNAL PULSE CHECK .....	EE-38
INSPECTION .....	EE-37	5. TRANSISTOR IGNITION UNIT CHECK ..	EE-39
1. POWER SUPPLY WIRING AND BATTERY CHECK .....	EE-37		

## DESCRIPTION

### TRANSISTOR IGNITION UNIT

The transistor ignition unit provides the following functions:

1. It makes and breaks the electric current in the primary circuit of the ignition coil.

2. The duty control circuit sets the rate of make and break within one cycle, i.e., this maintains good ignition characteristics of engine from low speed to high speed and is equal to the dwell angle in the conventional breaker type distributor.
3. A preventive circuit against lock-

ing is provided. This cuts off the primary electric current in the ignition coil when the ignition switch is turned on with the engine not running.

Each component part of this unit is highly reliable, however, should any part be found faulty, the entire assembly must be replaced.




Fig. EE-75 Transistor ignition unit circuit diagram

## REMOVAL AND INSTALLATION

Transistor ignition unit is located on the right-hand dash side panel in passenger compartment.

1. Disconnect battery negative cable.
2. Disconnect wiring harness from unit.
3. Remove two setscrews and remove unit.
4. To install, reverse the order of removal.

**Note:** Be sure to connect wiring harnesses to their proper positions. Failure to do so will damage the unit.

Refer to Figure EE-76.




Fig. EE-76 External view of ignition unit

## INSPECTION

If the engine does not run due to faulty ignition system, check the ignition system as follows:

Check for a cracked distributor rotor or cap and corroded terminals. Visually inspect high tension wires for condition and, if necessary, use an ignition oscilloscope or a circuit tester to make performance checks. Check spark plugs and adjust gaps as necessary.

Replace a spark plug which is not suitable for further use. If the above checks cannot correct the problem, check the entire ignition system with an oscilloscope or a circuit tester.

### CHECKING WITH AN OSCILLOSCOPE

An oscilloscope can be used for checking almost all the items in a transistor ignition system.

### CHECKING WITH A CIRCUIT TESTER

A circuit tester can not be used for the duty control circuit and power transistor performance tests. Both methods (use of an oscilloscope and a circuit tester) are described in this section.

The items are classified by numerals in accordance with the objective of checks to be performed. Several wiring diagrams are found on pages EE-41 to EE-45. The thick lines indicate the objective of each individual item check.


When checking a circuit with an oscilloscope or a circuit tester, be careful not to confuse the polarity of the lead wires if a potential difference exists between the check points at which the lead wires are to be contacted. Also, do not attempt to connect the lead wires to any points in the circuit other than those designated. Careless handling of the lead wires will result in damage to the transistor ignition unit as well as to the oscilloscope or circuit tester.

The connection of a tachometer or a timing light in parallel with an oscilloscope or a circuit tester is allowable, provided that such a connection is made with due consideration to wiring connections.

## 1. POWER SUPPLY WIRING AND BATTERY CHECK (See wiring diagram in Figure EE-88)

### Procedure:

1. Turn on ignition switch.
2. Connect a circuit tester or an oscilloscope as shown in the figure below.



EE302

Fig. EE-77 Checking power supply wiring and battery

### Criterion:

When power source (battery) voltage is indicated . . . . . OK  
Lower or no indication . . . . . N.G.

## Engine Electrical System

If the result is "N.G." — Take the following measures:

1. Check "BW" and "B" color wire harness respectively, for proper conductance.
2. Check battery terminals for proper connection.
3. Check charge condition of battery if an excessively low voltage is indicated.

harness respectively for proper conductance.

2. Check resistor and ignition coil terminals for loose contact.
3. Check resistor and ignition coil for discontinuity.
4. Check "WB" color wire harness of ignition coil assembly for proper continuity.




Fig. EE-80 Checking pick-up coil

### Criterion:

When approximately 720 ohm is indicated ..... OK  
Far less than or more than 720 ohm ..... N.G.

If the result is "N.G." — Replace pick-up coil assembly.

## 2. CONTINUITY CHECK OF PRIMARY CIRCUIT

### 2-1. Checking primary circuit (See wiring diagram in Fig. EE-89)

#### Procedure:

1. Disconnect "L" color wire from ignition unit.
2. Turn on ignition switch.
3. Connect a circuit tester or an oscilloscope as shown in Figure EE-78.




Fig. EE-78 Checking primary circuit

### Criterion:

When normal power source (battery) voltage is indicated . OK  
Lower or no indication ..... N.G.

If the result is "N.G." — Take the following measures:

1. Check "BW" and "L" color wire

### 2-2. Checking ignition coil assembly (See wiring diagram in Fig. EE-90)

#### Procedure:

1. Disconnect ignition coil and distributor harness from ignition coil external resistor.
2. Connect a circuit tester as shown in the figure below.




Fig. EE-79 Checking ignition coil assembly

### Criterion:

When approximately 1.6 to 2.0 ohm is indicated ..... OK  
More than 2.0 ohm ..... N.G.

If the result is "N.G." — Replace ignition coil assembly.

## 3. PICK-UP COIL CONTINUITY CHECK (See wiring diagram in Figure EE-91)

#### Procedure:

1. Disconnect "R" and "G" color wires from ignition unit.
2. Connect a circuit tester as shown in the figure below:

## 4. PICK-UP COIL POWER SIGNAL PULSE CHECK

#### Procedure:

1. Disconnect anti-dieseling solenoid valve connector.
2. Connect a circuit tester as shown in the figure below.
3. Rotate starter motor.
4. Read the tester indication.




Fig. EE-81 Checking pick-up coil power signal pulse


### Criterion:

When pointer deflects slightly ..... OK  
When pointer does not deflect at all ..... N.G.

If the result is "N.G." — Replace pick-up coil assembly.

## Procedure: (with an oscilloscope)

1. Disconnect anti-dieseling solenoid valve connector.
2. Connect a positive lead of an oscilloscope to "R" color wire and a negative lead (of an oscilloscope) to "G" color wire.
3. Set a "SLOPE" select switch of an oscilloscope to the positive side. (If so equipped.)
4. Rotate starter motor.
5. Check the wave form as shown in the figure below.



EE268

Fig. EE-82 Wave form of pick-up coil

## Criterion:

When the wave form takes the shape of a full line ..... OK  
When the wave form takes the shape of a dashed line or when there is no wave form ..... N.G.

If the result is "N.G." — Replace pick-up coil assembly.

## 5. TRANSISTOR IGNITION UNIT CHECK (See wiring diagram in Figure EE-92)

Check items 5-1 and 5-2 with an oscilloscope.


Where an oscilloscope is not available, check to make sure that all previous tests are satisfactory and that no spark is issuing from the secondary high-tension wire.

If everything else is satisfactory, then the transistor ignition unit is faulty or there is discontinuity in the secondary high-tension wire. Replace the faulty part. After replacement check the sparks from the secondary cord.

### 5-1. Checking operation of transistor ignition unit


#### Procedure:

1. Connect ignition coil and distributor harness to ignition coil external resistor.



EE307

Fig. EE-83 Checking operation of transistor ignition unit



EE452

Fig. EE-84 Wave form of pulse

2. Connect wiring harness to the ignition unit.
3. Disconnect anti-dieseling solenoid valve connector.
4. Connect oscilloscope as shown in Figure EE-83, rotate the starter motor and observe the wave form on the oscilloscope.

## Criterion:

See Figure EE-84.

When a wave form similar to (a) is observed ..... OK  
When a wave form similar to (b) is observed or when no wave form is observed ..... N.G.

If the result is "N.G.", the fault lies either in the transistor unit or in the secondary high-tension wire.

Replace these parts.

— If an oscilloscope is not available —

## Procedure:

1. Connect ignition coil and distributor harness to ignition coil external resistor.
2. Connect wiring harness to ignition unit.
3. Disconnect anti-dieseling solenoid valve connector.
4. Keep the secondary high-tension wire end 4 to 5 mm (0.16 to 0.20 in) away from engine block, rotate the starter motor, and check whether sparks fly across the clearance.

## Criterion:

Where sparks issue ..... OK  
Where no spark issues ..... N.G.


If the result is "N.G.", the fault lies either in the transistor unit or in the secondary high-tension wire.

Replace these parts.

## 5-2. Checking operation of duty

### Procedure:

1. Connect anti-dieseling solenoid valve connector.
2. While the engine is idling, observe the wave form on the oscilloscope in the same way as stated in item 5-1, Figure EE-83. Determine the ratio  $t/T$  as shown in Figure EE-85.



EE257

Fig. EE-85 Wave form of duty pulse

### Criterion:

When a standard ratio of about 20 to 40% is obtained . . . . . OK  
When the ratio obtained is less than 20%, or more than 40% . . . . . N.G.


If the result is "N.G." — Replace transistor ignition unit.

## 5-3. Checking lock preventive circuit

— If a circuit tester is used —

### Procedure:

1. Connect a circuit tester as shown in Figure EE-83 or EE-86; positive terminal of tester is connected to "L" color wire and negative terminal of tester is grounded.
2. Turn on ignition switch. Check to see whether the tester indicates the voltage of power source (battery) as soon as ignition switch is turned on.



EE357

Fig. EE-86 Checking lock preventive circuit

### Criterion:

When power source voltage is indicated . . . . . OK  
When approximately zero-voltage is indicated . . . . . N.G.

If the result is "N.G." — Take the following measures:

Replace transistor ignition unit.

— If an oscilloscope is used —

### Procedure:


1. When using an oscilloscope instead of a tester, arrange the connec-

tion in the same way as shown in Figure EE-83 or Figure EE-86. Turn on ignition switch.

Check to see whether the wave form on the oscilloscope rises up to the power source voltage within about 10 seconds after ignition switch is turned on.


### Criterion:

The same as described before for use of a tester.




EE430

Fig. EE-87 Wave form of lock preventive circuit




EE438

Fig. EE-88 Wiring diagram for item (1) (Power supply wiring and battery check)



EE439

Fig. EE-89 Wiring diagram for item (2)-1 (Checking primary circuit)




EE440


Fig. EE-90 Wiring diagram for item (2)-2 (Checking ignition coil assembly)



# Engine Electrical System



EE441  
Fig. EE-91 Wiring diagram for item (3) (Pick-up coil continuity check)



EE442

Fig. EE-92 Wiring diagram for item (5) (Transistor ignition unit check)

## IGNITION COIL


The ignition coil is an oil-filled type. The ignition coil case is filled with oil which has good insulating and heat-radiating characteristics.

The ignition coil has a greater ratio between the primary and secondary windings to step up battery voltage to high voltage. This causes stronger sparks to jump the spark plug gap.

The cap is made of alkyd resin which offers high resistance to electric arc and increased insulation.

The ignition coil and resistor should be handled as a matched set.

When high tension wire is installed to ignition coil, there should be no clearance between their caps.



EE314

Fig. EE-93 Sectional view of ignition coil




Fig. EE-94 Correct installation of high tension wire

### Notes:

- Do not disconnect high tension wires from spark plugs during engine running. (California models only)
- Roll up high tension wire rubber cap and install high tension wire to ignition coil securely. Refer to Figure EE-95.




Fig. EE-95 Installing high tension wire

## SPECIFICATIONS

		Non-California models	California models
Type .....		C6R-618, H5-15-18	C1T-16, STC-9
Primary voltage	V .....	12	12
Spark gap	mm (in) .....	more than 7 (0.28)	more than 7 (0.28)
Primary resistance at 20°C (68°F)	Ω .....	1.08 to 1.32	0.45 to 0.55
Secondary resistance at 20°C (68°F)	KΩ .....	8.24 to 12.4	8.5 to 12.7
External resistor at 20°C (68°F)	Ω .....	1.5	1.3 (0.4 + 0.9)

# SPARK PLUG

## CONTENTS

DESCRIPTION .....	EE-47	SERVICE DATA AND SPECIFICATIONS .....	EE-48
INSPECTION .....	EE-47	TROUBLE DIAGNOSES AND	
CLEANING AND REGAP .....	EE-47	CORRECTIONS .....	EE-48

## DESCRIPTION

The spark plugs are of the conventional type, having 14 mm (0.551 in) threads. The spark plug gaps are 1.0 to 1.1 mm (0.039 to 0.043 in) on California models and 0.8 to 0.9 mm (0.031 to 0.035 in) on non-California models. The inspection and cleaning should be made every suitable maintenance period. If necessary, replace.

**Note:** All spark plugs installed on an engine must be of the same brand and the same number of heat range.

## INSPECTION

1. Remove spark plug wire by pulling on boot, not on wire itself.
2. Remove spark plugs.
3. Check electrodes and inner and outer porcelains of plugs, noting the type of deposits and the degree of electrode erosion. Refer to Figure EE-96.


**Normal:** Brown to grayish-tan deposits and slight electrode wear indicate correct spark plug heat range.

**Carbon fouled:** Dry fluffy carbon deposits on the insulator and electrode are usually caused by slow speed driving in city, weak ignition, too rich fuel mixture, dirty air cleaner, etc.


It is advisable to replace with plugs having hotter heat range.

**Oil fouled:** Wet black deposits indicate excessive oil entrance into combustion chamber through worn rings and pistons or excessive clearance between valve guides and stems. If the same condition remains after repair, use a hotter plug.

**Overheating:** White or light gray insulator with black or gray brown spots and bluish burnt electrodes indicate engine overheating. Moreover, the appearance results from incorrect ignition timing, loose



Normal




Overheating

EE079



Carbon fouled



Worn

Fig. EE-96 Spark plug


4. After cleaning, dress electrodes with a small fine file to flatten the surfaces of both center and side electrodes in parallel. Set spark plug gap to specification.
5. Install spark plugs and torque each plug to 1.5 to 2.0 kg-m (11 to 14 ft-lb).
6. Connect spark plug wires.

## CLEANING AND REGAP

Clean spark plugs in a sand blast type cleaner. Avoid excessive blasting. Clean and remove carbon or oxide deposits, but do not wear away porcelain. If deposits are too stubborn,

discard plugs.

After cleaning spark plugs, renew firing surface of electrodes with file mentioned above. Then gap spark plugs to specified values with a round wire feeler gauge. All spark plugs new or used should have the gap checked and reset by bending ground electrode.



EE080

Fig. EE-97 Setting spark plug gap

## SERVICE DATA AND SPECIFICATIONS

		California models	Non-California models except for Canada	For Canada
Type	Standard	BP6ES-11 L45PW-11	BP6ES L45PW	BPR6ES
	Hot type	BP4E-11, BP5ES-11 L46PW-11, L47PW-11	BP4E, BP5ES L46PW, L47PW	BPR4ES BPR5ES
	Cold type	BP7ES-11 L44PW-11	BP7ES L44PW	BPR7ES
Plug gap	mm (in)	1.0 to 1.1 (0.039 to 0.043)	0.8 to 0.9 (0.031 to 0.035)	0.8 to 0.9 (0.031 to 0.035)
Tightening torque	kg-m (ft-lb)	1.5 to 2.0 (11 to 14)		

## TROUBLE DIAGNOSES AND CORRECTIONS

### 1. When engine does not start

If there is no problem in fuel system, ignition system should be checked. This can be easily done by detaching a high tension wire from

spark plug, starting engine and observing condition of spark that occurs between high tension wire and spark plug terminal. After checking this, repair as necessary.

**Note:** On California models, disconnect anti-dieseling solenoid valve connector to cut off supply of fuel to engine and then observe the condition of sparks while starter motor is in operation.

Condition	Location	Probable cause	Corrective action
No spark at all	Distributor	Faulty insulation of condenser (Non-California models).	Replace.
		Breakage of lead-wire on low tension side.	Repair.
		Poor insulation of cap and rotor head.	Replace.
		Seized points (Non-California models).	Repair.
		Open pick-up coil (California models).	Replace.
		Air gap wider than specification (California models).	Adjust.
	Ignition coil	Wire breakage or short circuit of coil.	Replace with new one.
	High tension wire	Wire coming off.	Repair.
		Faulty insulation.	Replace.
	Transistor ignition unit (California models)	Faulty transistor ignition unit.	Replace.

## Engine Electrical System

Condition	Location	Probable cause	Corrective action
Spark length 1 to 2 mm (0.039 to 0.079 in) or irregular.	Distributor	Point gap too wide (Non-California models). Oil on point (Non-California models). Burned points (Non-California models).	Correct. Clean. Replace.
More than 6 mm (0.236 in)	Spark plugs	Spark plug gap too wide. Too much carbon. Broken neck of insulator. Expiration of plug life.	Correct or replace. Clean or replace. Replace. Replace.
	Distributor	Air gap too wide (California models).	Correct.
	Transistor ignition unit (California models)	Faulty transistor ignition unit.	Replace.

2. Engine rotates but does not run smoothly.

This may be caused by the ignition

system or other engine conditions not related to ignition. Therefore, first a

complete inspection of ignition system should be carried out.

Condition	Location	Probable cause	Corrective action
Engine misses.	Distributor	Dirty point (Non-California models). Foreign matter on pick-up coil (California models). Improper point gap (Non-California models). Improper air gap (California models). Leak of electricity at cap and rotor head. Damaged insulation of condenser (Non-California models). Malfunctioning contact arm (Non-California models). Faulty contact arm spring (Non-California models). Breakage of lead wire (Non-California models). Breakage of pick-up coil lead wire (California models). Worn or shaky breaker plate. Worn or shaky distributor driving shaft.	Clean. Clean. Correct. Correct. Repair or replace. Replace. Oil shaft. Replace. Replace. Replace. Replace assembly. Replace assembly.
	Ignition coil	Layer short circuit or inferior quality coil.	Replace with good one.
	High tension wire	Deterioration of insulation with consequent leak of electricity.	Replace.

## Engine Electrical System

Condition	Location	Probable cause	Corrective action
	Spark plugs	Fouled. Leak of electricity at upper porcelain insulator.	Clean. Repair or replace.
	Transistor ignition unit (California models)	Faulty transistor ignition unit.	Replace.
Engine causes knocking very often.	Distributor	Improper ignition timing (too advanced). Coming off or breakage of governor spring. Worn pin or hole of governor.	Correct. Correct or replace. Replace.
	Spark plugs	Burnt too much.	Replace.
Engine does not deliver enough power.	Distributor	Improper ignition timing (too retarded). Improper functioning governor. Point gap too narrow (Non-California models). Foreign particles stuck in air gap (California models).	Correct. Replace assembly. Correct. Clean.
	Spark plugs	Fouled.	Clean.

# **SERVICE MANUAL**

**DATSUN PICK-UP  
MODEL 620 SERIES**

## **SECTION ER**

# **ENGINE REMOVAL & INSTALLATION**

**ER**

**ENGINE REMOVAL AND  
INSTALLATION .....ER- 2**



**NISSAN MOTOR CO., LTD.  
TOKYO, JAPAN**



# ENGINE REMOVAL AND INSTALLATION

## CONTENTS

REMOVAL .....	ER-2	FRONT INSULATOR .....	ER-4
INSTALLATION .....	ER-3	REAR INSULATOR .....	ER-4
ENGINE MOUNTING INSULATORS .....	ER-3	TIGHTENING TORQUE .....	ER-4

## REMOVAL

It is much easier to remove engine and transmission as a single unit than to remove them separately. After removal, engine can be separated from transmission assembly.

### Notes:

- Be sure to hoist engine and jack up transmission in a safe manner.
- Use fender covers to protect vehicle body.

- Remove battery.
- Scribe hood hinge location for proper reinstallation, and remove hood.

**Note:** Have an assistant help you so as to prevent damage to body.

- Drain radiator coolant.
- Disconnect upper and lower radiator hoses from engine.
- Remove two oil cooler hoses from lower end of radiator. (Automatic transmission models only)
- Remove radiator shroud.
- Remove four bolts securing radiator and detach radiator.

**Note:** Always tighten securing bolt at upper right hand side together with body harness terminal.

8. Remove carburetor air cleaner as follows:

- Remove fresh air duct.
- Remove hot air duct.
- Loosen air cleaner band bolt and air cleaner supporting bolts.
- Disconnect air cleaner-to-air pump hose.
- Disconnect air cleaner-to-rocker cover hose at rocker cover.
- Disconnect air cleaner-to-air control valve hose. (California models only)

- Disconnect air cleaner-to-A.B. valve hose.
- Disconnect air cleaner-to-vacuum hoses.

**Note:** Protect carburetor from dust and foreign matter by placing cover over air inlet opening.

- Disconnect fuel pump-to-fuel filter hose and return hose.
- Disconnect carbon canister hose on engine side.
- Disconnect air pump air cleaner-to-air pump hose.
- Disconnect following cables, wires and hoses:
  - Engine ground cable.
  - Accelerator wire at carburetor.
  - High tension cable between ignition coil and distributor.
  - Wire to distributor at body terminal.
  - Wire to oil pressure switch.
  - Wires to thermal transmitter.
  - Wires to B.C.D.D. cut solenoid (Non-California models only), auto-choke heater and anti-dieseling solenoid.
  - Wires to alternator.
  - Wires to starter motor.
  - Heater inlet and outlet hoses, if so equipped.
  - Vacuum hose of Master-Vac at intake manifold.
  - Wires for back-up lamp switch.
  - Cable to speedometer.
- Remove transmission control linkage from transmission.
  - Manual transmission models.
    - Detach rubber boot.
    - Remove E-ring and control lever pin from transmission striking rod guide and remove control lever.




Fig. ER-1 Removing shift lever

- Automatic transmission models.
  - Disconnect selector range lever from manual shaft.
  - Disconnect wires at inhibitor switch and down shift solenoid.
- Air conditioner equipped models need following procedures.
  - After removing flexible hose support, remove four compressor securing bolts. Then move the compressor to battery support.
  - Remove vacuum hoses of F.I.C.D. solenoid valve.
  - Remove F.I.C.D. actuator.
- Remove two bolts securing clutch operating cylinder. Then disconnect operating cylinder and flexible tube as an assembly. (Manual transmission models only)
- Disconnect front exhaust tube from exhaust manifold.
- Remove propeller shaft.
  - Disconnect propeller shaft center bearing bracket from third crossmember.
  - Disconnect propeller shaft from companion flange of differential carrier.
  - Remove propeller shaft from transmission, and plug up rear end of extension housing of transmission to prevent oil leakage.
- Attach a suitable wire or chain to lift engine.
- Remove front engine mounting bolts at engine mounting front support.

## Engine Removal & Installation




Fig. ER-2 Removing front engine mounting bolts

20. Place a jack under transmission and jack it up.
21. Loosen two rear engine mounting bolts ①.
22. Loosen two exhaust tube hanger bolts ②. (California models only)
23. Remove four bolts ③ securing engine mounting rear support to side member and detach rear support.




Fig. ER-3 Removing rear engine mounting support

24. Remove steering idler arm securing bolts and push down cross rod.





Fig. ER-4 Removing idler arm

25. Pull engine towards front as far as possible and carefully raise it and transmission with a hoist and cable.

**Note:** In this operation, care should always be taken not to allow the unit to hit against any adjacent parts.



ER367

Fig. ER-5 Lifting engine


## INSTALLATION

Install engine with transmission in reverse order of removal, observing the following:

1. When installing, first secure rear

engine mounting support to body.

2. Refer to applicable section when installing and adjusting any parts.



- 1 Bracket R.H.
- 2 Insulator R.H.
- 3 Bracket L.H.
- 4 Heat shield plate
- 5 Insulator L.H.
- 6 Rear support
- 7 Rear insulator
- 8 Exhaust tube hanger (California models only)

ER279

Fig. ER-6 Structural view of engine mounting

## ENGINE MOUNTING INSULATORS

Three insulators are used to mount the engine and transmission; two are located at the left and right of the cylinder block and one at the transmission rear extension housing.

Replace any insulator that shows signs of separation or deterioration.

Be sure to keep insulator free from oil or grease.

## Engine Removal & Installation

### FRONT INSULATOR

#### Removal and Installation

1. Disconnect battery ground cable.
2. Remove hood.
3. Suspend engine with wire or chain.
4. Loosen front engine mounting insulator upper nuts (both sides).
5. Carefully raise engine a little with a hoist and cable.
6. Remove front mounting insulators at front supports after removing front mounting bolts.

7. To install, reverse order of removal.

### REAR INSULATOR

#### Removal and Installation

1. Place a jack under transmission

and jack it up slightly.

2. Loosen two rear engine mounting bolts.
3. Loosen two exhaust tube hanger bolts. (California models only)
4. Remove rear mounting insulator at transmission rear extension after removing insulator securing bolts.
5. To install, reverse order of removal.

## TIGHTENING TORQUE

#### Fixing bolts and nuts

Front mounting bracket to cylinder block	kg-m (ft-lb) .....	2.6 to 3.6 (19 to 26)
Front mounting insulator to bracket	kg-m (ft-lb) .....	2.6 to 3.6 (19 to 26)
Front mounting insulator to front support	kg-m (ft-lb) .....	1.4 to 1.8 (10 to 13)
Rear mounting insulator to transmission	kg-m (ft-lb) .....	3.2 to 3.7 (23 to 27)
Rear mounting insulator to rear support	kg-m (ft-lb) .....	1.6 to 2.2 (12 to 16)
Rear support to frame	kg-m (ft-lb) .....	3.2 to 4.3 (23 to 31)
Clutch operating cylinder to transmission	kg-m (ft-lb) .....	2.5 to 3.5 (18 to 25)
Exhaust front tube to exhaust manifold	kg-m (ft-lb) .....	1.9 to 2.5 (14 to 18)
Center bearing bracket to crossmember	kg-m (ft-lb) .....	1.6 to 2.2 (12 to 16)
Propeller shaft to companion flange	kg-m (ft-lb) .....	2.4 to 3.3 (17 to 24)

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES

## SECTION CL

### CLUTCH

CL

CLUTCH.....	CL- 2
CLUTCH CONTROL .....	CL- 5
SERVICE DATA AND SPECIFICATIONS .....	CL- 9
TROUBLE DIAGNOSES AND CORRECTIONS .....	CL-10
SPECIAL SERVICE TOOL .....	CL-12



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

# CLUTCH

## CLUTCH

### CONTENTS

DESCRIPTION .....	CL-2	DISASSEMBLY AND ASSEMBLY .....	CL-3
REMOVAL AND INSTALLATION .....	CL-2	Disassembly .....	CL-3
Removal .....	CL-2	Assembly .....	CL-3
Installation .....	CL-3	INSPECTION .....	CL-4

### DESCRIPTION

The clutch is a single dry disc type

using a diaphragm spring. It consists of the clutch disc, pressure plate, dia-

phragm spring, thrust rings, clutch cover, and clutch release bearing.




Fig. CL-1 Construction of clutch disc and cover assembly

### REMOVAL AND INSTALLATION

#### Removal

1. Remove transmission from vehicle.

For details of transmission removal, refer to "Transmission Section."

2. Insert Clutch Aligning Bar KV30100200 into clutch disc hub until it will no longer go. It is im-

portant to support weight of clutch disc during further steps. See Figure CL-2.

3. Loosen six screws attaching clutch cover to flywheel one turn at a time each until spring pressure is released. Be sure to turn them out in a crisscross fashion.

**Note:** Exercise special care to avoid grease or oil getting on clutch linings.




Fig. CL-2 Supporting clutch assembly

# CLUTCH


## Installation

1. Apply a light coat of lithium base grease (containing molybdenum disulfide) on transmission main drive gear splines.

Slide clutch disc on main drive gear several times. Remove clutch disc and wipe off excess lubricant pushed off by disc hub.

2. Install clutch disc and clutch cover assembly on flywheel. Support two assemblies with Clutch Aligning Bar KV30100200. See Figure CL-3.

**Note:** Be sure to keep disc facings, flywheel, and, pressure plate clean and dry.



CL109  
**Fig. CL-3** Installing clutch cover assembly

3. Install six bolts to tighten clutch cover assembly to flywheel squarely. Each bolt should be tightened one turn at a time to the specified torque 1.5 to 2.2 kg-m (11 to 16 ft-lb).

**Note:** Three dowels are used to locate clutch cover on flywheel properly.

4. Remove Clutch Aligning Bar KV30100200 after tightening the bolts securely.

5. Install transmission.

**Note:** Make certain that withdrawal lever engages lever ball pin.

6. Connect push rod of clutch operating cylinder to withdrawal lever.

## DISASSEMBLY AND ASSEMBLY

### Disassembly

1. Clutch cover assembly can not be

disassembled since diaphragm spring is securely reveted to clutch cover and clutch cover assembly is balanced.

If necessary, replace clutch cover assembly as a complete unit.


2. Remove clutch release mechanism as follows (See Figure CL-4):

(1) Remove dust cover from clutch housing.

(2) Remove withdrawal lever from clutch housing.


(3) Remove retainer spring from withdrawal lever.

(4) Remove release bearing, bearing sleeve and holder spring from clutch housing as an assembly.




**Fig. CL-4** Exploded view of clutch release mechanism

3. Take out clutch release bearing from bearing sleeve, using a universal puller. See Figure CL-5.



CL014  
**Fig. CL-5** Disassembling release bearing

4. Remove pilot bushing in crankshaft by Pilot Bushing Puller ST16610001 if necessary. See Figure CL-6.




CL088  
**Fig. CL-6** Removing pilot bushing

## Assembly

### Release mechanism


1. When assembling release bearing on sleeve, use a press and seat bearing squarely on sleeve. See Figure CL-7.



CL215  
**Fig. CL-7** Installing release bearing

2. Before or during assembling, lubricate the following points with a light coat of multi-purpose grease.

(1) Inner groove of release bearing sleeve. See Figure CL-8.




CL216  
**Fig. CL-8** Lubricating recess of bearing sleeve

(2) Contact surfaces of withdrawal lever, lever ball pin and bearing sleeve.

(3) Contact surfaces of transmission front cover. See Figure CL-9.

# CLUTCH



**Fig. CL-9 Lubricating points of withdrawal lever and front cover**

(4) Contact surfaces of transmission main drive gear splines. [lithium base grease (including molybdenum disulfide)].

**Note:** Very small amount of grease should be coated to the above points. If too much lubricant is applied, it will run out on the friction plates when hot, resulting in damaging clutch disc facings.

3. Install retainer spring to withdrawal lever. Fit holder spring to release bearing and sleeve assembly, then assemble withdrawal lever and bearing sleeve as a unit. Install this assembly on transmission case. Then install dust cover.

## Pilot bushing

Before installing a new bushing, thoroughly clean bushing hole. Install bushing in crankshaft using a soft hammer. Bushing need not be oiled.

## INSPECTION

Wash all the disassembled parts except release bearing and disc assembly in suitable cleaning solvent to remove dirt and grease before making inspection and adjustment.

## Flywheel and pressure plate

Check friction surface of flywheel and pressure plate for scoring or roughness. Slight roughness may be smoothed by using fine emery cloth.


If surface is deeply scored or grooved, the part should be replaced.

## Clutch disc assembly

Inspect clutch disc for worn or oily facings, loose rivets, and broken or loose torsional springs.

1. If facings are oily, the disc should be replaced. In this case, inspect transmission front cover oil seal, pilot bushing, engine rear oil seals and other points for oil leakage.

2. The disc should also be replaced when facings are worn locally or worn down less than 0.3 mm (0.0118 in) at rivets. See Figure CL-10.




**Fig. CL-10 Measuring clutch lining**

3. Check disc plate for runout whenever the old disc or a new one is installed.

4. If runout exceeds the specified value at the outer circumference, replace or repair disc. See Figure CL-11.

**Runout:**  
0.5 mm (0.020 in)  
total indicator reading  
R (from the hub center):  
107.5 mm (4.23 in)



**Fig. CL-11 Measuring disc runout**

5. Check the fit of disc hub on transmission main drive gear for smoothly sliding. If splines are worn, clutch disc or main drive gear should be replaced; that is, backlash exceeds 0.4 mm (0.016 in) at the outer edge of clutch disc.

## Clutch cover assembly


1. Check the end surface of diaphragm spring for wear.

If excessive wear is found, replace clutch cover as an assembly.

2. Measure the height of diaphragm spring as outlined below. See Figure CL-12.

a. Place Distance Piece ST20050100 on Base Plate ST20050010 and then tighten clutch cover assembly on the base plate by using Set Bolts (ST20050051).


b. Measure diaphragm spring toe height "A" at several points with a vernier caliper depth gauge.



**Fig. CL-12 Measuring the height of diaphragm spring**

If the height "A" of spring end is beyond the specified value of 33 to 35 mm (1.23 to 1.38 in), adjust the spring height with Diaphragm Adjusting Wrench ST20050240. See Figure CL-13.

If necessary, replace clutch cover as an assembly. Also, unevenness of diaphragm spring toe height should be less than 0.5 mm (0.020 in).



**Fig. CL-13 Adjusting the spring height**

3. Inspect thrust rings for wear or damage. As these parts are invisible from outside, shake cover assembly up and down to listen for chattering noise, or lightly hammer on rivets for a slightly cracked noise. Any of these noises mean requirement for replacement as a complete assembly.

# CLUTCH

## Release bearing and sleeve

Check for abnormal wear on contact surface of withdrawal lever, ball pin and bearing sleeve.

## Pilot bushing

Check pilot bushing in crankshaft for wear or roughness. If necessary, replace it.

When bushing is faulty, be sure to check transmission main drive gear at the same time.

# CLUTCH CONTROL

## CONTENTS

DESCRIPTION .....	CL-5	Inspection .....	CL-8
CLUTCH PEDAL .....	CL-6	OPERATING CYLINDER .....	CL-8
Removal and installation .....	CL-6	Removal and installation .....	CL-8
Inspection and adjustment .....	CL-6	Disassembly and assembly .....	CL-8
CLUTCH MASTER CYLINDER .....	CL-7	Inspection .....	CL-8
Removal and installation .....	CL-7	BLEEDING CLUTCH SYSTEM .....	CL-8
Disassembly and assembly .....	CL-7		

## DESCRIPTION


The hydraulic clutch control consists of a pendent pedal, a master cylinder, an operating cylinder and a withdrawal lever.

When the clutch pedal is depressed, the piston of the master cylinder

forwards clutch fluid to the operating cylinder via a pipe line. The movement of the operating cylinder piston is transmitted to the withdrawal lever through the push rod, thus disengaging the clutch.

The operating cylinder is a non-

adjustable type that uses no return spring. In this unit, the withdrawal-to-push rod play adjustment is not necessary since the "S" as shown in Figure CL-15 serves to automatically compensate for wear on the clutch disc.



- |                          |                    |
|--------------------------|--------------------|
| 1 Clutch pedal           | 6 Push rod         |
| 2 Return spring          | 7 Withdrawal lever |
| 3 Clutch master cylinder | 8 Release bearing  |
| 4 Clutch piping          | 9 Clutch cover     |
| 5 Operating cylinder     | 10 Clutch disc     |

CL305

Fig. CL-14 Clutch operating system



# CLUTCH




Fig. CL-15 Non-adjustable operating cylinder

## CLUTCH PEDAL

### Removal and installation

#### Removal (See Figure CL-16.)

1. Pry off cotter pin and take out clevis pin; disconnect push rod from pedal assembly.
2. Unhook return spring. Loosen off fulcrum pin and remove pedal assembly.




Fig. CL-16 Exploded view of clutch pedal

Note: Before removing clutch pedal, note toe board clearance at pedal pad.

#### Installation

To install, reverse the order of removal. Apply multi-purpose grease to the friction surfaces of the disassembled parts as shown in Figure CL-17.

#### Tightening torque:

Pedal installation bolt  
(Fulcrum pin):

1.9 to 2.4 kg-m  
(14 to 17 ft-lb)

Lock nuts "A" and "B":

0.8 to 1.2 kg-m  
(5.8 to 8.7 ft-lb)

Note: Refer to Figure CL-18 for the correct direction of return spring.




Fig. CL-18 Hooking return spring

### Inspection and adjustment

Clean all the following parts in cleaning solvent and check for wear, damage or any other abnormal condition. Replace the parts which are faulty.

- (1) Return spring
- (2) Bush
- (3) Pedal boss, etc.




Fig. CL-17 Adjusting pedal height

1. Adjust the pedal height to 153 mm (6.02 in) by adjusting pedal stopper and tighten lock nut "A" to the specified torque 0.8 to 1.2 kg-m (5.8 to 8.7 ft-lb).
2. Turn in or out push rod adjusting screw until a play of 1 to 3 mm (0.039 to 0.118 in) at clevis pin is obtained. Then tighten lock nut "B" to the specified torque 0.8 to 1.2 kg-m (5.8 to 8.7 ft-lb).

Note: Exercise care in adjusting the play not to block the port or master cylinder. A blocked port may result if too small play at clevis pin exists.

3. After adjusting, check the pedal full stroke is in 117 to 123 mm (4.61 to 4.84 in).

Note: Depress and release clutch pedal over its entire stroke to ensure that the clutch linkage operates smoothly without squeak noise, interference and binding.

## CLUTCH

### CLUTCH CYLINDER MASTER

#### Removal and installation

##### Removal

1. Remove clevis pin at push rod.
2. Disconnect clutch tube from master cylinder and drain clutch fluid.
3. Remove bolts securing master

cylinder to the vehicle, and dismount master cylinder.

**Note:** Remove dust cover from master cylinder body, on the side of driver's seat.

##### Installation

To install, reverse the order of removal. Closely observe the following instructions.

1. Adjust pedal height by changing pedal stopper length.

2. Bleed air out of hydraulic system.


##### Tightening torque:

Master cylinder to dash panel:  
0.8 to 1.2 kg-m  
(5.8 to 8.7 ft-lb)

Clutch tube connector (Flare nut):  
1.5 to 1.8 kg-m  
(11 to 13 ft-lb)

3. Using Flare Nut Torque Wrench GG94310000, tighten each connector to the specified torque.

#### Disassembly and assembly



- 1 Reservoir cap
- 2 Reservoir
- 3 Reservoir band
- 4 Cylinder body
- 5 Supply valve stopper
- 6 Return spring
- 7 Spring seat
- 8 Valve spring
- 9 Supply valve rod
- 10 Supply valve
- 11 Primary cup
- 12 Piston
- 13 Push rod
- 14 Secondary cup
- 15 Stopper
- 16 Stopper ring
- 17 Dust cover
- 18 Lock nut

CL265

Fig. CL-19 Exploded view of master cylinder

#### Disassembly

1. Remove dust cover and remove stopper ring from body.
2. Remove push rod and piston assembly.
3. Take off piston cups.
4. Remove spring seat from piston and take off supply valve if necessary. See Figure CL-19.

**Note:** Discard piston cup, supply valve and spring seat after removal.

#### Assembly

To assemble, reverse the order of disassembly. Closely observe the following instructions.

1. Dip piston cup in brake fluid before installing. Make sure that it is correctly faced in position.
2. Apply a coating of brake fluid to cylinder and piston when assembling.
3. Press piston into spring seat when assembling.

**Note:** The clutch master cylinder is available in both NABCO make and TOKICO make. There is no interchangeability of repair kits or component parts between NABCO and TOKICO makes.

When replacing the repair kit or component parts, ascertain the brand of the clutch master cylinder body. Be sure to use parts of the same make as the former ones.

# CLUTCH

## Inspection

**Note:** To clean or wash all parts of master cylinder, operating cylinder and piping, clean brake fluid must be used. Never use mineral oils such as gasoline and kerosene. It will ruin the rubber parts of the hydraulic system.

1. Check cylinder and piston for uneven wear or damage, and if necessary, replace.
2. If the clearance between cylinder and piston is more than 0.15 mm (0.0059 in), replace cylinder.
3. Renew piston cup when disassembled. It must also be replaced when wear or deformation due to fatigue or damage is found.
4. Damaged dust cover, oil reservoir or cap, should be replaced.

Return spring and valve spring must also be replaced when they are broken or weak.

5. Replace clutch hose and tube if any abnormal sign of damage or deformation is found.

## OPERATING CYLINDER

### Removal and installation

#### Removal

1. Detach clutch hose from operating cylinder.
2. Remove two bolts securing operating cylinder to clutch housing.

#### Installation

Install in the reverse order of removal.

Observe the following instructions.

1. Bleed air thoroughly from clutch hydraulic system.
2. Do not install return spring, or clutch will not be disengaged properly.

**Tightening torque:**

Operating cylinder securing bolt:  
2.5 to 3.5 kg-m (18 to 25 ft-lb)


Bleeder screw:  
0.7 to 0.9 kg-m (5.1 to 6.5 ft-lb)

Clutch hose connector:  
1.7 to 2.0 kg-m (12 to 14 ft-lb)

## Disassembly and assembly

### Disassembly

1. Remove push rod with dust cover.
2. Remove piston assembly and piston spring.
3. Remove bleeder screw.



*Fig. CL-20 Exploded view of operating cylinder*

### Assembly

Assemble in the reverse order of disassembly. Closely observe the following instructions.

1. Prior to assembly, dip piston cup in clean brake fluid.
- When installing cup, pay particular attention to its direction.
2. Dip cylinder and piston in clean brake fluid before assembly.

#### Notes:

- a. Be sure to install piston assembly with piston spring in place.
- b. The clutch operating cylinder is available in both NABCO make and TOKICO make. There is no interchangeability of repair kits or component parts between NABCO and TOKICO makes.

When replacing the repair kit or component parts, ascertain the brand of the clutch operating cylinder body. Be sure to use parts of the same make as the former ones.

## Inspection

Visually inspect all disassembled parts, replacing those found worn or

damaged too badly beyond specifications.

## BLEEDING CLUTCH SYSTEM

The hydraulic clutch system must be bled whenever clutch line has been disconnected or air has entered it.

When pedal action has a "spongy" feeling, it is an indication that air has entered the system.

Bleeding clutch system is an essential part of regular clutch service.

1. Remove reservoir cap and top up with recommended brake fluid.
2. Thoroughly clean mud and dust from bleeder screw of operating cylinder so that outlet hole is free from any foreign material. Install bleeder hose (vinyl hose) on bleeder screw.

Place the other end of it in a clean container.

3. Have a co-worker depress clutch pedal two or three times. With clutch pedal depressed fully, loosen bleeder screw to bleed air out of clutch system.
4. Close bleeder screw quickly as clutch pedal is on down stroke.
5. Allow clutch pedal to return slowly with bleeder screw closed.
6. Repeat steps 4 and 5 until no air bubble shows in the vinyl hose.
7. Operate clutch several times; then, check connections for external hydraulic leaks.

#### Notes:

- a. Brake fluid containing air is white and has visible air bubbles.
- b. Brake fluid containing no air runs out of bleeder screw in a solid stream without air bubbles.
- c. Pay close attention to clutch fluid level in reservoir during bleeding operation.
- d. Do not reuse brake fluid drained during bleeding operation.
- e. Exercise care not to splash brake fluid on exterior finish as it will damage the paint.
- f. Pour brake fluid into reservoir up to specified level.

---

## CLUTCH

---

### SERVICE DATA AND SPECIFICATIONS

#### Clutch cover

Clutch cover type .....	Diaphragm (C225S)
Diaphragm spring-to-flywheel distance	mm (in) ..... 33 to 35 (1.23 to 1.38)
Unevenness of diaphragm spring toe height	mm (in) ..... less than 0.5 (0.020)
Full load	kg (lb) ..... 400 (882)
Out of flatness of pressure plate	mm (in) ..... 0.1 (0.004)
Allowable refacing limit of pressure plate	mm (in) ..... 1.0 (0.040)

#### Clutch disc

##### Facing size

Outer dia. x inside dia. x thickness	mm (in) ..... 225 x 150 x 3.5 (8.86 x 5.91 x 0.138)
Thickness of disc assembly	
Free	mm (in) ..... 8.3 to 8.9 (0.327 to 0.350)
Compressed	mm (in) ..... 7.6 to 8.0 (0.299 to 0.315)
Number of torsion springs	6
Allowable minimum depth of rivet head from surface	mm (in) ..... 0.3 (0.012)
Allowable facing run-out	mm (in) ..... 0.5 (0.020)
Allowable free play of spline (at the outer edge of disc)	mm (in) ..... 0.4 (0.016)

#### Clutch pedal

Pedal height	mm (in) ..... 153 (6.02)
Play at clevis pin	mm (in) ..... 1 to 3 (0.039 to 0.118)
Full stroke	mm (in) ..... 117 to 123 (4.61 to 4.84)

#### Clutch master cylinder

Dia. of master cylinder	mm (in) ..... 15.87 (5/8)
Allowable maximum clearance between cylinder and piston	mm (in) ..... 0.15 (0.0059)

#### Clutch operating cylinder

Dia. of operating cylinder	mm (in) ..... 19.05 (¾)
----------------------------	-------------------------

#### Tightening torque

Clutch assembly to flywheel securing bolt	kg-m (ft-lb) ..... 1.5 to 2.2 (11 to 16)
Pedal installation bolt (Fulcrum pin)	kg-m (ft-lb) ..... 1.9 to 2.4 (14 to 17)
Pedal stopper lock nut	kg-m (ft-lb) ..... 0.8 to 1.2 (5.8 to 8.7)
Push rod lock nut	kg-m (ft-lb) ..... 0.8 to 1.2 (5.8 to 8.7)
Master cylinder to dash panel securing bolt	kg-m (ft-lb) ..... 0.8 to 1.2 (5.8 to 8.7)
Clutch tube connector (Flare nut)	kg-m (ft-lb) ..... 1.5 to 1.8 (11 to 13)
Clutch hose connector	kg-m (ft-lb) ..... 1.7 to 2.0 (12 to 14)
Operating cylinder to clutch housing securing bolt	kg-m (ft-lb) ..... 2.5 to 3.5 (18 to 25)
Bleeder screw	kg-m (ft-lb) ..... 0.7 to 0.9 (5.1 to 6.5)

## CLUTCH

### TROUBLE DIAGNOSES AND CORRECTIONS







Condition	Probable cause and testing	Corrective action
Clutch slips	<p>Slipping of the clutch may be noticeable when any of the following symptoms is encountered during operation.</p> <ol style="list-style-type: none"> <li>(1) Vehicle will not respond to engine speed during acceleration.</li> <li>(2) Insufficient vehicle speed.</li> <li>(3) Lack of power during uphill driving.</li> </ol> <p>Some of the above conditions are also experienced when engine problem is occurring. First determine whether engine or clutch is causing the problem.</p> <p>If slipping clutch is left unheeded, wear and/or overheating will occur on clutch facing until it is no longer serviceable.</p> <p><b>TO TEST FOR SLIPPING CLUTCH</b>, proceed as follows:</p> <p>During upgrade travelling, run engine at about 40 to 50 km/h (25 to 31 MPH) with gear shift lever in 3rd speed position, shift into highest gear and at the same time rev up engine. If clutch is slipping, vehicle will not readily respond to depression of accelerator pedal.</p>	
	<ul style="list-style-type: none"> <li>• Clutch facing worn excessively.</li> <li>• Oil or grease on clutch facing.</li> <li>• Warped clutch cover or pressure plate.</li> </ul>	<p>Replace.</p> <p>Replace.</p> <p>Repair or replace.</p>
Clutch drags	<p>Dragging clutch is particularly noticeable when shifting gears, especially into low gear.</p> <p><b>TO TEST FOR DRAGGING CLUTCH</b>, proceed as follows:</p> <ol style="list-style-type: none"> <li>(1) Start engine. Disengage clutch. Shift into reverse gear, and then into Neutral. Gradually increase engine speed, and again shift into reverse gear. If clutch is dragging, gear "grating" is heard when shifting from Neutral into Reverse.</li> <li>(2) Stop engine and shift gear. (Conduct this test at each gear position.)</li> <li>(3) Gears are smoothly shifted in step (2), but drag when shifting to 1st speed position at idling.               <ol style="list-style-type: none"> <li>a. If dragging is encountered at the end of shifting, check condition of synchro-mechanism in transmission.</li> <li>b. If dragging is encountered at the beginning of shifting, proceed to step (4) below.</li> </ol> </li> <li>(4) Push change lever toward Reverse side, depress pedal to check for free travel.               <ol style="list-style-type: none"> <li>a. If pedal can be depressed further, check clutch condition.</li> <li>b. If pedal cannot be depressed further, proceed to step (5) below.</li> </ol> </li> <li>(5) Check clutch control (pedal height, pedal free travel, withdrawal lever play, etc.). If no abnormal condition exists and if pedal cannot be depressed further, check clutch condition.</li> </ol>	
	<ul style="list-style-type: none"> <li>• Clutch disc runout or warped.</li> <li>• Wear or rust on hub splines in clutch disc.</li> <li>• Diaphragm spring toe height out of adjustment or toe tip worn.</li> <li>• Worn or improperly installed parts.</li> </ul>	<p>Repair or replace.</p> <p>Clean and lubricate with grease, or replace.</p> <p>Adjust or replace.</p> <p>Repair or replace.</p>

## CLUTCH


Condition	Probable cause and testing	Corrective action
Clutch chatters	Clutch chattering is usually noticeable when vehicle is just rolled off with clutch partially engaged.	
	<ul style="list-style-type: none"> <li>● Weak or broken clutch disc torsion spring.</li> <li>● Oil or grease on clutch facing.</li> <li>● Clutch facing out of proper contact or clutch disc runout.</li> <li>● Loose rivets.</li> <li>● Warped pressure plate or clutch cover surface.</li> <li>● Unevenness of diaphragm spring toe height.</li> <li>● Loose engine mounting or deteriorated rubber.</li> </ul>	Replace.  Replace. Replace.  Replace. Repair or replace.  Adjust or replace.  Retighten or replace.
Noisy clutch	A noise is heard after clutch is disengaged.	
	<ul style="list-style-type: none"> <li>● Damaged release bearing.</li> </ul>	Replace.
	A noise is heard when clutch is disengaged. <ul style="list-style-type: none"> <li>● Insufficient grease on the sliding surface of bearing sleeve.</li> <li>● Clutch cover and bearing are not installed correctly.</li> </ul>	Apply grease.  Adjust.
	A noise is heard when vehicle is suddenly started off with clutch partially engaged.	
	<ul style="list-style-type: none"> <li>● Damaged pilot bushing.</li> </ul>	Replace.
Clutch grabs	When grabbing of clutch occurs, vehicle will not start off smoothly from a standing start or clutch is engaged before clutch pedal is fully depressed.	
	<ul style="list-style-type: none"> <li>● Oil or grease on clutch facing.</li> <li>● Clutch facing worn or loose rivets.</li> <li>● Wear or rust on splines in drive shaft and clutch disc.</li> <li>● Warped flywheel or pressure plate.</li> <li>● Loose mountings for engine or power train units.</li> </ul>	Replace. Replace. Clean or replace.  Repair or replace. Retighten.

# CLUTCH

## SPECIAL SERVICE TOOLS

No.	Tool number & tool name	Description	Unit: mm (in)	For use on	Reference page or Figure No.
1.	ST20050010 Base plate	  SE002 SE003	620 B210 710 610 S30	Fig. CL-12	
2.	ST20050051 Set bolt				
3.	ST20050100 Distance piece 7.8 mm (0.31 in)				
4.	ST20050240 Diaphragm adjusting wrench	 SE032	620 B210 710 610 S30	Fig. CL-13	
5.	KV30100200 Clutch aligning bar	<p>This tool is used to conduct disc centering by inserting the tool into pilot bush in flywheel, when installing clutch assembly to flywheel.</p>  SE001	620 710 610 S30	Fig. CL-2 Fig. CL-3	
6.	ST16610001 Pilot bushing puller	 SE191	620 710 610 S30	Fig. CL-6	

## CLUTCH

No.	Tool number & tool name	Description  Unit: mm (in)	For use on	Reference page or Figure No.
7.	GG94310000 Flare nut torque wrench	<p>This tool is used to tighten and loosen brake and clutch tube flare nut. A built-in torque limiting wrench is provided to assure torque accuracy.</p>  <p style="text-align: right;">SE227</p>	All models	Page CL-7



# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

## SECTION MT

# MANUAL TRANSMISSION

MT

4-SPEED TRANSMISSION (TYPE: F4W71B)	MT- 2
5-SPEED TRANSMISSION (TYPE : FS5W71B)	MT-14
SERVICE DATA AND SPECIFICATIONS	MT-21
TROUBLE DIAGNOSES AND CORRECTIONS	MT-23
SPECIAL SERVICE TOOLS	MT-24

## 4-SPEED TRANSMISSION (TYPE: F4W71B)

### CONTENTS

DESCRIPTION .....	MT- 2	GEARS AND SHAFTS .....	MT- 8
REMOVAL .....	MT- 4	BAULK RING .....	MT- 9
DISASSEMBLY .....	MT- 4	OIL SEAL .....	MT- 9
TRANSMISSION CASE DISASSEMBLY .....	MT- 4	ASSEMBLY .....	MT- 9
DISASSEMBLY OF GEAR ASSEMBLY .....	MT- 5	FRONT COVER ASSEMBLY .....	MT- 9
REAR EXTENSION DISASSEMBLY .....	MT- 8	REAR EXTENSION ASSEMBLY .....	MT- 9
ADAPTER PLATE DISASSEMBLY .....	MT- 8	ADAPTER PLATE ASSEMBLY .....	MT- 9
INSPECTION .....	MT- 8	GEAR ASSEMBLY .....	MT- 9
TRANSMISSION CASE AND		TRANSMISSION ASSEMBLY .....	MT-13
REAR EXTENSION HOUSING .....	MT- 8	INSTALLATION .....	MT-14
BEARING .....	MT- 8		

### DESCRIPTION

The transmission is of a 4-speed forward, fully synchronized constant-mesh type that uses helical gears.

The reverse gear is of a sliding-mesh type using spur gears.

In construction, the main drive gear is meshed with the counter drive gear which is keyed to the countershaft. The forward speed gears on the countershaft are in constant mesh with the mainshaft gears which ride on the mainshaft freely through the needle bearing. When shifting is accom-

plished, the inner teeth of the coupling sleeve slide over the synchronizer hub and mesh with the outer teeth which are provided on the mainshaft gear.

The synchronizer hub is fitted to the mainshaft by splines so the mainshaft gear turns together with the mainshaft.


The baulk ring serves to synchronize the coupling sleeve and mainshaft gear.

Placing the control lever in reverse position brings the reverse idler gear into mesh with mainshaft reverse gear.

The transmission assembly consists of three main parts; a transmission case with clutch housing, adapter plate to which all gears and shafts are installed, and rear extension.

The cast-iron adapter plate supports the mainshaft, countershaft, reverse idler shaft and three fork rods, and bolted at the front to the transmission case and, at the rear, to the rear extension by means of through-bolts.

By removing these through-bolts all gears and shafts are stripped.




TM858

- 1 Front cover
- 2 Transmission case
- 3 Adapter plate
- 4 Bearing retainer
- 5 Rear extension housing

Fig. MT-1 F4W71B transmission case components


# Manual Transmission



- 1 Main drive gear
- 2 Baulk ring
- 3 Synchronizer hub, 3rd & 4th
- 4 Shifting insert spring
- 5 Shifting insert
- 6 Coupling sleeve
- 7 3rd main gear
- 8 Mainshaft
- 9 2nd main gear
- 10 1st main gear
- 11 1st gear spacer
- 12 Reverse main gear
- 13 Counter drive gear
- 14 Countershaft
- 15 Reverse counter gear
- 16 Reverse idler shaft
- 17 Reverse idler gear

TM857

Fig. MT-2 F4W71B transmission gear components



- 1 Striking lever
- 2 Lock pin
- 3 O-ring
- 4 Striking guide
- 5 Oil seal
- 6 Striking rod
- 7 E-ring
- 8 Stopper guide pin
- 9 Return spring plunger
- 10 Return spring
- 11 Reverse check spring
- 12 Return spring plug
- 13 Check ball plug
- 14 Check spring
- 15 Check ball
- 16 Interlock ball
- 17 Retaining pin
- 18 1st & 2nd shift fork
- 19 1st & 2nd fork rod
- 20 3rd & 4th fork rod
- 21 Reverse fork rod
- 22 3rd & 4th shift fork
- 23 Reverse shift fork
- 24 Control lever
- 25 Control lever bushing
- 26 Control lever pin
- 27 Control lever bushing

TM045A

Fig. MT-3 F4W71B transmission shift control components

## Manual Transmission

### REMOVAL

In dismantling transmission from the vehicle, proceed as follows:

1. Disconnect battery ground cable from terminal.
2. Place transmission control lever in neutral position.
3. Remove E-ring and control lever pin from transmission striking rod guide, and remove control lever. See Figure MT-4.





Fig. MT-4 Removing control lever

4. Jack up the vehicle and support its weight on safety stands. Use a hydraulic hoist or open pit, if available.

Confirm that safety is insured.

5. Disconnect exhaust front tube.
6. Disconnect wires from reverse lamp switch. See Figure MT-5.
7. Disconnect speedometer cable from rear extension housing. See Figure MT-5.
8. Remove clutch operating cylinder from transmission case. See Figure MT-5.




- 1 Speedometer cable
- 2 Reverse lamp switch
- 3 Clutch operating cylinder

TM774

Fig. MT-5 Bottom view of car

9. Remove bracket holding center bearing on 3rd crossmember by loosening off attaching bolts. See Figure MT-6.




PD219

Fig. MT-6 Removing center bearing holding bracket

10. Detach propeller shaft from companion flange of gear carrier by removing four bolts. See Figure MT-7.

#### Notes:


- a. Remove propeller shaft carefully so as not to damage spline, sleeve yoke and rear oil seal.
- b. Plug up the opening in the rear of rear extension housing to prevent oil from flowing out.



PD220

Fig. MT-7 Removing four bolts securing propeller shaft to companion flange

11. Support engine by locating a jack under oil pan with a wooden block used between oil pan and jack.
12. Support transmission with a transmission jack.
13. Remove exhaust pipe bracket by unscrewing attaching bolts (2) (California models only). See Figure MT-8.
14. Remove rear engine mounting insulator securing bolts (1) and rear mounting member securing bolts (3). See Figure MT-8.



ER277

Fig. MT-8 Removing engine mounting rear support

15. Remove starter motor.
16. Remove bolts securing transmission to engine.

After removing these bolts, support the engine and transmission with jacks, and then slide transmission rearward away from engine and remove from the vehicle.

Note: Take care in dismantling transmission not to strike any adjacent parts and main drive shaft.


### DISASSEMBLY

#### TRANSMISSION CASE DISASSEMBLY

1. Prior to disassembling transmission, thoroughly wipe off dirt and grease from it.
2. Drain oil thoroughly.
3. Remove dust cover from transmission case.

Remove release bearing and withdrawal lever.

4. Remove reverse lamp switch.
5. Move gear to Neutral.
6. Remove speedometer pinion and pinion sleeve by taking off lock plate.
7. Remove E-ring and stopper guide pin from rear end of rear extension. See Figure MT-9.



TM337

Fig. MT-9 Removing striking rod E-ring and stopper pin

8. Remove return spring plug, return spring, reverse check spring, and plunger from rear extension. See Figure MT-10.




Fig. MT-10 Removing return spring plug

9. Remove rear extension securing bolts and turn the striking rod toward left.

Drive out rear extension backward by lightly tapping around it with a soft hammer. See Figure MT-11.




Fig. MT-11 Removing rear extension

10. Remove front cover securing bolts and remove front cover.

Detach countershaft front bearing shim.

11. Remove main drive bearing snap ring with Expander. See Figure MT-12.




Fig. MT-12 Removing main drive bearing snap ring

12. Separate transmission case from adapter plate with a soft hammer. See Figure MT-13.




Fig. MT-13 Removing transmission case

13. Set up Setting Plate Adapter ST23810001 on adapter plate.

With countershaft side up, place the above assembly in a vise. See Figure MT-14.




Fig. MT-14 Attaching gear assembly to special tool

## DISASSEMBLY OF GEAR ASSEMBLY

### Fork rod

1. Drive out retaining pins from each fork rod with Fork Rod Pin Punch ST23540000. See Figure MT-15.




Fig. MT-15 Drive out retaining pins

2. Remove three(3) check ball plugs, and drive out fork rods from adapter plate by lightly tapping on the front end.

Be careful not to lose three(3) check balls and four(4) interlock balls. See Figure MT-16.

Note: Each gear and shaft can be detached from adapter plate without removing each fork rod.




Fig. MT-16 Layout of check ball and interlock ball

## Gear assembly

1. With gears doubly engaged, draw out countershaft front bearing using a suitable gear puller. See Figure MT-17.
2. Remove counter drive gear snap ring.
3. Draw out counter drive gear complete with main drive gear assembly by means of a gear puller.

When drawing out main drive gear assembly, be careful not to drop pilot needle bearing onto floor from the front end of mainshaft. See Figure MT-18.




Fig. MT-17 Removing countershaft front bearing





Fig. MT-18 Removing counter drive gear and main drive gear

## Manual Transmission

4. Remove snap ring and then thrust washer from mainshaft front end.

Draw out 3rd & 4th synchronizer assembly and remove 3rd gear assembly.

5. Release caulking on mainshaft nut and loosen it. See Figure MT-19.



TM346

Fig. MT-19 Removing mainshaft nut


6. Remove mainshaft nut, thrust washer and mainshaft reverse gear.

7. Remove snap ring from countershaft rear end, and remove reverse idler gear.

8. Draw out mainshaft gear assembly together with countershaft by

lightly tapping the rear end with a soft hammer while holding the front of mainshaft gear assembly by hand.

Be careful not to drop off gear shaft. See Figure MT-20.



TM347


Fig. MT-20 Driving out gear assembly

### Mainshaft assembly

1. Remove thrust washer, steel ball, 1st gear and needle bearing. Be careful not to lose steel ball retaining thrust washer.


2. Press out 1st gear mainshaft bushing together with 2nd gear and 1st & 2nd speed synchronizer using Bearing Puller ST30031000. See Figure MT-21.

Note: When pressing out bushing, hold mainshaft by hand so as not to drop it.



TM049A

Fig. MT-21 Removing 1st gear mainshaft bushing




- 1 Pilot bearing
- 2 3rd & 4th synchronizer assembly
- 3 Baulk ring
- 4 3rd main gear
- 5 Needle bearing
- 6 Mainshaft
- 7 Needle bearing
- 8 2nd main gear
- 9 1st & 2nd synchronizer assembly
- 10 Coupling sleeve
- 11 Shifting insert
- 12 Shifting insert spring
- 13 Synchronizer hub
- 14 1st main gear
- 15 Needle bearing
- 16 1st gear bushing
- 17 Thrust washer
- 18 Mainshaft bearing
- 19 Reverse main gear
- 20 Thrust washer
- 21 Nut
- 22 Steel ball
- 23 Thrust washer
- 24 Snap ring

TM348

Fig. MT-22 Exploded view of mainshaft assembly

## Main drive gear

1. Remove main drive gear snap ring and spacer.
2. Remove main drive bearing with Bearing Puller ST30031000 and a suitable press. See Figure MT-23.



TM349


Fig. MT-23 Removing main drive bearing

## Countershaft assembly

Install Bearing Puller ST30031000 on countershaft rear bearing; press out countershaft rear bearing through a rod.


See Figure MT-25.

**Note:** When pressing out bearing, hold shaft by hand so as not to drop shaft onto floor.




TM350

Fig. MT-24 Exploded view of main drive gear



TM351

Fig. MT-25 Removing countershaft bearing




TM352

Fig. MT-26 Exploded view of countershaft assembly

## REAR EXTENSION DISASSEMBLY

Remove lock pin from striking lever, and remove striking rod.

Note: Do not disassemble rear extension bush from rear extension.



- 1 Control lever
- 2 Striking rod guide
- 3 Striking rod
- 4 Striking lever
- 5 Return spring plug
- 6 Stopper pin

TM353

Fig. MT-27 Exploded view of shifting mechanism

## ADAPTER PLATE DISASSEMBLY


1. Remove six(6) bearing retainer attaching screws with an impact wrench and remove bearing retainer from adapter plate.
2. Remove reverse idler shaft.
3. Remove mainshaft bearing from the rear extension side.

Remove all nicks, projection or sealant with a fine stone.

3. If rear extension bush is worn or cracked, replace it as an assembly of bush and rear extension housing.

## BEARING

1. Thoroughly clean bearing and dry with a compressed air.
2. When race and ball surfaces are worn or rough, or when balls are out-of-round or rough, replace bearing with a new one. See Figure MT-28.



TM372

Fig. MT-28 Inspecting ball bearing

## INSPECTION

Wash all parts in a suitable cleaning solvent and check for wear, damage or other faulty conditions.

### Notes:

- a. Be careful not to damage any parts with scraper.
- b. Do not clean, wash or soak oil seals in solvent.

## TRANSMISSION CASE AND REAR EXTENSION HOUSING

1. Clean with solvent thoroughly and check for cracks which might cause oil leak or other faulty conditions.
2. Check mating surface of the case to engine or adapter plate for small nicks, projection or sealant.

3. Replace needle bearing if worn or damaged.

## GEARS AND SHAFTS

1. Check all gears for excessive wear, chips or cracks; replace as required.

2. Check shaft for bending, crack, wear, and worn spline; if necessary, replace.
3. Measure backlash in gears.

Standard:

0.05 to 0.10 mm  
(0.0020 to 0.0039 in)

If the above limits are exceeded, replace drive and driven gears as a set.

4. Measure gear end play:

1st gear:


0.32 to 0.39 mm  
(0.0126 to 0.0154 in)

2nd gear:

0.12 to 0.19 mm  
(0.0047 to 0.0075 in)

3rd gear:

0.13 to 0.37 mm  
(0.0051 to 0.0146 in)



TM374

Fig. MT-29 Measuring end play




5. Check for stripped or damaged speedometer pinion gear. If necessary, replace.

## BAULK RING

1. Replace baulk ring if found to be deformed, cracked or otherwise damaged excessively.
2. Place baulk ring in position on gear cone.

While holding baulk ring against gear as far as it will go, measure gap between baulk ring and outer gear.

If gap is small, discard baulk ring. See Figure MT-30.



TM375

Fig. MT-30 Baulk ring-to-cone gap

## OIL SEAL

Discard O-ring or oil seal which is once removed. Replace oil seal if sealing lip is deformed or cracked. Also discard oil seal if spring is out of position.


## ASSEMBLY

To assemble, reverse the order of disassembly. Observe the following instructions.

### FRONT COVER ASSEMBLY

1. Wipe clean seal seat in front cover, then press fit oil seal in place.

Coat oil seal with gear oil to provide initial lubrication.



TM354


Fig. MT-31 Front cover oil seal

2. Apply sealant to withdrawal lever ball pin screw. Install withdrawal lever ball pin to front cover and tighten screw to 1.6 to 2.1 kg-m (12 to 15 ft-lb) torque.

## REAR EXTENSION ASSEMBLY

1. Wipe clean seal seat in rear extension housing; press fit oil seal in place.

Coat oil seal and bushing with gear oil for initial lubrication.



TM355

Fig. MT-32 Rear extension oil seal

2. Apply grease to O-ring and plunger grooves in striking rod.

Insert striking rod with striking rod guide through rear extension.


3. Install striking lever on front end of striking rod. Install lock pin and torque screw to 0.9 to 1.2 kg-m (7 to 9 ft-lb).

## ADAPTER PLATE ASSEMBLY

1. Place dowel pin, mainshaft bearing and oil gutter on adapter plate, and tap with a soft hammer until they are properly positioned in place.

Use a new dowel pin.

Bend oil gutter on front side and expand on rear side. See Figure MT-33.



TM356


Fig. MT-33 Oil gutter

2. Insert reverse idler shaft in adapter plate.

Make sure that the cut-out portion of reverse idler shaft is lined up with inner face of adapter plate.

3. Install bearing retainer in adapter plate.

Align bearing retainer with reverse idler shaft at the cut-out portion of this shaft, torque screws to 1.9 to 2.5 kg-m (14 to 18 ft-lb) and stake each screw at two points with a punch. See Figure MT-34.



TM400

Fig. MT-34 Staking screw

4. Install countershaft rear bearing in adapter plate by lightly tapping around it with a soft hammer.


## GEAR ASSEMBLY

Clean all parts in solvent and dry with compressed air.

### Synchronizer assembly

Assemble synchronizer assembly.

Position shifting insert springs and shifting inserts in three(3) slots in synchronizer hub; put coupling sleeve on synchronizer hub.




TM357

Fig. MT-35 Installing synchronizer hub

## Manual Transmission

### Mainshaft assembly


1. Assemble 2nd gear needle bearing, 2nd gear, baulk ring, 1st & 2nd speed synchronizer assembly, 1st gear baulk ring, 1st gear bush, needle bearing, 1st gear, steel ball, and thrust washer on mainshaft. Before installing a steel ball, apply grease to it. See Figure MT-36.



TM358

Fig. MT-36 Installing thrust washer


2. Set Transmission Press Stand KV31100400 and place adapter plate assembly on it. See Figure MT-37.



TM438

Fig. MT-37 Transmission Press Stand

3. Install mainshaft assembly to adapter plate assembly. Be sure to place bearing squarely against shaft and press it into place on shaft gradually. See Figure MT-38.



TM439

Fig. MT-38 Installing mainshaft assembly


### Countershaft assembly

1. Place new woodruff keys in grooves in countershaft and tap them lightly until they are seated securely.

Use a soft hammer to avoid damaging keys.

2. Place adapter plate assembly and mainshaft assembly so that countershaft rear bearing rests on Transmission Press Stand KV31100400 properly.

3. Install countershaft into adapter plate by pressing it. See Figure MT-39.



TM440


Fig. MT-39 Installing countershaft

4. Position 3rd gear needle bearing, mainshaft 3rd gear, baulk ring, and 3rd & 4th synchronizer assembly on the front of mainshaft.

5. Install thrust washer on mainshaft and secure it with snap ring of proper thickness that will fit the groove in mainshaft. See Figure MT-40.

Available snap ring

No.	Thickness mm (in)
1	1.4 (0.055)
2	1.5 (0.059)
3	1.6 (0.063)



TM441

Fig. MT-40 Installing snap ring


### Main drive gear assembly

1. Using Transmission Adapter ST23800000, press main drive bearing onto the shaft of main drive gear. Make sure that snap ring groove on shaft clears bearing.

2. Place main drive bearing spacer on main drive bearing and secure main drive bearing with thicker snap ring that will eliminate end play. See Figure MT-41.

Available snap ring

No.	Thickness mm (in)
1	1.80 (0.0709)
2	1.87 (0.0736)
3	1.94 (0.0764)
4	2.01 (0.0791)
5	2.08 (0.0819)
6	2.15 (0.0846)



TM364

Fig. MT-41 Installing snap ring

3. Position baulk ring on cone surface of main drive gear. Apply gear oil to mainshaft pilot bearing and install it on mainshaft.

Assemble main drive gear assembly on the front end of mainshaft.

4. Press counter drive gear onto countershaft with Counter Gear Drift ST23860000 by meshing gears and secure counter drive gear with thicker snap ring. See Figures MT-42 and MT-43.

Note: Be sure to drive in counter drive gear and main drive gear simultaneously.




Fig. MT-42 Installing countershaft drive gear

Available counter drive gear snap ring

No.	Thickness mm (in)
1	1.4 (0.055)
2	1.5 (0.059)
3	1.6 (0.063)




Fig. MT-43 Installing snap ring

5. Press countershaft front bearing onto countershaft with Drift C ST22360002. See Figure MT-44.




Fig. MT-44 Installing countershaft front bearing

6. Support adapter plate in a vise with Setting Plate Adapter ST23810001, with mainshaft facing down.

7. Install mainshaft reverse gear, plain washer on the rear of mainshaft and install mainshaft nut.

Tighten mainshaft nut temporarily.

8. Install counter reverse gear on the rear of countershaft and secure with snap ring.

Use snap ring to give a minimum gear end play. See Figure MT-45.

No.	Thickness mm (in)
1	1.4 (0.055)
2	1.5 (0.059)
3	1.6 (0.063)




Fig. MT-45 Installing counter reverse gear snap ring

9. Install reverse idler gear on reverse idler shaft.

10. With 1st and 2nd gears doubly engaged, tighten mainshaft nut to the converted torque "C" (See Figure MT-48) using Wrench ST22520000. See Figure MT-47.




Fig. MT-46 Tightening mainshaft nut

## Explanation of converted torque

Mainshaft nut should be tightened to 14 to 17 kg-m (101 to 123 ft-lb) torque with the aid of Wrench ST22520000. When doing so, the amount of torque to be read on wrench needle should be modified according to the following formula:

$$C \text{ kg-m} = 14 \times \left( \frac{L}{L + 0.10} \right) \text{ to } 17 \times \left( \frac{L}{L + 0.10} \right)$$

or

$$C \text{ (ft-lb)} = 101 \times \left( \frac{L}{L + 0.33} \right) \text{ to } 123 \times \left( \frac{L}{L + 0.33} \right)$$

Where,

C: Value read on the torque wrench kg-m (ft-lb)

L: Effective length of torque wrench m (ft)




Fig. MT-47 Setting wrench

Example,

When a 0.40 m (1.31 ft)-long torque wrench is used, the "C" in Figure MT-48 will be 11.2 to 13.6 kg-m (81 to 98 ft-lb).




Fig. MT-48 Converted torque

11. Tighten mainshaft nut to 14.0 to 17.0 kg-m (101 to 123 ft-lb) torque, and stake mainshaft nut to groove of mainshaft with a punch. See Figure MT-49.




Fig. MT-49 Staking mainshaft nut

12. Measure gear end play and backlash.

Make sure that they are held within the specified values.

For details, refer to the instructions under topic "Inspection".

**Note:** The main drive gear and counter drive gear should be handled as a matched set.

When you replace a main drive gear or counter drive gear, be sure to replace as a set of main drive gear and counter drive gear.

## Shift forks and fork rods assembly

1. Place 1st & 2nd shift fork in groove in 1st & 2nd coupling sleeve, and slide 1st & 2nd fork rod through adapter plate and 1st & 2nd shift fork. Prior to installing 1st & 2nd fork rod, install 3rd & 4th shift fork in groove in 3rd & 4th coupling sleeve.


**Note:** Shift forks for 1st & 2nd and 3rd & 4th are one and the same parts.

Make sure that the long end of shift fork for 1st & 2nd is placed on the counter gear side and the long end for 3rd & 4th is on the opposite side.

Secure 1st & 2nd fork rod to shift fork with a new retaining pin.

2. Install check ball, check ball spring, and check ball plug. Prior to tightening check ball plug, apply sealant to check ball plug.

Align notch in 1st & 2nd fork rod with check ball. See Figure MT-50.



TM367

Fig. MT-50 Installing 1st & 2nd fork rod


3. Slide 3rd & 4th fork rod through adapter plate and 3rd & 4th shift fork, and secure with a new retaining pin.

**Note:** Prior to assembling 3rd & 4th fork rod, install two(2) interlock balls into adapter plate as shown in Figure MT-16.

4. Install check ball and check ball spring.

Apply sealant to check ball plug and install it in place.

Align notch in 3rd & 4th fork rod with check ball by sliding 3rd & 4th fork rod as necessary. See Figure MT-51.



TM368

Fig. MT-51 Installing 3rd & 4th fork rod

5. Place reverse shift fork in reverse idler gear.

Slide reverse fork rod through reverse shift fork and adapter plate, and secure with a new retaining pin.

## Manual Transmission

**Note:** Prior to assembling reverse fork rod, install two(2) interlock balls into adapter plate as shown in Figure MT-16.

6. Install check ball and check ball spring.

Apply sealant to check ball plug and install it in place.

Align notch in reverse fork rod with check ball. See Figure MT-52.




Fig. MT-52 Installing reverse fork rod

7. Torque each check ball plug to 1.9 to 2.5 kg-m (14 to 18 ft-lb).

**Note:** Ball plug for 1st & 2nd fork rod is longer than those for reverse shift fork rod and 3rd & 4th fork rod.

8. Apply gear oil to all sliding surfaces and check to see that shift rods operate correctly and gears are engaged smoothly.

### TRANSMISSION ASSEMBLY

#### Transmission case assembly

1. Clean mating surfaces of adapter plate and transmission case.

Apply sealant to mating surfaces of adapter plate and transmission case.

2. Slide transmission case onto adapter plate by lightly tapping with a soft hammer until case bears against adapter plate.

Carefully install main drive bearing and countershaft front bearing.

Make certain that mainshaft rotates freely.

3. Fit main drive bearing snap ring to groove in main drive bearing by using Expander. See Figure MT-53.




Fig. MT-53 Fitting main drive bearing snap ring

#### Rear extension assembly

1. Clean mating surfaces of adapter plate and rear extension.

Apply sealant to mating surfaces of adapter plate and rear extension.

2. With fork rods in their neutral positions, gradually slide rear extension onto adapter plate, making sure that speed change cross lever engages with fork rod brackets correctly.

3. Install washers and through-bolts and torque to 1.6 to 2.1 kg-m (12 to 15 ft-lb)

#### Available shim

No.	"A" mm (in)	Countershaft front bearing shim mm (in)
1	2.92 to 3.01 (0.1150 to 0.1185)	0.6 (0.024)
2	3.02 to 3.11 (0.1189 to 0.1224)	0.5 (0.020)
3	3.12 to 3.21 (0.1228 to 0.1264)	0.4 (0.016)
4	3.22 to 3.31 (0.1268 to 0.1303)	0.3 (0.012)
5	3.32 to 3.41 (0.1307 to 0.1343)	0.2 (0.008)
6	3.42 to 3.51 (0.1346 to 0.1382)	0.1 (0.004)
7	3.52 to 3.61 (0.1386 to 0.1421)	—
8	3.62 to 3.71 (0.1425 to 0.1461)	—

2. Clean mating surfaces of front cover and transmission case.

Apply grease to shim selected to retain it on front cover; install front cover to transmission case with gasket in place.

Install through-bolts with washers under them and tighten to 1.6 to 2.1 kg-m (12 to 15 ft-lb) torque.

Apply sealant to threads of through-bolts before installation.

#### Front cover assembly

1. Select countershaft front bearing shim as follows: See Figure MT-54.

(1) Measure depth "A" from front end of transmission case to countershaft front bearing.

(2) Select a shim of thickness "A" measured.




Fig. MT-54 Selecting countershaft front bearing shim

3. Install speedometer pinion assembly on rear extension. After making sure that lock plate is lined up with groove in speedometer pinion sleeve, install through-bolts and torque to 0.4 to 0.5 kg-m (3 to 4 ft-lb).
4. Install back-up lamp switch and torque to 2.0 to 3.0 kg-m (14 to 22 ft-lb).

Be sure to apply sealant before installation.

5. Apply a light coat of multi-purpose grease to withdrawal lever, release bearing and bearing sleeve; install them on clutch housing.

After connecting them with holder spring, install dust cover on clutch housing.

6. Install control lever temporarily, and shift control lever through all gears to make sure that gears operate smoothly.


**Note:** Install drain plug and filler plug with sealant in place.

## INSTALLATION

Install the transmission in the reverse order of removal paying attention to the following points.

1. Before installing, clean mating surfaces of engine rear plate and transmission case.
2. Before installing, lightly apply grease to spline parts of clutch disc and main drive gear.
3. Tighten bolts securing transmission to engine to specifications. See Figure MT-55.

4.4 to 5.9 kg-m (32 to 43 ft-lb)



0.9 to 1.2 kg-m (7 to 9 ft-lb)

TM773

*Fig. MT-55 Tightening torque*

4. Remove filler plug and fill transmission with recommended gear oil to the level of the plug hole. [Approximately 1.7 liters (3 3/4 pt, 3 pt)].

## 5-SPEED TRANSMISSION (TYPE : FS5W71B)

### CONTENTS

DESCRIPTION .....	MT-14	BEARING .....	MT-19
REMOVAL .....	MT-17	GEARS AND SHAFTS .....	MT-19
DISASSEMBLY .....	MT-17	BAULK RING .....	MT-19
TRANSMISSION CASE DISASSEMBLY .....	MT-17	OIL SEAL .....	MT-19
DISASSEMBLY OF GEAR ASSEMBLY .....	MT-17	ASSEMBLY .....	MT-19
REAR EXTENSION DISASSEMBLY .....	MT-18	FRONT COVER ASSEMBLY .....	MT-19
ADAPTER PLATE DISASSEMBLY .....	MT-19	REAR EXTENSION ASSEMBLY .....	MT-19
INSPECTION .....	MT-19	GEAR ASSEMBLY .....	MT-19
TRANSMISSION CASE AND REAR		TRANSMISSION ASSEMBLY .....	MT-20
EXTENSION HOUSING .....	MT-19	INSTALLATION .....	MT-20

## DESCRIPTION

The transmission is of a 5-speed forward with overdrive (4 + OD speed), fully synchronized constant-mesh type that uses helical gears.


The 5-speed transmission covered in this section is similar in all respects to the 4-speed transmission (type: F4W71B) stated previously except the

overdrive position of it.

The overdrive gear rides on the mainshaft freely through the needle roller bearing and counter overdrive gear is fitted to the countershaft by splines.

The overdrive synchronizer system is on the mainshaft rear side.


Placing the control lever in overdrive position brings the reverse & OD coupling sleeve (reverse gear) on mainshaft into mesh with overdrive clutch gear. The reverse & OD synchronizer hub is fitted to the mainshaft by splines so the overdrive gear on mainshaft turns together with the mainshaft.



TM046A

*Fig. MT-56 FS5W71B transmission case components*

Age Group	Percentage
18-24	10%
25-34	20%
35-44	25%
45-54	20%
55-64	15%
65-74	10%
75-84	5%
85+	5%




- 1 Main drive gear
- 2 Baulk ring
- 3 Shifting insert
- 4 Shifting insert spring
- 5 Synchronizer hub
- 6 Coupling sleeve
- 7 3rd main gear
- 8 Needle bearing
- 9 Mainshaft
- 10 2nd main gear
- 11 Bushing
- 12 1st main gear
- 13 OD-reverse synchronizer hub
- 14 Reverse gear
- 15 Circlip
- 16 Thrust block
- 17 Brake band
- 18 Synchronizer ring
- 19 Overdrive main gear
- 20 Overdrive gear bushing
- 21 Washer
- 22 Mainshaft nut
- 23 Overdrive mainshaft bearing
- 24 Speedometer drive gear
- 25 Countershaft front bearing shim
- 26 Countershaft front bearing
- 27 Countershaft drive gear
- 28 Countershaft
- 29 Countershaft bearing
- 30 Reverse counter gear spacer
- 31 Reverse counter gear
- 32 Overdrive counter gear
- 33 Countershaft rear bearing
- 34 Countershaft nut
- 35 Reverse idler shaft
- 36 Reverse idler thrust washer
- 37 Reverse idler gear
- 38 Reverse idler gear bearing
- 39 Reverse idler thrust washer

TM047A

**Fig. MT-57 FS5W71B transmission gear components**





TM048A

Fig. MT-58 FS5W71B transmission shift control components

## REMOVAL

Same as for the F4W71B.

## DISASSEMBLY

### TRANSMISSION CASE DISASSEMBLY

Same as for the F4W71B.

### DISASSEMBLY OF GEAR ASSEMBLY

#### Fork rod


Same as for the F4W71B.

#### Gear assembly

1. With gears doubly engaged, draw out countershaft front bearing using a suitable gear puller. See Figure MT-59.
2. Remove counter drive gear snap ring.


3. Draw out counter drive gear complete with main drive gear assembly by means of a gear puller.

When drawing out main drive gear assembly, be careful not to drop pilot needle bearing onto floor from the front end of mainshaft. See Figure MT-60.



TM756

Fig. MT-60 Removing counter drive gear and main drive gear



TM398

Fig. MT-59 Removing countershaft front bearing

4. Remove snap ring and then thrust washer from mainshaft front end.


Draw out 3rd & 4th synchronizer assembly and remove 3rd gear assembly.

5. Remove snap ring and then draw out speedometer gear and bearing from mainshaft rear side.

6. With gears doubly engaged, release caulking on countershaft and mainshaft nuts then loosen them.

Remove countershaft nut.

# Manual Transmission




TM757

**Fig. MT-61** Removing countershaft nut

**Note:** When removing mainshaft assembly, loosen mainshaft nut.

7. Draw out counter overdrive gear and bearing from countershaft rear end by using a suitable gear puller. See Figure MT-62.



TM758


**Fig. MT-62** Removing counter overdrive gear and bearing

8. Remove counter reverse idler gear and spacer.

9. Remove countershaft by lightly tapping the rear end with a soft hammer.

Be careful not to drop off gear shaft.


10. Remove reverse idler gear snap ring.



TM759


**Fig. MT-63** Removing reverse idler gear snap ring

11. Remove reverse idler gear.  
12. Remove snap ring of mainshaft end bearing. Draw out bearing using Mainshaft Rear Bearing Puller KV32101330. Remove other snap ring of mainshaft end bearing. See Figure MT-64.



TM760

**Fig. MT-64** Removing mainshaft end bearing



TM761

**Fig. MT-65** Driving out gear assembly  
**Mainshaft**

Same as for the F4W71B.

## Main drive gear

Same as for the F4W71B.


## Countershaft assembly

Same as for the F4W71B.

## REAR EXTENSION DISASSEMBLY

Remove lock pin from striking lever, and remove striking rod.

**Note:** Do not disassemble rear extension bushing from rear extension.




- 1 Striking lever
- 2 Striking rod
- 3 Stopper pin
- 4 Control lever
- 5 Striking rod guide
- 6 Reverse select plunger
- 7 Reverse select plug

TM767

**Fig. MT-66** Exploded view of shifting mechanism

## ADAPTER PLATE DISASSEMBLY

Same as for the F4W71B.



TM768

Fig. MT-67 Removing screws

## INSPECTION

Wash all parts in a suitable cleaning solvent and check for wear, damage or other faulty conditions.

### Notes:

- Be careful not to damage any parts with scraper.
- Do not clean, wash or soak oil seals in solvent.

## TRANSMISSION CASE AND REAR EXTENSION HOUSING

Same as for the F4W71B.

## BEARING

Same as for the F4W71B.

## GEARS AND SHAFTS

- Check all gears for excessive wear, chips or cracks; replace as required.
- Check shaft for bending, crack, wear, and worn spline; if necessary, replace.
- Measure backlash in gears.

Main drive and counter drive gear:

0.05 to 0.10 mm  
(0.0020 to 0.0039 in)

1st, 2nd, 3rd, 5th and reverse gears:

0.05 to 0.20 mm  
(0.0020 to 0.0040 in)

If the above limits are exceeded, replace drive and driven gears as a set.

### 4. Measure gear end play:

1st gear:

0.32 to 0.39 mm  
(0.0126 to 0.0154 in)

2nd gear:

0.12 to 0.19 mm  
(0.0047 to 0.0075 in)

3rd gear:

0.13 to 0.37 mm  
(0.0051 to 0.0146 in)

OD gear (on mainshaft):

0.32 to 0.39 mm  
(0.0126 to 0.0154 in)

## BAULK RING

Same as for the F4W71B.

## OIL SEAL

Same as for the F4W71B.

## ASSEMBLY

To assemble, reverse the order of disassembly. Observe the following instructions.


### FRONT COVER ASSEMBLY

Same as for the F4W71B.

### REAR EXTENSION ASSEMBLY

- Wipe clean seal seat in rear extension housing; press fit oil seal in place.

Coat oil seal and bushing with gear oil for initial lubrication. See Figure MT-68.



TM355

Fig. MT-68 Rear extension oil seal

- Apply multi-purpose grease to O-ring and plunger grooves in striking rod.

Insert striking rod with striking rod guide through rear extension.

- Install striking lever on front end of striking rod. Install lock pin and torque screw to 0.9 to 1.2 kg-m (7 to 9 ft-lb).


- Install mainshaft bearing by lightly tapping around it with a soft hammer.

- Insert reverse idler shaft in adapter plate.

Make sure that the cut-out portion of reverse idler shaft is lined up with inner face of adapter plate.

- Install bearing retainer in adapter plate.

Align bearing retainer with reverse idler shaft at the cut-out portion of this shaft, torque screws to 1.9 to 2.5 kg-m (14 to 18 ft-lb) and stake each screw at two points with a punch. See Figure MT-69.



TM764

Fig. MT-69 Staking screw

- Install countershaft rear bearing in adapter plate by lightly tapping around it with a soft hammer.

## GEAR ASSEMBLY

Clean all parts in solvent and dry with compressed air.


### Synchronizer assembly

Same as for the F4W71B.

### Overdrive gear synchronizer assembly

- Assemble reverse & OD synchronizer assembly.
- Assemble overdrive gear assembly.

Position synchronizer ring, band brake, thrust block and anchor block on overdrive clutch gear; install circlip.



TM449

Fig. MT-70 Installing overdrive gear assembly

## Mainshaft assembly

Same as for the F4W71B.

## Countershaft assembly


Same as for the F4W71B.

## Main drive gear assembly

Procedures are the same as for the F4W71B transmission, except as follows:

1. Insert countershaft and mainshaft into adapter plate, and place adapter plate in a vise with setting plate.

Install snap ring, spacer, needle roller bearing, reverse idler gear, spacer and snap ring:



TM451

Fig. MT-71 Reverse idler gear

2. Assemble OD & reverse synchronizer assembly, OD gear bushing, needle bearing, OD gear assembly, steel ball, and thrust washer on mainshaft rear side. Before installing steel ball, apply grease to it.

3. Install new mainshaft nut, and tighten it temporarily.

4. Install counter reverse gear, counter 5th gear, bearing and new countershaft nut. Tighten nut temporarily.

5. Tighten mainshaft and countershaft nuts and stake nuts at groove in shafts with a punch. Tightening procedures for mainshaft nut are the same as those for the F4W71B.

## Shift forks and fork rods assembly

Same as for the F4W71B.

## TRANSMISSION ASSEMBLY



Same as for the F4W71B.

## INSTALLATION

Same as for the F4W71B.

## SERVICE DATA AND SPECIFICATIONS

### GENERAL SPECIFICATIONS

Transmission type	F4W71B	FS5W71B
Synchromesh type	Warner	1st to 4th Warner, 5th Servo
Shift type		
Gear ratio		
1st	3.592	3.321
2nd	2.246	2.077
3rd	1.415	1.308
4th	1.000	1.000
5th	—	0.864
Reverse	3.657	3.382
Final gear ratio	4.375	4.375
Speedometer gear ratio	20/6	20/6
Oil capacity (US pt, Imp pt)	1.7 (3⅜, 3)	2.0 (4⅛, 3⅜)

## TIGHTENING TORQUE

### Installation

Unit: kg-m (ft-lb)

Engine to transmission installation bolt .....	4.4 to 5.9 (32 to 43)
Transmission to engine rear plate bolt .....	0.9 to 1.2 (7 to 9)
Clutch operating cylinder installation bolt .....	2.5 to 3.0 (18 to 22)
Rear mounting insulator to transmission installation bolt .....	0.8 to 1.1 (6 to 8)
Crossmember mounting bolt .....	3.2 to 4.3 (23 to 31)
Propeller shaft to diff. installation bolt .....	2.4 to 3.3 (17 to 24)

### Gear assembly

Rear extension installation bolt .....	1.6 to 2.1 (12 to 15)
Front cover installation bolt .....	1.6 to 2.1 (12 to 15)
Bearing retainer to adapter plate screw .....	1.9 to 2.5 (14 to 18)
Mainshaft nut .....	14.0 to 17.0 (101 to 123)
Check ball plug .....	1.9 to 2.5 (14 to 18)
Striking lever lock pin .....	0.9 to 1.2 (7 to 9)
Reverse select return plug .....	0.9 to 1.2 (7 to 9)
Speedometer sleeve locking plate nut .....	0.4 to 0.5 (3 to 4)
Reverse lamp switch .....	2.0 to 3.0 (14 to 22)
Gear oil filler plug .....	2.5 to 3.5 (18 to 25)
Gear oil drain plug .....	2.5 to 3.5 (18 to 25)

## SPECIFICATIONS

### Gear backlash

Unit: mm (in)

Maindrive gear to counter drive gear .....	0.05 to 0.10 (0.0020 to 0.0039)
1st gear .....	0.05 to 0.20 (0.0020 to 0.0079)
2nd gear .....	0.05 to 0.20 (0.0020 to 0.0079)
3rd gear .....	0.05 to 0.20 (0.0020 to 0.0079)
OD gear .....	0.05 to 0.20 (0.0020 to 0.0079)

### Gear end play

1st gear .....	0.32 to 0.39 (0.0126 to 0.0154)
2nd gear .....	0.12 to 0.19 (0.0047 to 0.0075)
3rd gear .....	0.13 to 0.37 (0.0051 to 0.0146)
OD gear .....	0.32 to 0.39 (0.0126 to 0.0154)
Counter gear .....	0.01 to 0.21 (0.0004 to 0.0083)
Reverse idler gear .....	0.05 to 0.20 (0.0020 to 0.0079)

### Clearance between baulk ring and gear

All gears .....	1.25 to 1.60 (0.0492 to 0.0630)
-----------------	---------------------------------





### Counter bearing adjusting shim

0.6 (0.024)
0.5 (0.020)
0.4 (0.016)
0.3 (0.012)
0.2 (0.008)
0.1 (0.004)

# TROUBLE DIAGNOSES AND CORRECTIONS





Condition	Probable cause	Corrective action
<b>Difficult to intermesh gears</b> Causes for difficult gear shifting are classified to troubles concerning control system and transmission. When gear shift lever is heavy and it is difficult to shift gears, clutch disengagement may also be unsmooth. First, make sure that clutch operates correctly, and inspect transmission.	Worn gears, shaft, and/or bearing. Insufficient operating stroke due to worn or loose sliding part. Faulty or damaged synchronizer.	Replace. Repair or replace. Replace.
<b>Gear slips out of mesh.</b> In most cases, this trouble occurs, when interlock ball, check ball, and/or spring is worn or weakened, or when control system is faulty. In this case, the trouble cannot be corrected by replacing gears, and therefore, trouble shooting must be carried out carefully. It should also be noted that gear slips out of mesh due to vibration generated by weakened front and rear engine mounts.	Worn interlock ball. Worn check ball and/or weakened or broken spring. Worn fork rod ball groove. Worn or damaged bearing. Worn or damaged gear.	Replace. Replace. Replace. Replace. Replace.
<b>Noise</b> When noise occurs with engine idling and ceases when clutch is disengaged, or when noise occurs while shifting gears, it is an indication that the noise is from transmission. (Transmission may rattle during engine idling. Check air-fuel mixture and ignition timing. After above procedure, readjust engine idling.)	Insufficient or improper lubricant. Oil leaking due to faulty oil seal or sealant, clogged breather, etc. Worn bearing (High humming occurs at a high speed.). Damaged bearing (Cyclic knocking sound occurs also at a low speed.). Worn spline. Worn bushing.	Add oil or replace with designated oil. Clean or replace. Replace. Replace. Replace. Replace.

# SPECIAL SERVICE TOOLS


No.	Tool number & tool name	Description  Unit: mm (in)	For use on	Reference page or Figure No.
1.	ST23540000 Fork rod pin punch	For removal of fork rod retaining pin.  	All models	Fig. MT-15
2.	ST22360002 Drift C	For assembly of counter drive bearing.  	71BT/M FS5W- 63A	Fig. MT-44
3.	ST23800000 Transmission adapter	For assembly of main bearing.  	All models	Page MT-10
4.	ST23810001 Setting plate adapter	For setting adapter plate in a vise.  	71BT/M	Fig. MT-14 Fig. MT-15 Fig. MT-45



# Manual Transmission

No.	Tool number & tool name	Description Unit: mm (in)	For use on	Reference page or Figure No.
5.	ST22520000 Wrench [38 mm (1.50 in)]	For removal and assembly of mainshaft nut.   SE313	71BT/M 63A T/M	Fig. MT-46 Fig. MT-47
6.	ST23860000 Counter gear drift	For assembly of counter drive gear.   SE039	71BT/M	Fig. MT-42
7.	KV31100400 Transmission press stand	For assembly of mainshaft, countershaft, counter drive gear and counter drive bearing.   TM438	71BT/M	Fig. MT-37 Fig. MT-39 Fig. MT-44
8.	ST30031000 Bearing puller	For replacing bearing.   SE041	All models	Fig. MT-21 Fig. MT-23 Fig. MT-25

# Manual Transmission

No.	Tool number & tool name	Description  Unit: mm (in)	For use on	Reference page or Figure No.
9.	KV32101330 Bearing puller	For removal of mainshaft end bearing, counter overdrive gear and bearing.   SE308	63A T/M FSSW- 71B T/M	Fig. MT-64

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES

## SECTION AT

# AUTOMATIC TRANSMISSION

AT

DESCRIPTION .....	AT- 2
HYDRAULIC CONTROL SYSTEM .....	AT- 4
REMOVAL AND INSTALLATION .....	AT-33
MAJOR REPAIR OPERATION .....	AT-36
TRUBLE DIAGNOSES AND ADJUSTMENT .....	AT-48
SERVICE DATA AND SPECIFICATIONS .....	AT-59
SPECIAL SERVICE TOOLS .....	AT-62



NISSAN MOTOR CO., LTD.  
TOKYO, JAPAN

## DESCRIPTION

The model 3N71B automatic transmission is a fully automatic unit consisting primarily of 3-element hydraulic torque converter and two planetary gear sets. Two multiple-disc clutches, a multiple-disc brake, a band brake and a one way sprag clutch provide the friction elements required to obtain the desired function of the two planetary gear sets.

The two planetary gear sets give three forward ratios and one reverse. Changing of the gear ratios is fully automatic in relation to vehicle speed and engine torque input. Vehicle speed and engine manifold vacuum signals are constantly fed to the transmission to provide the proper gear ratio for maximum efficiency and performance at all throttle openings.

The model 3N71B has six selector positions: P, R, N, D, 2, 1.

**"P"** – Park position positively locks the output shaft to the transmission case by means of a locking pawl to prevent the vehicle from rolling in either direction.

This position should be selected whenever the driver leaves the vehicle.

The engine may be started in Park position.

**"R"** – Reverse range enables the vehicle to be operated in a reverse direction.

**"N"** – Neutral position enables the engine to be started and run without driving the vehicle.

**"D"** – Drive range is used for all normal driving conditions.

Drive range has three gear ratios, from the starting ratio to direct drive.


**"2"** – "2" range provides performance for driving on slippery surfaces. "2" range can also be used for engine braking.

"2" range can be selected at any vehicle speed, and prevents the transmission from shifting out of second gear.

**"1"** – "1" range can be selected at any vehicle speed and the transmission will shift to second gear and remain in second until vehicle speed is reduced to approximately 40 to 50 km/h (25 to 30 MPH).

"1" range position prevents the transmission from shifting out of low gear. This is particularly beneficial for maintaining maximum engine braking when continuous low gear operation is desirable.

The torque converter assembly is of welded construction and can not be disassembled for service.



AT344

Fig. AT-1 Identification number

### Identification of number

#### Arrangements:

See below.

#### Model code

JAPAN AUTOMATIC TRANSMISSION CO., LTD.	
MODEL	X2402
NO.	4912345

#### Unit number

#### Number designation

4 9 1 2 3 4 5

Serial production number for the month
Month of production (X: Oct., Y: Nov., Z: Dec.)
Last figure denoting the year (A.D.)

### FLUID RECOMMENDATION


Use automatic transmission fluid having "DEXRON" identifications only in the 3N71B automatic transmission.

### IDENTIFICATION NUMBER

#### Stamped position:

The plate is attached to the right hand side of transmission case as shown in Figure AT-1.

# Automatic Transmission



AT288

- 1 Transmission case
- 2 Oil pump
- 3 Front clutch
- 4 Band brake
- 5 Rear clutch
- 6 Front planetary gear
- 7 Rear planetary gear
- 8 One way clutch
- 9 Low & Reverse brake
- 10 Oil distributor

- 11 Governor
- 12 Output shaft
- 13 Rear extension
- 14 Oil pan
- 15 Control valve
- 16 Input shaft
- 17 Torque converter
- 18 Converter housing
- 19 Drive plate

Tightening torque (T) of bolts and nuts kg-m (ft-lb)

- Ⓐ T : 4 to 5 (29 to 36)
- Ⓑ T : 14 to 16 (101 to 116)
- Ⓒ T : 4.5 to 5.5 (33 to 40)
- Ⓓ T : 0.6 to 0.8 (4 to 6)
- Ⓔ T : 0.5 to 0.7 (4 to 5)
- Ⓕ T : 2.0 to 2.5 (14 to 18)
- Ⓖ T : 1.3 to 1.8 (9 to 13)
- Ⓗ T : 0.55 to 0.75 (4 to 5)
- Ⓘ T : 0.25 to 0.35 (2 to 3)

Fig. AT-2 Cross-sectional view of 3N71B automatic transmission

# HYDRAULIC CONTROL SYSTEM

## CONTENTS

### FUNCTIONS OF HYDRAULIC CONTROL

UNIT AND VALVES .....	AT- 4
OIL PUMP .....	AT- 4
MANUAL LINKAGE .....	AT- 4
VACUUM DIAPHRAGM .....	AT- 5
DOWNSHIFT SOLENOID .....	AT- 5
GOVERNOR VALVE .....	AT- 5
CONTROL VALVE ASSEMBLY .....	AT- 6
HYDRAULIC SYSTEM AND MECHANICAL OPERATION .....	AT-13


"P" RANGE (PARK) .....	AT-14
"R" RANGE (REVERSE) .....	AT-16
"N" RANGE (NEUTRAL) .....	AT-18
"D <sub>1</sub> " RANGE (LOW GEAR) .....	AT-20
"D <sub>2</sub> " RANGE (2ND GEAR) .....	AT-22
"D <sub>3</sub> " RANGE (TOP GEAR) .....	AT-24
"D" RANGE KICK-DOWN .....	AT-26
"2" RANGE (2ND GEAR) .....	AT-28
"1 <sub>1</sub> " RANGE (LOW GEAR) .....	AT-30
"1 <sub>2</sub> " RANGE (2ND GEAR) .....	AT-32

## FUNCTIONS OF HYDRAULIC CONTROL UNIT AND VALVES

The hydraulic control system con-

tains an oil pump for packing up oil from the oil pan through the oil strainer. A shift control is provided by two centrifugally operated hydraulic governors on the output shaft, vacuum control diaphragm and downshift

solenoid. These parts work in conjunction with valves in the valve body assembly located in the base of the transmission. The valves regulate oil pressure and direct it to appropriate transmission components.



## OIL PUMP


The oil pump is the source of control medium (i.e., oil) for the control system.

The oil pump is of an internal, involute gear type. The drive sleeve is a part of the torque converter pump impeller and serves to drive the pump inner gear with the drive sleeve directly coupled with the engine operation.

The oil flows through the following route:

Oil pan — Oil strainer (bottom of the control valve) — Control valve lower body suction port — Transmission case suction port — Pump housing suction port — Pump gear space — Pump

housing delivery port — Transmission case delivery port — Lower body delivery port — Control valve line pressure circuit.



- 1 Housing      4 Inner gear  
2 Cover        5 Crescent  
3 Outer gear

AT071

Fig. AT-3 Oil pump

## MANUAL LINKAGE

The hand lever motion (the hand lever is located in the driver's compartment), mechanically transmitted from the remote control linkage, is further transmitted to the inner manual lever in the transmission case from the range selector lever in the right center portion of the transmission case through the manual shaft. The inner manual lever is thereby turned.

A pin installed on the bottom of the inner manual lever slides the manual valve spool of the control valve thus positioning the spool opposite the appropriate select position.

The parking rod pin is held in the groove on the top of the inner manual

plate. The parking rod pin operates the rod at "P" range, and operates the mechanical lock system.

The above described manual shaft is further equipped with an inhibitor switch. A rotor inside the inhibitor switch rotates in response to each range. When the range is selected at "P" or "N", the rotor closes the starter magnet circuit so that the engine can be started. When the range is selected at "R", the rotor closes the back-up lamp circuit, and the back-up lamp lights.




Fig. AT-4 Manual linkage

## VACUUM DIAPHRAGM

The vacuum diaphragm is installed on the left center portion of the transmission case. The internal construction of the vacuum diaphragm is as follows:

A rubber diaphragm forms a partition in the center. The engine intake manifold negative pressure is led through a vacuum tube and spring force is applied to the front surface of the rubber diaphragm while atmospheric pressure is applied to the back surface. The difference between pressure applied to the front and back surfaces causes a vacuum reaction, which activates the throttle valve of the control valve inside the transmission case.

When accelerator pedal is fully depressed and the carburetor is fully opened but the engine speed is not sufficiently increased, the manifold negative pressure lowers (i.e., tends towards atmospheric pressure) and the

vacuum reaction increases since the flow velocity of mixture inside the intake manifold is slow. Contrarily, when the engine speed increases and the flow velocity of the mixture increases or when the carburetor is closed, the manifold negative pressure increases (i.e., tends towards vacuum) and the vacuum reaction is reduced.

Thus, a signal to generate hydraulic pressure perfectly suited to the engine loading at the control valve is transmitted from the vacuum diaphragm, and the most suitable timing for speed change and line pressure is obtained so that the most proper torque capacity is obtained against the transmitting torque.




Fig. AT-5 Vacuum diaphragm

## DOWNSHIFT SOLENOID

The downshift solenoid is of a magnetic type installed on the left rear portion of the transmission case. When a driver requires accelerating power and depresses the accelerator pedal down to the stopper, a kickdown switch located in the middle of the accelerator link is depressed by a push rod, the kickdown switch closes, current flows to the solenoid, the solenoid push rod is depressed, the downshift valve of the control valve inside the transmission case is depressed, and the speed is changed forcibly from "3rd" to "2nd" within a certain vehicle speed limit.

Note: Since the kickdown switch closes when the accelerator pedal is depressed from 7/8 to 15/16 of the whole stroke, the accelerator pedal should be correctly adjusted so as to afford a complete stroke. The arrangement of the switch varies according to model.




Fig. AT-6 Downshift solenoid

## GOVERNOR VALVE

The primary and secondary governor valves are installed separately on the back of the oil distributor on the transmission output shaft. They operate at the same speed as that of the output shaft. (that is, they operate at a speed in proportion to the vehicle speed.) The line pressure is applied to those valves as the input from the control valve, through the transmission case, rear flange and oil distributor. The governor pressure [in proportion to the output shaft speed (vehicle speed)] is led to the shift valve of the control valve through the opposite route of the output. In this manner speed change and line pressure are controlled.

### Operation of secondary governor valve

The secondary valve is a control valve which receives line pressure (1) and controls the governor pressure.

When the manual valve is selected at "D", "2" or "1" range, line pressure is applied to the ring shaped area of this valve from circuit (1), and this valve is depressed toward the center. Movement of this valve to a certain position closes the circuit from (1) to (15) while simultaneously making a space from (15) to the center drain port, and pressure in the circuit (15) is lowered.

When the vehicle is stopped and the centrifugal force of this valve is zero, the valve is balanced. At this point, a governor pressure which is balanced with the spring force occurs on (15).

When the vehicle is started and the centrifugal force increases, this valve moves slightly to the outside, and as

## Automatic Transmission

the space from (1) to (15) increases, space from (15) to the drain port simultaneously decreases. As a result, governor pressure of (15) increases, and the governor pressure is balanced with the sum of centrifugal force and spring force. The governor pressure thus changes in response to the vehicle speed change (centrifugal force).

### Operation of primary governor valve

The valve is an ON-OFF valve which closes the governor pressure (15) regulated by the secondary governor valve when the vehicle reaches the minimum speed, and when the vehicle speed exceeds a certain level, the governor opens and forwards the governor pressure (15) to the control valve.

When the vehicle is stopped, the governor pressure is zero. However, when the vehicle is running slowly, this valve is depressed to the center and the groove to (15) is closed since the governor pressure applied to the ring shaped area is higher than the centrifugal force of this valve. When the governor speed exceeds a certain revolution, the governor pressure in the circuit (15) also increases. However, as the centrifugal force increases and exceeds the governor pressure, this valve moves toward the outside, and the governor pressure is transmitted to the circuit (15).

Two different valves are employed in the governor so that it will independently control the speed at high and low speeds. That is, within the low speed range, the governor pressure is not generated because of the primary valve; whereas at the high speed range above the breaking point, governor pressure is regulated by the secondary valve.

\* The breaking point is the point at which the function of one of the governor is transferred to the other as the speed changes from the low-speed to the high-speed range.




Fig. AT-7 Cross-sectional view of governor




Fig. AT-8 Output shaft with oil distributor and governor





Fig. AT-9 Exploded view of governor

## CONTROL VALVE ASSEMBLY

### Flow chart of control valve system



The control valve assembly receives oil from the pump and individual signals from the vacuum diaphragm, and transmits the individual line pressures to the transmission friction element, torque converter circuit, and lubricating system circuit as outputs. More specifically, the oil from the oil pump is regulated by the regulator valve as line pressure build up. The line pressure is fed out from the control valve assembly through various direc-

tion changeover valves (including ON-OFF valve) and regulator valves, are newly reformed to a throttle system oil pressure and operate other valves. Finally, the line pressure is transmitted to the required clutch or brake servo piston unit in response to the individual running conditions after receiving signals from the vacuum diaphragm, downshift solenoid, governor valve, and/or manual linkage.



The control valve assembly consists of the following valves (See Figure AT-20):

1. Pressure regulator valve (PRV)
2. Manual valve (MNV)
3. 1st-2nd shift valve (FSV)
4. 2nd-3rd shift valve (SSV)
5. Pressure modifier valve (PMV)
6. Vacuum throttle valve (VTM)
7. Throttle back-up valve (TBV)
8. Solenoid downshift valve (SDV)
9. Second lock valve (SLV)
10. 2nd-3rd timing valve (TMV)

### Pressure regulator valve (PRV)

The pressure regulator valve receives valve spring force, force from the plug created by the throttle pressure (16) and line pressure (7), and force of the throttle pressure (18). With the interaction of those forces, the PRV regulates the line pressure (7) to that most suitable for individual driving conditions.

The oil from the oil pump is applied to the ring-shaped area through orifice (20). As a result, the PRV is depressed downward, and moves from port (7) up to such extent that the space to the next drain port (marked with "X" in Figure AT-10) opens slightly. Thus, the line pressure (7) is balanced with the spring force, thereby balancing the PRV. In this operation, the space from port (7) to the subsequent converter oil pressure (14) circuit has also been opened. As a result, the converter is filled with pressurized oil in circuit (14), and this oil is further used for lubrication of the rear unit. Moreover, part of the oil is branched and used for lubrication of the front unit for the front and rear clutches.

When the accelerator pedal is depressed, the throttle pressure (16) increases as described in the preceding paragraph, oil pressure is applied to the plug through orifice (21), and this pressure is added to the spring force. As a result, the PRV is contrarily forced upward, space to the drain port is reduced, and the line pressure (7) increases.




Fig. AT-10 Pressure regulator valve

When the range is selected at "R" (Reverse), the line pressure (6) is applied to the plug in a manner identical to the throttle pressure (16) and is added to the spring force. Consequently, the line pressure (7) further increases.

When vehicle speed increases and the governor pressure rises, the throttle pressure (18) is applied to the port on the top of the PRV, and pressure is applied contrarily against the spring force. As a result, the line pressure (7) decreases. Moreover, at individual conditions, the line pressure (7) is equal to

the line pressure (6) and the throttle pressure (16) is equal to (18).

### Manual valve (MNV)

The manual lever turning motion is converted to reciprocating motion of the manual valve through a pin, and the MNV is positioned so that the line pressure (7) is distributed to the individual line pressure circuits at each "P", "R", "N", "D", "2" or "1" range as shown below.

"P" range:

- (7) - { (4) - SDV and TBV  
(5) - FSV (12) - TBV and Low & reverse brake

"R" range:

- (7) - { (4) - same as above  
(5) - same as above  
(6) - PRV and SSV - (F.C.) and band release

"N" range: (7) - None

"D" range:

- (7) - { (1) - Governor valve, FSV, and rear clutch  
(2) - SLV  
(3) - SLV and SSV

"2" range:

- (7) - { (1) - Same as above  
(2) - SLV - (9) Band applied  
(4) - SDV and TBV

"1" range:

- (7) - { (1) - Same as above  
(4) - Same as above  
(5) - FSV

Moreover, (1), (2), (3), (4), (5), and (6) are always drained at a position where the line pressure is not distributed from (7).




Fig. AT-11 Manual valve

## 1st-2nd shift valve (FSV)

The FSV is a transfer valve which shifts gears from low to second. When the vehicle is stopped, the FSV is depressed to the right side by force of a spring located on the left side, putting the FSV in the "Low" position.

When vehicle speed increases, the governor pressure (15) is applied to the right side of the FSV, and the FSV is forced toward the left. Contrarily, the line pressure (1) together with the spring force, force the FSV toward the right opposing the governor pressure (15).

When the vehicle speed exceeds a certain level, the governor pressure (15) exceeds the sum of the throttle pressure and the spring force, and the FSV is forced toward the left.

When the FSV is depressed to a certain position, the line pressure (1) is closed, and only the spring depresses the FSV toward the right, and it is depressed to the end for a moment. As a result, the line pressure (1) is forwarded to (8), the band servo is engaged through the SLV, and the speed is shifted to "2nd". With the accelerator pedal depressed, the FSV remains in the "Low" position unless the governor pressure (15) increases to a high level corresponding to the line pressure (1) since the line pressure (1) increase when the accelerator pedal is depressed.

Contrarily, when vehicle speed decreases, the governor pressure (15) decreases. However, the gear is not shifted to "Low" unless the governor pressure (15) becomes zero, since the force depressing the FSV toward the right is being delivered only by the spring.

"Low" in range "1" is led to the low and reverse clutch from line pressure (5) through line pressure (12), and is simultaneously, led to the left end spring unit. Consequently, although the governor pressure increases, the valve is still forced toward the right, and the FSV is fixed in the "Low" position. When kicked down to the "2nd" speed, the SDV operates, and the line pressure (13) forces the FSV toward the right. Although the

governor pressure (15) is considerably high, the valve is forced completely toward the right, and the FSV is returned to the "Low" position. (This operation is called "Kickdown shift".)




Fig. AT-12 "1st-2nd" shift valve

## 2nd-3rd shift valve (SSV)

The SSV is a transfer valve which shifts gears from "2nd" to "3rd". When the vehicle is stopped, the SSV is forced toward the right by the spring, and is in the "2nd" position. It is so designed, however, that the FSV can decide to shift either to "Low" or "2nd".

When the vehicle is running, the governor pressure (15) is applied to the right end surface, and the SSV is forced toward the left. Contrarily, the spring force, line pressure (3), and throttle pressure (19) force the SSV toward the right.

When vehicle speed exceeds a certain level, the governor pressure surpasses the sum of the spring force, line pressure, and throttle pressure, and the valve is forced toward the left. The line pressure (3) is then closed. Consequently, the forces being rapidly unbalanced, the force depressing the SSV toward the right decreases, and thus the SSV is depressed to the left end for a moment. With the SSV depressed toward the left end, the line pressure (3) is connected with the line pressure (10), the band servo is released, the front clutch is engaged, and

speed is shifted to "3rd".

When the accelerator pedal is depressed, both the line pressure (3) and the throttle pressure (19) are high, and the SSV is thus retained in "2nd" unless the governor pressure (15) exceeds the line pressure (3) and the throttle pressure (19).

In the "3rd" position, force depressing the SSV toward the right is retained only by the throttle pressure (16), and the throttle pressure (16) is slightly lower than that toward the right which is applied while shifting from "2nd" to "3rd".

Consequently, the SSV is returned to the "2nd" position at a slightly lower speed. (Shifting from "3rd" to "2nd" occurs at a speed slightly lower than that for "2nd" to "3rd" shifting.)

When kicked down at "3rd", line pressure (13) is led from the SDV, and the SSV is forced toward the right. Although the governor pressure is considerably high, the valve is forced completely toward the right, and the SSV is thus returned to "2nd" position. (This operation is called "Kickdown shift".)

When the shift lever is shifted to "2" or "1" range at the "3rd" speed, the line pressure (3) is drained at the MNV. Consequently, the front clutch and band servo releasing oils are drained. As a result, the transmission is shifted to "2nd" or "low" speed although the SSV is in the "3rd" position.

When the speed is shifted to the "3rd", a one-way orifice (24) on the top of the SSV relieves oil transmitting velocity from the line pressure (3) to the line pressure (10), and reduces the shock generated from the shifting. Contrarily, when the lever is shifted to "2" or "1" range and the speed is shifted from "3rd" to the "2nd", the orifice checking valve spring (24) is depressed, the throttle becomes ineffective, the line pressure (10) is drained quickly, and delay in shifting speeds is thus eliminated.

The throttle of line pressure (6) transmits the oil transmitting velocity from line pressure (6) to line pressure (10) when the lever is shifted to the "R" range, and transmits drain velocity from line pressure (10) to line

pressure (6) when shifting from "3rd" to "2nd" at "D" range. Thus, the throttle of line pressure (6) reduces the shock generated from shifting.

A plug in the SSV left end readjust the throttle pressure (16) which varies depending on the engine throttle condition, to a throttle pressure (19) suited to the speed change control. Moreover, the plug is a valve which applies line pressure (13), in lieu of the throttle pressure, to the SSV and the FSV when kickdown is performed.

When the throttle pressure (16) is applied to the left side of this plug, and the plug is depressed toward the right, a slight space is formed from the throttle pressure (16) to (19). A throttle pressure (19) which is lower by the pressure loss equivalent to this space is

generated, the pressure loss is added to the spring force, and the plug is thus forced back from the right to the left. When this pressure (19) increases excessively, the plug is further depressed toward the left, space from the throttle pressure (19) to the drain circuit (13) increases, and the throttle pressure (19) decreases. Thus, the plug is balanced, and the throttle pressure (19) is reduced to a certain value against the throttle pressure (16).

When performing 'kickdown', the SDV moves, a high line pressure is led to the circuit (19) from the line pressure circuit (13) (which had been drained); the plug is forced toward the left, and circuit (19) becomes equal to the line pressure (13).




Fig. AT-13 "2nd-3rd" shift valve

## Pressure modifier valve (PMV)

Compared to the operating pressure required in starting the vehicle, the power transmitting capacity of the clutch (that is, required operating pressure) may be lower when the vehicle is once started. When the line pressure is retained at a high level up to a high vehicle speed, shock generated from the shifting increases, and the oil pump loss also increases. In order to prevent this, the throttle pressure must be changed over with the operation of the governor pressure (15) to reduce the line pressure. The PMV is used for this purpose.

(16) to circuit (18). This throttle pressure (18) is applied to the top of the PRV, and the force of the line pressure source (7) is reduced. Contrarily, when the vehicle speed decreases and the governor pressure (15) decreases, the force toward the right exceeds the governor pressure, the valve is forced back toward the right, and the throttle pressure (18) is drained to the spring unit.

This valve is switched when the throttle pressure and the governor pressure are high or when they are both low.




Fig. AT-14 Pressure modifier valve

## Vacuum throttle valve (VTV)

The vacuum throttle valve is a regulator valve which uses the line pressure (7) for the pressure source and regulates the throttle pressure (16) which is proportioned to the force of the vacuum diaphragm. [The vacuum diaphragm varies depending on the engine throttle condition (negative pressure in the intake line)].

When the line pressure (7) is applied to the bottom through the valve hole and the valve is forced upward, space from the line pressure (7) to the throttle pressure (16) is closed, and the space from the throttle pressure (16) to the drain circuit (17) is about to open. In this operation, the throttle pressure (16) becomes lower than the line pressure (7) by the pressure equivalent of the loss of space, and the force depressing the rod of the vacuum diaphragm is balanced with the throttle pressure (16) applied upward to the bottom.

When the engine torque is high, the negative pressure in the intake line rises (tending toward atmospheric pressure); and the force of the rod to depress the valve increases. As a result, the valve is depressed downward, the

## Automatic Transmission

space from the throttle pressure (16) to the drain (17) decreases, and the space from the line pressure (7) to the throttle pressure (16) increases.

Consequently, the throttle pressure (16) increases, and the valve is balanced. Contrarily, when the engine torque lowers and the negative pressure in the intake line lowers (tending toward vacuum), the force of the rod depressing the valve decreases, and the throttle pressure (16) also decreases. When pressure regulated by the throttle back-up valve (described in the subsequent paragraph) is led to circuit (17), a high pressure is applied through the space from the circuit (17) to the throttle pressure (16). Consequently, the VTV is unbalanced, the throttle pressure (16) becomes equal to the back-up pressure (17), and the valve is locked upward.




Fig. AT-15 Vacuum throttle valve

### Throttle back-up valve (TBV)

Usually, this valve is depressed downward by the spring force, and circuit (17) is drained upward.

As soon as the lever is shifted either to "2" or "1" range, line pressure is led from circuit (4), the line pressure is applied to the area difference of the valve, the valve is forced upward, the space from circuit (4) to circuit (17) is closed, and with the space from circuit

(17) to the upper drain about to open, the back-up pressure (17) which is lower than the line pressure (4) by the pressure loss due to the space from circuit (4) to circuit (17) is balanced with the spring force.

Further, when gear is shifted from "2nd" to "Low" at the range "1", line pressure is led from circuit (12), and the line pressure is applied upward to the bottom of the valve through the valve hole. Consequently, the valve is forced upward, and locked. As a result, the space from the line pressure (4) to the back-up pressure (17) is closed completely, and the back-up pressure (17) is drained upward.




Fig. AT-16 Throttle back-up valve

### Solenoid downshift valve (SDV)

This valve is a transfer valve which leads the line pressure (7) to (13) and transmits the same to the FSV and SSV when a kickdown signal is received from the downshift solenoid. Usually, the solenoid push rod and valve are locked upward by the spring in the lower end, and the circuit from line pressure (4) to line pressure (13) is opened.

When kickdown is performed, the push rod operates, the valve is depressed downward, and the circuit from line pressure (7) to line pressure (13) opens. Line pressure (13) opposes the governor pressure (15) at the SSV and FSV, thus accomplishing the downshift operation.




Fig. AT-17 Solenoid downshift valve

### Second lock valve (SLV)

This valve is a transfer valve which assists the shift valve in determining the fixed "2nd" speed at the "2" range.

In the "D" range, the sum of the spring force and line pressure (3) applied upward exceeds the line pressure (2) which is applied to the valve area difference as a downward force. As a result, the valve is locked upward, and the circuit from line pressure (8) to line pressure (9) is opened.

Consequently, the FSV becomes the "2nd" speed condition, and line pressure is led to the band servo engaging circuit (9) only when line pressure (1) is released to line pressure (8).

In the "2" range, the upward force is retained only on the spring, and the downward line pressure (2) exceeds the upward force.

As a result, the valve is locked downward, line pressure (2) is released to (9) regardless of the operating condition of the FSV, and the band servo is engaged.




Fig. AT-18 Second lock valve

## 2nd-3rd timing valve (TMV)

This valve is a transfer valve which switches the by-pass circuit of the orifice (22) in the front clutch pressure circuit (11) in response to vehicle speed and throttle condition. A force created when the governor pressure (15) is applied to the bottom of the TMV constitutes the upward force, and a force created when the spring force and the throttle pressure are applied to the top of the TMV constitutes the downward force.

When the throttle pressure (16) is lower than the governor pressure (15),

the upward force exceeds the downward force, the valve is locked upward, and passage from circuit (10) ("2nd" from the "Top") to circuit (11) is closed. Consequently, the line pressure (10) is led to the front clutch circuit (11) through the orifice (22), and the oil pressure is thus transmitted slowly. However, under normal shifting, the throttle pressure (16) has a pressure exceeding a certain level, and the downward force exceeds the upward force. As a result, the valve is locked downward, the passage from circuit (10) to circuit (11) is opened, and the orifice (22) is bypassed.





Fig. AT-19 "2nd-3rd" timing valve



AT094

- |                                   |                                   |
|-----------------------------------|-----------------------------------|
| 1 Pressure regulating valve (PRV) | 6 Vacuum throttle valve (VTV)     |
| 2 Manual valve (MNV)              | 7 Throttle back-up valve (TBV)    |
| 3 1st-2nd shift valve (FSV)       | 8 Solenoid down shift valve (SDV) |
| 4 2nd-3rd shift valve (SSV)       | 9 Second lock valve (SLV)         |
| 5 Pressure modifier valve (PMV)   | 10 2-3 timing valve (TMV)         |

Fig. AT-20 Control valve

## HYDRAULIC SYSTEM AND MECHANICAL OPERATION

The operating system of oil pressure in each range is described below:

The oil pressure in each circuit shown in the illustration is classified as follows according to the function:  
(The numerals show the circuit numbers.)

Pressure source of the line: 7


Operating line pressure  
for friction elements:

1, 2, 3, 4, 5, 6, 8, 9, 10, 11, 12.

Auxiliary line pressure: 13


Throttle system pressure:  
16, 17, 18, 19.

Others: 14, 15




AT106

*Fig. AT-22 Identification of oil channels in case front face*



AT105

*Fig. AT-21 Identification of oil channels in oil pump*



AT107


*Fig. AT-23 Identification of oil channels in case face*

## Automatic Transmission

### "P" RANGE (PARK)

The operation of clutches and band are functionally the same as in "Neutral".

In parking, however, when the parking pawl meshes in a gear which is splined to the output shaft, the output shaft is mechanically locked from rotating.



AT086

Fig. AT-24 Parking mechanism

The oil discharged from the oil pump is fed to each part in a similar manner to that of the "N" range. The oil having the line pressure (7) which has been introduced into the manual valve ② reaches the "1st-2nd" shift valve ③ through the line pressure circuit (5). As the "1st-2nd" shift valve is forced to the right-hand side by the spring, the line pressure (5) and (12) actuates the low and reverse brake through the groove. Also, the parking pawl engages with the outer teeth of the oil distributor by means of the manual lever, mechanically locking the output shaft.

Range		Gear ratio	Clutch		Low & reverse brake	Band servo		One way clutch	Parking pawl
			Front	Rear		Operation	Release		
Park					on				on
Reverse		2.182	on		on		on		
Neutral									
Drive	D1 Low	2.458		on				on	
	D2 Second	1.458		on		on			
	D3 Top	1.000	on	on		(on)	on		
2 Second		1.458		on		on			
1	1 <sub>2</sub> Second	1.458		on		on			
	1 <sub>1</sub> Low	2.458		on	on				



# Automatic Transmission

## "P" range (Park)





Fig. AT-25 Oil pressure circuit diagram — "P" range (Park)


**"R" RANGE (REVERSE)**

In "R" range, the front clutch and the low and reverse brake are applied. The power flow is through the input shaft, front clutch, and connecting shell to the sun gear. Clockwise rotation of the sun gear causes counterclockwise rotation of the rear planetary gears. With the connecting drum held stationary by the low and reverse brake, the rear planetary gears rotate the rear internal gear and drive the flange counterclockwise. The rear drive flange splined to the output shaft rotates the output shaft counterclockwise at a reduced speed with an increase in torque for reverse gear.



AT084

Fig. AT-26 Power transmission during "R" range



AT085

Fig. AT-27 Operation of each mechanism during "R" range

When the manual valve ② is positioned at "R" range, the oil having the line pressure (7) is directed to line pressure circuits (5) and (6). The pressure in the circuit (5) actuates the low and reverse brake after being introduced into line pressure circuit (12) through the "1st-2nd" shift valve ③. The pressure in the circuit operates the release side of the band servo and the front clutch after being led to line pressure circuit (10) through the "2nd-3rd" shift valve ④. The throttle pressure (16) and the line pressure (6) which vary with the degree of accelerator pedal depression both act on the pressure regulator valve ① and press against its valve ①, increasing line pressure (7). In "R" range, the governor pressure is absent, making all such valves as the "1st-2nd" shift valve ③, "2nd-3rd" shift valve ④, and pressure modifier valve ⑥ inoperative.

Range		Gear ratio	Clutch		Low & reverse brake	Band servo		One way clutch	Parking pawl
			Front	Rear		Operation	Release		
Park					on				on
Reverse		2.182	on		on		on		
Neutral									
Drive	D1 Low	2.458		on				on	
	D2 Second	1.458		on		on			
	D3 Top	1.000	on	on		(on)	on		
2		Second		on		on			
1	1 <sub>2</sub> Second	1.458		on		on			
	1 <sub>1</sub> Low	2.458		on	on				

# Automatic Transmission

## "R" range (Reverse)




Fig. AT-28 Oil pressure circuit diagram — "R" range (Reverse)

## Automatic Transmission

### "N" RANGE (NEUTRAL)

In "N" range none of the clutches and band are applied, thus no power is transmitted to the output shaft.

The pressure of oil discharged from the oil pump is regulated by the pressure regulator valve ① to maintain the line pressure (7), and the oil is led to the manual valve ②, vacuum throttle valve ⑥, and solenoid down shift valve ⑧. The oil is further introduced into the torque converter at its operating pressure (14), and a portion of this oil is distributed to each part as the front lubricant. The oil which has been discharged from the torque converter is also distributed to each part as the rear lubricant.

As the oil pump rotates at the same speed as the engine, the oil pump discharge increases with engine speed. But the surplus oil is returned to the oil pan by the pressure regulator valve ①.

Range		Gear ratio	Clutch		Low & reverse brake	Band servo		One way clutch	Parking pawl
			Front	Rear		Operation	Release		
Park					on				on
Reverse		2.182	on		on		on		
Neutral									
Drive	D1 Low	2.458		on				on	
	D2 Second	1.458		on		on			
	D3 Top	1.000	on	on		(on)	on		
2 Second		1.458		on		on			
1	12 Second	1.458		on		on			
	11 Low	2.458		on	on				

# Automatic Transmission

## "P" range (Park)





Fig. AT-25 Oil pressure circuit diagram — "P" range (Park)




**"R" RANGE (REVERSE)**

In "R" range, the front clutch and the low and reverse brake are applied. The power flow is through the input shaft, front clutch, and connecting shell to the sun gear. Clockwise rotation of the sun gear causes counterclockwise rotation of the rear planetary gears. With the connecting drum held stationary by the low and reverse brake, the rear planetary gears rotate the rear internal gear and drive the flange counterclockwise. The rear drive flange splined to the output shaft rotates the output shaft counterclockwise at a reduced speed with an increase in torque for reverse gear.



AT084

Fig. AT-26 Power transmission during "R" range



AT085

Fig. AT-27 Operation of each mechanism during "R" range

When the manual valve ② is positioned at "R" range, the oil having the line pressure (7) is directed to line pressure circuits (5) and (6). The pressure in the circuit (5) actuates the low and reverse brake after being introduced into line pressure circuit (12) through the "1st-2nd" shift valve ③. The pressure in the circuit operates the release side of the band servo and the front clutch after being led to line pressure circuit (10) through the "2nd-3rd" shift valve ④. The throttle pressure (16) and the line pressure (6) which vary with the degree of accelerator pedal depression both act on the pressure regulator valve ① and press against its valve ①, increasing line pressure (7). In "R" range, the governor pressure is absent, making all such valves as the "1st-2nd" shift valve ③, "2nd-3rd" shift valve ④, and pressure modifier valve ⑥ inoperative.

Range		Gear ratio	Clutch		Low & reverse brake	Band servo		One way clutch	Parking pawl
			Front	Rear		Operation	Release		
Park					on				on
Reverse		2.182	on		on		on		
Neutral									
Drive	D1 Low	2.458		on				on	
	D2 Second	1.458		on		on			
	D3 Top	1.000	on	on		(on)	on		
2		Second		on		on			
1	1 <sub>2</sub> Second	1.458		on		on			
	1 <sub>1</sub> Low	2.458		on	on				



# Automatic Transmission

## "R" range (Reverse)




Fig. AT-28 Oil pressure circuit diagram — "R" range (Reverse)

## Automatic Transmission

### "N" RANGE (NEUTRAL)

In "N" range none of the clutches and band are applied, thus no power is transmitted to the output shaft.

The pressure of oil discharged from the oil pump is regulated by the pressure regulator valve ① to maintain the line pressure (7), and the oil is led to the manual valve ②, vacuum throttle valve ⑥, and solenoid down shift valve ⑧. The oil is further introduced into the torque converter at its operating pressure (14), and a portion of this oil is distributed to each part as the front lubricant. The oil which has been discharged from the torque converter is also distributed to each part as the rear lubricant.

As the oil pump rotates at the same speed as the engine, the oil pump discharge increases with engine speed. But the surplus oil is returned to the oil pan by the pressure regulator valve ①.

Range	Gear ratio	Clutch		Low & reverse brake	Band servo		One way clutch	Parking pawl
		Front	Rear		Operation	Release		
Park				on				on
Reverse	2.182	on		on		on		
Neutral								
Drive	D1 Low	2.458		on			on	
	D2 Second	1.458		on	on			
	D3 Top	1.000	on	on	(on)	on		
2	Second	1.458		on	on			
1	1 <sub>2</sub> Second	1.458		on	on			
	1 <sub>1</sub> Low	2.458		on	on			



# Automatic Transmission

## "N" range (Neutral)




Fig. AT-29 Oil pressure circuit diagram — "N" range (Neutral)



**"D<sub>1</sub>" RANGE (LOW GEAR)**


The low gear in "D" range is somewhat different from that in "1<sub>1</sub>" range.

The rear clutch is applied as in "1<sub>1</sub>" range, but the one-way clutch holds the connecting drum. The power flow is the same as in "1<sub>1</sub>" range. That is, the power flow takes place through the input shaft and into the rear clutch. The input shaft is splined to the rear clutch drum and drives it. Rotation of the rear clutch drives the rear clutch hub and front internal gear.


The front internal gear rotates the front planetary gears clockwise to cause the sun gear to rotate counterclockwise. Counterclockwise rotation of the sun gear turns the rear planetary gears clockwise. With the rear planetary carrier held stationary by the one-way clutch, the clockwise rotation of the rear planetary gears rotates the rear internal gear and drives the flange clockwise. The internal drive flange is splined to the output shaft and rotates the output shaft clockwise.

When the manual valve is positioned at "D", the line pressure (7) introduced into the manual valve is led to the line pressure circuits (1), (2) and (3). The pressure in the circuit (1) actuates the rear clutch and the governor, and at the same time, operates the "1st-2nd" shift valve (3) to change the speed. The circuit (2) leads to the second lock valve (9). The circuit (3) actuates the "2nd-3rd" shift valve (4) for the "2nd-3rd" speed change, and at the same time, locks the second lock valve (9).

The throttle pressure (16) which changes with the degree of accelerator pedal depression, presses the pressure regulator valve (1) and increases the line pressure (7). When the speed of the vehicle has increased, the governor pressure (15) introduced from the line pressure circuit (1) actuates the "1st-2nd" shift valve (3), "2nd-3rd" shift valve (4), and pressure modifier valve (5). When the governor pressure is high, the pressure modifier valve (5) acts in such a direction as to compress the spring, and the throttle pressure is led to the throttle pressure (18). This



AT080

Fig. AT-30 Power transmission during "D<sub>1</sub>" range

AT081

Fig. AT-31 Operation of each mechanism during "D<sub>1</sub>" range

Range	Gear ratio	Clutch		Low & reverse brake	Band servo		One way clutch	Parking pawl
		Front	Rear		Operation	Release		
Park				on				on
Reverse	2.182	on		on		on		
Neutral								
Drive	D1 Low		on				on	
	D2 Second		on		on			
	D3 Top	on	on		(on)	on		
2	Second		on		on			
1	12 Second		on		on			
	11 Low		on	on				

pressure acts against the force of the spring of the pressure regulator valve (1) and also against the throttle pressure (16), thus lowering the line pressure (7).

The governor pressure also increases with the speed of the vehicle, exerting a pressure on one side of the "1st-2nd" shift valve, and counter acts the throttle pressure (19), line pressure

(1), and the spring which are exerting against the governor pressure. Therefore, when the governor pressure exceeds this pressure, the speed is shifted from the "1st" gear to the "2nd" gear. The further the accelerator pedal is depressed, the higher becomes the throttle pressure (19), increasing the governor pressure and shifting the speed change point to the higher side.



# Automatic Transmission

## "D<sub>1</sub>" range (Low gear)





Fig. AT-32 Oil pressure circuit diagram — "D<sub>1</sub>" range (Low gear)




**"D<sub>2</sub>" RANGE (2ND GEAR)**

In this case, the rear clutch is applied and the band brake holds the front clutch drum, the connecting shell and the sun gear from rotating.

The power flow takes place through the input shaft into the rear clutch and the front internal gear. With the sun gear held stationary, the front planetary gears rotate around the sun gear, carrying the front planet carrier with them. The front planet carrier, being splined to the output shaft, causes clockwise rotation of the output shaft at a reduced speed compared with the speed of the input shaft, with an increase in torque. As the low and reverse brake is not applied, the clockwise rotation of the output shaft causes clockwise rotation of rear internal gear and the rear planet carrier also rotates around the sun gear in a clockwise direction. The one-way clutch will act to allow the clockwise rotation of connecting drum.



AT078

Fig. AT-33 Power transmission during "D<sub>2</sub>" range


AT079

Fig. AT-34 Operation of each mechanism during "D<sub>2</sub>" range

When the car speed increases while running at "D<sub>1</sub>" range (1st gear), the "1st-2nd" shift valve ③ moves allowing the line pressure (1) to be introduced into the line pressure (8) through itself. The line pressure (8) is further led to the line pressure (9) through the second lock valve ⑨, and by locking the band servo, obtains the "2nd" gear condition.

Range		Gear ratio	Clutch		Low & reverse brake	Band servo		One way clutch	Parking pawl
			Front	Rear		Operation	Release		
Park					on				on
Reverse		2.182	on		on		on		
Neutral									
Drive	D1 Low	2.458		on				on	
	D2 Second	1.458		on		on			
	D3 Top	1.000	on	on		(on)	on		
2		Second		on		on			
1	1 <sub>2</sub> Second	1.458		on		on			
	1 <sub>1</sub> Low	2.458		on	on				

**"D<sub>2</sub>" range (2nd gear)**







**"D<sub>3</sub>" RANGE (TOP GEAR)**

In 3rd gear position, the front and rear clutches are engaged. The power flow takes place through the input shaft into rear clutch drum. The rear clutch drum rotates the steel drive plates of the rear clutch and the lined drive plates of the rear clutch and the lined drive plates of the front clutch. The rear clutch directs the power flow through the rear clutch hub and front internal gear to the front planet carrier.

The front clutch directs the power flow through the connecting shell to the sun gear. With the sun gear and the rear clutch hub driven at the same speed, the front planet assembly is forced to rotate the output shaft at the same speed in the direction to provide the top gear.



AT082

Fig. AT-36 Power transmission during "D<sub>3</sub>" range

AT083

Fig. AT-37 Operation of each mechanism "D<sub>3</sub>" range

When the car speed further increases while running at "D<sub>2</sub>" range (2nd gear) and the governor pressure (15) exceeds the combined force of the spring of the "2nd-3rd" shift valve (4) and the throttle pressure (19), the "2nd-3rd" shift valve (4) moves, and the line pressure (8) acts to release the front clutch and band servo through the line pressure (10).

Range		Gear ratio	Clutch		Low & reverse brake	Band servo		One way clutch	Parking pawl
			Front	Rear		Operation	Release		
Park					on				on
Reverse		2.182	on		on		on		
Neutral									
Drive	D1 Low	2.458		on				on	
	D2 Second	1.458		on		on			
	D3 Top	1.000	on	on		(on)	on		
2		Second		on		on			
1	1 <sub>2</sub> Second	1.458		on		on			
	1 <sub>1</sub> Low	2.458		on	on				

# Automatic Transmission

## "D<sub>3</sub>" range (Top gear)




Fig. AT-38 Oil pressure circuit diagram — "D<sub>3</sub>" range (Top gear)



## Automatic Transmission

### "D" RANGE KICKDOWN

While operating at speeds below approximately 80 to 90 km/h (50 to 55 MPH), a kick "3rd-2nd" downshift can be accomplished by fully depressing the accelerator.

A kick "3rd-1st" or "2nd-1st" downshift can also be accomplished below approximately 40 to 50 km/h (25 to 30 MPH).

When kickdown is performed, the push rod operates by the solenoid, the valve is depressed downward, and the circuit from the line pressure (7) to the line pressure (13) opens. The line pressure (13), (3) plus the force of the "2nd-3rd" shift valve spring oppose the governor pressure (15) at the "2nd-3rd" shift valve ④, and thus, performs "3rd-2nd" downshift operation.

Moreover, the line pressure (13) plus the force of the "1st-2nd" shift valve spring oppose the governor pressure (15) at the "1st-2nd" shift valve ③, and thus, perform "3rd-2nd" or "2nd-1st" downshift operation.

Range		Gear ratio	Clutch		Low & reverse brake	Band servo		One way clutch	Parking pawl
			Front	Rear		Operation	Release		
Park					on				on
Reverse		2.182	on		on		on		
Neutral									
Drive	D1 Low	2.458		on				on	
	D2 Second	1.458		on		on			
	D3 Top	1.000	on	on		(on)	on		
2		Second	1.458		on	on			
1	1 <sub>2</sub> Second	1.458		on		on			
	1 <sub>1</sub> Low	2.458		on	on				




**"D" range kickdown (Shift valves in 2nd gear position)**


Fig. AT-39 Oil pressure circuit diagram — "D" range kickdown (shift valves in 2nd gear position)



**"2" RANGE (2ND GEAR)**


In "2" range the gear ratio is locked in the 2nd forward speed. In this case, the rear clutch is engaged and the band brake holds the front clutch drum, the connecting shell and sun gear from rotating.

The power flow takes place through the input shaft into the rear clutch and the front internal gear. With the sun gear held stationary, the front planetary gears rotate around the sun gear, carrying the front planet carrier with them. The front planet carrier, being splined to the output shaft, causes clockwise rotation of the output shaft at a reduced speed compared to the speed of the input shaft, with an increase in torque. As the low and reverse brake is not engaged, the clockwise rotation of the output shaft causes clockwise rotation of rear internal gear and the rear planet carrier also rotates around the sun gear in a clockwise direction. The one-way clutch will act to allow clockwise rotation of connecting drum.



AT078

Fig. AT-40 Power transmission during "2" range



AT079

Fig. AT-41 Operation of each mechanism during "2" range

When the manual valve (2) is positioned at "2", the line pressure (7) is introduced into the line pressure circuits (1), (2) and (4). The line pressure (1) is led to the governor, rear clutch and "1st-2nd" shift valve (3) as in the case of "D" range. The line pressure (2) locks the second lock valve (9) and is led to the tightening side of the band servo.

The "2nd" gear is therefore fixed regardless of vehicle speed. When "D<sub>3</sub>" range (3rd gear) is shifted to "2" range, the line pressure (4) enters the throttle back-up valve (7) and produces a high pressure in the circuit (17), increasing the throttle pressure (16). The line pressure (7) is, therefore, increased and quickly tightens the band.

Note: "D<sub>3</sub>" range (3rd gear) to "2" range:

If "D<sub>3</sub>" range (3rd gear) is shifted to "2" range during operation, the manual valve (2) is also shifted to

Range	Gear ratio	Clutch		Low & reverse brake	Band servo		One way clutch	Parking pawl
		Front	Rear		Operation	Release		
Park				on				on
Reverse	2.182	on		on		on		
Neutral								
Drive	D1 Low		on				on	
	D2 Second		on		on			
	D3 Top	on	on		(on)	on		
2	Second		on		on			
1	12 Second		on		on			
	11 Low		on	on				

"2" position, causing the line pressure circuit (3) to be drained. Therefore, the line pressure circuit (10) which is situated at the release side of the front clutch and servo is also drained through the "2nd-3rd" shift valve (4), forcing the speed to

decrease from "3rd gear" to "2nd gear." In this case the speed change quickly takes place because the line pressure (7) and other pressure are heightened by the action of the line pressure (4), in the same manner as described under "2" range.



# Automatic Transmission

## "2" range (2nd gear)




Fig. AT-42 Oil pressure circuit diagram — "2" range (2nd gear)



**"1." RANGE (LOW GEAR)**


When starting in "1" range, the driving gear is locked to the low gear ratio.

In "1" range, the rear clutch is engaged and the low and reverse brake holds the connecting drum and rear planet carrier from rotating. The power flow takes place through the input shaft and into the rear clutch. Rotation of the rear clutch drives the rear clutch hub and front internal gear. The front internal gear rotates the front planetary gears clockwise to cause the sun gear to rotate counterclockwise.

Counterclockwise rotation of the sun gear turns the rear planetary gear clockwise.


The rear planet carrier splined to the connecting drum is held from rotating by the low and reverse brake.

The clockwise rotation of the rear planetary gears therefore rotates the rear internal gear and internal drive flange. The internal drive flange is splined to the output shaft and rotates the output shaft clockwise. However, the output shaft rotates at a lower speed compared to that of the input shaft. This is caused by the fact that the front planet carrier rotates at the same speed as the output shaft in the same direction since the carrier is splined to the output shaft. The front internal gear and planetary gear assembly are rotating in the same direction, but the planet carrier is rotating at a speed slower than the ring gear. So the gear ratio of this speed range is a combination of the ratios provided by the front and rear planetary gear assemblies.



AT076

Fig. AT-43 Power transmission during "1" range



AT077

Fig. AT-44 Operation of each mechanism during "1" range

Range	Gear ratio	Clutch		Low & reverse brake	Band servo		One way clutch	Parking pawl
		Front	Rear		Operation	Release		
Park				on				on
Reverse	2.182	on		on		on		
Neutral								
Drive	D1 Low		on				on	
	D2 Second		on		on			
	D3 Top	on	on		(on)	on		
2	Second		on		on			
1	12 Second		on		on			
	11 Low		on	on				

When the manual valve ② is positioned at "1", the line pressure (7) is applied into the line pressure circuits (1), (4) and (5). The oil pressure in (5) actuates the low and reverse brake after being introduced into the circuit (12) through the "1st-2nd" shift valve ③, and the line pressure (1) acts on

the rear clutch and governor. The line pressure (4) acts in the same manner as in "2" range.

Similar to that of the "D" range, the line pressure increases with the degree of accelerator pedal depression, and the line pressure decreases with the increase of car speed. The governor

pressure (15) which acts on the "1st-2nd" shift valve does not increase until it overcomes the combined force of the line pressure (12) and the spring, causing no "1st-2nd" speed change.



# Automatic Transmission

## "1<sub>1</sub>" range (Low gear)




Fig. AT-45 Oil pressure circuit diagram — "1<sub>1</sub>" range (Low gear)

# Automatic Transmission

## "1<sub>2</sub>" range (2nd gear)




Fig. AT-46 Oil pressure circuit diagram — "1<sub>2</sub>" range (2nd gear)



# REMOVAL AND INSTALLATION

## CONTENTS

TRANSMISSION ASSEMBLY .....	AT-33	TRANSMISSION CONTROL LINKAGE .....	AT-35
REMOVAL .....	AT-33	REMOVAL AND INSTALLATION .....	AT-35
INSTALLATION .....	AT-33	ADJUSTMENT .....	AT-35

## TRANSMISSION ASSEMBLY

When dismantling the automatic transmission from a vehicle, pay attention to the following points:

1. Before dismantling the transmission, rigidly inspect it by aid of the "Troubleshooting Chart," and dismount it only when considered to be necessary.
2. Dismount the transmission with utmost care; and when mounting, observe the tightening torque indicated on another table, not to exert excessive force.

## REMOVAL

In dismantling automatic transmission from vehicle, proceed as follows:

1. Disconnect battery ground cable from terminal.
2. Disengage torsion shaft from accelerator linkage.
3. Jack up vehicle and support its weight on safety stands. Recommend a hydraulic hoist or open pit be utilized, if available.

Make sure that safety is insured.

4. Remove propeller shaft.

**Note:** Plug up the opening in the rear extension to prevent oil from flowing out.

5. Disconnect front exhaust tube.
6. Disconnect selector range lever from manual shaft.
7. Disconnect wire connections at inhibitor switch.

8. Disconnect vacuum tube from vacuum diaphragm, and wire connections at downshift solenoid.
9. Disconnect speedometer cable from rear extension.
10. Disconnect oil charging pipe.
11. Disconnect oil cooler inlet and outlet tubes at transmission case.
12. Support engine by locating a jack under oil pan with a wooden block used between oil pan and jack. Support transmission by means of a transmission jack.
13. Detach converter housing dust cover. Remove bolts securing torque converter to drive plate. See Figure AT-47.




Fig. AT-47 Removing torque converter attaching bolts

**Note:** Before removing torque converter, scribe match marks on two parts so that they may be replaced in their original positions at assembly.

14. Remove rear engine mount securing bolts and crossmember mounting bolts.
15. Remove starter motor.
16. Remove bolts securing transmission to engine. After removing these

bolts, support engine and transmission with jack, and lower the jack gradually until transmission can be removed and take out transmission under the car.

**Note:** Plug up the opening such as oil charging pipe, oil cooler tubes, etc.

## INSTALLATION

Installation of automatic transmission on vehicle is reverse order of removal. However, observe the following installation notes.

1. Drive plate runout

Turn crankshaft one full turn and measure drive plate runout with indicating finger of a dial gauge rested against plate. See Figure AT-48.

[Replace drive plate if in excess of 0.5 mm (0.020 in).]

- Maximum allowable runout:  
0.3 mm (0.012 in)





Fig. AT-48 Measuring drive plate runout

2. Installation of torque converter  
Line up notch in torque converter with that in oil pump. Be extremely careful not to cause undue stresses in parts in installing torque converter. See Figure AT-49.




AT116

Fig. AT-49 Torque converter aligning cut

3. When connecting torque converter to transmission, measure distance "A" to be certain that they are correctly assembled. See Figure AT-50.

Distance "A":

More than 21.5 mm (0.846 in)



AT117

Fig. AT-50 Installing torque converter

4. Bolt converter to drive plate.

**Note:** Align chalk marks painted across both parts during disassembling processes.

5. After converter is installed, rotate crankshaft several turns and check to be sure that transmission rotates freely without binding.

6. Pour recommended automatic transmission fluid up to correct level through oil charge pipe.

7. Connect manual lever to shift rod. Operation should be carried out with manual and selector levers in "N."

8. Connect inhibitor switch wires.

**Notes:** a. Refer to covering topic under "Checking and adjusting inhibitor switch" on page AT-49.

b. Inspect and adjust switch as above whenever it has to be removed for service.

9. Check inhibitor switch for operation:

Starter should be brought into operation only when selector lever is in "P" and "N" positions (it should not be started when lever is in "D," "2," "1" and "R" positions).

Back-up lamp should also light when selector lever is placed in "R" position.

10. Check level of oil in transmission. For detailed procedure, see page AT-48.

11. Move selector lever through all positions to be sure that transmission operates correctly.

With hand brake applied, rotate engine at idling. Without disturbing the above setting, move selector lever through "N" to "D," to "2," to "1" and to "R." A slight shock should be felt by hand gripping selector each time transmission is shifted.


**Note:** See page AT-49 for checking engine idling.

12. Check to be sure that line pressure is correct. To do this, refer to relative topic under "Testing line pressure" on page AT-52.

13. Perform stall test as per the instructions on page AT-50.



## TRANSMISSION CONTROL LINKAGE



- 1 Control lever knob
- 2 Pusher
- 3 Control lever assembly
- 4 Selector range lever
- 5 Control lever bracket
- 6 Selector rod

Tightening torque (T) of  
nuts and screws kg-m (ft-lb)

- Ⓓ T : 0.07 to 0.13 (0.5 to 0.9)
- Ⓔ T : 1.6 to 2.2 (12 to 16)
- Ⓕ T : 3 to 4 (22 to 29)
- Ⓖ T : 0.35 to 0.45 (2.5 to 3.3)
- Ⓗ T : 0.8 to 1.1 (6 to 8)

AT273

Fig. AT-51 Control linkage system

### REMOVAL AND INSTALLATION

1. Disconnect control knob from control lever by removing two (2) screws.
2. Remove console box.
3. Remove selector rod, selector range lever and control lever assembly with bracket.

To install, reverse the order of removal.

### ADJUSTMENT

The adjustment of linkage is as

important as "Inspection of oil level" for the automatic transmission.

Therefore, great care should be exercised because faulty adjustment will result in the breakdown of the transmission.

1. Prior to installing control knob, set the dimension "A" to 11 to 12 mm (0.43 to 0.47 in).
2. Install control knob on lever. At the same time, check the dimension "B" and adjust it to 0.1 to 1.1 mm (0.004 to 0.043 in) by turning pusher ②. See Figure AT-51.

3. Loosen adjust nuts ⑨. Set control lever ③ and selector lever ④ at "N" position, moreover, set the clearance "C" to 1 mm (0.039 in) by turning in or out adjusting nuts at trunnion with connects selector rod ⑥.

After adjusting, make sure that control lever can be set in any position correctly and that selector lever operates properly without any binding.

If levers do not operate satisfactorily, readjust or replace parts as necessary.

# MAJOR REPAIR OPERATION

## CONTENTS

### SERVICE NOTICE FOR DISASSEMBLY AND ASSEMBLY

TORQUE CONVERTER	AT-36
INSPECTION	AT-36
TRANSMISSION	AT-36
DISASSEMBLY	AT-36
INSPECTION	AT-38
ASSEMBLY	AT-38

COMPONENT PARTS	AT-40
FRONT CLUTCH	AT-40
REAR CLUTCH	AT-41
LOW & REVERSE BRAKE	AT-42
SERVO PISTON	AT-42
GOVERNOR	AT-43
OIL PUMP	AT-43
PLANETARY CARRIER	AT-44
CONTROL VALVE	AT-44

## SERVICE NOTICE FOR DISASSEMBLY AND ASSEMBLY

1. It is advisable that repair operations be carried out in a dust-proof room.
2. Due to the differences of the engine capacities, the specifications of component parts for each model's transmission may be different. They do, however, have common adjustment and repair procedures as well as cleaning and inspection procedures, outlined hereinafter.
3. During repair operations, refer to "Service Data and Specifications" section for the correct parts for each model.
4. Before removing any of subassemblies, thoroughly clean the outside of the transmission to prevent dirt from entering the mechanical parts.
5. Do not use a waste rag. Use a nylon or paper cloth.
6. After disassembling, wash all disassembled parts, and examine them to see if there are any worn, damaged or defective parts, and how they are affected. Refer to "Service Data" for the extent of damage that justifies replacement.
7. As a rule, packings, seals and similar parts once disassembled should be replaced with new ones.

## TORQUE CONVERTER

The torque converter is a welded construction and can not be disassembled.

## INSPECTION

1. Check torque converter for any sign of damage, bending, oil leak or deformation. If necessary, replace.
2. Remove rust from pilots and bosses completely.

If torque converter oil is fouled or contaminated due to burnt clutch, flush the torque converter as follows:

- (1) Drain oil in torque converter.
- (2) Pour non lead gasoline or kerosene into torque converter [approximately 0.5 liter (1  $\frac{1}{4}$  U.S.pt.,  $\frac{1}{2}$  Imp.pt.)].
- (3) Blow air into torque converter and flush and drain out gasoline.
- (4) Fill torque converter with torque converter oil [approximately 0.5 liter (1  $\frac{1}{4}$  U.S.pt.,  $\frac{1}{2}$  Imp.pt.)].
- (5) Again blow air into torque converter, and drain torque converter oil.

## TRANSMISSION

### DISASSEMBLY

1. Drain oil from the end of rear extension. Mount transmission on Transmission Case Stand ST07870000 or ST07860000. Remove oil pan. See Figure AT-52.




Fig. AT-52 Removing oil pan

2. Remove bolts securing converter housing to transmission case. Remove torque converter.
3. Remove speedometer pinion sleeve bolt. Withdraw pinion.
4. Remove downshift solenoid and vacuum diaphragm. Do not leave diaphragm rod at this stage of disassembly. Rod is assembled in top of vacuum diaphragm. See Figure AT-53.




Fig. AT-53 Downshift solenoid and vacuum diaphragm

5. Remove bolts which hold valve body to transmission case. See Figure AT-54.




Fig. AT-54 Removing valve body

6. Loosen lock nut ② on piston stem ① as shown in Figure AT-55. Then tighten piston stem in order to prevent front clutch drum from falling when oil pump is withdrawn.




Fig. AT-55 Loosening band servo

7. Pull out input shaft.
8. Withdraw oil pump using Sliding Hammer ST25850000. Do not allow front clutch to come out of position and drop onto floor. See Figure AT-56.




Fig. AT-56 Removing oil pump

9. Remove band strut. This can be done by loosening piston stem further. See Figure AT-57.




Fig. AT-57 Removing band strut

10. Remove brake band, front clutch and rear clutch as an assembled unit.

11. Remove connecting shell, rear clutch hub and front planetary carrier as a unit. See Figure AT-58.




Fig. AT-58 Removing connecting shell

12. With the aid of Snap Ring Remover HT69860000, pry snap ring off output shaft. See Figure AT-59.




Fig. AT-59 Removing snap ring

13. Remove connecting drum and inner gear of rear planetary carrier as an assembly. See Figure AT-60.




Fig. AT-60 Removing connecting drum

14. Remove snap rings and then remove rear planetary carrier, internal gear, connecting drum, one-way clutch outer race and one-way clutch in that order.

15. Remove rear extension by loosening securing bolts. See Figure AT-61.




Fig. AT-61 Removing rear extension

16. Pull out output shaft; remove oil distributor ② together with governor valve ①. See Figure AT-62.




Fig. AT-62 Removing governor and oil distributor

17. Pry off snap ring using a pair of pliers. Remove retaining plate, drive plate, driven plate and dish plate in that order. See Figure AT-63.




Fig. AT-63 Removing drive and driven plates

18. Reaching through back side of transmission case, remove hex-head slotted bolts as shown in Figure AT-64. To do this, use Hex-head Extension ST25570001 (ST25570000). One-way clutch inner race, thrust washer, piston return spring and thrust spring ring can now be removed.




Fig. AT-64 Removing hex-head slotted bolt

19. Blow out low and reverse brake piston by directing a jet of air into hole in cylinder. See Figure AT-65.




Fig. AT-65 Removing piston

20. Remove band servo loosening attaching bolts.

Note: If difficulty is encountered in removing retainer, direct a jet of air toward release side as shown in Figure AT-66.




Fig. AT-66 Removing band servo

21. Pry snap rings ① from both ends of parking brake lever ② and remove the lever. Back off manual shaft lock nut ③ and remove manual plate ④ and parking rod ⑤. See Figure AT-67.




Fig. AT-67 Removing manual plate

22. Remove inhibitor switch and manual shaft by loosening two securing bolts.




Fig. AT-68 Measuring seal ring to ring groove clearance

## INSPECTION

### Torque converter housing, transmission case and rear extension

1. Check for damage or cracking; if necessary, replace.
2. Check for dents or score marks on mating surfaces. Repair as necessary.
3. If rear extension bushing is worn or cracked, replace it as an assembly of bushing and rear extension housing.

### Gaskets and O-ring

1. Always use new gaskets when the units are to be disassembled.
2. Check O-rings for burrs or cracking. If necessary, replace with new rings.

### Oil distributor

1. Check for signs of wear on seal ring and ring groove, replacing with new ones if found worn beyond use.
2. Check that clearance between seal ring and ring groove is correct. If out of specification, replace whichever is worn beyond limits. Correct clearance is from 0.04 to 0.16 mm (0.0016 to 0.0063 in). See Figure AT-68.

## ASSEMBLY

Assembly is in reverse order of disassembly. However, observe the following assembly notes.

1. After installing piston of low and reverse brake, assemble thrust spring ring, return spring, thrust washer and one-way clutch inner race. Torque hex-head slotted bolt to 1.3 to 1.8 kg-m (9 to 13 ft-lb), using Hex-head Extension ST25570001 (ST25570000), Torque Wrench GG93010000 and Socket Extension ST25490000 (ST25512001). See Figure AT-69.




Fig. AT-69 Installing one-way clutch inner race

2. After low and reverse brake has been assembled, measure the clearance between snap ring ① and retaining plate ②. Select proper thickness of retaining plate to give correct ring to plate clearance. See Figure AT-70.

- Low and reverse brake clearance:

0.80 to 1.05 mm  
(0.0315 to 0.0413 in)

## Automatic Transmission





Fig. AT-70 Measuring ring to plate clearance

### Available retaining plate

Thickness mm (in)
11.8 (0.465)
12.0 (0.472)
12.2 (0.480)
12.4 (0.488)
12.6 (0.496)
12.8 (0.504)

For inspection procedure for low and reverse brake, see page AT-42 for Assembly.

3. Install one-way clutch so that the arrow mark "→" is toward front of vehicle. It should be free to rotate only in clockwise direction. See Figure AT-71.



AT137


Fig. AT-71 One-way clutch

4. After installing rear extension, torque attaching bolts to 2.0 to 2.5 kg-m (14 to 18 ft-lb). Place manual lever in "P" range and check to be sure that rear output shaft is securely blocked.

5. Tighten servo retainer temporarily at this stage of assembly.

6. Place rear clutch assembly with needle bearing on front assembly.


7. Install rear clutch hub and front planetary carrier as shown in Figure AT-72.



AT142

Fig. AT-72 Installing planetary carrier


8. Assemble connecting shell and other parts up to front clutch in reverse order of disassembly.



AT143

Fig. AT-73 Installing connecting shell

9. Adjust total end play and front end play as follows:




AT138

- |                              |                               |
|------------------------------|-------------------------------|
| 1 Front clutch thrust washer | 5 Transmission case           |
| 2 Oil pump cover             | 6 Oil pump gasket             |
| 3 Front clutch               | 7 Oil pump cover bearing race |
| 4 Rear clutch                |                               |

Fig. AT-74 End play


(1) Measure the distance "A" and "C" by vernier calipers as shown in Figure AT-75.



AT139

Fig. AT-75 Measuring the distance "A" and "C"

(2) Measure the distance "B" and "D" of oil pump cover as shown in Figure AT-76.



AT140

Fig. AT-76 Measuring the distance "B" and "D"

### Adjustment of total end play

Select oil pump cover bearing race by calculating the following formula:

$$T_T = A - B + W$$

where,

- $T_T$  : Required thickness of oil pump cover bearing race mm (in)  
A : Measured distance A mm (in)  
B : Measured distance B mm (in)  
W : Thickness of bearing race temporarily inserted mm (in)

### Available oil pump cover bearing race

Thickness mm (in)
1.2 (0.047)
1.4 (0.055)
1.6 (0.063)
1.8 (0.071)
2.0 (0.079)
2.2 (0.087)

Specified total end play:  
0.25 to 0.50 mm  
(0.0098 to 0.0197 in)

## Automatic Transmission

### Adjustment of front end play

Select front clutch thrust washer by calculating the following formula:

$$T_F = C - D - 0.2 \text{ (mm)}$$

where,

$T_F$  : Required thickness of front

clutch thrust washer mm (in)

C : Measured distance C mm (in)

D : Measured distance D mm (in)

### Available front clutch thrust washer

Thickness mm (in)
1.5 (0.059)
1.7 (0.067)
1.9 (0.075)
2.1 (0.083)
2.3 (0.091)
2.5 (0.098)
2.7 (0.106)

Specified front end play:  
0.5 to 0.8 mm  
(0.020 to 0.031 in)

#### Notes:

- Correct thickness of bearing race and thrust washer is always the one which is nearest the calculated one.
- Installed thickness of oil pump gasket is 0.4 mm (0.016 in).

10. Check to be sure that brake servo piston moves freely. For detailed procedure, refer to page AT-42 for Servo Piston. Use care to prevent piston from coming out of place during testing since servo retainer is not tightened at this point of assembly.


11. Make sure that brake band strut is correctly installed. Torque piston stem to 1.2 to 1.5 kg-m (9 to 11 ft-lb). Back off two full turns and secure with lock nut. Lock nut tightening torque is 1.5 to 4.0 kg-m (11 to 29 ft-lb).

12. After inhibitor switch is installed, check to be sure that it operates properly in each range. For detailed procedure, refer to page AT-49 for Checking and Adjusting Inhibitor Switch.

13. Check the length "L" between case end to rod end of vacuum throttle valve fully pushed in. Then select adequate diaphragm rod of corresponding measured length. See Figure AT-77.

### Available diaphragm rod

Distance measured "L" mm (in)	Diaphragm rod length mm (in)
Under 25.55 (1.0059)	29.0 (1.142)
25.65 to 26.05 (1.0098 to 1.0256)	29.5 (1.161)
26.15 to 26.55 (1.0295 to 1.0453)	30.0 (1.181)
26.65 to 27.05 (1.0492 to 1.0650)	30.5 (1.201)
Over 27.15 (1.0689)	31.0 (1.220)



AT145


Fig. AT-77 Measuring the distance "L"

## COMPONENT PARTS

The transmission consists of many small parts that are quite alike in construction yet machined to very close tolerances. When disassembling parts, be sure to place them in order in part rack so they can be restored in the unit in their proper positions. It is also very important to perform functional test whenever it is designated.

### FRONT CLUTCH

#### Disassembly




AT146

- 1 Snap ring
- 2 Retaining plate
- 3 Drive plate
- 4 Driven plate
- 5 Dished plate
- 6 Snap ring
- 7 Spring retainer
- 8 Coil spring

Fig. AT-78 Sectional view of front clutch

1. Pry off snap ring ① with a suitable screwdriver or a pair of pliers. Remove a retaining plate ②, drive plate ③, driven plate ④ and dished plate ⑤ in the order listed, as shown in Figure AT-78.


2. Compress clutch springs, using Clutch Spring Compressor ST25420001 (or ST25420000). Remove snap ring ⑥ from spring retainer, using Snap Ring Remover ST25320001. See Figure AT-79.



AT147

Fig. AT-79 Removing snap ring

Note: When Clutch Spring Compressor ST25420000 is to be used, cut the toe-tips of three legs by a grinding wheel. See Figure AT-80.




AT148

Cut off hatched portion

**Fig. AT-80 Modifying coil spring compressor**

3. Take out spring retainer ⑦ and spring ⑧. See Figure AT-78.
4. Blow out piston by directing a jet of air into hole in clutch drum. See Figure AT-81.



AT149

**Fig. AT-81 Blowing out piston**

## Inspection

1. Check for signs of wear or damage to clutch drive plate facing. If found worn or damaged excessively, discard. See "Service Data" for limits.
2. Check for wear on snap ring and for weakened or broken coil spring.


If necessary, replace with new ones.

Spring retainer should also be inspected for warpage.

## Assembly

1. Assembly is in reverse the order of disassembly. Dip all parts in clean automatic transmission fluid before installing.
2. Line up driven plates so that stripped arcs are properly aligned, paying particular attention to the location of oil holes in clutch drum. See Figure AT-82.

**Note:** The number of drive and driven plates varies with the type of vehicle. For detailed information, see "Service Data & Specifications."



AT150

Lubrication hole

**Fig. AT-82 Inserting clutch plate**


3. After clutch is assembled, make sure that clearance between snap ring ① and retaining plate ② is held within specified limits. If necessary, try with other plates having different thickness until correct clearance is obtained. See Figure AT-83.

Specified clearance:

1.6 to 1.8 mm  
(0.063 to 0.071 in)

## Available retaining plate

Thickness mm (in)
10.6 (0.417)
10.8 (0.425)
11.0 (0.433)
11.2 (0.441)
11.4 (0.449)
11.6 (0.457)




AT151

**Fig. AT-83 Measuring ring to plate clearance**

4. Testing front clutch

With front clutch assembled on oil pump cover, direct a jet of air into hole in clutch drum. See Figure AT-84.




AT152

**Fig. AT-84 Testing front clutch**

## REAR CLUTCH

### Disassembly




AT153

- |                       |                   |
|-----------------------|-------------------|
| 1 Rear clutch drum    | 6 Driven plate    |
| 2 Front clutch piston | 7 Dished plate    |
| 3 Snap ring           | 8 Spring retainer |
| 4 Retaining plate     | 9 Coil spring     |
| 5 Drive plate         |                   |

**Fig. AT-85 Sectional view of rear clutch**

1. Take out snap ring ③, retaining plate ④, drive plate ⑤, driven plate ⑥ and dished plate ⑦. Same technique can be applied as in disassembling front clutch. See Figure AT-85.

2. Remove snap ring from coil spring retainer. See Figure AT-86.



**Fig. AT-86 Removing snap ring**

3. Blow out piston by directing a jet of air into hole in clutch drum. See Figure AT-87.




Fig. AT-87 Blowing out piston




Fig. AT-89 Testing rear clutch

3. Without disturbing the above setting, check to be sure that clearance between snap ring and retaining plate is within specified limits. If necessary, use other plates of different thickness until correct clearance is obtained.

Specified clearance:  
0.80 to 1.05 mm  
(0.0315 to 0.0413 in)

4. Blow compressed air into oil hole in low & reverse brake to test for definite brake operation as shown in Figure AT-90.




Fig. AT-90 Testing low & reverse brake

## Inspection

Refer to page AT-41 for Inspection of Front Clutch.

## Assembly

Assemble in reverse the order of disassembly. Dip all parts in clean automatic transmission fluid before assembling. Note that the number of drive and driven plates varies with type of vehicle. For details, refer to "Service Data & Specifications".

1. After rear clutch is assembled, check to be sure that clearance between snap ring ① and retaining plate ② is held within prescribed tolerances. See Figure AT-88.

Specified clearance:  
1.0 to 1.5 mm  
(0.039 to 0.059 in)




Fig. AT-88 Measuring ring to plate clearance

2. Testing rear clutch

Install rear clutch on oil pump cover.

Blow compressed air into oil hole to test for definite clutch operation as shown in Figure AT-89.

## LOW & REVERSE BRAKE

### Disassembly

1. Follow steps as described in page AT-36 for Transmission Disassembly.
2. Blow out piston by directing a jet of air into oil hole in clutch piston.

### Inspection

1. Check drive plate facing for wear or damage; if necessary, replace. Refer to "Service Data & Specifications" for tolerances.
2. Test piston return spring for weakness. Discard if weakened beyond use.
3. Replace faulty parts with new ones.

### Assembly

1. After low & reverse piston is installed, assemble thrust spring ring, return spring, thrust washer and one-way clutch inner race. Using Hex-head Extension ST25570001 (ST25570000), torque hex-head slotted bolt 1.3 to 1.8 kg-m (9 to 13 ft-lb).
2. Insert dished plate, driven plate, drive plate and retaining plate into transmission case in that order. Install snap ring to secure the installation.

**Note:** The number of drive and driven plates varies with type of vehicle. For detailed information, refer to "Service Data & Specifications".

## SERVO PISTON

### Disassembly

1. Blow out piston by directing a jet of air into hole in release-side of piston.
2. Remove servo piston return spring.

### Inspection

Check piston for wear, damage or other faults which might interfere with proper brake operation.




Fig. AT-91 Removing piston






Fig. AT-92 Sectional view of servo piston

## Assembly

1. Prior to assembly, dip all parts in clean automatic transmission fluid.  
Reverse disassembly procedure to assemble brake.
2. Use extreme care to avoid damaging rubber ring when installing seal lace.
3. Blow compressed air from apply-side of piston to test for definite piston operation as shown in Figure AT-93.




Fig. AT-93 Testing piston (Apply side)

4. With apply-side of piston plugged with thumb, blow compressed air into cylinder from release-side as shown in Figure AT-94. If retainer is raised a little, it is an indication that attaching bolts are loose, calling for retightening.




Fig. AT-94 Testing piston (Release side)

## GOVERNOR

### Disassembly

1. Separate governor from oil distributor by unscrewing attaching bolts.
2. To disassemble secondary governor, remove spring seat, spring and secondary governor valve from valve body in that order as shown in Figure AT-95.




Fig. AT-95 Testing secondary governor

3. If primary governor is to be disassembled for any purpose, remove spring seat, primary governor valve, spring and spring seat.

## Inspection

1. Check valve for faulty condition. Replace spring if found weakened beyond use. Faulty piston should also be replaced with a new one.
2. Examine to see if primary governor slides freely without binding.
3. To determine if secondary governor is in good condition, blow air under light pressure into hole at "A" and listen for noise like that of a model plane.

## Assembly

Reverse disassembly procedure to assemble governor.

**Note:** Do not confuse primary governor with secondary governor. After installation, check that spring is not deflected.

## OIL PUMP

### Disassembly

1. Free pump cover from pump housing by removing attaching bolts.
2. Take out inner and outer gears from pump housing.

## Inspection

1. Inspect for wear or damage to gear teeth. Replace rubber ring if found damaged beyond use.
2. Using a straight edge and feelers, measure pump and gear clearances as follows:

- Clearance between inner (or outer) gear and pump cover. See Figure AT-96.

Standard clearance:

0.02 to 0.04 mm  
(0.0008 to 0.0016 in)

[Replace if over 0.08 mm (0.0031 in).]




Fig. AT-96 Measuring clearance

- Clearance between seal ring and ring groove. See Figure AT-97.

Standard clearance:  
0.04 to 0.16 mm  
(0.0016 to 0.0063 in)




Fig. AT-97 Measuring clearance

## Assembly

1. Set up pump housing with inner and outer pump gears on it.
2. Using Oil Pump Assembling Gauge ST25580000, install pump cover to pump housing as shown in Figure AT-98.




Fig. AT-98 Centering oil pump

3. Temporarily tighten pump securing bolts.
4. Set the runout of oil pump cover within 0.07 mm (0.0028 in) total indicator reading. See Figure AT-99.




Fig. AT-99 Measuring runout

5. Tighten pump securing bolts to specified torque 0.6 to 0.8 kg-m (4 to 6 ft-lb).

**Note:** Be sure to align converter housing securing bolt holes.

6. Again, check the runout of oil pump cover.

**Note:** When former Oil Pump Assembling Gauge is to be used, make a screw hole in side of it.

## PLANETARY CARRIER

The planetary carrier cannot be divided into its individual components.

If any part of component is faulty, replace the carrier as a unit.

## Inspection

Check clearance between pinion washer and planetary carrier with a feeler. See Figure AT-100.

- Standard clearance:  
0.20 to 0.70 mm  
(0.0079 to 0.0276 in)




Fig. AT-100 Measuring pinion washer to carrier clearance

[Replace if over 0.80 mm (0.0315 in).]

## CONTROL VALVE

The control valve assembly consists of many precision parts and requires extreme care when it has to be removed and serviced. It is good practice to place parts in a part rack so that they can be reassembled in valve body in their proper positions. Added care should also be exercised to prevent springs and other small parts from being scattered and lost.

Before assembly, dip all parts in clean automatic transmission fluid and check to be certain that they are free of lint and other minute particles. If clutch or band is burnt or if oil becomes fouled, the control valve assembly should be disassembled and flushed.

## Disassembly

1. Remove bolts and nuts which retain oil strainer. Bolts may be removed with a screwdriver, but it is recommended that Hexagon Wrench HT61000800 and Spinner Handle HT62350000 be used. See Figure AT-101.




Fig. AT-101 Disassembling valve body

2. Remove attaching bolts. With bolts removed, lower valve body, separate plate, and upper valve body are free for removal. See Figure AT-102.

**Note:** Do not allow orifice check valve and valve spring in lower valve body to be scattered and lost when removing separate plate.




Fig. AT-102 Removing separate plate

3. Pull out manual valve as shown in Figure AT-103.
4. Remove side plate. Take out "1st-2nd" shift valve, "2nd-3rd" shift valve, pressure modifier valve and three valve springs. See Figure AT-104.




Fig. AT-103 Removing manual valve




Fig. AT-104 Removing side plate

Note: Do not work it off with screwdrivers. To avoid damaging machine screws do not work it off with screwdriver.

5. Remove side plate; pull out pressure regulator valve, second lock valve, pressure regulator plug and two valve springs.
6. Remove side plate. With side plate removed, solenoid downshift valve; throttle back-up valve, vacuum throttle valve, "2nd-3rd" timing valve and three valve springs are free for removal.




Fig. AT-105 Components parts of control valve

## Inspection

1. Check valves for sign of burning and, if necessary, replace.
2. Check to be certain that oil strainer is in good condition. If found damaged in any manner, discard.
3. Test valve springs for weakened


- tension; if necessary replace.
4. Examine for any sign of damage or score marks on separate plate. If left unheeded, oil will bypass, correct oil passages causing many types of abnormalities in the system.

5. Check oil passages in valve body for sign of damage and other conditions which might interfere with proper valve operation.
6. Check bolts for stripped threads. Replace as required.

## Automatic Transmission

### Valve spring chart

Valve spring	Wire dia. mm (in)	Mean coil dia. mm (in)	No. of active coil	Free length mm (in)	Installed	
					Length mm (in)	Load kg (lb)
Manual detent	1.3 (0.051)	6.0 (0.236)	15.0	32.4 (1.276)	26.5 (1.043)	5.5 (12.1)
Pressure regulator	1.2 (0.047)	10.5 (0.413)	13.0	43.0 (1.693)	23.5 (0.925)	2.8 (6.2)
Pressure modifier	0.4 (0.016)	8.0 (0.315)	5.0	18.5 (0.728)	9.0 (0.354)	0.1 (0.2)
1st - 2nd shift	0.6 (0.024)	6.0 (0.236)	16.0	32.0 (1.260)	16.0 (0.630)	0.625 (1.378)
2nd - 3rd shift	0.7 (0.028)	6.2 (0.244)	18.0	41.0 (1.614)	17.0 (0.669)	1.40 (3.09)
2nd - 3rd timing	0.7 (0.028)	5.5 (0.217)	15.0	32.5 (1.280)	27.0 (1.063)	0.55 (1.21)
Throttle back-up	0.8 (0.031)	6.5 (0.256)	14.0	36.0 (1.417)	18.8 (0.740)	1.92 (4.23)
Solenoid downshift	0.55 (0.0217)	5.0 (0.197)	12.0	22.0 (0.866)	12.5 (0.492)	0.60 (1.32)
Second lock	0.55 (0.0217)	5.0 (0.197)	16.0	33.5 (1.319)	21.0 (0.827)	0.60 (1.32)
Throttle relief	0.9 (0.035)	5.6 (0.220)	14.0	26.8 (1.055)	19.0 (0.748)	2.19 (4.83)
Orifice check	0.23 (0.0091)	4.77 (0.1878)	12.0	15.5 (0.610)	11.5 (0.453)	0.01 (0.02)
Primary governor	0.45 (0.0177)	8.3 (0.327)	5.0	21.8 (0.858)	7.5 (0.295)	0.215 (0.474)
Secondary governor	0.7 (0.028)	8.5 (0.335)	5.5	25.1 (0.988)	10.5 (0.413)	1.10 (2.43)



AT172

Fig. AT-106 Valve spring

### Assembly


Assemble in reverse order of disassembly. However, observe the following assembly notes. Refer to "Valve Spring Chart" and illustration in assembling valve springs. Dip all parts in clean automatic transmission fluid before assembly. Tighten parts to spec-

ifications when designated.

1. Slide valve into valve body and be particularly careful that they are not forced in any way.
2. Install side plates using Torque Driver ST25160000 and Hexagon Wrench HT61000800. See Figure AT-107.

## Automatic Transmission

Tightening torque:  
0.25 to 0.35 kg-m  
(2 to 3 ft-lb)



AT173

*Fig. AT-107 Installing side plate*


3. Install orifice check valve, valve spring, throttle relief valve spring and steel ball in valve body.

**Note:** Install check valve and relief spring so that they are properly positioned in valve body.

4. Install upper and lower valves.  
See Figure AT-108.

Tightening torque:  
0.25 to 0.35 kg-m  
(2 to 3 ft-lb)

Reamer bolt tightening torque:  
0.5 to 0.7 kg-m  
(4 to 5 ft-lb)



AT174

*Fig. AT-108 Installing valve body*

5. Install oil strainer.

Tightening torque:  
0.25 to 0.35 kg-m  
(2 to 3 ft-lb)

# TROUBLE DIAGNOSIS AND ADJUSTMENT

## CONTENTS

INSPECTION AND ADJUSTMENT		ROAD TEST .....	AT-51
BEFORE TROUBLE DIAGNOSIS .....	AT-48	VEHICLE SPEED AT GEAR SHIFT .....	AT-51
TESTING INSTRUMENT FOR INSPECTION .....	AT-48	CHECKING SPEED CHANGING	
CHECKING OIL LEVEL .....	AT-48	CONDITION .....	AT-52
INSPECTION AND REPAIR OF		CHECKING ITEMS DURING SPEED	
OIL LEAKAGE .....	AT-49	CHANGE .....	AT-52
CHECKING ENGINE IDLING		SHIFT SCHEDULE .....	AT-52
REVOLUTION .....	AT-49	LINE PRESSURE TEST .....	AT-52
CHECKING AND ADJUSTING KICKDOWN		LINE PRESSURE (governor feed pressure) ....	AT-53
SWITCH AND DOWNSHIFT SOLENOID ....	AT-49	JUDGEMENT IN MEASURING LINE	
INSPECTION AND ADJUSTMENT OF		PRESSURE .....	AT-53
MANUAL LINKAGE .....	AT-49	TROUBLE SHOOTING CHART .....	AT-53
CHECKING AND ADJUSTING INHIBITOR		INSPECTING ITEMS .....	AT-53
SWITCH .....	AT-49	TROUBLE SHOOTING CHART FOR 3N71B	
STALL TEST .....	AT-50	AUTOMATIC TRANSMISSION .....	AT-54
STALL TEST PROCEDURES .....	AT-50	TROUBLE SHOOTING GUIDE FOR 3N71B	
JUDGEMENT .....	AT-50	AUTOMATIC TRANSMISSION .....	AT-57

Since most automatic transmission troubles can be repaired by simple adjustment, do not disassemble immediately.

Firstly inspect and adjust the automatic transmission in place utilizing the "Trouble Shooting Chart".

If the trouble can not be solved by this procedure, remove and disassemble the automatic transmission. It is advisable to check, overhaul and repair each part in the order listed in the "Trouble Shooting Chart".

1. In the "Trouble Shooting Chart" the diagnosis items are arranged according to difficulty from easy to difficult, therefore please follow these items. The transmission should not be removed, unless necessary.

2. Tests and adjustments should be made on the basis of standard values and the data should be recorded.

## INSPECTION AND ADJUSTMENT BEFORE TROUBLE DIAGNOSIS

### TESTING INSTRUMENT FOR INSPECTION

1. Engine tachometer
2. Vacuum gauge

### 3. Oil pressure gauge

It is convenient to install these instruments in a way that allows measurements to be made from the driver's seat.

### CHECKING OIL LEVEL

In checking the automatic transmission the oil level and the condition of oil around the oil level gauge should be examined. This is an easy and effective trouble shooting procedure since some changes in oil condition are often linked with developed troubles.

For instance:

Lack of oil causes faulty operation by making the clutches and brakes slip, resulting in severe wear.

This is because the oil pump sucks air causing oil foaming, thus rapidly deteriorating the oil quality and producing sludge and varnish.

Excessive oil is also bad because of oil foaming caused by the gears stirring up the oil. During high speed driving excessive oil in the transmission often blows out from the breather.

### Measuring oil level

To check the fluid level, start the engine and run it until normal operat-

ing temperatures [oil temperature: 50 to 80°C (122 to 176°F). Approximately ten-minute of operation will raise the temperature to this range.] and engine idling conditions are stabilized. Then, apply the brakes and move the transmission shift lever through all drive positions and place it in park "P" position. In this inspection, the car must be placed on a level surface.

The amount of the oil varies with the temperature. As a rule the oil level must be measured after its temperature becomes sufficiently high.

1. Fill the oil to the line "H". The difference of capacities between both "H" and "L" is approximately 0.4 liter ( $\frac{3}{8}$  U.S.pt.,  $\frac{3}{4}$  Imp.pt.) and, therefore, do not to fill beyond the line "H".

2. When topping-up and changing oil, care should be taken to prevent mixing the oil with dust and water.

### Inspecting oil condition

The condition of oil sticking to the level gauge indicates whether to overhaul and repair the transmission or look for the faulty part.

If the oil has deteriorated to a varnish-like quality, it causes the control valve to stick. Blackened oil indicates a burned clutch, brake band, etc.

## Automatic Transmission

In these cases, the transmission must be repaired.

### Notes:

- In checking oil level, use special paper cloth to handle the level gauge and be careful not to let the scraps of paper and cloth stick to the gauge.
- Insert the gauge fully and take it out quickly before splashing oil adheres to the gauge. Then observe the level.
- Use automatic transmission fluid having "DEXRON" identifications only in the 3N71B automatic transmission.
- Pay attention because the oil to be used differs from that used in the Nissan Full Automatic Transmission 3N71A. Never mix the oils.

## INSPECTION AND REPAIR OF OIL LEAKAGE

When oil leakage takes place, the portion near the leakage is covered with oil, presenting difficulty in detecting the spot. Therefore, the places where oil seals and gaskets are equipped are enumerated below:

1. Converter housing
  - Rubber ring of oil pump housing.
  - Oil seal of oil pump housing.
  - Oil seal of engine crankshaft.
  - Bolts of converter housing to case.
2. Transmission and rear extension
  - Junction of transmission and rear extension.
  - Oil cooler tube connectors.
  - Oil pan.
  - Oil-pressure inspection holes (Refer to Figure AT-112).
  - Mounting portion of vacuum diaphragm and downshift solenoid.
  - Breather and oil charging pipe.
  - Speedometer pinion sleeve.
  - Oil seal of rear extension.

To exactly locate the place of oil leakage, proceed as follows:

- Place the vehicle in a pit, and by sampling the leaked oil, determine if it is the torque converter oil. The torque converter oil has a color like red wine, so it is easily distinguished from engine oil or gear oil.

- Wipe off the leaking oil and dust and detect the spot of oil leakage. Use nonflammable organic solvent such as carbon tetrachloride for wiping.

- Raise the oil temperature by operating the engine and shift the lever to "D" to increase the oil pressure. The spot of oil leakage will then be found more easily.

**Note:** As oil leakage from the breather does not take place except when running at high speed, it is impossible to locate this leakage with vehicle stationary.

## CHECKING ENGINE IDLING REVOLUTION

The engine idling revolution should be properly adjusted.

If the engine revolution is too low, the engine does not operate smoothly, and if too high, a strong shock or creep develops when changing over from "N" to "D" or "R".

## CHECKING AND ADJUSTING KICKDOWN SWITCH AND DOWNSHIFT SOLENOID

When the kickdown operation is not made properly or the speed changing point is too high, check the kickdown switch, downshift solenoid, and wiring between them. When the ignition key is positioned at the 1st stage and the accelerator pedal is depressed deeply, the switch contact should be closed and the solenoid should click. If it does not click, it indicates a defect. Then check each part with the testing instruments. See Figure AT109.




Fig. AT-109 Downshift solenoid

**Note:** Watch for oil leakage from transmission case.

## INSPECTION AND ADJUSTMENT OF MANUAL LINKAGE

The adjustment of manual linkage is equally important as "Inspection of Oil Level" for the automatic transmission. Therefore, great care should be exercised because incorrect adjustment will result in the breakdown of the transmission.

### Inspection

Pull the selector lever toward you and turn it as far as "P" to "1" range, where clicks will be felt by the hand. This is the detent of manual valve in the valve body, and indicates the correct position of the lever.


Inspect whether the pointer of selector dial corresponds to this point, and also whether the lever comes in alignment with the stepping of position plate when it is released.

### Adjustment

This procedure can be accomplished by referring to page AT-35 for Removal and Installation.

## CHECKING AND ADJUSTING INHIBITOR SWITCH

The inhibitor switch lights the reverse lamp in the range "R" of the transmission operation and also rotates the starter motor in the ranges "N" and "P".



- |                    |                      |
|--------------------|----------------------|
| 1 Inhibitor switch | 6 Washer             |
| 2 Manual shaft     | 7 Nut                |
| 3 Washer           | 8 Inhibitor switch   |
| 4 Nut              | 9 Range select lever |
| 5 Manual plate     |                      |

Fig. AT-110 Construction of inhibitor switch

## Automatic Transmission

Check whether the reverse lamp and the starter motor operate normally in these ranges. If there is any trouble, first check the linkage. If no fault is found in the linkage, check the inhibitor switch.

Separate the manual lever from the remote control selector rod and turn the range select lever to "N".

**Note:** In the position "N" the slot of the manual shaft is vertical.

Using the tester, check the two black-yellow (BY) wires from the inhibitor switch in the ranges "N" and "P" and the two red-black (RB) wires in the range "R" for continuity. Turn range select lever in both directions from each lever set position and check each continuity range. It is normal if the electricity is on while the lever is within an angle of about 3° on both sides from each lever set line. However, if its continuity range is obviously unequal on both sides, adjustment is required.

If any malfunction is found, unscrew the fastening nut of the range selector lever and two fastening bolts of the switch body and then remove the machine screw under the switch body. Adjust the manual shaft correctly to the position "N" by means of the selector lever. (When the slot of the shaft becomes vertical, the detent works to position the shaft correctly with a clicking sound.)

Move the switch slightly aside so that the screw hole will be aligned with the pin hole of the internal rotor combined with the manual shaft and check their alignment by inserting a 1.5 mm (0.059 in) diameter pin into the holes. If the alignment is correct, fasten the switch body with the bolts, pull out the pin, tighten up the screw in the hole, and fasten the selector lever as before. Check the continuity again with the tester. If the malfunction still remains, replace the inhibitor switch.

## STALL TEST

The purpose of this test is to check the transmission and engine for trouble by measuring the maximum numbers of revolutions of the engine while

vehicle is held in a stalled condition. The carburetor is in full throttle operation with the selector lever in ranges "D", "2" and "1" respectively. Compare the measured results with the standard values.

### Components to be tested and test items

1. Clutches, brake and band in transmission for slipping
2. Torque converter for proper functioning
3. Engine for overall properly

## STALL TEST PROCEDURES

Before testing, check the engine oil and torque converter oil; warm up the engine cooling water to suitable temperature by running at 1,200 rpm with the selector lever in the range "P" for several minutes. Warm up the torque converter oil to suitable temperature [60 to 100°C (140 to 212°F)].

1. Mount the engine tachometer at a location that allows good visibility from the driver's seat and put a mark on specified revolutions on the meter.
2. Secure the front and rear wheels with chocks and apply the hand brake. Be sure to depress the brake pedal firmly with the left foot before depressing the accelerator pedal.
3. Throw the selector lever into the range "D".
4. Slowly depress the accelerator pedal until the throttle valve is fully opened. Quickly read and record the engine revolution when the engine begins to rotate steadily and then release the accelerator pedal.
5. Shift the selector lever to "N" and operate the engine at approximately 1,200 rpm for more than one minute to cool down the torque converter oil and coolant.
6. Make similar stall tests in ranges "2", "1" and "R".

**Note:** The stall test operation as specified in item (4) should be made within five seconds. If it takes too long, the oil deteriorates and the clutches, brake and band are adversely affected. Sufficient cooling time should be given between each

test for the four ranges "D", "2", "1" and "R".

## JUDGEMENT

### 1. High stall revolution more than standard revolution

If the engine revolution in stall condition is higher than the standard values, it indicates that one or more clutches in the transmission are slipping and, therefore, no further test is required.

For the following abnormalities, the respective causes are presumed.

- High rpm in all ranges ... Low line pressure
- High rpm in "D", "2" and "1" and normal rpm in "R" ... Rear clutch slipping
- High rpm in "D" and "2" and normal rpm in "1" ... One-way clutch slipping
- High rpm in "R" only ... Front clutch or low and reverse brake slipping

To determine which is slipping, front clutch or low and reverse brake, a road test is needed.

If, while coasting, after starting with the lever in "1" range, engine braking does not work properly, the low and reverse brake is slipping. Otherwise, the front clutch is slipping.

Slipping of the band brake is difficult to ascertain. However, if it occurs with the lever in "2" range, engine revolution increases up to the same level as in "1st" range. It is impossible to check it in the stall test.

### 2. Standard stall revolution

If the engine revolution in stall condition is within the standard values, the control elements are normally operating in the ranges "D", "2", "1" and "R".

Also, the engine and one-way clutch of the torque converter are normal in performance and operation.

The one-way clutch of the torque converter, however, sometimes sticks. This is determined in the road test.

### 3. Lower stall revolution than standard revolution

If the engine revolution in stall condition is lower than the standard



values, it indicates that the engine is in abnormal condition or the torque converter's one-way clutch is slipping.

## 4. Others

(1) If the accelerating performance is poor until vehicle speed of approximately 50 km/h (30 MPH) is attained and then normal beyond that speed, it can be judged that the torque converter's one-way clutch is slipping.

(2) If the torque converter's one-way clutch sticks, vehicle speed can not exceed approximately 80 km/h (50 MPH) in the road test. In such a case, the torque converter oil temperature rises abnormally and so special care is required.

(3) If the transmission does not operate properly at all vehicle speeds, it indicates poor engine performance.

## ROAD TEST

An accurate knowledge of the automatic transmission is required for an exact diagnosis.

It is recommended that a diagnosis guide chart with the standard vehicle speeds for each stage of the up- and down-shiftings be prepared. Measured vehicle speeds are to be filled in the adjoining column after each testing.

Also it is advisable to mount a stopper for positioning the throttle opening.

## VEHICLE SPEED AT GEAR SHIFT

Throttle opening (—mmHg)	Gear shift	Vehicle speed** km/h (MPH)	Propeller shaft rpm
Kickdown (0)	D <sub>1</sub> → D <sub>2</sub>	51 to 65 (32 to 40)	1,840 to 2,340
	D <sub>2</sub> → D <sub>3</sub>	92 to 106 (57 to 66)	3,340 to 3,840
	D <sub>3</sub> → D <sub>2</sub>	96 to 82 (60 to 51)	3,460 to 2,960
	D <sub>2</sub> → D <sub>1</sub>	49 to 36 (30 to 22)	1,790 to 1,290
Half throttle (200)	D <sub>1</sub> → D <sub>2</sub>	9 to 23 (6 to 14)	330 to 830
	D <sub>2</sub> → D <sub>3</sub>	48 to 61 (30 to 38)	1,720 to 2,220
	D <sub>3</sub> → D <sub>2</sub> or	37 to 24 (23 to 15)	1,350 to 850
	D <sub>3</sub> → D <sub>1</sub>		
	D <sub>2</sub> → D <sub>1</sub>	19 (12)	700 Max.
Fuol throttle (0)	1 <sub>2</sub> → 1 <sub>1</sub> *	51 to 38 (32 to 24)	1,860 to 1,360
Minimum throttle (450)	1 <sub>2</sub> → 1 <sub>1</sub> *	51 to 38 (32 to 24)	1,860 to 1,360

\* : Reduce the speed by shifting to "1" range from "D" range (output shaft 2,000 rpm).

Note: Vehicle speed can be calculated by the following formula;

$$V = \frac{2 \times \pi \times r \times N_p \times 60}{R_F \times 1,000}$$

where,

V = Vehicle speed (km/h)

N<sub>p</sub> = Propeller shaft revolution (rpm)

R<sub>F</sub> = Final gear ratio

r = Tire effective radius (m)

π = The ratio of circumference of a circle to its diameter: 3.14

\*\* : R<sub>F</sub> = 4.375

r = 0.321 [6.00-14]

## CHECKING SPEED CHANGING CONDITION

The driver's feeling during gear changes should also be checked attentively.

1. A sharp shock or unsmoothness is felt during a gear change.
2. A gear change is made with a long and dragging feeling.

These indicate that the throttle pressure is too low or some valve connected to the throttle is faulty.

## CHECKING ITEMS DURING SPEED CHANGE

1. In "D" range, gear changes,  $D_1 \rightarrow D_2 \rightarrow D_3$  are effected. In "R" range, the speed does not increase.
2. The kickdown operates properly.
3. By moving the lever from "D" to "1", gear changes  $D_3 \rightarrow 2(1_2) \rightarrow 1_1$  are effected. In the ranges "1<sub>2</sub>" and "1<sub>1</sub>", the engine braking works properly.
4. In "1", the speed does not increase.
5. Should be quickly fixed at "2" range.
6. In "P", vehicle can be parked properly.

If any malfunction occurs in second gear during the road test, that is, if vehicle shakes, drags or slings while shifting up from "D<sub>1</sub>"; directly to "D<sub>3</sub>" or in shifting up from "D<sub>1</sub>" to "D<sub>2</sub>", the brake band should be adjusted. If these troubles remain after the brake band is adjusted, check the servo piston seal for oil leakage.

## SHIFT SCHEDULE




Fig. AT-111 Shift schedule


## LINE PRESSURE TEST

When any slipping occurs in clutch or brake, or the feeling during a speed change is not correct, the line pressure must be checked.

Measuring line pressure is done by a pressure gauge attached to two pressure measuring holes after removing blind plugs located at transmission case. See Figure AT-112.

The line pressure measurement is begun at idling and taken step by step by enlarging the throttle opening.

1. A sharp shock in up-shifting or too high changing speeds are caused mostly by too high throttle pressure.
2. Slipping or incapability of operation is mostly due to oil pressure leakage within the gear trains or spool valve.



AT113

- 1 Line pressure
- 2 Governor feed
- 3 Servo release pressure

Fig. AT-112 Measuring line pressure

## Automatic Transmission

### LINE PRESSURE (GOVERNOR FEED PRESSURE)

Range-	Throttle opening		At cut back point [under approximately 15 km/h (10 MPH)]	After cut back [over approximately 35 km/h (22 MPH)]
		Unit: -mmHg	Unit: kg/cm <sup>2</sup> (psi)	Unit: kg/cm <sup>2</sup> (psi)
"D"	Full throttle	0	9.4 to 11.0 (134 to 156)	5.5 to 6.5 ( 78 to 92)
	Minimum throttle	450	3.0 to 4.0 ( 43 to 57)	3.0 to 4.0 ( 43 to 57)
"2"	Full throttle	0	10.0 to 12.0 (142 to 171)	5.5 to 7.0 ( 78 to 100)
	Minimum throttle	450	6.0 to 12.0 ( 85 to 171)	5.5 to 7.0 ( 78 to 100)
"R"	Full throttle	0	14.0 to 16.0 (199 to 228)	14.0 to 16.0 (199 to 228)
	Minimum throttle	450	3.0 to 5.5 ( 43 to 78)	3.0 to 5.5 ( 43 to 78)

- Notes: a. The line pressure during idling corresponds to the oil pressure before cut down at minimum throttle.  
b. The oil pressure "After cut back" means that after the pressure modifier valve has operated.

### JUDGEMENT IN MEASURING LINE PRESSURE

1. Low idling line pressure in the ranges "D", "2", "1", "R" and "P".

This can be attributed to trouble in the pressure supply system or too low output of power caused by:

- (1) A worn oil pump
- (2) An oil pressure leak in the oil pump, valve body or case
- (3) A sticking regulator valve

2. Low idling, line pressure in certain ranges only

This is presumably caused by an oil leak in the devices or circuits connected to the relevant ranges.

- (1) When there is an oil leak in the rear clutch and governor, the line pressure in "D", "2" and "1" are low but the pressure is normal in "R".
- (2) When an oil leak occurs in the low and reverse brake circuit, the line pressure in "R" and "P" are low but the pressure is normal in "D", "2" and "1".

3. High idling line pressure

This is presumably caused by an increased vacuum throttle pressure owing to a leak in the vacuum tube or diaphragm or by an increased line

pressure due to a sticking regulator valve.

Vacuum leakage is checked by directly measuring the negative pressure after removing the vacuum pipe.

A puncture of the vacuum diaphragm can be easily ascertained because the torque converter oil is absorbed into the engine and the exhaust pipe emits white smoke.

4. Items to be checked when the line pressure is increasing

In this check, the line pressure should be measured with vacuums of 450 mmHg and 0 mmHg in accordance with the stall test procedure.

- (1) If the line pressure do not increase despite the vacuum decrease, check whether the vacuum rod is incorporated.
- (2) If the line pressure do not meet the standard, it is caused mostly by a sticking pressure regulating valve, pressure regulating valve plug, or amplifier.

### TROUBLE-SHOOTING CHART

#### INSPECTING ITEMS

1. Inspection with automatic transmission on vehicle.

- A Oil level
  - B Range select linkage
  - C Inhibitor switch and wiring
  - D Vacuum diaphragm and piping
  - E Downshift solenoid, kickdown switch and wiring
  - F Engine idling rpm
  - G Oil pressure (throttle)
  - H Engine stall rpm
  - I Rear lubrication
  - J Control valve (manual)
  - K Governor valve
  - L Band servo
  - M Transmission air check
  - N Oil quantity
  - O Ignition switch and starter motor
  - P Engine adjustment and brake inspection
2. Inspection after inspecting automatic transmission on vehicle.
- m Rear clutch
  - n Front clutch
  - q Band brake
  - r Low and reverse brake
  - s Oil pump
  - t Leakage of oil passage
  - u One-way clutch of torque converter
  - v One-way clutch of transmission
  - w Front clutch check ball
  - x Parking linkage
  - y Planetary gear

# Automatic Transmission

## TROUBLE-SHOOTING CHART FOR 3N71B AUTOMATIC TRANSMISSION

(The number shown below indicates the sequence in which the checks should be taken up.)

Trouble	A B C D	E F G H	I J K L	M N O P	m n q r	s t u v	w x y
Engine does not start in "N", "P" ranges.	. 2 3 .	. . . . .	. . . . .	. . 1 .	. . . . .	. . . . .	. . . . .
Engine starts in other range than "N" and "P".	. 1 2 .	. . . . .	. . . . .	. . . . .	. . . . .	. . . . .	. . . . .
Sharp shock in shifting from "N" to "D" range.	. . . 2	. 1 3 .	. 4 . .	. . . . .	⑤. . .	. . . . .	. . . . .
Vehicle will not run in "D" range (but runs in "2", "1" and "R" ranges).	. 1 . .	. . 2 .	. 3 . .	. . . . .	. . . . .	. . . ④	. . . . .
Vehicle will not run in "D", "1", "2" ranges (but runs in "R" range). Clutch slips. Very poor acceleration.	1 2 . .	. . 4 .	. 5 . .	6 3 . 7	⑧. . .	. ⑨. .	. . . . .
Vehicle will not run in "R" range (but runs in "D", "2" and "1" ranges.) Clutch slips. Very poor acceleration.	1 2 . .	. . 3 .	. 5 . .	6 4 . .	⑨⑧. ⑦	. ⑩. .	⑪. .
Vehicle will not run in any range.	1 2 . .	. . 3 .	. 5 . .	6 4 . .	. . . . .	⑦⑧. .	. ⑨. .
Clutches or brakes slip somewhat in starting.	1 2 . 6	. . 3 .	. 5 . .	7 4 . .	. . . . .	⑧⑨. .	. . . . .
Vehicle runs in "N" range.	. 1 . .	. . . . .	. 3 . .	. 2 . .	④. . .	. . . . .	. . . . .
Maximum speed not attained. Acceleration poor.	1 2 . .	. . 4 5	. 7 . 6	. 3 . 8	⑪⑫⑨⑩	⑬. . .	. . . . .
Vehicle braked by throwing lever into "R" range.	. . . . .	. . . . .	. . . 3	2 1 . .	④. ⑤. .	. . . . .	. ⑥. .
Excessive creep.	. . . . .	. 1 . .	. . . . .	. . . . .	. . . . .	. . . . .	. . . . .
No creep at all.	1 2 . .	. 3 . .	. 5 . .	. 4 . .	⑧⑨. .	⑥⑦. .	. . . . .
Failure to change gear from "2nd" to "3rd".	. 1 . 2	3 . . .	. 5 6 8	7 4 . .	. . ⑨. .	. ⑩. .	. . . . .
Failure to change gear from "1st" to "2nd".	. 1 . 2	3 . . .	. 5 6 8	7 4 . .	. ⑨. . .	. ⑩. . .	⑪. . .
Too high a gear change point from "1st" to "2nd", from "2nd" to "3rd".	. . . 1	2 . 3 .	. 5 6 .	. 4 . .	. . . . .	. ⑦. . .	. . . . .
Gear change directly from "1st" to "3rd" occurs.	. . . . .	. . . . .	. 2 4 .	3 1 . .	. . ⑤. .	. ⑥. . .	. . . . .

# Automatic Transmission

Trouble	A B C D	E F G H	I J K L	M N O P	m n q r	s t u v	w x y
Too sharp a shock in change from "1st" to "2nd".	. . . 1	. . . 2	. 4 . 5	. 3 . .	. . ⑥ .	. . . .	. . . .
Too sharp a shock in change from "2nd" to "3rd".	. . . 1	2 . 3 .	. 3 . 5	4 . . .	. ⑥ . .	. . . .	. . . .
Almost no shock or clutches slipping in change from "1st" to "2nd".	1 2 . 3	. . 4 .	. 6 . 8	7 5 . .	. . ⑨ .	. ⑩ . .	. . . .
Almost no shock or slipping in change from "2nd" to "3rd". Engine races extremely.	1 2 . 3	. . 4 .	. 6 . 8	7 5 . .	. ⑨ . .	. ⑩ . .	⑪ . .
Vehicle braked by gear change from "1st" to "2nd".	. . . .	. . . .	. 2 . .	. 1 . .	. ④ . ③	. . . ⑤	. . . .
Vehicle braked by gear change from "2nd" to "3rd".	. . . .	. . . .	. 3 . 2	. 1 . .	. . ④ .	. . . .	. . . .
Failure to change gear from "3rd" to "2nd".	. . . 1	. . . .	. 3 4 6	5 2 . .	. ⑦ ⑧ .	. ⑨ . .	. . . .
Failure to change gear from "2nd" to "1st" or from "3rd" to "1st".	. . . 1	. . . .	. 3 4 6	5 2 . .	. . ⑦ .	. . . ⑧	. . . .
Gear change shock felt during deceleration by releasing accelerator pedal.	. 1 . 2	3 . 4 .	. 5 6 .	. . . .	. . . .	. ⑦ . .	. . . .
Too high a change point from "3rd" to "2nd", from "2nd" to "1st".	. 1 . 2	3 . 4 .	. 5 6 .	. . . .	. . . .	. ⑦ . .	. . . .
Kickdown does not operate when depressing pedal in "3rd" within kickdown vehicle speed.	. . . 2	1 . . .	. 4 5 .	. 3 . .	. . ⑥ .	. ⑦ . .	. . . .
Kickdown operates or engine over-runs when depressing pedal in "3rd" beyond kickdown vehicle speed limit.	. 1 . 2	. . 3 .	. 5 6 .	7 4 . .	. ⑧ . .	. ⑨ . .	. . . .
Races extremely or slips in changing from "3rd" to "2nd" when depressing pedal.	. . . 1	. . 2 .	. 4 . 6	5 3 . .	. ⑦ ⑧ .	. ⑨ . .	⑩ . .
Failure to change from "3rd" to "2nd" when changing lever into "2" range.	. 1 . .	. . 2 .	. 4 . 5	. 3 . .	. . ⑥ .	. ⑦ . .	. . . .
Gear change from "2nd" to "1st" or from "2nd" to "3rd" in "2" range.	. 1 . .	. . 2 .	. 3 . .	. . . .	. . . .	. . . .	. . . .

# Automatic Transmission

Trouble	A B C D	E F G H	I J K L	M N O P	m n q r	s t u v	w x y
No shock at change from "1" to "2" range or engine races extremely.	1 2 . 3	. 4 . 1	. 6 . .	7 5 . .	. . ⑨ .	⑩ . . .	. . . .
Failure to change from "3rd" to "2nd" when shifting lever into "1" range.	. 1 . .	. . 2 .	. 4 5 7	6 3 . .	. ⑧ ⑨ .	. ⑩ . .	. . . .
Engine brake does not operate in "1" range.	. 1 . .	. . 2 .	. 4 . .	5 3 . .	. . . ⑥	. ⑦ . .	. . . .
Gear change from "1st" to "2nd" or from "2nd" to "3rd" in "1" range.	. 1 . .	. . . .	. 2 . .	. . . .	. . . .	. ③ . .	. . . .
Does not change from "2nd" to "1st" in "1" range.	1 2 . .	. . . .	. 4 5 6	7 3 . .	. . . ⑧	. ⑨ . .	. . . .
Large shock changing from "2nd" to "1st" in "1" range.	. . . 1	. . . 2	. 4 . .	. 3 . .	. . . ⑤	. . . .	. . . .
Vehicle moves when changing into "P" range or parking gear does not disengage when shifted out of "P" range.	. 1 . .	. . . .	. . . .	. . . .	. . . .	. . . .	. ② .
Transmission overheats.	1 . . .	. . 3 4	2 6 . 8	7 5 . .	. ⑨ ⑩ ⑪	⑫ ⑬ ⑭	. . ⑮
Oil shoots out during operation. White smoke emitted from exhaust pipe during operation.	1 . . 3	. . 5 6	2 7 . .	8 4 . .	. ⑨ ⑩ ⑪	⑫ ⑬ ⑭	. . ⑮
Offensive smell at oil charging pipe.	1 . . .	. . . .	. . . .	. 2 . .	③ ④ ⑤ ⑥	⑦ ⑧ ⑨ .	. . ⑩
Transmission noise in "P" and "N" ranges.	1 . . .	. . 2 .	. . . .	. . . .	. . . .	③ . . .	. . . .
Transmission noise in "D", "2", "1" and "R" ranges.	1 . . .	. . 2 .	. . . .	. . . .	③ . . .	④ . . ⑤	. . ⑥

**TROUBLE-SHOOTING GUIDE FOR 3N71B AUTOMATIC TRANSMISSION**

Order	Test item	Procedure
Checking	<ol style="list-style-type: none"> <li>1. Oil level gauge</li> <li>2. Downshift solenoid</li> <li>3. Manual linkage</li> <li>4. Inhibitor switch</li> <li>5. Engine idling rpm.</li> <li>6. Vacuum pressure of vacuum pipe.</li> <li>7. Operation in each range.</li> <li>8. Creep of vehicle.</li> </ol>	<p>Check gauge for oil level and leakage before and after each test.</p> <p>Check for sound of operating solenoid when depressing accelerator pedal fully with ignition key "ON".</p> <p>Check by shifting into "P", "R", "N", "D", "2" and "1" ranges with selector lever.</p> <p>Check whether starter operates in "N" and "P" ranges only and whether reverse lamp operates in "R" range only.</p> <p>Check whether idling rpm meet standard.</p> <p>Check whether vacuum pressure is more than 450 mmHg in idling and whether it decreases with increasing rpm.</p> <p>Check whether transmission engages positively by shifting "N" → "D", "N" → "2", "N" → "1" and "N" → "R" range while idling with brake applied.</p> <p>Check whether there is any creep in "D", "2", "1" and "R" ranges.</p>
Stall test	<ol style="list-style-type: none"> <li>1. Oil pressure before testing.</li> <li>2. Stall test.</li> <li>3. Oil pressure after testing</li> </ol>	<p>Measure line pressures in "D", "2", "1" and "R" range while idling.</p> <p>Measure engine rpm and line pressure in "D", "2", "1" and "R" ranges during full throttle operation.</p> <p>Notes:</p> <ol style="list-style-type: none"> <li>a. Temperature of torque converter oil used in test should be from 60° to 100°C (140° to 212°F) i.e., sufficiently warmed up but not overheated.</li> <li>b. To cool oil between each stall test for "D", "2", "1" and "R" ranges, idle engine, i.e., rpm at about 1,200 rpm for more than 1 minute in "P" range. Measurement time must not be more than 5 seconds.</li> </ol> <p>Same as item 1.</p>
Road test	<ol style="list-style-type: none"> <li>1. Slow acceleration, 1st → 2nd 2nd → 3rd</li> <li>2. Quick acceleration, 1st → 2nd 2nd → 3rd</li> <li>3. Kick-down operation, 3rd → 2nd or 2nd → 1st</li> </ol>	<p>Check vehicle speeds and engine rpm in shifting up 1st → 2nd range and 2nd → 3rd range while running with lever in "D" range and engine vacuum pressure of about 200 mmHg.</p> <p>Same as item 1 above except with engine vacuum pressure of 0 mmHg (i.e., in position just before kickdown.).</p> <p>Check whether the kickdown operates and measure the time delays while running at 30, 40, 50, 60, 70 km/h (18, 25, 30, 37, 43 MPH) in "D<sub>3</sub>" range.</p>

## Automatic Transmission

Order	Test item	Procedure
	<p>4. Shift down, <math>D_3 \rightarrow D_2 \rightarrow D_1</math></p> <p>5. Shift down, <math>D_3 \rightarrow 1_2 \rightarrow 1_1</math></p> <p>6. Shift down, <math>D_3 \rightarrow 2</math></p> <p>7. Shift up, <math>1_1 \rightarrow 1_2</math></p> <p>8. Shift up or down when starting in "2" range.</p> <p>9. Parking.</p>	<p>Check vehicle speeds and engine rpm in shifting down from 3rd <math>\rightarrow</math> 2nd <math>\rightarrow</math> 1st (sequentially) while coasting with accelerator pedal released in "D<sub>3</sub>" range and engine vacuum pressure of about 450 mmHg.</p> <p>Check for shifting down <math>D_3 \rightarrow 1_2</math> and engine braking, and further for shifting down <math>1_2 \rightarrow 1_1</math> and engine braking, after shifting the lever into "1" range with the accelerator pedal released and the engine vacuum pressure of 0 mmHg while driving at about 50 km/h (30 MPH) in "D<sub>3</sub>" range.</p> <p>Check for quick shifting down <math>D_3 \rightarrow 2</math> and engine braking, after shifting the lever into "2" range while driving at about 50 km/h (30 MPH) in "D<sub>3</sub>" range.</p> <p>Further, check for locking of the transmission in 2nd gear ratio regardless of vehicle speed.</p> <p>Check for failure of the transmission to shift up during acceleration, when starting in "1" range.</p> <p>Check the transmission for not shifting up or down during acceleration or deceleration, when starting in "2" range.</p> <p>Confirm that vehicle will not move on grade when shifting to "P" range.</p>
Others	Abnormal shock, oil leakage.	Enter into record conditions observed during these tests such as gear noise, abnormal clutch noise and acceleration performance.



## SERVICE DATA AND SPECIFICATIONS

### General specifications A/T

Torque converter		
Type .....		Symmetrical 3-element 1-stage 2-phase torque converter
Stall torque ratio .....		2.0 : 1
Transmission		
Type .....		3-speed forward and one-speed reverse with planetary gear train
Control elements:	Multiple-disc clutch .....	2
	Band brake .....	1
	Multiple-disc brake .....	1
	One-way clutch .....	1
Gear ratio:	1st .....	2.458
	2nd .....	1.458
	3rd .....	1.000
	Reverse .....	2.182
Selector positions:	P (Park) .....	Transmission is placed in neutral. Output shaft is fixed. Engine can be started.
	R (Reverse) .....	Backward running
	N (Neutral) .....	Transmission is in neutral. Engine can be started.
	D (Drive) .....	Up- or downshifts automatically to and from 1st, 2nd, and top
	2 (2nd lock) .....	Fixed at 2nd
	1 (Lock up) .....	Fixed at low or downshifts from 2nd
Oil pump		
Type .....		Internally intermeshing involute gear pump
Number of pump .....		1
Oil .....		Automatic transmission fluid "DEXRON" type
Capacity .....		5.5 liters
		(5 $\frac{1}{4}$ U.S. qt., 4 $\frac{3}{4}$ Imp. qt.)
		Approximately 2.7 liters
		(2 $\frac{1}{4}$ U.S. qt., 2 $\frac{1}{2}$ Imp. qt.) in torque converter
Hydraulic control system .....		Controlled by measuring the nega- tive pressure of intake manifold and the revolution of output shaft.
Lubrication system .....		Forced lubrication by an oil pump
Cooling system .....		Water-cooled by a circulation-type auxiliary cooler (located at the radiator).

## Automatic Transmission

### Specifications and adjustment A/T

#### Automatic transmission assembly

Model code number ..... X2402

#### Torque converter assembly

Stamped mark on the T/C ..... 16-B

#### Front clutch

Number of drive plates ..... 3

Number of driven plates ..... 3

Clearance mm (in) ..... 1.6 to 1.8 (0.063 to 0.071)

Thickness of retaining plate mm (in) ..... 10.6 (0.417)

10.8 (0.425)

11.0 (0.433)

11.2 (0.441)

11.4 (0.449)

11.6 (0.457)

#### Rear clutch

Number of drive plates ..... 4

Number of driven plates ..... 4

Clearance mm (in) ..... 1.0 to 1.5 (0.039 to 0.059)

Thickness of retaining plate mm (in) ..... 4.8 (0.189)

#### Low & reverse brake

Number of drive plates ..... 4

Number of driven plates ..... 4

Clearance mm (in) ..... 0.80 to 1.05 (0.0315 to 0.0413)

Thickness of retaining plate mm (in) ..... 11.8 (0.465)

12.0 (0.472)

12.2 (0.480)

12.4 (0.488)

12.6 (0.496)

12.8 (0.504)

#### Brake band

Piston size mm (in)

Big dia. .... 64 (2.52)

Small dia. .... 40 (1.57)

#### Control valve assembly

Stamped mark on strainer ..... E

#### Governor assembly

Stamped mark on governor body ..... 35

## Automatic Transmission

### Engine Idling and stall revolution

Idling revolution	rpm	650 at "D" position
Stall revolution	rpm	2,000 to 2,200






### Tightening torque

kg-m(ft-lb)






Drive plate to crankshaft	14.0 to 16.0	(101 to 116)
Drive plate to torque converter	4.0 to 5.0	(29 to 36)
Converter housing to engine	4.0 to 5.0	(29 to 36)
Transmission case to converter housing	4.5 to 5.5	(33 to 40)
Transmission case to rear extension	2.0 to 2.5	(14 to 18)
Oil pan to transmission case	0.5 to 0.7	(4 to 5)
Servo piston retainer to transmission case	0.5 to 0.7	(4 to 5)
Piston stem (when adjusting band brake)	*1.2 to 1.5	(9 to 11)
Piston stem lock nut	1.5 to 4.0	(11 to 29)
One way clutch inner race to transmission case	1.3 to 1.8	(9 to 13)
Control valve body to transmission case	0.55 to 0.75	(4 to 5)
Lower valve body to upper valve body	0.25 to 0.35	(2 to 3)
Side plate to control valve body	0.25 to 0.35	(2 to 3)
Nut for control valve reamer bolt	0.5 to 0.7	(4 to 5)
Oil strainer to lower valve body	0.25 to 0.35	(2 to 3)
Governor valve body to oil distributor	0.5 to 0.7	(4 to 5)
Oil pump housing to oil pump cover	0.6 to 0.8	(4 to 6)
Inhibitor switch to transmission case	0.5 to 0.7	(4 to 5)
Manual shaft lock nut	3.0 to 4.0	(22 to 29)
Oil cooler pipe to transmission case	3.0 to 5.0	(22 to 36)
Test plug (oil pressure inspection hole)	1.4 to 2.1	(10 to 15)
Support actuator (parking rod inserting position) to rear extension	0.8 to 1.1	(6 to 8)
Oil charging pipe to case	0.55 to 0.75	(4 to 5)
Dust cover to converter housing	0.55 to 0.75	(4 to 5)
Selector range lever to manual shaft	3.0 to 4.0	(22 to 29)

\* Turn back two turns after tightening.




## SPECIAL SERVICE TOOLS

No.	Tool number & tool name	Description	For use on	Reference page or Figure No.
1.	ST2505S001  Oil pressure gauge set	Use for checking hydraulic pressure    SE119	3N71B and 3N71A A/T	Fig. AT-112
2.	ST07870000  Transmission case stand	Use for setting transmission    SE120	3N71B A/T	Page AT-36
3.	ST25850000  Sliding hammers	Use for removing oil pump    SE121	3N71B and 3N71A A/T	Fig. AT-56
4.	ST25420001  Clutch spring compressor	Use for assembling or disassembling front and rear clutch    SE122	3N71B and 3N71A A/T	Fig. AT-79 Fig. AT-86
5.	GG93010000  Torque wrench	Use for tightening correct torque Max. torque: 4.6 kg-m (0.33 ft-lb) Drive angle 3/8" square    SE123	3N71B and 3N71A A/T	Fig. AT-69

# Automatic Transmission

No.	Tool number & tool name	Description	For use on	Reference page or Figure No.
6.	ST25490000 Socket extension	Socket extension to connect torque wrench (GG93010000) with ½" square socket wrench    SE124	3N71B A/T	Fig. AT-69
7.	ST25160000 Torque driver	Use for tightening correct torque Max. torque: 1.04 kg-m (90 ft-lb)    SE125	3N71B A/T and 3N71A	Fig. AT-107 Fig. AT-108
8.	HT69860000 Snap ring remover	Use for removing and replacing snap ring    SE126	3N71B and 3N71A A/T	Fig. AT-59
9.	ST25320001 Snap ring remover	Use for removing and replacing snap ring    SE305	3N71B and 3N71A A/T	Fig. AT-79 Fig. AT-86
10.	ST25570001 Hex-head extension	Use for removing and installing one-way clutch inner race with torque wrench. Drive angle ½" square and 6 mm (across flat width)    SE128	3N71B A/T	Fig. AT-64 Fig. AT-69 Page AT-42

# Automatic Transmission

No.	Tool number & tool name	Description	For use on	Reference page or Figure No.
11.	HT62350000 Spinner handle	Use for disassembling and assembling control valve    SE 129	3N71B and 3N71A A/T	Fig. AT-101 Fig. AT-104
12.	HT61000800 Hexagon wrench	Use for disassembling and assembling control valve    SE 130	3N71B and 3N71A A/T	Fig. AT-101 Fig. AT-104 Fig. AT-107 Fig. AT-108
13.	ST25580000 Oil pump assembling gauge	Use for centering oil pump    SE 131	3N71B and 3N71A A/T	Fig. AT-98 Fig. AT-99

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES

## SECTION PD

### PROPELLER SHAFT & DIFFERENTIAL CARRIER

PD

PROPELLER SHAFT AND CENTER BEARING .....	PD- 2
DIFFERENTIAL CARRIER (TYPE H190) .....	PD- 5
TROUBLE DIAGNOSES AND CORRECTIONS .....	PD-14
SERVICE DATA AND SPECIFICATIONS .....	PD-16
SPECIAL SERVICE TOOLS .....	PD-19



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

# PROPELLER SHAFT & DIFFERENTIAL CARRIER

## PROPELLER SHAFT AND CENTER BEARING

### CONTENTS

DESCRIPTION .....	PD-2	CHECKING AND CORRECTING	
REMOVAL AND INSTALLATION .....	PD-2	UNBALANCED PROPELLER SHAFT .....	PD-3
DISASSEMBLY AND ASSEMBLY .....	PD-3	SERVICE DATA .....	PD-4
INSPECTION .....	PD-3	TROUBLE DIAGNOSES AND	
		CORRECTIONS .....	PD-4




Fig. PD-1 Cross-sectional view of propeller shaft

### DESCRIPTION

The propeller shaft on the 620 series is 3-joint type.

The propeller shaft and universal joint assembly is carefully balanced during original assembly; that is, the dynamic unbalance is under 35 gr-cm (0.49 in-oz) at 5,800 rpm.

If the propeller shaft has to be assembled, it must be made carefully so that the above limit is not exceeded. Therefore, when the vehicle is to be undercoated, cover the propeller shaft and universal joints to prevent application of the undercoating material.

### REMOVAL AND INSTALLATION

1. Raise vehicle on hoist. Put match marks both on propeller shaft and companion flange so that shaft can be reinstalled in the original position.
2. Remove bolts retaining center bearing bracket. See Figure PD-2.




Fig. PD-2 Removing center bearing bracket

3. Remove bolts connecting shaft to companion flange of differential carrier. See Figure PD-3.




Fig. PD-3 Removing propeller shaft

4. Withdraw propeller shaft sleeve yoke from transmission by moving shaft rearward, passing it under rear axle.



# PROPELLER SHAFT & DIFFERENTIAL CARRIER

Watch for oil leakage from transmission end.

## Notes:

- Remove propeller shaft carefully so as not to damage spline, sleeve yoke and rear oil seal.
- Plug up the opening in the rear of rear extension housing to prevent oil from flowing out.

To install, reverse the foregoing removal procedure.

- Align propeller shaft with companion flange using reference marks prescribed in removal procedure and assemble with bolts.

## Tightening torque:

2.4 to 3.3 kg-m  
(17 to 24 ft-lb)

- Insert bolts through the holes of center bearing bracket and torque nuts to retain center bearing on cross-member.

## Tightening torque:

1.6 to 2.2 kg-m  
(12 to 16 ft-lb)

## DISASSEMBLY AND ASSEMBLY

Primarily, do not disassemble propeller shaft because it is balanced as an assembly.

However, check propeller shaft with journal for movement. When journal does not move smoothly, disassemble.

- Mark propeller shaft and journal so that the original combination can be restored at assembly.
- Remove snap ring with a standard screwdriver.
- Lightly tap base of yoke with a hammer, and withdraw bearing race. See Figure PD-4.




Fig. PD-4 Removing bearing

**Note:** When removing journal from yoke, be careful not to damage journal and yoke hole.

When disassembling and repairing center bearing are required, the following procedures are applied.

- Put match marks on flange and front propeller shaft. Remove bolts connecting flange yoke to companion flange.
- Applying Drive Pinion Flange Wrench ST31530000, loosen off locking nut and remove center bearing. See Figure PD-5.




Fig. PD-5 Removing locking nut

To assemble, reverse the foregoing procedure using reference marks prescribed in disassembly procedure.

New bearing need not be lubricated since it is lubricated for life. Fill joint with recommended multi-purpose grease whenever propeller shaft is overhauled.

Use related snap rings of the same thickness and be sure that play is below 0.02 mm (0.0008 in).

## Available snap ring

Thickness mm (in)	Color identification
2.00 (0.0787)	White
2.02 (0.0795)	Yellow
2.04 (0.0803)	Red
2.06 (0.0811)	Green
2.08 (0.0819)	Blue
2.10 (0.0827)	Right Brown
2.12 (0.0835)	No paint
2.14 (0.0843)	Pink

Install and assemble components correctly so that joint moves under friction resistance of less than 15.0 kg-cm (13 in-lb).

When the above steps are complete, place the shaft in a balancing machine and adjust unbalance less than 35 gr-cm (0.49 in-oz) at 5,800 rpm.

Center bearing assembling procedures are as follows:

- Install center bearing in center bearing insulator.
- Install center bearing assembly and companion flange on front shaft using reference marks established in disassembly procedure.
- Install washer and locking nut on front shaft and tighten nut using Drive Pinion Flange Wrench ST31530000 to specified torque.

## Tightening torque:

20.0 to 24.0 kg-m  
(145 to 174 ft-lb)

- Join companion flange of front shaft with flange yoke of rear shaft and tighten connect bolts to specified torque.

## Tightening torque:

2.4 to 3.3 kg-m  
(17 to 24 ft-lb)

- Install center bearing bracket on center bearing.

## INSPECTION

- Check journal pin for dent or brinell marks, and yoke hole for sign of wear or damage.

Snap ring, bearing and seal ring should also be inspected to see if these are damaged, worn or deformed. Replace if necessary.

- Check center bearing by rotating bearing race. If it is rough, noisy or damaged, discard. Cracked bearing insulator cannot be tolerated here.

- Check propeller shaft tube surface for dent or crack. Change if necessary.

## PROPELLER SHAFT & DIFFERENTIAL CARRIER

### CHECKING AND CORRECTING UNBALANCED PROPELLER SHAFT

To check and correct an unbal-

anced propeller shaft, proceed as follows:

1. Remove undercoating and other foreign materials which could upset shaft balance, and check shaft vibration by road test.
2. If shaft vibration is noted during

road test, disconnect propeller shaft at differential carrier companion flange, rotate companion flange 180 degrees and reinstall propeller shaft.

3. Again check shaft vibration. If vibration still persists, replace propeller shaft assembly.

### SERVICE DATA

Permissible dynamic unbalance	gr-cm (in-oz) ..... 35 (0.49) at 5,800 rpm
Axial play of spider journal	mm (in) ..... Less than 0.02 (0.0008)
Journal swinging torque	kg-cm (in-lb)..... Less than 15.0 (13)
Propeller shaft (front and rear) out of round	mm (in) ..... Less than 0.6 (0.024)
Tightening torque	
Shaft to companion flange (Gear carrier) bolt	kg-m (ft-lb) ..... 2.4 to 3.3 (17 to 24)
Self locking nut (front shaft)	kg-m (ft-lb) ..... 20.0 to 24.0 (145 to 174)
Flange yoke (rear shaft) to companion flange (front shaft) bolt	kg-m (ft-lb) ..... 2.4 to 3.3 (17 to 24)
Center bearing bracket to cross member bolt	kg-m (ft-lb) ..... 1.6 to 2.2 (12 to 16)

### TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
Vibration during at medium or high speed.	Worn or damaged universal joint needle bearing.	Replace.
	Unbalance due to bent or dented propeller shaft.	Replace.
	Loose propeller shaft installation.	Retighten.
	Worn transmission rear extension bushing.	Replace.
	Damaged center bearing or insulator.	Replace.
	Tight universal joints.	Impact yokes with hammer to free up. Replace joint if unable to free up or if joint feels rough when rotated by hand.
	Undercoating or mud on the shaft causing unbalance.	Clean up shaft.
	Tire unbalance.	Balance wheel and tire assembly or replace from known good vehicle.
	Balance weights missing.	Replace.

## PROPELLER SHAFT & DIFFERENTIAL CARRIER

Condition	Probable cause	Corrective action
Knocking sound during starting or noise during coasting on propeller shaft.	Worn damaged universal joint. Worn sleeve yoke and main shaft spline. Loose propeller shaft installation. Loose joint installation. Damaged center bearing or insulator. Loose or missing bolts at center bearing bracket to body.	Replace. Replace. Retighten. Adjust snap ring. Replace. Replace or tighten bolts.
Scraping noise.	Dust cover on sleeve yoke rubbing on transmission rear extension. Dust cover on companion flange rubbing on differential carrier.	Straighten out dust cover to remove interference.
Whine or whistle	Damaged center bearing.	Replace.

## DIFFERENTIAL CARRIER (TYPE H190)

### CONTENTS

DESCRIPTION .....	PD- 5	ASSEMBLY OF DIFFERENTIAL	
REMOVAL .....	PD- 7	CASE .....	PD- 8
PRE-DISASSEMBLY INSPECTION .....	PD- 7	ADJUSTMENT OF DRIVE PINION	
DISASSEMBLY .....	PD- 7	HEIGHT .....	PD- 9
INSPECTION .....	PD- 8	ADJUSTMENT OF DRIVE PINION	
ASSEMBLY AND ADJUSTMENT .....	PD- 8	PRELOAD .....	PD-10
PRECAUTIONS IN REASSEMBLY .....	PD- 8	ADJUSTMENT OF SIDE BEARING	
ASSEMBLY OF DIFFERENTIAL CASE .....	PD- 8	SHIMS .....	PD-11
		INSTALLATION .....	PD-13
		REPLACEMENT OF FRONT OIL SEAL .....	PD-13

### DESCRIPTION

The differential carrier on the 620 series has a gear ratio of 4.375.

The drive pinion is mounted in two tapered roller bearings which are preloaded by pinion bearing adjusting spacer and washer during assembly.

The drive pinion is positioned by a washer located between a shoulder of

the drive pinion and the rear bearing.


The differential case is supported in the carrier by two tapered roller side bearings. These are preloaded by inserting shims between the bearings and the differential case. The differential case assembly is positioned for proper ring gear and drive pinion backlash by

varying these shims. The ring gear is bolted to the differential case. The case houses two side gears in mesh with two pinion mates mounted on a pinion shaft. The pinion shaft anchored in the case by lock pin. The pinion mates and side gears are backed by thrust washers.

The carrier is of malleable cast iron.

# PROPELLER SHAFT & DIFFERENTIAL CARRIER

(TYPE H190)



PD229

Fig. PD-6 Cross-sectional view of differential carrier

# PROPELLER SHAFT & DIFFERENTIAL CARRIER

## REMOVAL

1. Jack up rear of vehicle and support it by placing a safety stand under rear axle case. Drain gear oil.
2. Remove propeller shaft and rear axle shafts. These works can be done by referring to "Rear Axle and Rear Suspension".
3. Loosen off bolts securing differential carrier to rear axle case, and take out differential carrier assembly.

## PRE-DISASSEMBLY INSPECTION

Differential carrier should be inspected before any parts are removed from it.

These inspections are helpful to find the cause of a problem and to determine the corrections needed.

1. Mount differential carrier on Differential Attachment ST06310000.




Fig. PD-7 Holding differential carrier

2. Visually inspect parts for wear or damage.
3. Rotate gears to see if there is any roughness which would indicate damaged bearings or chipped gears. Check the gear teeth for scoring or signs of abnormal wear. Measure preload of drive pinion. See Figure PD-19.
4. Set up a dial indicator and check the backlash at several points around ring gear. Backlash should be 0.15 to 0.20 mm (0.0059 to 0.0079 in).
5. Check the gear tooth contact with a mixture of ferric oxide and gear oil to all ring gear teeth.

For the tooth contact pattern, see paragraph dealing with tooth contact pattern adjustment.

## DISASSEMBLY

1. Put match marks on side bearing caps and carrier, and remove side bearing caps and take out differential case assembly.




Fig. PD-8 Removing differential case assembly

Note: Care should be taken not to confuse the left and right hand bearing caps and bearing outer race so that reassembly will be easily carried out with the same parts in the original position.

2. Remove drive pinion nut using Drive Pinion Flange Wrench ST31530000, and pull off companion flange using a standard puller.




Fig. PD-9 Removing drive pinion nut

3. Extract drive pinion assembly to the rearwards by tapping the front end with a soft hammer. Drive pinion can be taken out together with rear bearing inner race, bearing spacer and washer.

4. Remove oil seal and take out front bearing inner race.

Note: Oil seal must not be reused.

5. Hold rear bearing inner race with Drive Pinion Rear Bearing Inner Race Puller ST30031000 and extract from drive pinion with a press.




Fig. PD-10 Removing pinion rear bearing inner race

6. To remove outer races of both front and rear bearing, apply a brass drift to race side surface, and withdraw them by tapping the top of drift with a hammer.




Fig. PD-11 Removing pinion front and rear bearing outer races

## Disassembly of differential case

1. When replacing side bearing, use Differential Side Bearing Puller Set ST3306S001 (set of ST33051001 and ST33061000).




Fig. PD-12 Removing side bearing

# PROPELLER SHAFT & DIFFERENTIAL CARRIER

## Notes:

- Puller should be handled with care in catching the edge of bearing inner race.
  - Be careful not to confuse left and right hand parts.
- Remove ring gear by spreading out lock strap and loosening ring gear bolts in diagonally.
  - Punch off pinion mate shaft lock pin from ring gear side using Solid Punch KV31100300.




Fig. PD-13 Removing lock pin

**Note:** Lock pin is caulked at pin hole mouth on differential case. Do not punch it off forcibly without checking how it is caulked.

- Draw out pinion shaft and remove thrust block, pinion mates, side gears and thrust washers.

**Note:** Put marks on gear and thrust washer so that they can be reinstalled in their original positions from which they were removed.

## INSPECTION

Thoroughly clean all disassembled parts, and examine them to see if they are worn, damaged or otherwise faulty, and how they are affected. Repair or replace all faulty parts, whichever is necessary.

- Check gear teeth for scoring, cracking and chipping, and make sure that tooth contact pattern indicates correct meshing depth. If any fault is evident, replace parts as required.

**Note:** Drive pinion and ring gear are supplied for replacement as a set, therefore, should either part be damaged, replace as a set.

- Check pinion shaft, and pinion mate for scores and signs of wear, and replace as required.

Follow the same procedure for side gear and their seats on differential case.

- Inspect all bearing races and rollers for scoring, chipping or evidence of excessive wear. They should be in tiptop condition such as not worn and with mirror-like surfaces. Replace if there is a shadow of doubt on their efficiency, as an incorrect bearing operation may result in noises and gear seizure.
- Inspect thrust washer faces. Small faults can be corrected with sandpaper. If pinion mate-to-side gear backlash (or the clearance between side gear and thrust washer) exceeds limits 0.02 to 0.08 mm (0.0008 to 0.0031 in), replace thrust washers.
- Inspect carrier and differential case for cracks or distortion. If either condition is evident, replace faulty parts.
- As a general rule, oil seal should be replaced at each disassembly.

## ASSEMBLY AND ADJUSTMENT

Assembly can be done in the reverse order of disassembly. The following directions for adjustment and usage of special tools enable to obtain a perfect differential operation.

## PRECAUTIONS IN REASSEMBLY

- Arrange shims, washers and the like to install them correctly.
- Thoroughly clean the surfaces on which shims, washers, bearings and bearing caps are installed.
- Apply gear oil when installing bearings.
- Pack grease cavity between lips when fitting oil seal.

## ASSEMBLY OF DIFFERENTIAL CASE

- Assemble pinion mates, side gears, thrust block and thrust washers in differential case.
- Fit pinion shaft to differential case so that it meets lock pin holes.
- Adjust pinion mate-to-side gear backlash (or the clearance between the rear face of side gear and thrust washer) to 0.02 to 0.08 mm (0.0008 to 0.0031 in) by selecting side gear thrust washer.

### Side gear thrust washer

Thickness mm (in)
Over 0.75 to 0.80 (0.0295 to 0.0315)
Over 0.80 to 0.85 (0.0315 to 0.0335)
Over 0.85 to 0.90 (0.0335 to 0.0354)
Over 0.90 to 0.95 (0.0354 to 0.0374)

- Lock pinion shaft lock pin using a punch after it is secured into place.
- Apply oil to gear tooth surfaces and thrust surfaces and check if they turn properly.
- Place ring gear on differential case and install bolts and lock washers. Torque bolts to specification, and bend up lock strap.

Tightening torque:

7.0 to 8.0 kg-m  
(51 to 58 ft-lb)

## Notes:

- Use only genuine ring gear bolts and new lock strap.
- Tighten bolts in criss-cross fashion lightly tapping around bolt heads with a hammer.

- When replacing side bearing, measure bearing width using a standard gauge [20.00 mm (0.7874 in) thickness] and a weight block 2.5 kg (5.5 lb) prior to installation. See Figure PD-14.

Standard bearing width:

20.00 mm (0.7874 in)

# PROPELLER SHAFT & DIFFERENTIAL CARRIER




Fig. PD-14 Measuring bearing width

8. Press fit side bearing cone into differential case using Differential Side Bearing Drift ST33230000 and Adapter ST33061000.




Fig. PD-15 Installing side bearing cone

## ADJUSTMENT OF DRIVE PINION HEIGHT

Adjust the pinion height with washer provided between rear bearing inner race and the back of pinion gear.

1. Press fit front and rear bearing outer races into gear carrier using Drive Pinion Outer Race Drift.

Front:

ST30611000 and  
ST30613000

Rear:

ST30611000 and  
ST30621000

2. Fit rear bearing on carrier and install Dummy Shaft ST31942000 and Collar ST31970000 on rear bearing, and place Height Gauge ST31941000 on carrier.




Fig. PD-16 Adjusting pinion height

3. Measure the clearance (N) between the tip end of height gauge and the end surface of dummy shaft, using a thickness gauge.




Fig. PD-17 Measuring clearance

4. The thickness of drive pinion height adjusting washers can be obtained from the following formula:

$$T = N - [(H - D' - S) \times 0.01] + 2.18$$

Where,

T : Required thickness of rear bearing adjusting washers (mm).

N : Measured value with thickness gauge (mm).

H : Figure marked on the drive pinion head. See Figure PD-18.

D' : Figure marked on the dummy shaft.

S : Figure marked on the height gauge.

Figures for H, D' and S, are dimensional variations in a unit of 1/100 mm against each standard measurement.




Fig. PD-18 Variation number on drive pinion

## Examples of calculation

Ex. 1 ---

$$N = 0.51 \text{ mm}, H = +2, D' = -1, S = 0$$

$$T = N - [(H - D' - S) \times 0.01] + 2.18$$

$$= 0.51 - [((+2) - (-1) - (0)) \times 0.01] + 2.18$$

$$= 0.51 - [(2 + 1 - 0) \times 0.01] + 2.18$$

$$= 0.51 - [3 \times 0.01] + 2.18$$

$$= 0.51 - 0.03 + 2.18$$

$$= 2.66 \text{ mm}$$

The correct washer is 2.67 mm thick. See following table for drive pinion adjusting washer.

# PROPELLER SHAFT & DIFFERENTIAL CARRIER

Ex. 2 --

$N = 0.68 \text{ mm}$ ,  $H = -3$ ,  $D' = +1$   
 $S = -2$

$$\begin{aligned} T &= N - [(H - D' - S) \times 0.01] \\ &\quad + 2.18 \\ &= 0.68 - [((-3) - (+1) - (-2)) \\ &\quad \times 0.01] + 2.18 \\ &= 0.68 - [(-3 - 1 + 2) \times 0.01] \\ &\quad + 2.18 \\ &= 0.68 - [-2 \times 0.01] + 2.18 \\ &= 0.68 - [-0.02] + 2.18 \\ &= 0.68 + 0.02 + 2.18 \\ &= 2.88 \text{ mm} \end{aligned}$$

The correct washer is 2.88 mm thick.

Ex. 3 --

$N = 0.70 \text{ mm}$ ,  $H = 0$ ,  $D' = 0$   
 $S = 0$

$$\begin{aligned} T &= N - [(H - D' - S) \times 0.01] \\ &\quad + 2.18 \\ &= 0.70 - [(0 - 0 - 0) \times 0.01] \\ &\quad + 2.18 \\ &= 0.70 - [0 \times 0.01] + 2.18 \\ &= 0.70 - 0 + 2.18 \\ &= 0.70 + 2.18 \\ &= 2.88 \text{ mm} \end{aligned}$$

The correct washer is 2.88 mm thick.

**Note:** If values signifying  $H$ ,  $D'$  and  $S$  are not given, regard them as zero and compute. After assembly, check to see that tooth contact is correct. If not, readjust. For the tooth contact pattern, see page PD-12 for Contact Pattern.

## Drive pinion adjusting washer

Thickness mm (in)

2.58 (0.1016)
2.61 (0.1028)
2.64 (0.1039)
2.67 (0.1051)
2.70 (0.1063)
2.73 (0.1075)
2.76 (0.1087)
2.79 (0.1098)
2.82 (0.1110)
2.85 (0.1122)
2.88 (0.1134)
2.91 (0.1146)
2.94 (0.1158)
2.97 (0.1169)
3.00 (0.1181)
3.03 (0.1193)
3.06 (0.1205)
3.09 (0.1217)
3.12 (0.1228)
3.15 (0.1240)
3.18 (0.1252)

5. Fit determined drive pinion adjusting washer in drive pinion, and press fit rear bearing inner race in it, using Base ST30901000.

## ADJUSTMENT OF DRIVE PINION PRELOAD

Adjust the preload of drive pinion with spacer and washer between front and rear bearing inner races.

This procedure has nothing to do with thickness of drive pinion adjusting washer.

This adjustment must be carried out without oil seal inserted.

1. Lubricate pinion front and rear bearings. Install drive pinion in gear carrier. Be sure that spacer, washer, front bearing inner race, companion flange and flat washer are fitted on pinion. Tighten nut to specified torque and confirm preload.

Tightening torque:  
 14.0 to 17.0 kg-m  
 (101 to 123 ft-lb)


**Note:** Replace bearing washer and spacer with thicker ones if pinion cannot be turned by hand while it is being tightened.

2. Measure pinion bearing preload using Preload Gauge ST3127S000 and select washer and spacer that will provide required preload.

Preload (without oil seal):  
 10.0 to 13.0 kg-cm  
 (8.7 to 11 in-lb)

At companion flange bolt hole:  
 2.9 to 3.7 kg  
 (6.4 to 8.2 lb)

**Note:** Preload of old bearing is the same value as that of a new bearing.



PD236

Fig. PD-19 Measuring pinion preload

## Pinion bearing adjusting spacer

Length mm (in)

54.50 (2.1457)
54.80 (2.1575)
55.10 (2.1693)
55.40 (2.1811)
55.70 (2.1929)
56.00 (2.2047)



# PROPELLER SHAFT & DIFFERENTIAL CARRIER

## Drive pinion bearing adjusting washer

	Thickness mm (in)
over 3.80 to 3.82 (0.1496 to 0.1504)	
over 3.82 to 3.84 (0.1504 to 0.1512)	
over 3.84 to 3.86 (0.1512 to 0.1520)	
over 3.86 to 3.88 (0.1520 to 0.1528)	
over 3.88 to 3.90 (0.1528 to 0.1535)	
over 3.90 to 3.92 (0.1535 to 0.1543)	
over 3.92 to 3.94 (0.1543 to 0.1551)	
over 3.94 to 3.96 (0.1551 to 0.1559)	
over 3.96 to 3.98 (0.1559 to 0.1567)	
over 3.98 to 4.00 (0.1567 to 0.1575)	
over 4.00 to 4.02 (0.1575 to 0.1583)	
over 4.02 to 4.04 (0.1583 to 0.1591)	
over 4.04 to 4.06 (0.1591 to 0.1598)	
over 4.06 to 4.08 (0.1598 to 0.1606)	
over 4.08 to 4.10 (0.1606 to 0.1614)	

3. Check and adjust tooth contact pattern when former adjustment of bearing preload is completed. Unless anything wrong is found, remove drive pinion nut and companion flange and press new oil seal into gear carrier using Oil Seal Fitting Tool KV381025S0. Apply grease cavity between seal lips.

4. Again install companion flange and washer, and tighten nut to specified torque 14.0 to 17.0 kg-m (101 to 123 ft-lb)

5. Measure preload again.

Preload (with oil seal):  
11.0 to 14.0 kg-cm  
(9.5 to 12 in-lb)

At companion flange bolt hole:  
3.1 to 4.0 kg  
(6.8 to 8.8 lb)

## ADJUSTMENT OF SIDE BEARING SHIMS

1. If hypoid gear set, carrier, differential case or side bearing has been replaced with new one, adjust the side bearing preload with adjusting shim.

The required thickness of adjusting shim can be calculated by the following formulas.

$$T_1 = (A - C + D - H') \times 0.01 + 0.175 + E$$

$$T_2 = (B - D + H') \times 0.01 + 0.150 + F$$

Where,

$T_1$  : Required thickness of left side bearing adjusting shim (mm);

$T_2$  : Required thickness of right side bearing adjusting shim (mm).

A : Figure marked on the left side bearing housing of gear carrier.

B : Figure marked on the right side bearing of gear carrier.

C & D : Figure marked on the differential case.

E & F : These are differences in width of left or right side bearing against the standard width (20.00 mm) (mm).

If bearing width is 19.89, the difference will be as follows:

$$20.00 - 19.89 = 0.11$$

$H'$  : Figure marked on the ring gear.  
See Figures PD-20 and PD-21.

Figures for A, B, C, D and  $H'$  are dimensional variations in a unit of 1/100 mm against each standard measurement.




Fig. PD-20 Thickness of shim on left and right sides




Fig. PD-21 Variation number on ring gear

## Examples of calculation

Ex. 1 --

$$\begin{aligned} A &= 1, B = 2, C = 2, D = 3 \\ E &= 0.11 \text{ mm}, F = 0.15 \text{ mm} \\ H' &= -2 \end{aligned}$$

Left side:

$$\begin{aligned} T_1 &= (A - C + D - H') \times 0.01 + 0.175 + E \\ &= (1 - 2 + 3 - (-2)) \times 0.01 + 0.175 + 0.11 \\ &= (1 - 2 + 3 + 2) \times 0.01 + 0.175 + 0.11 \\ &= 4 \times 0.01 + 0.175 + 0.11 \\ &= 0.04 + 0.175 + 0.11 \\ &= 0.325 \text{ mm} \end{aligned}$$

The correct shims are as follows:

Thickness	Quantity	
0.07	x 2	= 0.14
0.20	x 1	= 0.20
Total thickness		= 0.34 mm

Right side:

$$\begin{aligned} T_2 &= (B - D + H') \times 0.01 + 0.150 + F \\ &= (2 - 3 + (-2)) \times 0.01 + 0.150 + 0.15 \\ &= (2 - 3 - 2) \times 0.01 + 0.150 + 0.15 \\ &= -3 \times 0.01 + 0.150 + 0.15 \\ &= -0.03 + 0.150 + 0.15 \\ &= 0.27 \text{ mm} \end{aligned}$$

The correct shims are 0.07 plus 0.20 mm thick.

# PROPELLER SHAFT & DIFFERENTIAL CARRIER

Ex. 2 —

A = 0, B = 3, C = 1, D = 0  
E = 0.20 mm, F = 0.17 mm  
H' = 2

Left side:

$$\begin{aligned} T_1 &= (A - C + D - H') \times 0.01 \\ &\quad + 0.175 + E \\ &= (0 - 1 + 0 - (+2)) \times 0.01 \\ &\quad + 0.175 + 0.20 \\ &= (0 - 1 + 0 - 2) \times 0.01 \\ &\quad + 0.175 + 0.20 \\ &= -3 \times 0.01 + 0.175 + 0.20 \\ &= -0.03 + 0.175 + 0.20 \\ &= 0.345 \text{ mm} \end{aligned}$$

The correct shims are 0.05 plus 0.10 plus 0.20 mm thick.

Right side:

$$\begin{aligned} T_2 &= (B - D + H') \times 0.01 \\ &\quad + 0.150 + F \\ &= (3 - 0 + (+2)) \times 0.01 \\ &\quad + 0.150 + 0.17 \\ &= (3 - 0 + 2) \times 0.01 \\ &\quad + 0.150 + 0.17 \\ &= 5 \times 0.01 + 0.150 + 0.17 \\ &= 0.05 + 0.150 + 0.17 \\ &= 0.37 \text{ mm} \end{aligned}$$

The correct shims are 0.07 plus 0.10 plus 0.20 mm thick.

**Note:** If values signifying A, B, C, D and H' are not given, regard them as zero and compute. After assembly, check to see that preload and backlash are correct. If not, readjust.

Side bearing adjusting shim

Thickness mm (in)
0.05 (0.0020)
0.07 (0.0028)
0.10 (0.0039)
0.20 (0.0079)
0.50 (0.0197)

2. Fit determined side bearing adjusting shim on differential case, and press fit left and right side bearing inner races on it, using Side Bearing Drift ST33230000 and Adapter ST33061000.

3. Install differential case assembly into gear carrier, tapping with a rubber mallet.

4. Align mark on bearing cap with that on gear carrier, and install bearing cap on carrier. And tighten bolts to specified torque.

Tightening torque:  
4.0 to 5.0 kg-m  
(29 to 36 ft-lb)

5. Measure ring gear-to-drive pinion backlash.

If backlash is too small, remove shims from left side and add them to right side. To reduce backlash, remove shims from right side and add them to left side.

Backlash:  
0.15 to 0.20 mm  
(0.0059 to 0.0079 in)




Fig. PD-22 Measuring backlash

6. At the same time, check side bearing preload. Bearing preload should read 12.0 to 20.0 kg-cm (10 to 17 in-lb) of rotating torque, [3.5 to 5.8 kg (7.7 to 12.8 lb) at ring gear bolt hole].

If preload does not accord with this specification, adjust it with side bearing shims.

7. Check and adjust the tooth contact pattern of ring gear and drive pinion.

(1) Thoroughly clean ring and drive pinion gear teeth.

(2) Paint ring gear teeth lightly and evenly with a mixture of ferric oxide and gear oil to produce a contact pattern.

(3) Rotate pinion through several revolutions in the forward and reverse directions until a definite contact pattern is developed on ring gear.

(4) When contact pattern is incorrect, readjust thickness of adjusting washer.

(5) Incorrect contact pattern of teeth can be adjusted in the following manner.

a. Heel contact

To correct, increase thickness of pinion height adjusting washer in order to bring drive pinion close to ring gear.




Fig. PD-23 Heel contact

b. Toe contact

To correct, reduce thickness of pinion height adjusting washer in order to make drive pinion go away from ring gear.





Fig. PD-24 Toe contact

# PROPELLER SHAFT & DIFFERENTIAL CARRIER

## c. Flank contact

Adjust in the same manner as in b.




PD195

Fig. PD-25 Flank contact

## d. Face contact


Adjust in the same manner as in a.



PD196

Fig. PD-26 Face contact

## e. Correct tooth contact



PD197

Fig. PD-27 Correct contact

## INSTALLATION

Installing can be done in the reverse order of removal.

### Tightening torque:

Gear carrier to rear axle case:


1.7 to 2.5 kg-m  
(12 to 18 ft-lb)

Drain and filler plug:

6.0 to 10.0 kg-m  
(43 to 72 ft-lb)

Gear oil capacity: 1.0 liter

(2  $\frac{1}{4}$  US pt, 1  $\frac{1}{4}$  Imp pt)



PD238

Fig. PD-29 Removing companion flange

## REPLACEMENT OF FRONT OIL SEAL

Replacement of front oil seal with differential carrier assembly installed on the vehicle.

When replacing front oil seal, do as follows:

1. Drain gear oil.
2. Raise the rear end of vehicle and support it with safety stands.
3. Detach propeller shaft from companion flange of carrier.
4. Remove drive pinion nut, holding companion flange with Drive Pinion Flange Wrench ST31530000.

6. Remove oil seal.

7. Set new oil seal in position using Oil Seal Fitting Tool KV381025S0. Apply grease in between seal lips.

8. Fit companion flange and flat washer on drive pinion, and secure them in position by tightening nut to the given torque confirming specified preload, using Drive Pinion Flange Wrench ST31530000.

### Tightening torque:


14.0 to 17.0 kg-m  
(101 to 123 ft-lb)

Pinion bearing preload  
(with oil seal):

11.0 to 14.0 kg-cm  
(9.5 to 12 in-lb)

At companion flange bolt hole:

3.1 to 4.0 kg  
(6.8 to 8.8 lb)



PD237

Fig. PD-28 Removing drive pinion nut

### Notes:

- a. Preload of old bearing is the same value as that of a new bearing.
- b. If the desired nut tightening torque cannot be obtained, renew nut and readjust.

Note: Change in thickness of adjusting washer is accompanied by change in backlash. Check it when installing gear.

5. Extract companion flange using a standard puller.

8. Reinstall propeller shaft, and fill up differential carrier with gear oil.

# PROPELLER SHAFT & DIFFERENTIAL CARRIER

## TROUBLE DIAGNOSES AND CORRECTIONS

When a differential carrier is suspected of being noisy, it is advisable to make a thorough test to determine whether the noise originates in the

tires, road surface, exhaust, universal joint, propeller shaft, wheel bearings, engine, transmission, or differential carrier. Noise which originates in other

places cannot be corrected by adjustment or replacement of parts in differential carrier.

Condition	Probable cause	Corrective action
Noise on drive, coast and float.	<p>Shortage of oil.</p> <p>Incorrect tooth contact between ring gear and drive pinion.</p> <p>Incorrect backlash between ring gear and drive pinion.</p> <p>Seized up or damaged ring gear and drive pinion.</p> <p>Seized up, damaged or broken drive pinion bearing.</p> <p>Seized up, damaged or broken side bearing.</p> <p>Loose bolts or nuts fixing ring gear, bearing cap, etc.</p>	<p>Supply gear oil. Rebuild gear carrier if necessary.</p> <p>Adjust tooth contact or replace the hypoid gear set.</p> <p>Adjust backlash or replace the hypoid gear set if necessary.</p> <p>Replace the hypoid gear set.</p> <p>Replace the pinion bearing and faulty parts.</p> <p>Replace the side bearing and faulty parts.</p> <p>Clamp them to specified torque, and replace faulty parts.</p>
Noise on turn.	<p>Seized up, damaged or broken side and pinion mate.</p> <p>Seized up, damaged or broken side gear and pinion thrust washer.</p> <p>Pinion mates too tight on their shaft.</p>	<p>Replace faulty parts.</p> <p>Replace faulty parts.</p> <p>Replace faulty parts.</p>
Knocking sound during starting or gear shifting.	<p>Excessive backlash.</p> <p>Incorrect backlash ring gear-to-drive pinion or side gear-to-pinion mate.</p> <p>Worn gears or case.</p> <p>Worn rear axle shaft and side gear spline.</p> <p>Drive pinion bearing under preload.</p> <p>Loose drive pinion nut.</p> <p>Loose bolts or nuts fixing ring gear, bearing cap, etc.</p>	<p>Adjust backlash.</p> <p>Replace worn parts.</p> <p>Replace worn parts.</p> <p>Adjust preload.</p> <p>Repair or replace.</p> <p>Clamp them or replace if necessary.</p>

## PROPELLER SHAFT & DIFFERENTIAL CARRIER

Condition	Probable cause	Corrective action
Seizure of breakage.	<p>Shortage of oil or use of unsuitable oil.</p> <p>Excessively small backlash.</p> <p>Incorrect adjustment of bearings or gears.</p> <p>Severe service due to an excessive loading, improper use of clutch.</p> <p>Loose bolts and nuts, such as ring gear bolts.</p>	<p>Replace faulty parts and use recommended gear oil.</p> <p>Adjust backlash and replace as required.</p> <p>Replace faulty parts.</p> <p>Replace faulty parts.</p> <p>Replace faulty parts.</p>
Oil leakage.	<p>Worn-out, damaged or improperly driven front oil seal, or bruised, dented or abnormally worn slide face of companion flange.</p> <p>Loose gear carrier bolts.</p> <p>Faulty gasket.</p> <p>Loose filler or drain plug.</p> <p>Clogged or damaged breather.</p>	<p>Replace faulty oil seal. Repair the affected flange with sandpaper or replace if necessary.</p> <p>Tighten the bolts to specified torque.</p> <p>Replace faulty gasket with new one.</p> <p>Tighten the plug.</p> <p>Repair or replace.</p>

# PROPELLER SHAFT & DIFFERENTIAL CARRIER

## SERVICE DATA AND SPECIFICATIONS

Type .....	H190
Gear carrier material .....	Malleable cast-iron
Gear ratio (number of teeth) .....	4.375 (35/8)
Drive pinion preload adjusted by .....	Spacer and washer
<b>Drive pinion</b>	
Preload	kg-cm (in-lb)
(without oil seal) .....	10.0 to 13.0 (8.7 to 11)
(with oil seal) .....	11.0 to 14.0 (9.5 to 12)
At companion flange bolt hole	kg (lb)
(without oil seal) .....	2.9 to 3.7 (6.4 to 8.2)
(with oil seal) .....	3.1 to 4.0 (6.8 to 8.8)
Thickness of drive pinion adjusting washer	mm (in)
	2.58 (0.1016)
	2.61 (0.1028)
	2.64 (0.1039)
	2.67 (0.1051)
	2.70 (0.1063)
	2.73 (0.1075)
	2.76 (0.1087)
	2.79 (0.1098)
	2.82 (0.1110)
	2.85 (0.1122)
	2.88 (0.1134)
	2.91 (0.1146)
	2.94 (0.1158)
	2.97 (0.1169)
	3.00 (0.1181)
	3.03 (0.1193)
	3.06 (0.1205)
	3.09 (0.1217)
	3.12 (0.1228)
	3.15 (0.1240)
	3.18 (0.1252)
Length of drive pinion bearing adjusting spacer	mm (in)
	54.50 (2.1457)
	54.80 (2.1575)
	55.10 (2.1693)
	55.40 (2.1811)
	55.70 (2.1929)
	56.00 (2.2047)

## PROPELLER SHAFT & DIFFERENTIAL CARRIER

Thickness of drive pinion bearing adjusting washer	mm (in)	over 3.80 to 3.82 (0.1496 to 0.1504)
		over 3.82 to 3.84 (0.1504 to 0.1512)
		over 3.84 to 3.86 (0.1512 to 0.1520)
		over 3.86 to 3.88 (0.1520 to 0.1528)
		over 3.88 to 3.90 (0.1528 to 0.1535)
		over 3.90 to 3.92 (0.1535 to 0.1543)
		over 3.92 to 3.94 (0.1543 to 0.1551)
		over 3.94 to 3.96 (0.1551 to 0.1559)
		over 3.96 to 3.98 (0.1559 to 0.1567)
		over 3.98 to 4.00 (0.1567 to 0.1575)
		over 4.00 to 4.02 (0.1575 to 0.1583)
		over 4.02 to 4.04 (0.1583 to 0.1591)
		over 4.04 to 4.06 (0.1591 to 0.1598)
		over 4.06 to 4.08 (0.1598 to 0.1606)
		over 4.08 to 4.10 (0.1606 to 0.1614)

### Side gear and pinion mate

Thickness of side gear thrust washer	mm (in)	over 0.75 to 0.80 (0.0295 to 0.0315)
		over 0.80 to 0.85 (0.0315 to 0.0335)
		over 0.85 to 0.90 (0.0335 to 0.0354)
		over 0.90 to 0.95 (0.0354 to 0.0374)

Pinion mate-to-side gear backlash (or clearance between side gear and thrust washer)

mm (in)	0.02 to 0.08 (0.0008 to 0.0031)
---------	---------------------------------

### Ring gear

Ring gear-to-drive pinion backlash	mm (in)	0.15 to 0.20 (0.0059 to 0.0079)
Thickness of side bearing adjusting shim	mm (in)	0.05 (0.0020)
		0.07 (0.0028)
		0.10 (0.0039)
		0.20 (0.0079)
		0.50 (0.0197)
Side bearing standard width	mm (in)	20.00 (0.7874)

### Tightening torque

	kg-m (ft-lb)
Drive pinion nut	14.0 to 17.0 (101 to 123)
Ring gear bolt	7.0 to 8.0 (51 to 58)
Side bearing cap bolt	4.0 to 5.0 (29 to 36)
Differential carrier to axle case	1.7 to 2.5 (12 to 18)
Companion flange of front shaft and flange yoke connecting nut	2.4 to 3.3 (17 to 24)
Center bearing bracket nut	1.6 to 2.2 (12 to 16)
Companion flange to propeller shaft	2.4 to 3.3 (17 to 24)
Oil drain and filler plug	6.0 to 10.0 (43 to 72)

## PROPELLER SHAFT & DIFFERENTIAL CARRIER

Oil capacity (about)                      liter (US pt, Imp pt) ..... 1.0 (2  $\frac{1}{8}$ , 1  $\frac{1}{4}$ )

### Adjusting methods

Variable numbers expressed by ..... 1/100 mm

Dummy shaft ..... Use

Drive pinion adjusting formula .....  $T = N - [(H - D' - S) \times 0.01] + 2.18$






Side bearing adjusting formula .....  $T_1 = (A - C + D - H') \times 0.01$   
+ 0.175 + E

$T_2 = (B - D + H') \times 0.01 + 0.150 + F$



# PROPELLER SHAFT & DIFFERENTIAL CARRIER





## SPECIAL SERVICE TOOLS

No.	Tool number & tool name	Description Unit: mm (in)	For use on	Reference page or Figure No.
1.	ST06310000 Diff. attachment	This tool is used for attaching gear carrier to ease disassembly or assembly.  SE023	620 610	Fig. PD-7
2.	ST3194S000 Drive pinion setting gauge assembly (H190)  ST31942000 Dummy shaft  ST31941000 Height gauge	These tools are used to adjust the pinion height.  SE209  SE210	620 610	Fig. PD-16 Fig. PD-17
3.	ST31970000 Collar	This tool is used for Type H190 to adjust the pinion height. This tool is used with ST3194S000. 	620 610	Fig. PD-16
4.	KV31100300 Solid punch	For driving out of lock pin of pinion shaft. 	620 610 710 S30	Fig. PD-13

## PROPELLER SHAFT & DIFFERENTIAL CARRIER

No.	Tool number & tool name	Description  Unit: mm (in)	For use on	Reference page or Figure No.
5.	<p>Drive pinion outer race drift</p> <p>ST30611000 Bar</p> <p>ST30613000 Adapter</p> <p>ST30611000 Bar</p> <p>ST30621000 Adapter</p>	<p>These tools are used when assembling drive pinion outer race.</p>	620 610	Page PD-9
6.	<p>ST3090S000 Drive pinion rear bearing inner race puller</p> <p>ST30031000 Puller</p> <p>ST30901000 Base</p>	<p>This assembly clamps rear bearing inner race and pulls it out by a hydraulic press. Before insertion, place another drift facing inner race, and then press-fit.</p>	620 610 S30	Fig. PD-10 Page PD-10
7.	<p>KV381025S0 Oil seal fitting tool</p> <p>ST30720000 Drift</p> <p>KV38102510 Drift</p>	<p>For installing the front oil seal.</p>	620 610	Page PD-11 Page PD-13

# PROPELLER SHAFT & DIFFERENTIAL CARRIER

No.	Tool number & tool name	Description Unit: mm (in)	For use on	Reference page or Figure No.
8.	ST31530000 Drive pinion flange wrench	<p>This tool is used to hold the flange to ease the operation of tightening and loosening drive pinion nut.</p> 	620 B210 610 710 S30	Fig. PD-5 Fig. PD-9 Fig. PD-28
9.	ST3127S000 Preload gauge 1. GG91030000 Torque wrench 2. HT62940000 Socket adapter 3. HT62900000 Socket adapter	<p>This tool is used to measure the preload of pinion bearing.</p> 	All models	Fig. PD-19
10.	ST3306S001 Diff. side bearing puller set ST33051001 Diff. side bearing puller ST33061000 Adapter	<p>This tool is used to pull out side bearing.</p> 	620 610 S30	Fig. PD-12 Fig. PD-15
11.	ST33230000 Diff. side bearing drift	<p>Use of this tool makes it possible to drive in bearing without damaging it.</p> 	620 610	Fig. PD-15

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

## SECTION FA

### FRONT AXLE & FRONT SUSPENSION

FA


FRONT AXLE AND FRONT SUSPENSION .....	FA- 2
SERVICE DATA AND SPECIFICATIONS .....	FA-13
TROUBLE DIAGNOSES AND CORRECTIONS .....	FA-14
SPECIAL SERVICE TOOLS .....	FA-17

# FRONT AXLE AND FRONT SUSPENSION

## CONTENTS

GENERAL DESCRIPTION .....	FA-2	REMOVAL AND INSTALLATION .....	FA- 8
FRONT AXLE .....	FA-3	INSPECTION .....	FA- 9
REMOVAL AND INSTALLATION .....	FA-3	TORSION BAR SPRING .....	FA- 9
WHEEL BEARING ADJUSTMENT .....	FA-4	REMOVAL AND INSTALLATION .....	FA- 9
DISASSEMBLY AND ASSEMBLY .....	FA-4	INSPECTION .....	FA- 9
INSPECTION .....	FA-5	UPPER AND LOWER LINKS .....	FA-10
SHOCK ABSORBER .....	FA-8	REMOVAL AND INSTALLATION .....	FA-10
REMOVAL AND INSTALLATION .....	FA-8	DISASSEMBLY AND ASSEMBLY .....	FA-11
INSPECTION .....	FA-8	INSPECTION .....	FA-11
STABILIZER .....	FA-8	ADJUSTMENT .....	FA-11
REMOVAL AND INSTALLATION .....	FA-8	VEHICLE POSTURE .....	FA-11
INSPECTION .....	FA-8	WHEEL ALIGNMENT .....	FA-12
TENSION ROD .....	FA-8	STEERING ANGLE .....	FA-12

## GENERAL DESCRIPTION



FA224

Fig. FA-1 Sectional view of front axle and front suspension

The design of the front suspension adopts the independent double-wishbone type suspension used the torsion bar spring. Both the upper and lower links are installed on the bracket which is welded on the frame. And the above links swing to allow the knuckle spindle to move freely in a vertical dimension.

The top and bottom of the knuckle spindle support are connected to the upper link through rubber bushing and to the lower link through screw bushing.

The tension rod held by the brackets on the chassis frame and lower link with rubber bushings, bears the force of fore and aft direction.

The front end of the torsion bar spring is installed to the torque arm which attaches to the lower link. The opposite end is installed to the spring anchor that secures to chassis frame firmly. The both ends of the torsion bar spring are serrated.

The shock absorber is double-action, telescopic hydraulic type.

The upper stem is attached to the bracket of the chassis frame. The lower insulated bracket is bolted to the lower link.

The bumper rubber secured to the bracket of the frame, limits the vertical motion of the suspension link.

The knuckle spindle is connected to the knuckle spindle arm by the king pin. The king pin bushings are fitted to the upper and lower arm portions of the knuckle spindle, and seals are provided at the portions mentioned to keep water and dirt from entering.

The knuckle arm is connected to the lower end of the knuckle spindle to transmit the movement of the steering wheel to the knuckle spindle.

The wheel hub is supported by two taper roller bearings on the knuckle spindle. The brake drum and wheel are secured to the hub by the hub bolts.

## FRONT AXLE

### REMOVAL AND INSTALLATION

#### Removal

1. Jack up and support vehicle on the stands at the frame in a safe manner.
2. Remove front wheel.
3. Remove brake hose together with connector from wheel cylinder.
4. Remove brake drum.
5. Remove hub cap and then remove cotter pin, adjusting cap, and spindle nut from knuckle spindle.
6. Remove wheel hub, outer and inner wheel bearings, bearing washer and grease seal from knuckle spindle.
7. Remove brake disc assembly from the flange of knuckle spindle.
8. Remove knuckle arm from knuckle spindle.
9. Remove king pin lock bolt.




Fig. FA-2 Removing king pin lock nut

10. After removing air breather, remove plug from the top of king pin with the following method: Drill a 10.5 mm (0.413 in) diameter hole on the plug, thread hole with a tap (M12-1.25), screw a bolt into threaded hole and pull out the plug.
11. Apply drift to the top of king pin and drive out king pin along with lower plug.
12. Tap spindle with a soft hammer and detach it from knuckle spindle support. Take care not to drop thrust bearing.




Fig. FA-3 Removing knuckle spindle

#### Installation

Install front axle in reverse sequence to removal by noting the following matters. Furthermore, when installing front axle, lightly coat grease to sliding parts.

1. Insert O-ring on the lower end of knuckle spindle support. Install thrust bearing and spindle shim together with knuckle spindle to knuckle spindle support.

In this operation, select spindle shims to obtain the specified clearance between knuckle spindle and knuckle spindle support. To measure the clearance with a filler gauge, jack up the bottom of spindle slightly.

Standard clearance:

0.1 mm (0.004 in) or less

**Note:** Be sure to install thrust bearing to face covered side upward.

2. Line up locking bolt hole of knuckle spindle support with the notch in king pin and secure lock bolt. Be sure to check knuckle spindle for smooth movement. Be certain to move knuckle spindle smoothly and readjust shim if necessary. In addition, check bushings and king pin as required.
3. Press fit plug to the upper of knuckle spindle. Then, install lower plug to the lower knuckle spindle.

**Note:** Make sure to place lower plug correctly.

4. Secure knuckle arm to knuckle


## Front Axle & Front Suspension

spindle and torque bolt to 10.3 to 12.1 kg-m (75 to 88 ft-lb). Bend lock plate to engaged flats on bolt head.

**Note:** When disassembled, discard used lock plate.

5. Pack grease to the upper and lower bushings on knuckle spindle until grease comes out from grease seal.

6. Fill wheel hub and cap with grease up to the described level. See Figure FA-4.



FA141

Fig. FA-4 Greasing wheel hub

7. Pack roller and cone assembly and the cavity of grease seal lip with grease.

8. Coat grease to the thread of knuckle spindle, bearing washer, and bearing lock nut.

9. Secure wheel hub, bearings, bearing washer and spindle nut on knuckle spindle and adjust bearing preload referring to the paragraph "Wheel bearing adjustment."


**Note:** Be sure to obtain correct preload on wheel bearings for the purpose of having their long life, taking care to keep wheel bearings, grease seal, bearing washer and spindle nut clean when installing them.

### WHEEL BEARING ADJUSTMENT

Wrong adjustment of wheel bearings causes abnormal wear and score on the bearings and knuckle spindle.

To attain proper preload on wheel bearings, proceed the following operations:

1. Torque spindle nut to 3.0 to 3.5 kg-m (22 to 25 ft-lb) using torque wrench.



FA227

Fig. FA-5 Tightening spindle nut

2. Rotate wheel hub a few turns clockwise and counterclockwise to seat bearings. Then, retighten spindle nut to the same tightening torque. Be certain to rotate hub smoothly.

3. Back off spindle nut in range from 40 to 70 degrees. Locate adjusting cap on spindle nut so as to align the castellation on the cap with the cotter pin hole in the spindle.

4. Check the hub rotation. If hub rotates properly, measure bearing rotation starting torque. If measured torque is deviated from the specified value, replace bearings or readjust.

The starting torque can be measured by a spring balance as shown in Figure FA-6.

Spring balance indication at hub bolt:

New bearing:


2.1 kg (4.6 lb) or less

Used bearing:

1.0 kg (2.2 lb) or less

#### Notes:

- When measuring the starting force, pull the spring balance toward tangential direction against normal line connected between hub bolt and spindle center.
- Axial play is permissible to exist in 0.1 mm (0.004 in) or less.



FA228

Fig. FA-6 Measuring bearing rotation starting torque


5. Install a new cotter pin. Bend the ends of cotter pin around the castellated flange of adjusting cap. Then, install hub cap.

## DISASSEMBLY AND ASSEMBLY

### Knuckle spindle

1. Drive spindle bushing and grease seal out of knuckle spindle with King Pin Bush Drift ST35380000. Discard bushing and grease seal when disassembled.

2. After cleaning king pin bores thoroughly, install bushing carefully by using the above special tool. Position bushing in accordance with the instructions filled in Figure FA-7 and FA-8.



FA229

Fig. FA-7 King pin bushing




Fig. FA-8 Bushing location

3. Remove grease nipple and drill grease hole on bushing through threaded grease nipple hole. When grease hole is drilled, remove metal chip and burr thoroughly.

Drilling diameter:

approximate 3 mm (0.118 in)

**Note:** When a spindle bushing has a grease nipple hole in it, an additional hole need not be drilled. When pressing it into position, align grease nipple hole with that in spindle bushing.

4. Ream the inside of bushing to the specified value with King Pin Bush Reamer HT56802000.

Bushing inner diameter

(when fitted):

20.010 to 20.035 mm

(0.7878 to 0.7888 in)

**Note:** Carry out reaming from both upper and lower bushings. When reaming upper side, use lower side as reaming guide, and when reaming lower side, use upper side as reaming guide to align the center line correctly.

5. Press fit grease seal on upper arm with King Pin Grease Seal Drift ST35390000. In installing grease seal, take care not to damage seal lip.

ST35390000




Fig. FA-9 Installing grease seal

## Wheel hub

1. After removing grease seal with screwdriver, lightly tap outer race circumference with a hammer by applying a brass bar and remove outer bearing race from hub. When tapping outer race circumference, tap evenly.
2. Remove all traces of old grease from bearings, hub and knuckle spindle.
3. Install inner and outer bearing races in hub with a suitable tool. Be sure to seat the races properly in hub.
4. Pack the inside of hub and hub cap with specified grease to the described level. See Figure FA-4. Also, pack the bearing cone and roller assemblies with the same lubricant.



Fig. FA-10 Greasing bearing cone and roller assembly

5. Place inner bearing cone and roller assembly in hub. Coat grease slightly to the lips of new grease seal, and seat it properly.

## INSPECTION

### 1. King pin and bushing

Check and replace king pin and/or bushing if the following faulty condition is detected; deformation, scores, partial wear, and excessive clearance between king pin and bushing in diameter direction exceeding limit listed below.

Clearance limit:

0.15 mm (0.0059 in)

Standard dimensions

King pin outer diameter:

19.979 to 20.000 mm

(0.7866 to 0.7874 in)

Bushing inner diameter:

20.010 to 20.035 mm


(0.7878 to 0.7888 in)

### 2. Wheel bearing

Thoroughly clean grease and dirt from wheel bearing with cleaning solvent, and dry with compressed air free of moisture. Check wheel bearing to see that it rolls freely and is free from noise, crack, pitting, or wear. Also, check outer race for condition. Removal of outer race from drum is not necessary.

Shown below is the chart which furnishes the necessary information on "Visual Serviceability Standard for Wheel Bearing."

## Visual serviceability standard for wheel bearing



- 1 Outer race
- 2 Roller
- 3 Small collar
- 4 Inner race fitted surface
- 5 Collar surface
- 6 Inner race surface
- 7 Outer race fitted surface
- 8 Outer race surface
- 9 Roller rolling surface
- 10 Inner race
- 11 Large collar
- 12 Supporter

Fig. FA-11 Wheel bearing assembly



## Front Axle & Front Suspension

Judgement	X : Unserviceable △ : May be used when minor * : Rust should be removed with #0 emery paper			
	Race and roller		Supporter	Cause
Components	Rolling surface	Fitted surface		
Flaking  (Fig. a, b)	X			Service life due to rolling fatigue. However, this symptom occurs before the service life. The following causes are considered. <ul style="list-style-type: none"> <li>● Abnormal load (overload).</li> <li>● Improper handling or installing.</li> </ul>
Crack  (Fig. c, d)	X	X	X	<ul style="list-style-type: none"> <li>● Excessive tightening.</li> <li>● Excessive gap and a considerable shock received from the outside.</li> <li>● Rapid heat generation on the race due to creep.</li> <li>● Bitten supporter with seizing rollers.</li> <li>● Abnormal thrust load.</li> <li>● Tapped with a hammer while removing.</li> </ul>
Seizure	X	X	X	In the most cases, seizure occurs as the result of grown discoloring or flaking.
Scratch	△	△	△	<ul style="list-style-type: none"> <li>● Shock is given carelessly during installation.</li> <li>● Bit foreign matter.</li> </ul>
Recess or wear made by pressing or striking (Fig. e, f, g)	△	△	△	<ul style="list-style-type: none"> <li>● Careless installation, removal, or other rough handling (scar due to striking).</li> <li>● Recess made by foreign matter.</li> </ul>
Wear	△	△	△	<ul style="list-style-type: none"> <li>● Poor lubricant quality or deteriorated lubricant.</li> <li>● Intrusion of dust. Fitted surface is worn remarkably.</li> <li>● Wear due to excessive preliminary pressure.</li> </ul>
Biting	△	△	△	<ul style="list-style-type: none"> <li>● Excessive preliminary pressure or faulty lubrication.</li> </ul>
Fretting	△*	△*	△*	<ul style="list-style-type: none"> <li>● The fitted part is discolored to brown or black.</li> <li>● Fretting corrosion (rust on fitted part) means fine relative slip on metal contact surface.</li> </ul>

## Front Axle & Front Suspension


Components	Race and roller		Supporter	Cause
	Rolling surface	Fitted surface		
Rust  (Fig. h)	△*	△*	△*	<ul style="list-style-type: none"> <li>• Temperature increased during operation lowers when the bearing stops, moisture inside the bearing is condensed, becoming fine drips, and the grease is moistened.</li> <li>• The bearing has been placed in a highly moistened place for a long period of time.</li> <li>• Intrusion of moisture, chemicals, etc., or the bearing is touched with bare hand and no rustproof action has been taken.</li> </ul>
Discoloring	The wheel bearing is serviceable if discoloring can be removed with solvent or by polishing.			<ul style="list-style-type: none"> <li>• Slight discoloring may become like oxidized oil stain due to grease.</li> <li>• In the most cases, this occurs when preliminary pressure is too high.</li> </ul>




a) Inner race flaking



b) Roller flaking




c) Cracked inner race




d) Cracked roller




e) Recess on inner race



f) Recess on outer race



g) Recess on roller



h) Rust outer race


FA007

Fig. FA-12 Defective conditions of bearing

## SHOCK ABSORBER

### REMOVAL AND INSTALLATION

1. Raise vehicle on a hoist or stands.
2. Remove wheel.
3. Hold the upper stem of shock absorber and remove nuts, washer, and rubber bushing.
4. Remove bolt from the lower end of shock absorber.



FA232

Fig. FA-13 Shock absorber

5. Retain lower rubber bushing in position, install the lower end of shock absorber to the bracket of lower link, and torque the bolt to 3.1 to 4.1 kg-m (23 to 30 ft-lb).

**Note:** Insert the bolt from the front side of vehicle.

6. Install the upper end of shock absorber to body bracket and tighten lock nuts to the specifications.

Tightening torque:

1.6 to 2.2 kg-m (12 to 16 ft-lb)

### INSPECTION

1. Check shock absorber for visible defects and oil leaks. Place shock absorber vertically in a vise, and hand stroke shock absorber as outlined below:

Extend and compress shock absorber as far as possible, travelling as long as possible.

If smooth hydraulic resistance is not present in both direction, replace absorber.

2. Replace rubber bushing if crack or deterioration is detected.

### Specifications for shock absorber

Model		All models
Item		
Piston stroke	mm (in)	110 (4.3)
Damping force	kg (lb) [0.3 m/sec. (0.98 ft/sec.)]	
Rebound		76 (168)
Compression		38 (84)


## STABILIZER

### REMOVAL AND INSTALLATION

1. Raise vehicle on a hoist or stands.
2. Remove wheel.
3. Loosen securing nut at the lower link side of stabilizer.
4. Remove bolt securing stabilizer mounting bracket to chassis frame.

Install stabilizer in the reverse sequence to removal, noting the following instructions.

5. Attach stabilizer mounting bracket to chassis frame, tightening bolt to 1.6 to 2.2 kg-m (12 to 16 ft-lb) torque.
6. Install stabilizer lower link side to connecting rod and tighten nut to the specifications as shown in Figure FA-14. Then, torque lock nut to 1.6 to 2.2 kg-m (12 to 16 ft-lb).



FA233

Fig. FA-14 Stabilizer detail

### INSPECTION


Check stabilizer for deformation

and rubber bushings for crack, wear and deterioration. Replace if necessary.

## TENSION POD

### REMOVAL AND INSTALLATION

1. Raise vehicle on a hoist or stands.
2. Remove wheel.
3. Remove nuts ① from both ends of tension rod.
4. Remove bracket bolt ② from the front end of tension rod, and remove tension rod with bracket.



FA234


Fig. FA-15 Tension rod

Install tension rod in reverse sequence to removal, noting the following instructions.

## Front Axle & Front Suspension

5. Install tension rod at rear end, tighten nut to make the distance of rubber bushing to be 33.4 mm (1.315 in), and torque lock nut to 1.6 to 2.2 kg-m (12 to 16 ft-lb).
6. Install tension rod bracket to chassis frame bracket and torque nut to 1.6 to 2.2 kg-m (12 to 16 ft-lb).

When two rubber bushings are different in size, arrange adjusting nut. Standard dimension is 11.0 mm (0.433 in) as shown in Figure FA-16. Torque lock nut to 1.6 to 2.2 kg-m (12 to 16 ft-lb).



Unit: mm (in)

FA235

Fig. FA-16 Tension rod detail

### INSPECTION

1. Check tension rod for bend and the thread for faulty condition. Repair or replace as required.
2. Check bushing rubber for wear and deterioration. Replace if necessary.

## TORSION BAR SPRING

### REMOVAL AND INSTALLATION

#### Removal

1. Raise vehicle on a hoist or stands.
2. Remove wheel.
3. Loosen nuts at spring anchor bolt.

4. Remove dust cover at the rear end of torsion bar spring and detach snap ring.

5. Withdraw torsion bar spring rearward after pulling out anchor arm rearward.

### Installation

Install torsion bar spring in the reverse sequence of removal, noting the following instructions.

1. Coat grease on the serrations of torsion bar spring and install it to torque arm.

**Note:** Be sure to install right and left torsion bar springs correctly. They can be identified with "R" (Right) and "L" (Left) marked on the end surface.

2. Install anchor arm and tighten adjusting nut to obtain "A" dimension. See Figure FA-17. When anchor arm is properly adjusted to "A" specification, upper link should be in contact with rebound bumper rubber. See Figure FA-18. Install snap ring and dust cover. Temporarily tighten adjusting nut until "B" specification is reached.




Fig. FA-17 Installing anchor arm

Anchor arm setting position "A":

15 to 25 mm  
(0.59 to 0.98 in)

Temporary tightening distance "B":

60 to 70 mm  
(2.36 to 2.76 in)




Fig. FA-18 Setting procedure

#### Notes:

- a. "A" and "B" specifications are only the preliminary rough settings; directions for performing the final adjustment that determines the ride height are found on page FA-11 under "Adjustment".
- b. Discard old snap ring after removing it. Replace with new one during reinstallation.

3. Install wheel and lower vehicle. Adjust vehicle posture at curb weight (full fuel tank, no passengers), referring to "Adjustment".

4. Torque lock nut to 3.1 to 4.1 kg-m (22 to 30 ft-lb).

### INSPECTION

Check torsion bar spring for wear, twist, etc. When adjusting vehicle posture, replace torsion bar spring with a new one if the specified height can not be obtained.

#### Specifications for torsion bar spring

Item	Model	All models
Diameter x length	mm (in)	21.9 x 830 (0.862 x 32.68)
Torsional rigidity	kg-m/deg. (ft-lb/deg.)	3.74 (27.1)

## UPPER AND LOWER LINKS

### REMOVAL AND INSTALLATION

#### Removal

1. Raise vehicle on a hoist or stands.
2. Remove wheel and brake drum as an assembly.
3. Remove wheel hub. Refer to section "Front Axle."
4. Loosen bolts retaining brake disc to knuckle spindle and remove brake disc.
5. Remove knuckle arm, torsion bar spring, stabilizer, shock absorber, and tension rod in this order referring the related sections.
6. Remove upper fulcrum bolt securing knuckle spindle support to upper link assembly and disassemble them.
7. Remove upper link bushings from knuckle spindle support.
8. Remove screw bushings from both ends of lower link fulcrum pin.
9. Loosen nut at lower portion of knuckle spindle support from inside and pull out cotter pin retaining fulcrum pin.
10. Pull out fulcrum pin with drift and remove knuckle spindle support with knuckle spindle from lower link. Then, detach dust cover.




Fig. FA-19 Removing fulcrum pin

11. Remove bolts retaining upper link spindle and remove upper link spindle with camber adjusting shims from body bracket.




Fig. FA-20 Removing upper link spindle

12. Remove nut retaining lower link spindle and remove lower link spindle. Remove lower link with torque arm from mounting bracket.
13. Using Transverse Link Bushing Replacer ST36070000 to lower link bushing, tap it with a hammer and drive out lower link bushing from bracket.




Fig. FA-21 Removing lower link bushing

#### Installation

Install upper and lower links in the reverse sequence to removal, noting the following instructions.

1. When the collar inside of lower link mounting bracket and bushing outside are rusted, remove rust with emery paper.
2. Fit lower link bushing into lower link mounting bracket using Transverse Link Bushing Replacer ST36070000. When tapping the drift with a hammer, be careful to hit the drift squarely.
3. Secure lower link to lower link bushing with lower link spindle and torque nut to 7.4 to 8.0 kg-m (54 to 58 ft-lb).

4. Install upper link spindle to upper link mounting bracket with used camber adjusting shims and bolts.

Torque bolt to 7.0 to 9.0 kg-m (51 to 65 ft-lb).

5. Install dust seat to the lower end of knuckle spindle support.
6. Coat grease on the thread of fulcrum pin and line up the notch of fulcrum pin with knuckle spindle support for inserting cotter pin. Fit fulcrum pin to spindle support with a soft hammer. Secure cotter pin and torque lock nut to 0.8 to 1.1 kg-m (5.8 to 8.0 ft-lb).
7. Coat grease to the thread portion of screw bushing inside liberally. Position knuckle spindle support at the center of lower link and secure screw bushings temporarily by hand. After ascertaining the dimensions become correct as shown in Figure FA-22, torque screw bushings to 20 to 30 kg-m (145 to 217 ft-lb).




Fig. FA-22 Installing screw bushing

8. Replace filler plug with grease nipple and pack grease until grease comes out from dust cover. Reinstall filler plug.
9. Upon installation, make sure that fulcrum pin operates smoothly with the following torque.

Operating torque:

Less than 0.5 kg-m (3.6 ft-lb)

10. Install upper link bushing to knuckle spindle support.
11. Install knuckle spindle support to upper link, insert fulcrum bolt, and torque nut to 3.9 to 5.3 kg-m (28 to 38 ft-lb).

## Front Axle & Front Suspension

**Note:** When installing fulcrum pin, insert it from rearward of vehicle.

12. Install tension rod, shock absorber, stabilizer, torsion bar spring, and knuckle arm, referring to the related paragraphs.

13. Install brake disc to knuckle spindle and torque securing bolt to 4.2 to 5.0 kg-m (30 to 36 ft-lb).

14. Install wheel and brake drum as an assembly and torque knuckle spindle nut to 8.0 to 9.0 kg-m (58 to 65 ft-lb).

### DISASSEMBLY AND ASSEMBLY

#### Upper link

1. Detach upper link spindle from upper links and remove clamp, dust cover and dust seal. Secure upper link in a vise and loosen screw bushing.

Assemble link spindle in reverse sequence to disassembling, noting the following instructions.

2. Torque screw bushing on upper link to 35 to 55 kg-m (253 to 398 ft-lb). Install new dust seal and dust cover and secure them with clamp.

3. Coat grease to screw bushing inside and the thread portion of upper link spindle liberally. Screw front and rear links to upper link spindle in the same length so as to obtain the specified figures as shown in Figure FA-23.




Fig. FA-23 Upper link and upper link spindle

4. Make sure to operate upper link spindle smoothly after installation.

5. Replace filler plug with grease nipple and pack grease until grease comes out from dust cover.

Reinstall filler plug.

#### Lower link

When installing torque arm on lower link, tighten it to the following specifications.

Serration boss:

1.8 to 2.6 kg-m  
(13 to 19 ft-lb)

Arm head:

2.7 to 3.7 kg-m  
(20 to 27 ft-lb)

### INSPECTION

#### Upper link spindle, fulcrum pin and screw bushing

Apply screw bushing to upper link spindle or fulcrum pin and measure axial end play between them.

When the end play exceeds 0.35 mm (0.0138 in), replace upper link spindle or fulcrum pin together with screw bushings.

Check the screw of upper link spindle, fulcrum pin, and screw bushing and repair or replace if necessary.

**Note:** Discard dust cover and dust seal when disassembled.

### ADJUSTMENT

#### VEHICLE POSTURE

Vehicle posture may be incorrect due to weakened spring or other faulty condition. The following procedures are necessary when adjustment is required.

That is, the vehicle posture can be adjusted by obtaining only the specified "H" dimension, changing the length of anchor bolt.

1. Raise front of vehicle on stands.
2. Adjust "H" dimension with turning nut adjusting anchor bolt. "H" dimension changes approximately 3.5 mm (0.138 in) vertically when adjust nut is turned one complete turn.
3. To make the best vehicle posture, "H" dimension must be in the following range.

H dimension mm (in)	
Model	All models
Condition	
Vehicle empty no payload	79 to 84 (3.11 to 3.31)
Vehicle loaded	54.5 (2.15)

#### Notes:

- a. Vehicle empty no payload consists of the following conditions:
  - 1) Full tank of gasoline, radiator filled and engine oil level full
  - 2) Spare tire, wheel, jack and jack handle in design position
- b. Vehicle loaded consists of the following conditions:

For all models, 2-persons and 500 kg (1,103 lb) payload.




Fig. FA-24 Dimension for standard vehicle posture

## WHEEL ALIGNMENT

Correct front wheel alignment attains proper vehicle handling characteristics and the least steering effort with a minimum amount of tire wear.

Before adjusting front wheel alignment, make sure to carry out a preliminary inspection of the front end parts for the following conditions:

1. Tire pressure and balance
2. Wheel bearings and nuts
3. Steering gear play
4. Steering gear housing at frame
5. Steering linkage and connections
6. Shock absorber action

When using the equipment for front wheel alignment inspection, follow the instructions furnished with the equipment. Furthermore, the inspection should be made with the vehicle level and at curb weight.

### Camber and caster

Measure camber and caster and adjust them in accordance with the following procedures if necessary.

Both camber and caster are adjusted by increasing and decreasing thickness of adjust shim inserted between upper link spindle and upper link mounting bracket.

To adjust caster, make a difference between thickness of front and rear shims. By adding a shim 1 mm (0.039 in) at front side, caster will be decreased by 33'. At the same time, camber will also be decreased by 6.5'.

To adjust camber, add or remove an equal amount of shims to front and rear sides. By adding a pack of shims 1 mm (0.039 in) thick at both sides, camber will be decreased by 13'.

Shims are available in 1 mm (0.039 in), 2 mm (0.079 in) and 4 mm (0.157 in) thickness.




Fig. FA-25 Adjusting camber and caster

### Notes:

- a. Do not make difference between front and rear shims in thickness beyond 2 mm (0.079 in) on a upper link spindle.
- b. Limit shim thickness for any one stack within 6 mm (0.236 in).
- c. Do not use shims for any one stack more the 2 sheets.

### Toe-in

Measure toe-in and adjust if necessary. For adjustment, carry out the following procedures.

Turn steering wheel to straight ahead position with front wheels in the same position. Then, check steering gear straight ahead position.

Loosen lock nuts ② (left hand thread) and ③ (right hand thread) and turn cross rod ① to adjust toe-in. Turn cross rod to forward direction as shown by arrow, and toe-in is reduced.

When cross rod is turned to opposite side, toe-in is increased.

After correct toe-in is obtained, tighten lock nut to 8.0 to 10.0 kg-m (58 to 72 ft-lb).




Fig. FA-26 Adjusting toe-in

## STEERING ANGLE

Check steering angle and use the following procedures if necessary.

Loosen lock nut at stopper bolt and adjust steering angle with stopper bolt. After obtaining correct steering angle, secure lock nut firmly.




Fig. FA-27 Adjusting steering angle

Model	Item	All models
Toe-in	mm (in) *1	2 to 3 (0.079 to 0.118)
	degree *2	10' to 16'
Camber		1°15' ±1°
Caster		1°50' ±45'
Kingpin inclination		6°15'
Steering angle	Inner wheel	36° ±1°
	Outer wheel	31° ±1°

\*1: The extreme front and rear of the tire center.

\*2: The total angle of the both tires.

Unladen

## SERVICE DATA AND SPECIFICATIONS

### King pin

Clearance limit between the king pin and bushing	mm (in) .....	0.15 (0.0059)
Bushing inner diameter (when fitted)	mm (in) .....	20.010 to 20.035 (0.7878 to 0.7888)
Clearance between the knuckle spindle support and spindle	mm (in) .....	less than 0.1 (0.004)

### Wheel bearing

Tightening torque	kg-m (ft-lb) .....	3.0 to 3.5 (22 to 25)
Spindle nut returning angle .....		40 to 70°
Wheel bearing rotation starting torque		
When both bearing and seal are new	kg-cm (in-lb) .....	less than 15 (13.0)
When readjusted	kg-cm (in-lb) .....	less than 7 (6.1)
At the hub bolt		
When both bearing and seal are new	kg (lb) .....	less than 2.1 (4.6)
When readjusted	kg (lb) .....	less than 1.0 (2.2)

### Suspension link

Upper link sliding resistance	kg-m (ft-lb) .....	less than 0.5 (3.6)
Lower link sliding resistance	kg-m (ft-lb) .....	less than 0.5 (3.6)

### Tightening torque

	kg-m (ft-lb)
Brake hose connecting nut .....	1.9 to 2.5 (14 to 18)
Wheel bearing lock nut .....	3.0 to 3.5 (22 to 25)
Brake disc fixing bolt .....	4.2 to 5.0 (30 to 36)
Knuckle arm fixing bolt .....	10.3 to 12.1 (74 to 88)
King pin lock bolt .....	2.1 to 2.5 (15 to 18)
Torque arm	
Arm end .....	2.7 to 3.7 (20 to 27)
Serration boss .....	1.8 to 2.6 (13 to 19)
Lower link spindle nut .....	7.4 to 8.0 (54 to 58)
Upper link screw bushing .....	24 to 35 (174 to 253)
Upper link spindle bolt fixing to bracket .....	7 to 9 (51 to 65)
Cotter pin lock nut .....	0.8 to 1.1 (5.8 to 8.0)
Lower link screw bushing .....	25 to 32 (181 to 231)
Fulcrum bolt .....	3.9 to 5.3 (28 to 38)
Tension rod	
Lock nut .....	1.6 to 2.2 (12 to 16)
Bracket bolt .....	1.6 to 2.2 (12 to 16)
Shock absorber	
Lock nut of the upper end .....	1.6 to 2.2 (12 to 16)
Lower end .....	3.1 to 4.1 (22 to 30)
Stabilizer	
Bracket bolt .....	1.6 to 2.2 (12 to 16)
Lock nut of the anchor bolt .....	3.1 to 4.1 (22 to 30)
Bumper rubber bolt .....	0.8 to 1.1 (5.8 to 8.0)



## TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
Vibration, shock and shimmying of steering wheel.	<p>Vibration: Too much backlash of steering gear, wear of each part of linkage and vibration of front wheels are, in many cases, transmitted to the steering wheel. This is very much noticeable when travelling over bad roads and at higher speeds.</p> <p>Shock: When the front wheels are travelling over bumpy roads, the play of the steering linkage is transmitted to the steering wheel. This is especially noticeable when travelling rough road.</p> <p>Shimmy: Abnormal vibrations of the front suspension group and the whole steering linkage, which occur when a specific speed is attained.</p> <p>Improper air pressure of tire.</p> <p>Unbalance and deformation of roadwheel.</p> <p>Unevenly worn tire or insufficient tightening.</p> <p>Improperly adjusted or worn front wheel bearing.</p> <p>Faulty wheel alignment.</p> <p>Worn or loose suspension link screw bushing.</p> <p>Damaged idler arm.</p> <p>Insufficiently tightened steering gear housing.</p> <p>Worn steering linkage.</p> <p>Improper steering gear adjustment (insufficient backlash).</p> <p>Faulty shock absorber or loose installation.</p> <p>Unbalanced vehicle posture.</p>	<p>Adjust.</p> <p>Correct the unbalance or replace.</p> <p>Replace or tighten.</p> <p>Adjust or replace.</p> <p>Adjust.</p> <p>Replace.</p> <p>Replace.</p> <p>Tighten.</p> <p>Replace ball joint.</p> <p>Adjust.</p> <p>Replace or tighten.</p> <p>Adjust.</p>
Vehicle pulls to right or left.	<p>When driving with hands off the steering wheel on a flat road, the vehicle gently swerves to right or left.</p> <p><b>Note:</b> A faulty rear suspension may also be the cause of this condition and, therefore, see also the chapter dealing with the rear suspension.</p> <p>Improper air-pressure of tire or insufficient tightening of wheel nuts.</p> <p>Difference in height of right and left tire treads.</p> <p>Incorrect adjustment or abrasion of front wheel bearing.</p> <p>Weakened front torsion spring or deviation from standard specification.</p> <p>Improper wheel alignment.</p> <p>Worn or loose suspension link screw bushing.</p>	<p>Adjust or tighten.</p> <p>Replace tires.</p> <p>Adjust or replace.</p> <p>Replace.</p> <p>Readjust.</p> <p>Replace.</p>





## Front Axle & Front Suspension

Condition	Probable cause	Corrective action
Vehicle pulls to right or left.	Deformed of steering linkage and suspension link. Unbalanced vehicle level.	Replace. Correct the unbalance.
Instability of vehicle.	Improper air pressure of tire. Worn or loose suspension link screw bushing. Incorrect wheel alignment. Worn or deformed steering linkage and suspension link. Incorrect adjustment of steering gear. Deformed unbalanced wheel.	Adjust. Replace. Adjust. Replace. Adjust. Correct or replace.
Stiff steering wheel	Check and correct in the following manner. Jack up front wheels, detach the steering gear and operate the steering wheel, and: a) If it is light, check steering linkage, and suspension groups. b) If it is heavy, check steering gear and steering column groups. Improper air pressure of tire. Insufficient lubricants or mixing impurities in steering linkage or excessively worn steering linkage. Insufficient lubricant in gear box or contaminated lubricant. Unsmooth king pin, damaged part, or insufficient lubrication. Worn or incorrectly adjusted wheel bearing. Worn damaged steering gear and bearing. Incorrectly adjusted steering gear. Deformed steering linkage. Incorrect wheel alignment. Interference of steering column with turn signal switch.	Adjust. Replenish grease or replace the part. Add or replace gear oil.  Replace.  Replace or adjust. Replace. Adjust. Replace. Adjust. Adjust.
Excessive steering wheel play.	Incorrectly adjusted steering gear. Worn steering linkage idler arm. Improperly fitted of gear box. Incorrectly adjusted wheel bearing. Worn or loose suspension link screw bushing.	Adjust. Replace. Retighten. Adjust. Replace.
Noise.	Improper air pressure of tire. Insufficient lubricating oil and grease for suspension link screw bushing and steering linkage, or their breakage.	Adjust. Replenish lubricating oil and grease, or replace.

## Front Axle & Front Suspension

Condition	Probable cause	Corrective action
Noise.	Loose steering gear bolts, linkage and suspension groups. Faulty shock absorber. Damaged wheel bearing. Worn steering linkage and steering gear. Worn or loose suspension link screw bushing.	Retighten.  Replace. Replace. Replace. Replace.
Grating tire noise.	Improper air pressure of tire. Incorrect wheel alignment. Deformed knuckle spindle and suspension linkage. Rough driving.	Adjust. Adjust. Replace. Avoid rough driving.
Jumping of disc wheel.	Improper air pressure of tire. Unbalanced wheels. Faulty shock absorber. Worn tire. Deformed wheel rim.	Adjust. Adjust. Replace. Replace. Replace.
Excessively or partially worn tire.	Improper air pressure of tire. Incorrect wheel alignment. Damaged wheel bearing. Incorrect brake adjustment. Improper tire shifting (rotation). Rough and improper driving manner.	Adjust. Adjust. Replace. Adjust. Adjust. Drive more gently.

## SPECIAL SERVICE TOOL

No.	Tool number & tool name	Description  Unit: mm (in)	For use on	Reference page or Figure No.
1.	ST35380000  King pin bush drift	 SE234	620	Page FA-4
2.	HT56802000  King pin bush reamer	 SE235	620	Page FA-5
3.	ST36070000  Transverse link bushing replacer	 SE236	620	Fig. FA-21
4.	ST35390000  King pin grease seal drift	 SE237	620	Fig.FA-9

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES

## SECTION RA

### REAR AXLE & REAR SUSPENSION

RA

REAR AXLE AND REAR SUSPENSION .....	RA- 2
SERVICE DATA AND SPECIFICATIONS .....	RA- 7
TROUBLE DIAGNOSES AND CORRECTIONS .....	RA- 8
SPECIAL SERVICE TOOLS .....	RA- 9




**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

## REAR AXLE AND REAR SUSPENSION

### CONTENTS

DESCRIPTION .....	RA-3	Shock absorber .....	RA-6
REMOVAL AND INSTALLATION .....	RA-3	INSPECTION .....	RA-6
Rear axle assembly .....	RA-3	Rear axle shaft and wheel bearing .....	RA-6
Rear axle shaft and wheel bearing .....	RA-4	Rear axle case .....	RA-6
Rear axle case .....	RA-5	Rear spring .....	RA-6
Rear spring .....	RA-5	Shock absorber .....	RA-6



RA132

- |  |  |   |
|--|--|---|
| 1 Air breather   | 14 Wheel bearing   | 28 Rear axle case   |
| 2 Thrust block   | 15 Rear axle bearing grease seal:<br>Supply wheel bearing grease to<br>oil seal lip when assembly. | 29 Filler plug<br>T = 6 to 10 kg-m<br>(43 to 72 ft-lb)<br>Oil capacity (about) = 1.0 liter<br>(1 US qt., 7/8 Imp.qt.) |
| 3 Nut<br>T = 3.1 to 4.1 kg-m<br>(22 to 30 ft-lb)   | 16 Rear axle bearing spacer  | 30 Drain plug<br>T = 6 to 10 kg-m<br>(43 to 72 ft-lb)   |
| 4 Shock absorber mounting rubber<br>bush   | 17 Rear axle shaft   | 31 Nut<br>T = 11.5 to 13.0 kg-m<br>(83 to 94 ft-lb)   |
| 5 Rear spring clip (U-bolt)  | 18 Grease catcher  | 32 Rear spring rear bush  |
| 6 Rear axle oil seal spacer  | 19 Bearing cage bolt   | 33 Rear spring  |
| 7 Rear axle shaft oil seal.<br>Supply wheel bearing grease to<br>oil seal lip when assembly. | 20 Rear axle case end shim   | 34 Rear spring shackle  |
| 8 Rear axle bearing lock nut<br>T = 15 to 20 kg-m<br>(108 to 145 ft-lb)                      | 21 Nut<br>T = 5.4 to 6.4 kg-m<br>(39 to 46 ft-lb)  | 35 Nut<br>T = 11.5 to 13.0 kg-m<br>(83 to 94 ft-lb)   |
| 9 Rear axle bearing lock washer  | 22 Rear spring pad   | 36 Rear spring  |
| 10 Plain washer  | 23 Rear spring   | 37 Rear spring front bush   |
| 11 Rear axle bearing cage  | 24 Nut<br>T = 7.3 to 9.9 kg-m<br>(53 to 72 ft-lb)  | 38 Rear spring front pin  |
| 12 Road wheel bolt   | 25 Nut<br>T = 1.6 to 2.2 kg-m<br>(12 to 16 ft-lb)  |   |
| 13 Road wheel nut<br>T = 8 to 9 kg-m<br>(58 to 65 ft-lb)                                     | 26 Shock absorber rubber bush  |   |
|  | 27 Shock absorber  |   |

T: Tightening torque

Fig. RA-1 Cross-sectional view of rear axle and suspension

## DESCRIPTION

The rear axle assembly is of the semi-floating type in which the vehicle weight is carried on the axle shafts through bearings enclosed in the bearing cages on outer rear axle case. The axle case is a pressed steel "Banjo" type housing.

The rear axle assembly is attached to the frame through semi-elliptic leaf springs and telescopic hydraulic shock absorbers. Rubber bushings at either end of the leaf springs and shock absorbers are designed to absorb vibration and noise.

The rear axle shaft splines engage the differential side gears with a floating fit. The outer ends are supported in the bearing cages by tapered-roller bearings.

The bearings are lubricated by wheel bearing grease. The axle shaft oil seals are located outboard and inboard of the bearing. The bearings are secured against shoulders on the shafts by press fit, and held in place by a large nuts.


The bearing cages hold the bearings against shoulders on the axle case.

Wheel side thrust is taken at the wheel bearings through the thrust block, so an axle shaft may be removed simply by removing the bolts holding the brake disc to the bearing cage and the rear axle case.

2. Mark relationship across propeller shaft flange and companion flange of differential carrier so that the original combination is restored at assembly.
3. Remove bolts retaining center bearing bracket and connecting shaft to companion flange. Withdraw propeller shaft sleeve yoke from transmission by moving the shaft rearward, passing it under rear axle.
4. Disconnect rear hand brake cable ① by removing adjusting nut ②,

three clamps ③ and connector ⑨. Slide front cable rearward and disconnect rear cable ④ at connector ⑤ by removing three clamps ③.

5. Disconnect rear brake hose at frame ⑥. Cover brake hose and pipe openings to prevent entrance of dirt.
6. Disconnect shock absorbers at lower end ⑦ and push shock absorbers up out of the way.
7. Lower jack under axle case. Remove U-bolts (spring clips) ⑧ to separate axle case from spring.



RA312

Fig. RA-2 Under view

## REMOVAL AND INSTALLATION

### REAR AXLE ASSEMBLY


It is not necessary to remove the rear axle assembly for any normal repairs.

However, if the axle case is damaged, the rear axle assembly may be removed and installed using the following procedures.

1. Raise rear of vehicle high enough to permit working underneath. Place a jack under center of axle case so it just starts to raise rear axle assembly.

Place stands solidly under frame members on both sides. Remove rear wheels.

8. Place a jack under center of axle case. Pass axle case through space above spring, and take it out to the side.



RA134

Fig. RA-3 Removing rear axle assembly

9. Install the axle case assembly in the reverse order of removal.

### Tightening torque:

U-bolt (Spring clip):  
7.3 to 9.9 kg-m  
(53 to 72 ft-lb)

Shock absorber lower end nut:  
1.6 to 2.2 kg-m  
(12 to 16 ft-lb)

Brake pipe flare nut:  
1.5 to 1.8 kg-m  
(11 to 13 ft-lb)

Propeller shaft to companion flange connecting bolt:  
2.0 to 2.7 kg-m  
(14 to 20 ft-lb)


Center bearing bracket fixing bolt:  
1.6 to 2.2 kg-m  
(12 to 16 ft-lb)

## REAR AXLE SHAFT AND WHEEL BEARING

1. Raise rear of vehicle and support under axle case on stands. Remove rear wheel.
2. Disconnect rear hand brake cable by removing adjusting nut and clamps.
3. Disconnect brake tube at rear wheel cylinder. Cover brake tube and wheel cylinder openings to prevent entrance of dirt.
4. Remove brake drum.

**Note:** If brake drum cannot be easily removed, return brake adjuster, install two bolts (M8 × 1.25) in holes on the flange face of brake drum, and tighten bolts evenly until brake drum is driven out.


5. Remove nuts retaining wheel bearing cage to brake disc.



RA135

Fig. RA-4 Removing nuts

6. Pull out axle shaft assembly together with brake disc using Rear Axle Stand KV40101000 and Sliding Hammer ST36230000.




RA418

Fig. RA-5 Removing rear axle shaft assembly

7. Remove oil seal in axle case if necessary and install new seal. Insure against damaging the seal lip.

8. Position axle shaft in vise with Rear Axle Stand ST07630000.
9. Unbend lock washer with a screwdriver.


**Note:** Do not use used lock washer again.



RA138

Fig. RA-6 Unbending lock washer


10. Remove lock nut using Rear Axle Bearing Lock Nut Wrench ST38020000.



RA139

Fig. RA-7 Removing lock nut

11. Withdraw wheel bearing together with bearing cage and brake disc using Rear Axle Shaft Bearing Puller HT72480000.




RA343

Fig. RA-8 Removing bearing

12. Remove oil seal in bearing cage if necessary.
13. To remove wheel bearing outer race after removed oil seal, apply a brass drift to race side surface, and withdraw it by tapping the top of drift with a hammer.

Installing can be proceeded in the reverse order of removal procedure as follows;

1. Fit wheel bearing outer race by tapping with a brass hammer evenly while fitting.
2. Install a new oil seal in bearing cage. Lubricate cavity between seal lips with wheel bearing grease after fitting seal.
3. Place bearing cage with brake disc and bearing spacer on axle shaft, and fit bearing cone. To install bearing cone, apply a brass drift to race side surface and tapping the top of drift with a hammer.



RA141

Fig. RA-9 Installing wheel bearing

4. Place bearing lock washer ① and bearing nut lock washer ② on axle shaft, and tighten lock nut ③ using Rear Axle Bearing Lock Nut Wrench ST38020000, and bend up lock washer.


### Notes:

- a. Be careful to place the faced side of nut to washer side so that washer is not damaged.
- b. Coincide washer lip with nut groove correctly by tightening nut, and bend washer carefully so that lip will not be damaged.

Tightening torque:

15 to 20 kg-m

(108 to 145 ft-lb)



RA142

Fig. RA-10 Layout of lock nut



## Rear Axle & Rear Suspension

5. Apply wheel bearing grease in wheel bearing and recess of axle case end.




Fig. RA-11 Lubricating portion

RA143

Fig. RA-11 Lubricating portion in and around wheel bearing


6. Apply gear oil to the spline at the inner end of axle shaft. Apply a coat of wheel bearing grease on the seal surface of the shaft.

7. Install left or right shaft, and adjust axial end play by applying rear axle case end shim (indicated by arrow mark).

Axial end play: 0.3 to 0.9 mm  
(0.012 to 0.035 in)

Standard shim thickness:  
1.5 mm (0.059 in)

Tightening torque of  
bearing cage fixing nut:  
5.4 to 6.4 kg-m  
(39 to 46 ft-lb)



RA144

Fig. RA-12 Installing rear axle shaft


### Rear axle case end shim

Thickness	mm (in)
0.05	(0.0020)
0.07	(0.0028)
0.10	(0.0039)
0.20	(0.0079)
0.50	(0.0197)

8. Install shaft in opposite side, and adjust axial end play by applying shim.

Axial end play: 0.02 to 0.15 mm  
(0.0008 to 0.0059 in)

Tightening torque of  
bearing cage fixing nut:  
5.4 to 6.4 kg-m  
(39 to 46 ft-lb)



RA145

Fig. RA-13 Measuring axial end play

9. Install other parts in reverse sequence to removal.

### REAR AXLE CASE

Rear axle case may be removed and installed using the following procedures:

1. Raise rear of vehicle and support securely under both frame members with stands.
2. Remove rear axle assembly (See removal of rear axle assembly.).
3. Remove rear axle shaft at both sides (See removal of rear axle shaft and wheel bearing.).
4. Remove differential carrier assembly.

Installing can be proceeded in the reverse order of removal procedure.

Another procedure is available as listed below:

1. Raise rear of vehicle and support under both frame members with stands.
2. Remove rear axle shaft at both sides.
3. Remove differential gear carrier assembly.
4. Remove rear axle case.

Installing can be proceeded in the reverse order of removal procedure.

### Tightening torque:


Differential carrier to axle case  
fixing nut: 1.7 to 2.5 kg-m  
(12 to 18 ft-lb)

### Oil drain and filler plug:

6 to 10 kg-m  
(43 to 72 ft-lb)

### REAR SPRING


1. Raise rear of vehicle and support under both frame members with stands.
2. Disconnect shock absorber at lower end ① and remove U-bolts (Spring clips) ②



RA146

Fig. RA-14 Removing shock absorber lower end and U-bolts

3. Position jack under rear axle case. Raise jack and float axle case from spring.
4. Disconnect rear spring shackle by removing nuts.



RA147

Fig. RA-15 Removing spring shackle

5. Disconnect spring from body by removing spring front pin.




Fig. RA-16 Removing spring pin

6. Remove rubber bush in spring if necessary and install new bush. Coat rubber bush with a soapy solution prior to assembly.

Install rear spring in the reverse order of removal, noting the following point:

Vehicle weight must be on rear wheels when tightening front pin, shackle and shock absorber lower end nut in order to clamp rubber bush in a neutral or unloaded position.

### Tightening torque:

Spring front pin nut:  
11.5 to 13.0 kg-m  
(83 to 94 ft-lb)

Spring shackle nut:  
11.5 to 13.0 kg-m  
(83 to 94 ft-lb)

U-bolt: 7.3 to 9.9 kg-m  
(53 to 72 ft-lb)

Shock absorber lower end nut:  
1.6 to 2.2 kg-m  
(12 to 16 ft-lb)

## SHOCK ABSORBER

1. Raise rear of vehicle and support under axle case on stands. It is recommended that a hydraulic hoist or open pit be utilized if available.
2. Disconnect lower end of shock absorber by removing nuts ① at spring seat.
3. Disconnect upper end of shock absorber by removing nut ② at frame.




Fig. RA-17 Removing shock absorber

Installation of shock absorber in the reverse order of removal.

Note: Vehicle weight must be on rear wheels when tightening shock absorber upper and lower ends in order to clamp rubber bushings in a neutral or unloaded position.

## INSPECTION

### REAR AXLE SHAFT AND WHEEL BEARING

Inspect the following parts for faults and replace as required.

1. Check axle shaft for straightness, cracks, damage, wear and distortion.
2. Check the lip of oil seal for damage, deformation and wear.
3. Check bearing for wear and damage.

### REAR AXLE CASE

Check axle case for yield, deformation, cracks or oil leakage and replace if necessary.

### REAR SPRING

Clean all rust and dirt from spring leaves, using a wire brush if necessary.

1. Examine spring leaves for fractures or cracks.
2. Check front bracket and pin, shackle, U-bolts and spring seat for wear, cracks, straightness and damaged threads. If faulty parts are found, replace with new ones.
3. Inspect all rubber parts for wear, damage, separation and deformation. Replace them if necessary.

## SHOCK ABSORBER

1. Test shock absorber and compare with the specifications given in Service Data and Specifications. Replace if necessary.
2. Check for oil leakage and cracks. Also, check shaft for straightness.
3. Inspect rubber bushings for damage, cracks and deformation. Replace parts if necessary.

## SERVICE DATA AND SPECIFICATIONS

Item	Applied model	All models	
<b>Rear shock absorber</b>			
Stroke x Maximum length mm (in)		190 x 475 (7.48 x 18.70)	
Damping force at 0.3 m (1.0 ft)/sec.			
Expansion kg (lb)		75 to 101 (165 to 223)	
Compression kg (lb)		35 to 53 (77 to 117)	
<b>Rear leaf spring</b>		Standard	*Option
Dimensions (Length x Width x Thickness-Number of leaves) mm (in)		1,200 x 60 x 6-3 5-1 13-1 ( 47.24 x 2.36 x 0.24-3 ) 0.20-1 0.51-1	1,200 x 60 x 7-2 6-1 13-2 ( 47.24 x 2.36 x 0.28-2 ) 0.24-1 0.51-2
Free camber mm (in)		153 (6.0)	140 (5.5)
Laden camber mm/kg (in/lb)		6/440 (0.24/970)	24/440 (0.94/970)
Spring constant kg/mm (lb/in)		2.1 to 5.0 (118 to 280)	2.6 to 10.0 (146 to 560)
<b>Rear axle</b>			
End play mm (in)		0.02 to 0.15 (0.0008 to 0.0059)	
Rear axle case end shim thickness mm (in)		0.05 (0.0020) 0.07 (0.0028) 0.10 (0.0039) 0.20 (0.0079) 0.50 (0.0197)	

\*Recommended for use on heavy load under high center of gravity such as camper loading.

### Tightening torque

Shock absorber upper end nut	kg-m (ft-lb) ..... 3.1 to 4.1 (22 to 30)
Shock absorber lower end nut	kg-m (ft-lb) ..... 1.6 to 2.2 (12 to 16)
Rear spring U-bolt (Clip)	kg-m (ft-lb) ..... 7.3 to 9.9 (53 to 72)

## Rear Axle & Rear Suspension

Spring front pin	kg-m (ft-lb) .....	11.5 to 13.0 (83 to 94)
Spring shackle	kg-m (ft-lb) .....	11.5 to 13.0 (83 to 94)
Bearing cage fixing bolt	kg-m (ft-lb) .....	5.4 to 6.4 (39 to 46)
Wheel bearing lock nut	kg-m (ft-lb) .....	15 to 20 (108 to 145)
Air breather	kg-m (ft-lb) .....	0.7 to 0.9 (5.1 to 6.5)
Differential gear carrier to axle case nut	kg-m (ft-lb) .....	1.7 to 2.7 (12 to 20)
Propeller shaft flange bolt	kg-m (ft-lb) .....	2.0 to 2.7 (14 to 20)
Drain and filler plug	kg-m (ft-lb) .....	6 to 10 (43 to 72)
Bumper rubber fixing bolt	kg-m (ft-lb) .....	1.6 to 2.2 (12 to 16)
Wheel nut	kg-m (ft-lb) .....	8 to 9 (58 to 65)

## TROUBLE DIAGNOSES AND CORRECTIONS

When rear axle and suspension is suspected of being noisy it is advisable to make a thorough test to determine whether the noise originates in the tires, road surface, exhaust, propeller

shaft, engine, transmission, universal joint, wheel bearings or suspension.

Noise which originates in other places can not be corrected by adjustment or replacement of parts in the





rear axle and rear suspension.

In case of oil leak, first check if there is any damage or restriction in breather.

Condition	Probable cause	Corrective action
Noise	Loose wheel nuts. Loose one or more securing bolts. Lack of lubricating oil or grease. Faulty shock absorber. Incorrect adjustment of rear axle shaft end play. Damaged or worn wheel bearing. Worn spline portion of rear axle shaft. Broken leaf spring. Loose journal, connections or so no. Wheel and tire unbalance. Damaged rubber parts such as leaf spring bush, shock absorber mounting bush. Faulty universal joints.	Tighten the wheel nuts. Tighten the bolts to the specified torque. Lubricate as required. Replace the shock absorber. Adjust the rear axle shaft end play.  Replace wheel bearing. Replace if necessary. Replace leaf spring. Tighten to the given torque. Balance wheel and tire. Replace the required parts.  Adjust or replace.
Instability in driving	Loose wheel nuts. Worn shock absorber. Worn or broken leaf spring.	Tighten to the given torque. Replace faulty shock absorber. Replace leaf spring.
Oil leakage	Damaged or restricted air breather. Damaged oil seal in rear axle case or differential carrier. Oil leakage from between the differential carrier and axle case.	Clean or replace air breather. Replace the damaged oil seal.  Tighten to the specified torque, or replace gasket.

# Rear Axle & Rear Suspension

## SPECIAL SERVICE TOOLS

No.	Tool number & tool name	Description Unit: mm (in)	For use on	Reference page or Figure No.
1.	KV40101000 Rear axle stand	<p>This tool is used to remove rear axle shaft. (Use with sliding hammer ST36230000.)</p>  <p>SE402</p>	All models	Fig. RA-5
2.	ST36230000 Sliding hammer	<p>This tool is used to remove rear axle shaft. (Use with rear axle stand KV40101000.)</p>  <p>SE111</p>	All models	Fig. RA-5
3.	ST38020000 Bearing lock nut wrench	<p>This tool is used to loosen and tighten rear axle bearing lock nut.</p>  <p>SE238</p>	620	Fig. RA-7
4.	HT72480000 Rear axle shaft bearing puller	<p>This tool is used to drive out rear axle shaft bearing.</p> <p>This parts (tools) are used for other rear axle type.</p>  <p>SE382</p>	All rigid axle car models	Fig. RA-8

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES



NISSAN MOTOR CO., LTD.  
TOKYO, JAPAN

## SECTION BR

### BRAKE SYSTEM

BR

GENERAL DESCRIPTION .....	BR- 2
ADJUSTMENT .....	BR- 2
SERVICE BRAKE .....	BR- 4
HAND BRAKE .....	BR-18
SERVICE DATA AND SPECIFICATIONS .....	BR-20
TROUBLE DIAGNOSES AND CORRECTIONS .....	BR-22
SPECIAL SERVICE TOOLS .....	BR-25

## GENERAL DESCRIPTION

The 620 series vehicles are equipped with hydraulic brakes on the four wheels, and mechanical hand brakes on the rear wheels. The front brake is the uni-servo type, and the rear the duo-servo, with the built-in hand

brake. The mechanical hand brake is controlled by a hand brake lever located in the driver's compartment.

For added safety, the tandem master cylinder, Master-Vac and Nissan Load Sensing Valve (N.L.S.V.)


are standard equipment on all models. The Master-Vac is installed to increase braking force. The N.L.S.V. ensures greater safety and reliability.

## ADJUSTMENT

### CONTENTS

BRAKE PEDAL .....	BR-2	HAND BRAKE (Parking brake) .....	BR-3
FRONT BRAKE .....	BR-2	BLEEDING HYDRAULIC SYSTEM .....	BR-3
REAR BRAKE .....	BR-3		

### BRAKE PEDAL



Unit: mm (in)

Free height:	A = 148 (5.83)
Full stroke at pedal pad:	B = 134 to 140 (5.28 to 5.51)
Depressed height:	C = 43 to 49 (1.69 to 1.93)

- 1 Push rod adjusting nut
- 2 Switch adjusting nuts
- 3 Brake lamp switch

BR765

Fig. BR-1 Adjusting brake pedal

1. Under the condition that the push rod of brake lamp switch is pushed in, position the height of brake pedal from toeboard to 148 mm (5.83 in), operating the switch adjusting nuts. Then, tighten nuts securely.

Tightening torque:  
1.2 to 1.5 kg-m  
(9 to 11 ft-lb)

2. Adjust the length of push rod

with its adjusting nut so as to become 0.6 to 1.2 mm (0.024 to 0.047 in) in play. Then, tighten nut securely.

Tightening torque:  
1.6 to 2.2 kg-m  
(12 to 16 ft-lb)

Note: Take care not to allow the push rod to get into master cylinder in free condition.

3. After completing adjustment, operate brake pedal several times to ensure that it travels over its entire stroke of 137 mm (5.39 in) smoothly without showing squeak noise, twisting or interference.

### FRONT BRAKE

1. Raise vehicle until wheel clear floor.
2. Remove rubber boot from brake disc.
3. Lightly tap adjuster housing and move it forward. Turn down adjuster wheel with a screwdriver, and spread brake shoes. Stop turning adjuster wheel when a considerable drag is felt and lock up brake drum.

Note: For both right and left brakes, brake shoes spread when adjuster wheel is turned downward.

4. Return adjuster wheel 12 ratches to obtain correct clearance between brake drum and brake shoes. Turn brake drum, and make sure that brake drum turns without dragging when brake shoes interfere with brake drum, then readjust clearance.
5. Install rubber boot.




Fig. BR-2 Adjusting front brake




Fig. BR-4 Adjusting lock nut

## REAR BRAKE

With hand brake fully released, adjust rear brake shoe clearance. For the service procedures, refer to Front Brake.




Fig. BR-3 Adjusting rear brake

## HAND BRAKE (Parking brake)

1. Raise vehicle until rear wheels are clear of the floor.
2. Apply hand brake lever, operate lock nuts to be 80 to 100 mm (3.15 to 3.94 in) in hand brake lever stroke, and tighten lock nuts securely.

Applying force to hand brake lever:

20 to 30 kg (44 to 66 lb)

3. Fully release hand brake and rotate rear wheels. No drag should be present.

### Notes:

- a. Before adjusting hand brake, complete the adjustment of rear brakes.
- b. After adjusting hand brake, operate the brake lever to make cable stable.
- c. Hand brake must be operated smoothly while being pulled and released. Make sure that no abnormal noise, dragging, twisting or other faulty condition occurs.

## BLEEDING HYDRAULIC SYSTEM

Hydraulic brake system must be bled whenever any line has been disconnected or air has entered into system.

When pedal action has a "spongy" feel, it is an indication that air has entered the system.

Bleeding the hydraulic system is an essential part of regular brake service.

1. Clean all dirt around master cylinder reservoir, remove cap and top up reservoir with recommended brake fluid.
2. Thoroughly clean mud and dust from bleeder valve so that outlet hole is free from any foreign material. Install a bleeder hose on bleeder valve. Place the other end of hose in a container filled with brake fluid.
3. Depress brake pedal two or three times, then keep pedal fully depressed.
4. With brake pedal fully depressed, open bleeder valve to expel air.

### Notes:

- a. Pay attention to brake fluid level in master cylinder reservoir during bleeding operation.
- b. Do not reuse brake fluid drained during bleeding operation.
- c. Bleed air as follows:
  - (1) Master cylinder, front
  - (2) Master cylinder, rear
  - (3) N.L.S.V., front
  - (4) Front wheels
  - (5) Rear wheels (left one first)
  - (6) N.L.S.V., rear
  - (7) N.L.S.V., center
- d. Exercise care not to splash brake fluid on exterior finish as it will damage the paint.
5. Close bleeder valve quickly as brake pedal is on down stroke.
6. Allow brake pedal to return slowly with bleeder screw closed.
7. Repeat bleeding operations until no air bubbles show in hose.

### Notes:

- a. Brake fluid containing air is white and has visible air bubbles.
- b. Brake fluid containing no air runs out of bleeder valve in a solid stream free of air bubbles.
8. Repeat above steps on the remaining brake lines to expel all air.



# SERVICE BRAKE

## CONTENTS

BRAKE PEDAL .....	BR- 4	REMOVAL .....	BR-10
REMOVAL .....	BR- 4	DISASSEMBLY AND ASSEMBLY .....	BR-10
INSPECTION .....	BR- 4	INSPECTION .....	BR-10
INSTALLATION .....	BR- 4	INSTALLATION .....	BR-11
MASTER CYLINDER .....	BR- 5	REAR BRAKE .....	BR-12
REMOVAL .....	BR- 5	REMOVAL .....	BR-12
DISASSEMBLY AND ASSEMBLY .....	BR- 6	DISASSEMBLY AND ASSEMBLY .....	BR-13
INSPECTION .....	BR- 6	INSPECTION .....	BR-13
INSTALLATION .....	BR- 6	INSTALLATION .....	BR-13
BRAKE LINE .....	BR- 7	MASTER-VAC .....	BR-14
REMOVAL .....	BR- 8	DESCRIPTION .....	BR-14
INSPECTION .....	BR- 8	INSPECTION OF OPERATION .....	BR-14
INSTALLATION .....	BR- 8	REMOVAL .....	BR-16
N.L.S.V. ....	BR- 9	DISASSEMBLY .....	BR-16
DESCRIPTION .....	BR- 9	INSPECTION .....	BR-17
N.L.S.V. TEST .....	BR- 9	ASSEMBLY AND ADJUSTMENT .....	BR-17
FRONT BRAKE .....	BR-10	INSTALLATION .....	BR-18

## BRAKE PEDAL

### REMOVAL

1. Remove pedal return spring.




Fig. BR-5 Brake pedal mounting




Fig. BR-6 Brake pedal

2. Remove cotter pin from clevis pin, and separate pedal from (Master-Vac) push rod.
3. Remove fulcrum pin and pedal.

**Note:** Loosen fulcrum pin clockwise.

### INSPECTION

Check brake pedal for the following items, servicing as necessary.

1. Check pedal bushing for wear, deformation or damage.
2. Check pedal shaft sleeve for wear or roughness.
3. Check for bent brake pedal.
4. Check for fatigued return spring.


### INSTALLATION

Install brake pedal in the reverse sequence of removal, paying attention to the following instructions.

1. Insert fulcrum pin into hole in brake pedal and bracket from right side.
2. Install clevis pin from left-hand side.

## Brake System

3. Hook return spring to brake pedal assembly from accelerator pedal side.
4. Apply a coating of recommended multipurpose grease to the inner and outer faces of pedal bushing, clevis pin, and hooks of return spring. Charge the clearances in bushings with grease.



BR298

Fig. BR-7 Greasing place

5. Install brake lamp switch.
6. Adjust the brake pedal after installation. (Refer to the instructions under Adjustment.)

Tightening torque:

Fulcrum pin:

1.9 to 2.4 kg-m

(14 to 17 ft-lb)

## MASTER CYLINDER

The diameter of cylinder is 19.05 mm ( $\frac{3}{4}$  in) for all models. The tandem master cylinder contains two fluid reservoirs which connect the front and rear brake lines independently.

Braking force is constantly maintained when failure occurs in either the front brake system or the rear brake system. Failure in the front brake system will leave the rear brake still operative or failure in the rear brake system will leave the front brake system still operative.

The reservoir is equipped with a retention cap.


To remove this cap, proceed as follows:

- (1) Turn retention ring fully in the REMOVE direction.
- (2) Pull out retention cap.


To install it, proceed as follows:  
(1) Turn retention ring (used in the retention cap) fully in the REMOVE direction.

- (2) Align the projection in retention cap with the slit in the reservoir tank and push retention cap in the tank.
- (3) Turn retention ring fully in the TIGHTEN direction.

Tokico




Nabco



BR926

- 1 Reservoir cap
- 2 Reservoir tank
- 3 Secondary piston return spring
- 4 Stopper screw
- 5 Secondary piston
- 6 Primary piston return spring
- 7 Primary piston

Fig. BR-8 Sectional view of tandem master cylinder



BR658

Fig. BR-9 Master cylinder

## REMOVAL

1. Disconnect front and rear brake tubes from master cylinder.

Notes:


- a. When removing brake tubes, use Flare Nut Torque Wrench GG94310000.

Never use open end or adjustable wrench.

- b. When disconnecting brake tubes, be sure to use a container to receive draining brake fluid. Use of rags is also suggested to keep adjacent parts and area clean.

2. Remove master cylinder securing nut. Then master cylinder can be taken out.

## DISASSEMBLY AND ASSEMBLY



BR927

- |                 |                            |                        |
|-----------------|----------------------------|------------------------|
| 1 Reservoir cap | 6 Secondary piston stopper | 11 Primary piston      |
| 2 Oil filter    | 7 Bleeder screw            | 12 Piston stopper      |
| 3 Oil reservoir | 8 Secondary return spring  | 13 Piston stopper ring |
| 4 Packing       | 9 Secondary piston         |                        |
| 5 Valve cap     | 10 Primary return spring   |                        |

Fig. BR-10 Master cylinder

1. Remove reservoir cap and filter and drain out brake fluid.
2. Pry off stopper ring, using a screwdriver.
3. Remove stopper screw and take out stopper, primary piston assembly, spring, and secondary piston assembly, in the order shown.

**Note:** Discard piston cup if it is removed from piston assembly and use a new one.

4. Unscrew plugs to gain access to check valve for disassembling.

**Note:** Never detach reservoir tank. If it is removed for any reason, discard it and install a new one.

5. Assemble master cylinder in the reverse sequence of disassembly, paying particular attention to the following notes:

### Tightening torque:

#### Valve cap:

##### Tokico

8 to 9 kg-m  
(58 to 65 ft-lb)

##### Nabco

2.5 to 3.5 kg-m  
(18 to 25 ft-lb)

#### Bleeder:

0.7 to 0.9 kg-m  
(5 to 7 ft-lb)

### Notes:

- a. Replace gaskets and packings with new ones.
- b. Apply brake fluid or rubber grease to sliding contact surfaces of parts to facilitate assembly of master cylinder.
- c. The brake master cylinder is available in both NABCO make and TOKICO make. There is no interchangeability of repair kits or component parts between NABCO and TOKICO makes. When replacing the repair kit or component parts,

ascertain the brand of the brake master cylinder body. Be sure to use parts of the same make as the former ones.

## INSPECTION

Thoroughly clean all parts in a suitable solvent, and check for worn or damaged parts. Replace any part that is faulty.

**Note:** Do not clean rubber parts with mineral oil since this will be the sure way of deteriorating parts. Use brake fluid or alcohol. When alcohol is used for cleaning these parts, do not immerse them in it longer than 30 seconds. After parts are cleaned, dry with compressed air.

1. Check cylinder and position for evidence of abnormal wear or damage. Replace if found faulty.
2. Check piston-to-cylinder clearance. If it is more than 0.15 mm (0.0059 in), replace either piston or cylinder.

Master cylinder inner diameter:  
19.05 mm ( $\frac{3}{4}$  in)

3. Check for weakened, fatigued or damaged springs, and replace if necessary.
4. When master cylinder is disassembled, be sure to discard cups and valves. Replace any other part which shows evidence of deformation, wear or damage.
5. Replace damaged oil reservoirs and caps.

## INSTALLATION

Install master cylinder in the reverse sequence of removal.

Bleed air out of master cylinder by loosening bleeder screw after it is installed in its original position.

### Tightening torque:



Brake master cylinder attaching nut:

0.8 to 1.1 kg-m  
(6 to 8 ft-lb)

Brake tube connector:

1.5 to 1.8 kg-m  
(11 to 13 ft-lb)

# BRAKE LINE



BR767

Fig. BR-11 Brake line

## Brake System

### REMOVAL

1. Removing flare nuts on both ends and clips effects the removal of brake tube and brake hose.
2. Rear brake hose can be removed by disconnecting the tube and then turning round the hose.

**Note:** When removing brake tubes and hoses, use Flare Nut Torque Wrench GG94310000.

**Never use an open end or an adjustable wrench.**

### INSPECTION

1. Examine all hoses for swell, rubbing marks or ozone-cracking, replacing those found with any of above badly beyond use. Also, inspect end fittings and be sure that no fluid leak through staked end has taken place; replace if necessary. Hose with badly rusted fitting should also be replaced with a new one.
2. Clean all tubes to remove dust and dirt with isopropyl alcohol, checking for collapse, wear, cracking, swell or rusting. Replace if found with any of above. Use care not to damage brake tubes while operation.

Check if tubes are clamped securely.

After all brake lines have been installed, retighten all connections, if necessary, to assist in obtaining correct torque. In retightening at front wheel cylinder, first remove hose clamp and loosen flare nut on opposite side to avoid twisting hose.

Hold pedal as far downward as possible 80 kg (176 lb) or more, examining evidence as to whether fluid is leaking through brake lines or connections. Leakage in any manner cannot be permitted here. In case fluid leaks, tightening to specified torque, tighten additionally up to 2.5 kg-m (18 ft-lb). Under no circumstances should not be tightened over 2.5 kg-m (18 ft-lb) torque since this elongates end fitting, making it impossible to reuse brake tube.

Under no circumstances should rear brake hose and 3-way connector be retightened over specified torques. In-

stead, replace copper washer with a new one after checking for sign of damage on seating surface. Never reuse an old copper washer.

### INSTALLATION

#### Brake hose

##### Front brake hose

In installing brake hose, first jack up vehicle to take off the weight of vehicle from wheels so that suspension is in rebound. Steering wheel should also be kept in straight-ahead position.

To connect brake line, first connect brake hose to wheel cylinder with the specified torque.

Tightening torque:

1.7 to 2.0 kg-m  
(12 to 14 ft-lb)

Then secure brake hose to the bracket with lock plate so as not to twist or abnormally bend the hose.

**Note:** After connecting brake hose at both ends, pay keen attention not to twist the hose when additional tightening is required.




Fig. BR-12 Front brake hose

##### Rear brake hose

First, secure rear brake hose to 3-way connector on rear axle case to the specifications. After connecting hose, do not tighten it at 3-way connector additionally since this operation causes hose to be twisted.

Tightening torque:

1.7 to 2.0 kg-m  
(12 to 14 ft-lb)




Fig. BR-13 Rear brake hose

After brake hose has been installed, check to be sure that there is enough clearance between hose and adjacent parts to avoid contact with other ones. The check should be carried out while moving wheel up and down through its full stroke and rotating steering wheel between two extreme lock positions. The above clearance must be as follows:

Hose to rotating or moving parts such as tire and rim:

40 mm (1.57 in) and more

Hose to stationary part:

25 mm (0.98 in) and more

In case that the above clearance cannot be obtained, it may be caused by the hose twisted. Accordingly, carry out the correction with hose connection again, following the above instructions.

#### Brake tube

In installing a brake tube, use care to locate its end squarely on mating seat, noting the fact that nut can be turned freely by a light finger twist. Then, tighten to correct torque with a Brake Pipe Torque Wrench GG94310000.

Tightening torque (Flare nut):

1.5 to 1.8 kg-m  
(11 to 13 ft-lb)

In addition, care should also be exercised to avoid damaging or collapsing brake tube during operation.

Be sure to make enough clearance between all tubes and other adjacent parts to avoid contact.

In installing tube through hood ledge grommet, be sure to position it at the center of grommet.

## Brake System

After connecting brake tube, be sure to check the clearance to prevent from damage. The clearance at the following portions must be specified distance or more.

Tube to body panel and frame:

Over 5 mm (0.20 in)

Tube to edge of each panel:

Over 10 mm (0.39 in)

Tube to tube:

Loop pitch:

Over 5 mm (0.20 in)

Between front tube and rear tube:

Over 9 mm (0.35 in)

Tube to moving parts:

Over 10 mm (0.39 in)

Loop tube to hoodedge panel:

Over 10 mm (0.39 in)

### Notes:

- Brake tubes are shaped at factory to secure specified clearance and may not require reshaping. Discard if they call for excessive reshaping.
- In reshaping a brake tube, take care to avoid damaging galvanization or collapsing section.

After brake lines have been assembled, check to make sure that all fittings and flare nuts are tightened to correct torques.

### Tightenint torque:

Brake tube to connector:

1.5 to 1.8 kg-m

(11 to 13 ft-lb)

Brake tube to brake hose:

1.7 to 2.0 kg-m

(12 to 14 ft-lb)

Connector and clip fixing bolt:

0.35 to 0.45 kg-m

(2.5 to 3.3 ft-lb)

3-way connector fixing bolt

(on rear axle case):

0.8 to 1.1 kg-m

(6 to 8 ft-lb)


## N.L.S.V.

### DESCRIPTION

The Nissan Load Sensing Valve (N.L.S.V.) serves to change braking power of the rear wheels in response to changes in the load and fluid pressure, improving braking stability and shortening stopping distances.

The N.L.S.V. is installed on the frame, being inclined at 10 degrees. A


summary of the N.L.S.V. operation is given in Figures BR-14 and BR-15.



BR928

Fig. BR-14 Construction of N.L.S.V.

Performance curve of brake fluid pressure is as follows:



BR769

Fig. BR-15 Performance curve of fluid pressure

### N.L.S.V. TEST

#### Operating test

The test should be conducted under these conditions:

Drive a vehicle with pay load and then with only driver on a dry, flat concrete or asphalt road, applying the brake suddenly at 40 km/h (25 MPH).

N.L.S.V. is functioning normally if

the following occurs:

When rear wheels lock, stopping distance is shorter than 13.1 m (43.0 ft) whether loaded or unloaded. (Stopping distance should be measured from the place where the brake pedal is first applied to the place the vehicle actually stops.) Front wheels lock simultaneously with or ahead of rear wheels.

## Brake System

Above mentioned operation is available when the

entire brake system except N.L.S.V. is correctly adjusted.

Wheel cylinder can be disassembled simply by the following procedures described below:

Remove retainer and dust cover, and take out piston from wheel cylinder. Be careful not to damage sliding part of piston and piston cup.

Thoroughly wash all disassembled parts in brake fluid or alcohol.

**Note:** Do not wash rubber parts with mineral oil since they are deteriorated.

When alcohol is used, however, do not immerse rubber parts in alcohol longer than 30 seconds. After parts are cleaned, dry them with compressed air.

Assemble wheel cylinder in reverse sequence of disassembly.

When securing connector bolt, insert its location tip to the hole of wheel cylinder firmly and tighten it securely.

Carry out operations carefully so that component parts are not damaged or no dust and other foreign materials enter cylinder.

**Note:** The brake wheel cylinder is available in both NABCO make and TOKICO make. There is no interchangeability of repair kits or component parts between NABCO and TOKICO makes.

When replacing the repair kit or component parts, ascertain the brand of the brake wheel cylinder body. Be sure to use parts of the same make as the former ones.

## FRONT BRAKE




Fig. BR-16 Front brake

## REMOVAL

1. Jack up front of vehicle just high enough to remove tire and support it with safety stands.
2. Remove wheel and brake drum. If brake drum cannot be easily removed, return brake adjuster, install two bolts (M8 x 1.25) in holes on the flange face of brake drum, and tighten bolts evenly until brake drum is driven out.
3. In order to ease operation, remove hub assembly from knuckle spindle. (Refer to Front Axle.)
4. Unhook upper, lower, and after shoe return springs, and then remove brake shoe assemblies.
5. Disconnect brake hose from wheel cylinder.
6. Loosen securing nut and remove wheel cylinder.
7. Remove rubber boot, adjuster shim, lock plate and retaining spring, and then remove adjuster assembly from brake disc.




Fig. BR-17 Removing wheel cylinder

## DISASSEMBLY AND ASSEMBLY

### Wheel cylinder




Fig. BR-18 Front wheel cylinder

## INSPECTION

### Brake drum

1. Replace brake drum whose diameter is beyond the limit of 1.5 mm (0.059 in) with respect to the standard inner diameter of 254.0 mm (10.00 in).

## Brake System

2. The allowable maximum "out-of-round" of brake drum is 0.02 mm (0.0008 in).

Re-condition or replace brake drum if specified limit is exceeded.

3. Measure for tapered brake drum. If specified limit of 0.02 mm (0.0008 in) is exceeded as measured at a position where the distance of 45 mm (1.77 in) is kept away from inlet, re-condition or replace brake drum.

4. Contact surface with which linings come into contact should be finished to such an extent that it is ground by a No. 120 to 150 sand-paper.

5. Using a drum racer, finish brake drum by machining if it shows any sign of score marks, partial wear or stepped wear on its contact surface.

**Note:** After brake drum is completely re-conditioned or renewed, check drum and shoes for proper contact pattern.

### Brake assembly

1. When brake shoe linings are cracked, incompletely seated, unevenly worn, and/or deteriorated due to excessive heating or soiled with oil, grease and brake fluid, replace.
2. Replace linings if the thickness is worn down to less than 1.0 mm (0.039 in).

**Note:** When brake shoe lining is installed, grind brake shoe lining face to diameter equal to that of brake drum.

#### Lining dimension:

Width × Thickness × Length  
45 × 4.5 × 244 mm  
(1.77 × 0.177 × 9.61 in)

3. Check adjuster for smooth operation.
4. Replace shoe return springs which are broken or fatigued.

**Standard dimensions of shoe springs**

Item	Free length mm (in)	Dia. of spring mm (in)	No. of coils	Installed length/load mm/kg (in/lb)
Upper	136.5 (5.37)	2.0 (0.079)	37	159.5/14 to 16 (6.28/31 to 35)
Lower	134.5 (5.30)	2.3 (0.091)	35	159.5/21 to 23 (6.28/46 to 51)
After shoe	83.2 (3.28)	1.4 (0.055)	27.5	99/4 to 5 (3.90/9 to 11)

### Wheel cylinder

1. Replace any cylinder or piston which is scratched, scored or worn on its sliding contact surface.
2. Replace worn parts if piston-to-cylinder clearance is beyond 0.15 mm (0.0059 in).

Wheel cylinder inner diameter:  
19.05 mm (¾ in)

3. Replace piston cup which is worn or otherwise damaged.
4. Replace if contacting face of cylinder and shoe is worn locally or in step.
5. Replace damaged dust cover, fatigued piston spring or faulty threaded parts.
6. Replace tube connector which is worn on its threaded portion.

### INSTALLATION

Install front brake in the reverse sequence of removal, paying particular attention to the following instructions.

1. When assembling adjuster assembly, apply brake grease to adjuster housing bore, adjuster wheel and adjuster screw.

When installing adjuster assembly to brake disc, apply brake grease to disc, adjuster and retaining spring sliding surfaces to slide adjuster smoothly.

Measure adjuster sliding resistance. Adjust by adjuster shim when sliding resistance is incorrect.

Adjuster sliding resistance:  
5 to 12 kg (11 to 26 lb)

2. When installing wheel cylinder, be sure to secure the cylinder with "R" mark to right-hand disc and the one with "L" mark to left-hand disc. Otherwise, brake hoses may interfere with other adjacent parts. As to the connecting instructions of brake hose, no twist or contact is existed on brake hose, referring the related topic Brake Line.

#### Tightening torque:

##### Wheel cylinder:

5.4 to 6.6 kg-m  
(39 to 48 ft-lb)

##### Connector bolt:

1.9 to 2.5 kg-m  
(14 to 18 ft-lb)

##### Brake hose:

1.7 to 2.0 kg-m  
(12 to 14 ft-lb)

##### Air bleeder:

0.7 to 0.9 kg-m  
(5 to 7 ft-lb)


##### Brake disc:

4.2 to 5.0 kg-m  
(30 to 36 ft-lb)

3. Before installing brake shoe assemblies, apply brake grease to wheel cylinder and adjuster brake shoe installing grooves, and brake disc and brake shoe assembly contact faces (two places). Exercise care not to allow grease to come into contact with linings and adjuster.



## Brake System




BR313

Fig. BR-19 Greasing points

4. Adjust brake shoe clearance and bleed brake system. (Refer to the instructions under topic Adjustment in this section.

Upon completion of the above adjustments, make sure that brake operates correctly and no brake fluid leaks.

## REAR BRAKE



BR315

- 1 Brake disc
- 2 Brake shoe assembly
- 3 Wheel cylinder assembly
- 4 Return upper spring
- 5 Return lower spring
- 6 After shoe return spring
- 7 Retainer
- 8 Antirattle spring
- 9 Spring seat
- 10 Adjuster assembly
- 11 Adjuster head
- 12 Adjuster head shim
- 13 Lock spring
- 14 Adjuster housing
- 15 Adjuster wheel
- 16 Adjuster screw
- 17 Toggle lever
- 18 Extension link
- 19 Return spring
- 20 Adjuster spring
- 21 Lock plate
- 22 Adjuster shim
- 23 Rubber boot
- 24 Antirattle pin


Fig. BR-20 Rear brake

### REMOVAL

1. Jack up rear of vehicle just high enough to remove tire and support it with safety stands.
2. Remove wheel, loosen hand brake and detach brake drum.
3. Turn pin by 90°, and remove antirattle springs.
4. Open brake shoe assemblies outward against return spring, and remove extension link.
5. Remove return springs.
6. Remove brake shoe assemblies. Note that after (secondary) brake shoe assembly must be separated from toggle lever. When separating after (secondary) brake shoe assembly from

toggle lever, withdraw clevis pin.

7. Disconnect toggle lever from hand brake rear cable.



BR316

Fig. BR-21 Removing toggle lever


8. Disconnect brake tube at wheel cylinder by loosening flare nut.
9. Remove wheel cylinder from brake disc by loosening installation nuts.
10. Remove rubber boot, adjuster shim, lock plate and adjuster springs and remove adjuster assembly from brake disc.

## Brake System

### DISASSEMBLY AND ASSEMBLY

#### Wheel cylinder

Remove dust cover, and pull out piston head and piston assembly. Refer to Wheel Cylinder of Front Brake.



- 1 Dust cover
- 2 Piston head
- 3 Piston
- 4 Piston cup
- 5 Wheel cylinder housing
- 6 Bleeder cap
- 7 Bleeder screw
- 8 Connector
- 9 Washer
- 10 Connector bolt

BR318

Fig. BR-22 Rear wheel cylinder

### INSPECTION

#### Brake drum

Check brake drum in the same manner as outlined in the Front Brake Drum.

#### Brake assembly

1. When brake shoe linings are cracked, incompletely seated, unevenly worn, and/or deteriorated due to excessive heating or soiled with oil, grease and brake fluid, replace.
2. Replace linings if the thickness is worn down to less than 1.0 mm (0.039 in).

**Note:** When brake shoe lining is installed, grind brake shoe lining face to diameter equal to that of brake drum.

**Lining dimension:**

Width × Thickness × Length

45 × 4.5 × 244 mm

(1.77 × 0.177 × 9.61 in)

3. Check adjuster for smooth operation.

4. Replace shoe return springs which are broken or fatigued.

#### Standard dimensions of shoe springs

Item	Free length mm (in)	Dia. of spring mm (in)	No. of coils	Installed length/load mm/kg (in/lb)
Upper	175 (6.89)	2.0 (0.079)	32.5	184/11 to 13 (7.24/24 to 29)
Lower	158 (6.22)	2.3 (0.091)	30	176/18 to 20 (6.93/40 to 44)
After shoe	83.2 (3.276)	1.4 (0.055)	27.5	99/4 to 5 (3.90/9 to 11)
Antirattle	20.5 (0.807)	1.6 (0.063)	3.5	12/3.5 to 4.5 (0.47/8 to 9.9)

#### Wheel cylinder

1. Replace any cylinder or piston which is scratched, scored or worn on its sliding contact surface.
2. Replace worn parts if piston-to-cylinder clearance is beyond 0.15 mm (0.0059 in).

Wheel cylinder inner diameter:

19.05 mm ( $\frac{3}{4}$  in)

3. Replace piston cup which is worn or damaged.
4. Replace if contacting face of cylinder and shoe is worn locally or in step.
5. Replace damaged dust cover, fatigued piston spring or faulty threaded parts.
6. Replace tube connector which is worn on its threaded portion.

2. When assembling toggle lever and after brake shoe assembly, adjust clearance between toggle lever and after brake shoe assembly to 0 to 0.3 mm (0 to 0.012 in) with a properly selected toggle pin washer.

#### Toggle pin washer

No.	Thickness mm (in)
1	2.0 (0.079)
2	2.3 (0.091)
3	2.6 (0.102)
4	2.9 (0.114)
5	3.2 (0.126)

### INSTALLATION

Install rear brake in the reverse sequence of removal, paying particular attention to the following instructions.

1. Rear adjuster assembly is the same as front. Refer to the paragraph covering Front Brake Installation.

Adjuster sliding resistance:


5 to 12 kg (11 to 26 lb)

3. Before installing brake shoe assemblies, apply brake grease to the following places:

- (1) Brake shoe installing grooves of adjuster and wheel cylinder.
- (2) Extension link installing grooves.
- (3) Lower surface of spring seat.
- (4) Contact surfaces between brake disc and brake shoe assembly (six places).

At this time, be sure not to coat brake grease to brake linings.

## Brake System



BR317

Fig. BR-23 Greasing points

### 4. Tightening torque:

#### Wheel cylinder:

1.5 to 1.8 kg-m  
(11 to 13 ft-lb)

#### Connector bolt:

1.9 to 2.5 kg-m  
(14 to 18 ft-lb)

#### Brake tube:

1.5 to 1.8 kg-m  
(11 to 13 ft-lb)

#### Air bleeder:

0.7 to 0.9 kg-m  
(5 to 7 ft-lb)

#### Brake disc:

5.4 to 6.4 kg-m  
(39 to 46 ft-lb)

5. Adjust brake shoe clearance and bleed brake system. Upon completion of the above adjustments, make sure that brake operates correctly and no brake fluid leaks.

## MASTER-VAC

### DESCRIPTION

A vacuum suspended Master-Vac is installed behind the master cylinder. As the brake pedal is depressed, fluid is forced under high pressure through the brake pipes to the wheel cylinders to retard or stop the vehicle.


The Master-Vac contains a spring loaded diaphragm of 152.4 mm (6 in) in diameter. It operates on negative pressure produced in the engine intake manifold.

The tandem master cylinder is capable of producing high pressure even if the Master-Vac is faulty.

**Note:** The Master-Vac diaphragm differs from former ones for improved braking force. Do not install former Master-Vac on 1976 models. The

Master-Vacs are identified by the label color as follows:

1976 model - Caution Label  
Former models - Yellow



BR321

- |                   |                        |                            |
|-------------------|------------------------|----------------------------|
| 1 Plate and seal  | 6 Seal                 | 11 Valve operating rod     |
| 2 Push rod        | 7 Vacuum valve         | 12 Valve return spring     |
| 3 Diaphragm       | 8 Poppet assembly      | 13 Poppet return spring    |
| 4 Rear shell      | 9 Valve body guard     | 14 Exhaust valve           |
| 5 Diaphragm plate | 10 Air silencer filter | 15 Valve plunger           |
|                   |                        | 16 Reaction disc           |
|                   |                        | 17 Diaphragm return spring |
|                   |                        | 18 Front shell             |


Fig. BR-24 Sectional view of Master-Vac

## INSPECTION OF OPERATION

### Checking vacuum pressure

1. Connect a vacuum gauge, in the line, between check valve and Master-

Vac, as shown in Figure BR-25.



- 1 Check valve
- 2 Vacuum gauge

BR169

Fig. BR-25 Air-tight test set-up

2. Start engine and increase engine speed. Stop engine when vacuum gauge indicates 500 mmHg (19.69 inHg).

### Air-tight test

1. Fifteen seconds after engine is stopped, observe the rate of drop in air pressure registered by vacuum gauge. If a pressure drop of 25 mmHg (0.98 inHg) is exceeded, refer to the following chart to determine the cause of failure.

## Brake System

Probable cause	Corrective action
1. Air leakage at check valve.	Replace check valve.
2. Air leakage at push rod seal.	Replace seal.
3. Air leakage between valve body and seal.	Repair or replace faulty part(s).
4. Air leakage at valve plunger seat.	Repair or replace seat.
5. Damaged piping or joints.	Repair or replace.

2. Fifteen seconds after engine is stopped and brake fully applied, observe the rate of drop in air pressure registered by vacuum gauge.

If a pressure drop of 25 mmHg (0.98 inHg) is exceeded, refer to the following chart to determine the cause of failure.

Probable cause	Corrective action
1. Air leakage at check valve.	Replace check valve.
2. Damaged diaphragm.	Replace.
3. Reaction disc dropped off.	Reinstall and check push rod for proper turn.
4. Air leakage at poppet assembly seat and valve body.	Replace faulty part(s).

**Note:** When replacement of any part is required, be sure to renew Master-Vac as an assembly.

### Inspecting check valve

1. Remove clip and disconnect hoses at connections. The check valve can now be removed.




Fig. BR-26 Location of check valve

2. Using a Master-Vac tester, apply a vacuum pressure of 200 mmHg (7.87 inHg) to the port of check valve on the Master-Vac side. If a pressure drop of 10 mmHg (0.39 inHg) is exceeded in




Fig. BR-27 Sectional view of check valve

### Operating test

1. Connect an oil pressure gauge in brake line, at connection on master cylinder.
2. Install a spring scale on brake pedal.
3. Start engine, and increase engine speed until a vacuum pressure of 500 mmHg (19.69 inHg) is registered on vacuum pressure gauge. With a vacuum pressure of 500 mmHg (19.69 inHg) held, measure an oil pressure with respect to each pedal operating force.

Relationship between oil pressure and pedal operating force is illustrated in Figure BR-28. If test results are not as specified in Figure BR-28, check Master-Vac for condition in a manner as described under Inspection, before removal of this unit.

Also check brake line for evidence of fluid leakage.

**Note:** Determine whether malfunction occurs in Master-Vac or in check valve. Always inspect check valve first.

15 seconds, replace check valve with a new one.

3. When pressure is applied to the Master-Vac side of check valve and valve does not open, replace check valve with a new one.





Fig. BR-28 Performance curves of Master-Vac

## Brake System

### REMOVAL

Referring to Figure BR-29, remove parts in numerical order enumerated.



BR175

Fig. BR-29 Removal method of Master-Vac

### DISASSEMBLY

When disassembling Master-Vac, observe the following instructions:


- Thoroughly clean mud or dust from Master-Vac.
- Extreme care should be taken not to allow dirt, dust, water or any other foreign matter into any component parts.

Be sure to select a clean place before disassembly or assembly.

- Mark mating joints so that they may be installed exactly in their original positions.
- Keep all disassembled parts arranged properly so that they may readily be assembled at any time.
- Clean rubber parts and synthetic resin parts in alcohol.
- After all disassembled parts are cleaned in a suitable clean solvent, place on a clean work bench. Use care not to allow dirt and dust to come into contact with these parts.

1. Install spacer on rear shell spacer temporarily. Place Master-Vac in a vise. Use soft jaws.

2. Remove clevis and lock nut. Detach valve body guard.




1 Clevis  
2 Lock nut  
3 Valve body guard

BR075

Fig. BR-30 Removing rear shell

3. Identify front shell and rear shell clearly so that they may be reassembled in their original positions from which they were withdrawn. (Bolts attached on dashboard are not the same in pitch.)

4. Using Master-Vac Wrench ST08080000, remove rear shell-seal assembly, and disassemble diaphragm plate assembly, front shell assembly, diaphragm spring and push rod assembly.




BR076

Fig. BR-31 Removing rear shell

### Rear shell-seal

Pry off retainer with use of screwdriver as shown and detach bearing and seal.

**Note:** Do not disassemble seal assembly unless absolutely necessary. Whenever this is to be removed, use care not to damage it.




BR078

Fig. BR-32 Removing retainer

### Diaphragm plate

1. Place diaphragm plate assembly on a clean work bench. Detach diaphragm from groove in plate as shown.




BR079

Fig. BR-33 Separating diaphragm

2. Using a screwdriver as shown, evenly pry air silencer retainer until it is detached from diaphragm plate assembly.

**Note:** Never use a hammer to remove this retainer since this will be the sure way of damaging it.




BR322

Fig. BR-34 Removing air silencer retainer

3. Pull out valve plunger stop key and withdraw silencer and plunger assembly.

**Note:** To remove valve plunger stop key properly, proceed as follows: With key hole facing down, lightly push valve operating rod simultaneously while applying vibration to it.



BR180

Fig. BR-35 Pulling out stop key




Fig. BR-36 Removing valve operating rod assembly

4. Withdraw reaction disc.




Fig. BR-37 Removing reaction disc

## Front shell-seal

1. Detach flange from front shell assembly.




Fig. BR-38 Removing flange

2. Withdraw front seal assembly.

## INSPECTION

1. Check poppet assembly for condition. If it shows evidence of wear or damage, replace it and valve operating rod assembly.
2. Check other component-parts for condition. If any part shows evidence of wear or damage, replace it with a new one.

## ASSEMBLY AND ADJUSTMENT

Assemble in the reverse sequence of disassembly.

### Rear shell-seal

1. Apply a coating of Master-Vac grease to the sealing surface and lip of seal, and install that seal in rear shell with the use of Master-Vac Oil Seal Retainer Drift ST08060000.




Fig. BR-39 Installing oil seal

Note: Referring to Figure BR-40, install seal in place by properly aligning the pawl of special tool with seal hole. Adjustment is correct when specified length at "A" is obtained.

Length "A"  
6.7 to 7.0 mm  
(0.264 to 0.276 in)




Fig. BR-40 Length at "A"

### Diaphragm plate

1. Apply a thin coating of grease to the sliding contact portion on the periphery of plunger assembly.




Fig. BR-41 Requiring grease place

2. Install plunger assembly and silencer in diaphragm plate, and lightly push plunger stop key in place.

Note: Diaphragm plate is made of bakelite. Exercise care in installing plunger assembly not to damage diaphragm plate.




Fig. BR-42 Inserting stop key

3. Before installing diaphragm into position, apply a thin coating of mica-power to it except outer diameter and seating portion with which shell comes into contact.
4. Before installing reaction disc in place on diaphragm plate, apply a thin coating of Master-Vac grease.

### Front shell-seal

Before installing front shell-seal assembly, apply a coating of Master-Vac grease to the inner wall of seal and front shell with which seal comes into contact.

### Final assembly

1. Apply thin coating of Master-Vac grease to the outer edges of diaphragm with which rear and front shells come into contact, before installing diaphragm in position.
2. Before installing push rod assembly in place, apply a coating of Master-Vac grease to the sliding contact surface of diaphragm plate.

## Brake System

3. Align marks scribed in the rear shell and front shell. Carefully turn the Master-Vac Wrench ST08080000 clockwise until it reaches notch in shell retainer.





Fig. BR-43 Tightening rear shell


4. After assembly, adjust the length of push rod to less than the specified value indicated below. Length adjustment of push rod is made at the tip of push rod.

Length "B"  
10.0 to 10.5 mm  
(0.394 to 0.413 in)



BR290

Fig. BR-44 Length at "B"



BR288

Fig. BR-45 Adjusting push rod length

## INSTALLATION

Install in the reverse sequence of removal.

### Tightening torque:

Master cylinder to Master-Vac:

0.8 to 1.1 kg-m

(6 to 8 ft-lb)

Master-Vac to body:

0.8 to 1.1 kg-m

(6 to 8 ft-lb)

**Note:** After Master-Vac is properly installed on vehicle, be sure to conduct an air-tight test and operation test described previously in this section.

## HAND BRAKE

### CONTENTS

HAND BRAKE (Stick lever type) ..... BR-18  
REMOVAL ..... BR-19

INSPECTION ..... BR-19  
INSTALLATION ..... BR-19

## HAND BRAKE (Stick lever type)

The hand brake system is of a cable reaction type, which actuates rear

wheel brake shoes. All the cable adjustment can be made by operating

only adjusting nut at balance lever.




Fig. BR-46 Hand brake linkage

## REMOVAL

### Control stem

1. Disconnect terminal from hand brake warning switch.
2. Remove nuts securing control bracket in place on dash panel.
3. Pull out lock pin and cotter pin, and then remove control stem assembly.




Fig. BR-47 Control stem

### Front cable

1. Fully release control stem.
2. Loosen adjusting nut at balance lever.
3. Disconnect front cable from control lever.
4. Remove retainer spring at cable guide bushing.
5. Disconnect rear cables (R.H. and L.H.) from balance lever brackets. See Figure BR-48.
6. Remove balance lever brackets from crossmember.
7. Detach front cable clip and pull front cable rearward.




Fig. BR-48 Balance lever

### Rear cable

1. Fully release control stem.
2. Remove both rear brake drums, and disconnect rear cable from toggle lever.
3. Detach spring and spring retainer.
4. Remove rear cable from brake disc.
5. Disconnect rear cable from balance lever bracket.
6. Detach cable clips and remove rear cable.

## INSPECTION

1. Check control stem and ratchet for evidence of wear or other damages. Replace parts which are faulty.
2. Replace worn or fatigued springs.
3. Check wires for evidence of discontinuity or other deterioration. Replace if necessary.
4. Replace faulty warning light and/or switch.
5. Check parts at each connection and, if found deformed or damaged, replace.

## INSTALLATION

Install hand brake assembly in the reverse sequence of removal by closely observing the following instructions.

1. When installing, apply a coating of grease to sliding contact surfaces. Make sure that each sliding part functions smoothly.
2. Upon completion of installation of hand brake assembly, adjust the entire system, referring to the instructions described under topic Adjustment.
3. Make sure that each cable is not interfered with by any adjacent parts. Do not apply an undue stress to cables.



## SERVICE DATA AND SPECIFICATIONS

### Brake pedal

Free height	mm (in)	148 (5.83)
Free play at pedal pad	mm (in)	1 to 3 (0.04 to 0.12)
Full stroke at pedal pad	mm (in)	134 to 140 (5.28 to 5.51)
Depressed height	mm (in)	43 to 49 (1.69 to 1.93)

### Brake adjustment notches

Front	12
Rear	12

### Master cylinder

Inner diameter	mm (in)	19.05 (¾)
Piston to cylinder clearance	mm (in)	0.15 (0.0059)

### Master-Vac

Diaphragm diameter	mm (in)	152.4 (6)
Maximum vacuum leakage (after 15 sec.)	mmHg (inHg)	25 (0.98)
Shell seal depth A	mm (in)	6.7 to 7.0 (0.264 to 0.276)
Push rod length B	mm (in)	10.0 to 10.5 (0.394 to 0.413)

### Front drum brake

Type .....	Uni-servo
Wheel cylinder inner diameter                      mm (in) .....	19.05 (¾)
Lining	45 x 4.5 x 244
Width x Thickness x Length                      mm (in) .....	(1.77 x 0.177 x 9.61)
Lining wear limit                                      mm (in) .....	1.0 (0.039)

### Rear drum brake

Type .....	Duo-servo
Wheel cylinder inner diameter	mm (in) ..... 19.05 (¾)

### Brake drum

Inner diameter	mm (in)	254.0 (10)
Repair limit of thickness	mm (in)	255.5 (10.06)
Inside runout	mm (in)	0.02 (0.0008) maximum

### Parking brake

Type .....	Stick type
Stroke mm (in) .....	80 to 100 (3.15 to 3.94)
Adjuster sliding resistance kg (lb) .....	5 to 12 (11 to 26)

## Brake System

---

### Tightening torque

Master cylinder to Master-Vac	kg-m (ft-lb) .....	0.8 to 1.1 (6 to 8)
Brake tube flare nut	kg-m (ft-lb) .....	1.5 to 1.8 (11 to 13)
Brake hose connector	kg-m (ft-lb) .....	1.8 to 2.1 (13 to 15)
Air bleeder valve	kg-m (ft-lb) .....	0.7 to 0.9 (5 to 7)
Fulcrum pin of brake pedal	kg-m (ft-lb) .....	1.2 to 1.5 (9 to 11)
Connector and clip fixing bolt	kg-m (ft-lb) .....	0.35 to 0.45 (2.5 to 3.3)
3-way connector fixing bolt (on rear axle case)	kg-m (ft-lb) .....	0.8 to 1.1 (6 to 8)
Brake pedal stopper lock nut	kg-m (ft-lb) .....	1.2 to 1.5 (9 to 11)
N.L.S.V. to body	kg-m (ft-lb) .....	0.8 to 1.1 (6 to 8)
Wheel cylinder mounting nut		
Front	kg-m (ft-lb) .....	5.4 to 6.6 (39 to 48)
Rear	kg-m (ft-lb) .....	1.5 to 1.8 (11 to 13)
Wheel cylinder connector bolt	kg-m (ft-lb) .....	1.9 to 2.5 (14 to 18)
Brake disc (Back plate) nut		
Front	kg-m (ft-lb) .....	4.2 to 5.0 (30 to 36)
Rear	kg-m (ft-lb) .....	5.4 to 6.4 (39 to 46)
Master-Vac		
Master-Vac to body nut	kg-m (ft-lb) .....	0.8 to 1.1 (6 to 8)
Flange to shell cover nut	kg-m (ft-lb) .....	0.8 to 1.1 (6 to 8)
Operating rod lock nut	kg-m (ft-lb) .....	1.6 to 2.2 (12 to 16)
Push rod adjusting nut	kg-m (ft-lb) .....	1.9 to 2.4 (14 to 17)

## Brake System

### TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
Excessive pedal travel	<p>Low brake fluid level or empty master cylinder reservoir.</p> <p>Leakage in master cylinder.</p> <p>Deteriorated check valve.</p> <p>Air in system.</p> <p>Faulty brake adjustment.</p>	<p>Fill and bleed as necessary. Test for source of leakage by examining all lines, connections and wheel cylinder.</p> <p>Overhaul master cylinder.</p> <p>Replace check valve and bleed system.</p> <p>Bleed system.</p> <p>Adjust shoe-to-drum clearance. Inspect auto-adjuster operation.</p>
Spongy pedal	<p>Low fluid level in master cylinder.</p> <p>Air in system.</p> <p>Faulty brake adjustment.</p> <p>Reservoir filler cap vent hole clogged.</p> <p>Swollen hose due to deterioration or use of poor quality hose.</p> <p>Distorted brake shoes, or excessively worn or cracked brake drum.</p> <p>Soft or swollen caliper seals.</p> <p>Use of a brake fluid with too low boiling point.</p>	<p>Top with fluid and inspect for leakage.</p> <p>Correct as necessary.</p> <p>Adjust shoe-to-drum clearance. Inspect auto-adjuster operation.</p> <p>Clean and bleed system.</p> <p>Replace hose and bleed system.</p> <p>Replace faulty parts.</p> <p>Drain hydraulic system, flush with alcohol and replace all seals.</p> <p>Replace with specified brake fluid and bleed system.</p>
Poor braking effect	<p>Fluid leakage in brake lines.</p> <p>Low brake fluid level or empty master cylinder reservoir.</p> <p>Air in brake lines.</p> <p>Excessive shoe-to-drum clearance.</p> <p>Grease, oil, mud or water on linings or pads.</p> <p>Deterioration of linings or pads.</p> <p>Local fit of linings or pads.</p> <p>Linings or pads excessively worn.</p> <p>Master cylinder or wheel cylinders in poor condition.</p> <p>Binding mechanical linkage at brake pedal and shoes.</p>	<p>Check master cylinder, piping and wheel cylinder for leaks, and repair.</p> <p>Fill and bleed as necessary.</p> <p>Bleed system.</p> <p>Adjust.</p> <p>Clean brake mechanism and check for cause of problem. Replace linings or pads.</p> <p>Replace.</p> <p>Shave or replace.</p> <p>Replace.</p> <p>Repair or replace.</p> <p>Free up as required.</p>
(Brakes drag)	<p>Clogged brake lines.</p> <p>Incorrect adjustment of wheel bearings.</p> <p>Improper shoe-to-drum clearance.</p> <p>Weak shoe return springs.</p> <p>No free travel in brake shoe return.</p>	<p>Check and clean.</p> <p>Adjust or repair.</p> <p>Adjust.</p> <p>Replace.</p> <p>Adjust pedal height.</p>




## Brake System

Condition	Probable cause	Corrective action
Brake chatters	Groove or out-of-round brake drum. Loose or bent brake disc.  Distorted brake shoes or pads. Grease or brake fluid on linings.	Grind or replace as required. Tighten support plate bolts to specified torque, or replace plate. Replace as necessary. Replace linings.
Brake squeals	Dirty or scored brake drums.  Distorted brake shoes or bent support plate. Weak or broken brake shoe retaining spring or return spring. Glazed or contaminated brake lining.	Blow out assembly with compressed air or refinish drum. Replace faulty unit. Replace if faulty.  Cam ground lining to eliminate glaze. If it doesn't, replace linings.
Pedal pulsates	Out-of-round or off-center drum.	Turn drum or replace as necessary.
Brakes fade	Brake fluid has too low boiling point. Use of improper linings or brake linings are contaminated. Brake drums are out-of-round. Hydraulic connections, master cylinder and wheel cylinders are corroded or damaged. Bleed screw is open.	Drain and fill system with approved fluid. Replace linings.  Repair or replace as necessary. Repair as necessary.  Close screw and bleed system.
Brakes drag	Pedal linkage is binding or push rod adjustment is too long.  Master cylinder compensator part is obstructed. Seized master cylinder piston.  Poor shoe condition.  Poor wheel cylinder condition. Deformation of piston cups. Hand brake will not return. Clogged master cylinder return port.	Lubricate linkage, check pedal return spring for condition and adjust push rod as necessary.  Blow out foreign matter with compressed air.  Disassemble master cylinder and replace piston. Bleed system. Clean and repair.  Repair or replace. Replace. Check and repair. Clean.
Unbalanced brakes	Improper tire inflation. Improper adjustment of shoe-to-drum clearance. Grease, oil, mud or water on linings or pads.  Mud in brake drum. Deterioration of linings or pads. Excessive wear of linings or pads.	Inflate to correct pressure. Readjust.  Clean brake mechanism and check for cause of problem. Replace linings or pads. Clean. Replace. Replace.

## Brake System

Condition	Probable cause	Corrective action
	Wheel cylinder in poor condition. Poor sliding condition of brake shoe. Looseness of cylinder body or back plate securing bolts. Scored or out-of-round drums.  Sticking wheel-cylinder cups. Deformation of back plate. Incorrect adjustment of wheel bearings. Incorrect adjustment of wheel alignment. Looseness of leaf spring securing U-bolts. Faulty N.L.S.V.	Repair or replace. Adjust. Fasten or replace.  Recondition or replace brake drum as required. Check for improper lining contact with drum and grind lining if necessary. Recondition or replace cylinder. Replace. Adjust or replace. Adjust. Tighten or replace. Replace.
Pedal yields under slight pressure.	Deteriorated check valve. External leaks.  Leakage on master cylinder.	Replace check valve and bleed system. Check master cylinder, piping and wheel cylinder for leaks and repair. Overhaul master cylinder.

## SPECIAL SERVICE TOOLS

No.	Tool number & tool name	Description  Unit: mm (in)	For use on	Reference page or Figure No.
1.	GG94310000  Flare nut torque wrench	<p>This tool is used to tighten and untighten brake tube flared nut. A built-in torque limiting wrench is provided to assure torque accuracy.</p>  <p>SE227</p>	All models	Page BR-8
2.	ST08080000  Master-Vac wrench	<p>This tool is used to remove rear shell after aligning rear shell stud bolt with the opening in this tool.</p>  <p>SE073</p>	All models	Fig. BR-31
3.	ST08060000  Master-Vac oil seal retainer drift	<p>This tool is used when rear shell seal is driven into position.</p> <p><b>Note:</b> Make sure that this tool is pushed in until rear guide of this tool touches rear shell.</p>  <p>SE115</p>	All models	Fig. BR-39

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES

## SECTION WT

## WHEEL AND TIRE

WT

WHEEL AND TIRE ..... WT- 2

TROUBLE DIAGNOSES AND ..... WT- 5  
CORRECTIONS



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

# WHEEL AND TIRE

## CONTENTS

DESCRIPTION .....	WT-2	TIRE ROTATION .....	WT-3
MAINTENANCE AND SERVICE .....	WT-2	CHANGING TIRE .....	WT-3
TIRE INFLATION .....	WT-2	INSPECTION .....	WT-4
TIRE REPAIR .....	WT-2	WHEEL BALANCE .....	WT-4
WHEEL REPAIR .....	WT-2	WHEEL AND TIRE .....	WT-4
WEAR .....	WT-2		

## DESCRIPTION

The 620 series models are equipped with 4½J-14 wheels with 25 mm (0.98 in) offset. All tires are tubeless.

### Tire size

Model	Tire size	Wheel size
All models	6.00-14-6PR (Tubeless)	4½J-14

### Tire pressure

Unit: kg/cm<sup>2</sup> (psi)

Vehicle speed km/h (MPH)			Under 100 km/h (60 MPH)	Over 100 km/h (60 MPH)
Model	Unloaded	Front	1.5 (21)	1.8 (26)
		Rear	1.75 (25)	2.25 (32)
All models	Loaded	Front	1.5 (21)	1.8 (26)
		Rear	3.0 (42)	3.15 (45)

**Note:** Tire inflation pressures should be measured when tires are cold.

## MAINTENANCE AND SERVICE

### TIRE INFLATION

Correct tire pressure is very important to ease of steering and riding comfort. This also reduces driving sound to a minimum, resulting in longer tire life; that is, overinflation or

underinflation promotes wear at center tread or shoulder of tire.

If all tires are inspected frequently and maintained correct tire pressure, it is possible to detect sharp material in the tread. Also, the above check avoids abnormal wear which invites serious problem. If tires indicate abnormal or uneven wear, the cause of problem should be detected and eliminated.

After inflating tires, leakage in valve should be checked. Without valve caps, leakage will occur due to dirt and water, resulting in underinflation. Accordingly, whenever tire pressure is checked, be sure to tighten valve caps firmly by hand.

### TIRE REPAIR

In order to inspect a leak, apply soapy solution to tire or submerge tire and wheel in the water after inflating tire to specified pressure. Special inspection for leaks should be carried out around the valve, wheel rim and along the tread. Exercise care to bead and rim where leakage occurs. Wipe out water from area which leaks air bubbles and then mark the place with chalk.

After removing the materials which caused puncture, seal the point. When repairing the puncture, use the tire repair kits which are furnished from tire dealers, following the instructions provided with the kits. In case that a puncture becomes large or there is any other damage on the tire fabric, repair must be carried out by authorized tire dealers.

### WHEEL REPAIR

Inspect the wheel rim flange for bend or dents.

The flange should be cleaned by a wire brush when rust is found on the flange. Furthermore, if excessive pitting occurs on the rim, eliminate it with a file.

### WEAR

#### Misalignment

When the front wheels align in excessive toe-in or toe-out condition, tires scrape the tread rubber off. The wear of tread appears feathered edge.




## Wheel and Tire

### Center


This wear is caused by overinflation of the tire. The inflation pressure must be kept at the specified value.

### Shoulder


The wear may be caused by underinflation, incorrect wheel camber, or continuous high speed driving on curves. In general, the former two causes are common. Underinflation wear occurs on both sides of treads,




Toe-in or toe-out wear



Underinflation wear



Overinflation wear



Uneven wear


WT007

Fig. WT-1 Abnormal tire wear

and on the other hand, camber causes wear only on one side of treads. For cornering tread wear, the driver must operate vehicle slowing down on curves.

### Uneven

Uneven wear is caused by incorrect camber or caster, malfunctioning suspension, unbalanced wheel, out-of-round brake drum, or other mechanical conditions. To repair this abnormal wear, correct the above faulty parts.




WH024

Fig. WT-4 Tread wear indicator

## CHANGING TIRE

To change tire with wheel using a jack in the safe manner, observe the following procedures.

1. To remove spare tire, insert jack rod to guide and then turn it counter-clockwise. When installing, tighten a little strong after lifting up and lock.



WH081

Fig. WT-5 Removing spare tire

## TIRE ROTATION

Tires wear unevenly and become unbalanced according to running distance. Uneven tire wear often results in tire noise which is attributed to rear axle gears, bearing, etc. Meanwhile, the front tires tend to wear unevenly because of improperly aligned front wheel.

Accordingly, to equalize tire wear, it is necessary to rotate tires periodically.

- All the tires including the spare tire are of the same type.





Fig. WT-2 Tire rotation (1)


- The spare tire has a different brand from 4 tires on the vehicle.



- \* The spare tire should be used in an emergency only.

Fig. WT-3 Tire rotation (2)

The tires are provided with "tread wear indicator" at six places around tire circumference, indicating 1.6 mm ( $\frac{1}{16}$  in) tread depth. When the tires wear and then the marks appear, replace them with new ones. See Figure WT-4.



WT012

Fig. WT-6 Jacking up front side

## Wheel and Tire

4. To jack up rear, place jack under rear axle case close to the side of rear spring after applying parking brake and blocking front wheels.




Fig. WT-7 Jacking up rear side

5. Remove wheel nuts and wheel from drum.
6. To install wheel, reverse the above steps.

Tighten wheel nuts in criss-cross fashion to 8.0 to 9.0 kg-m (58 to 65 ft-lb).

**Note:** Never get under the vehicle while it is supported only by the jack. Always use safety stands to support the side member of body construction when you must get beneath the vehicle.

## INSPECTION

### WHEEL BALANCE

The wheel and tire assembly should be kept balanced statically and dynamically.

Proper tire balance is necessary when driving the vehicle at high speeds. Consequently, the wheel and tire assembly should be properly re-balanced whenever puncture is repaired.

The wheel and tire assembly becomes out of balance according to uneven tire wear. Severe acceleration and braking, or fast cornering is the cause of wear on tire, resulting in unbalance of tire and wheel assembly.

The symptom of unbalance appears as tramp, vehicle shake and steering malfunction.

To correct unbalance, use proper wheel balancer.

Maximum allowable unbalance:

177 gr-cm (2.5 in-oz)

10 gr. (0.35 oz) at rim circumferences

Balance weight:

10 to 60 gr. (0.35 to 2.12 oz)

at 10 gr. (0.35 oz) interval

**Note:** Be sure to place the correct balance weights on the inner edge of rim as shown in Figure WT-8. Do not put more than two weights on each side.

### WHEEL AND TIRE

In order to ensure satisfactory steering condition as well as maximum tire life, proceed as follows:

1. Check wheel rim for rust, distortion, cracks or other faults.

Thoroughly remove rust, dust, oxidized rubber or sand from wheel rim with wire brush, emery cloth or paper. Use dial gauge to examine wheel rim for lateral run-out.

Lateral run-out limit:

Less than 1.5 mm (0.059 in) total indicator reading




Fig. WT-8 Wheel rim run-out check points

**Note:** In replacing tire, take extra care not to damage tire bead, rim-flange and bead seat.

Do not use tire irons to force beads away from wheel rim-flange; that is, always use tire replacement device whenever tire is removed.

2. Discard when any of the following problems occur:

- (1) Broken or damaged bead wire.
- (2) Ply or tread separation.
- (3) Cracked or damaged side wall, etc.

## TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
Wheel wobbles.	Improper tire pressure. Damaged tire or distorted wheel rim. Unbalanced wheel. Loose wheel nuts. Worn or damaged wheel bearing, or excessive play of wheel bearing. Improper front wheel alignment. Worn or damaged ball joint. Excessive steering linkage play or worn steering linkage. Loose steering linkage connection.  Broken suspension spring. Damaged shock absorber.	Measure and adjust. Repair or replace. Balance. Tighten. Correct play or replace wheel bearing.  Align. Replace. Adjust or replace.  Tighten nuts to rated torque, or replace worn parts if any. Replace. Replace.
Unevenly or excessively worn tire.	Improper tire rotation. Improper tire pressure. Unbalanced wheel. Improperly adjusted brake. Improper wheel alignment. Excessively distorted or improperly installed suspension link. High speed on curves. Sudden start and improper speed due to rapid acceleration or improper brake application.	Conduct tire rotation periodically. Measure and adjust. Balance or replace. Adjust. Align. Repair, replace or, if necessary, reinstall.  Reduce speed. Follow correct and proper driving manner.
Tire squeals.	Improper tire pressure. Improper front wheel alignment. Distorted knuckle or suspension link.	Measure and adjust. Align. Repair or replace.

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES

## SECTION ST

### STEERING SYSTEM

ST

STEERING .....	ST- 2
SERVICE DATA AND SPECIFICATIONS .....	ST- 8
TROUBLE DIAGNOSES AND CORRECTION .....	ST- 9
SPECIAL TOOLS .....	ST-10



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

# STEERING SYSTEM

## STEERING

### CONTENTS

DESCRIPTION .....	ST-2	Inspection and repair .....	ST-5
STEERING GEAR .....	ST-3	STEERING LINKAGE .....	ST-6
Removal and installation .....	ST-3	Removal and installation .....	ST-6
Disassembly and assembly .....	ST-4	Inspection and repair .....	ST-7

### DESCRIPTION

The steering gear used on this model series vehicles is the same recirculating type. This steering gear is designed especially for easy operation and high durability.


The steering linkage is of a relay design, of which gear arm is connected to one end of the adjustable cross rod.

The other end of the cross rod is linked to the idler arm connecting with the side member located on the opposite side of the steering gear. The two side rods serve to connect the steering gear arm and idler arm to the both knuckle arms (right and left hand sides).

With this construction, even if the left and/or right wheel moves vertical-

ly and independently, steering can be safely maintained.

Steering wheel rotation is converted to gear arm motion in proportion to the gear ratio by the steering gear. The gear arm motion operates the side rod on the same side. At the same time, the idler arm is moved through the cross rod, and the opposite side rod is also moved.




ST528

Fig. ST-1 Structural view of steering system

# STEERING SYSTEM

## STEERING GEAR



ST199

Fig. ST-2 Sectional view of steering gear

## Removal and installation

### Removal

1. Disconnect battery ground cable from the terminal.
2. Remove horn pad by unscrewing two bolts from the rear side of steering wheel bar.

**Note:** Be sure to punch mark with "o" on the top of steering column shaft.




Fig. ST-3 Removing horn pad

3. Remove steering wheel with Steering Wheel Puller ST27180001 after backing off steering wheel fixing nut.




Fig. ST-4 Removing steering wheel

**Note:** Be sure not to hammer the special tool while removing.

4. Remove upper and lower steering column shell covers.
5. Remove turn signal switch assembly.

6. Remove column clamp fixing bolts.




Fig. ST-5 Removing column clamp

7. Remove four bolts securing steering post grommet to dash panel.
8. Remove nut securing gear arm to sector shaft and then withdraw gear arm with the use of Pitman Arm Puller ST29020001.

# STEERING SYSTEM




Fig. ST-6 Withdrawing gear arm

Note: Before removing steering gear arm, scribe match marks on arm and housing so that they can easily be replaced in their original positions at assembly.

9. Remove three bolts securing steering gear housing to frame.
10. Withdraw steering gear assembly toward engine compartment.

## Installation

Install steering gear assembly in the reverse order of removal observing the following instructions.

1. When installing steering gear housing securing bolts, insert two bolts through gear housing to frame.
2. When installing steering gear arm, align four grooves of gear arm serrations with four projections of sector shaft serrations.
3. Tightening torque

Steering gear housing:

4.6 to 5.3 kg-m (33 to 38 ft-lb)

Gear arm:

13 to 15 kg-m (94 to 108 ft-lb)

Steering wheel:

7.0 to 7.5 kg-m (51 to 54 ft-lb)

4. With front wheels set in a straight ahead position, make sure that punch mark on the upper end surface of steering column shaft is at the center of the upper side in its installing portion.
5. When installing steering wheel, apply grease to sliding parts.
6. After installing, make sure that steering wheel turns smoothly.

## Disassembly and assembly

### Disassembly

1. Drain oil in steering gear housing by unscrewing filler plug.
2. Place steering gear assembly in a vise securely.
3. Loosen lock nut and turn sector shaft adjusting screw a few turns counterclockwise.

Remove sector shaft cover by unscrewing four fixing bolts.




Fig. ST-7 Removing sector shaft cover

4. Turn sector shaft adjusting screw a few turns clockwise and pull sector shaft cover together with sector shaft from gear housing.




Fig. ST-8 Pulling out sector shaft

5. Separate sector shaft, adjusting screw and shim from cover.
6. Remove jacket tube by unscrewing three fixing bolts.
7. Remove steering worm assembly from gear housing.
8. Detach worm bearings and worm bearing adjusting shims from worm gear assembly and column jacket.

Note: Be careful not to allow ball nut to run down to the worm end. If ball nut rotates suddenly to the worm end, the ends of ball guides may be damaged.

9. Pry out sector shaft oil seal from gear housing and discard it.
10. Remove O-ring from the rear cover of column jacket and discard it.
11. Remove column jacket bushing.

### Notes:

- a. Do not remove sector shaft bushing from housing. If necessary, replace as a gear housing assembly.
- b. Do not disassemble ball nut and worm gear. If necessary, replace them with new ones as a worm gear assembly.




Fig. ST-9 Removing steering worm assembly

## Assembly and adjustment

Apply recommended gear oil to all disassembled parts.

1. Fit column jacket bushing to column jacket in place.

Note: When fitting, apply adhesive to bushing exterior and grease to interior.

2. Fill the space between new sector shaft oil seal lips with grease, and fit it to gear housing.
3. Place steering worm assembly in position in gear housing together with worm bearings.
4. Install column jacket on gear housing with O-ring and worm bearing shims.

Be sure to install thicker shims to the gear housing side.

Standard shim thickness:

1.5 mm (0.059 in)

Tightening torque:

1.5 to 2.5 kg-m (11 to 18 ft-lb)

## STEERING SYSTEM

Available worm bearing adjusting shim

No.	Thickness mm (in)
1	0.762 (0.0300)
2	0.254 (0.0100)
3	0.127 (0.0050)
4	0.050 (0.0020)

5. Adjust the worm bearing preload with Preload Gauge ST3127S000 by selecting suitable bearing shims so that the initial turning torque of steering column is the specified value.

Initial turning torque of steering column shaft.

New worm bearing:

4.0 to 6.0 kg-cm (56 to 83 in-oz)

Used worm bearing:

2.4 to 4.4 kg-cm (33 to 61 in-oz)

6. Insert adjusting screw into the T-shaped groove at the sector shaft head, and adjust the end play between sector shaft and adjusting screw until it is within 0.01 to 0.03 mm (0.0004 to 0.0012 in) by choosing suitable adjusting shims.

Available sector shaft adjusting screw shim

No.	Thickness mm (in)
1	1.575 (0.0620)
2	1.550 (0.0610)
3	1.525 (0.0600)
4	1.500 (0.0591)
5	1.475 (0.0581)
6	1.450 (0.0571)

7. Rotate ball nut by hand until it is in the center of its travel, then install sector shaft together with adjusting screw in gear housing, ensuring that the center gear of sector shaft engages with that of ball nut.

8. Install sector shaft cover to gear housing. Be sure to apply sealant to each face of sector shaft cover packing when installing cover.

9. By turning adjusting screw counterclockwise, attach sector shaft cover to gear housing and then temporarily secure it with its fixing bolts.

10. Pull sector shaft toward cover approximately 2 to 3 mm (0.08 to 0.12 in) by turning adjusting screw counterclockwise and tighten sector shaft cover fixing bolts to 1.5 to 2.5 kg-m (11 to 18 ft-lb).

11. Push sector shaft against ball nut gear by gradually turning adjusting screw clockwise until sector shaft gear lightly meshes with ball nut gear and then temporarily secure adjusting screw with lock nut.

12. Install gear arm to sector shaft and move sector shaft several times from the side of gear arm and make sure that it turns smoothly.

13. Adjust the backlash at the neutral position of gear arm by turning in or out adjusting screw so that the movement of the gear arm top end is less than 0.1 mm (0.004 in).




Fig. ST-10 Measuring backlash

14. Turn adjusting screw approximately 1/8 to 1/6 turn clockwise and then retighten lock nut to 3.0 to 4.0 kg-m (22 to 29 ft-lb).

15. Fill recommended gear oil approximately 0.33 liter (3/4 U.S. pt., 3/4 Imper. pt.) into gear assembly through the filler hole and install filler plug.

## Inspection and repair

Wash clean all the disassembled parts in solvent and check for conditions.

### Sector shaft

1. Check gear tooth surface for pitting, burrs, cracks or any other damage, and replace if faulty.
2. Check sector shaft for distortion of its serration, and if necessary replace. In this case, be sure to check gear housing for deformation.

### Steering column shaft assembly

1. Inspect the ball nut gear tooth surface, and replace if pitting, burrs, wear or any other damage is found.
2. Ball nut must rotate smoothly on worm gear. If found too tight, assembly should be replaced. Check as follows:

Move ball nut to either end of worm gear, and gradually stand steering column shaft assembly until ball nut moves downward on worm gear under its own weight. In the above test, if ball nut does not move freely over entire stroke, assembly may be damaged. Replace with a new one as an assembly.

**Note:** In this inspection, be careful not to damage ball nut guide tube.

### Bearings and bushings

1. Replace worm bearings if pitting, wear or any other damage is found on them.
2. Replace column bushing which is excessive worn or deformed.
3. If sector shaft bushings in gear housing are found worn or damaged, replace as an assembly of gear housing and bushing.

### Oil seal, gasket and O-ring

Do not reuse above parts which are removed once.

Be sure to use new parts at each reassembly.



# STEERING SYSTEM

## STEERING LINKAGE

### Removal and installation

#### Removal

1. Jack up the front of vehicle and support it on the safety stands.
2. Remove cotter pins and nuts fastening side rod ball stud to knuckle arms.
3. To detach side rod ball studs from knuckle arms, insert Ball Joint Remover HT72520000 between them and separate them by striking the top of this tool with a hammer. If this operation must be done without this tool, strike the knuckle arm boss with a hammer backing up the opposite side of it with a large hammer and ball stud is freed from knuckle arm. Must not strike the ball stud head, the ball socket of side rod and side rod with a hammer and so on in this operation.




Fig. ST-11 Ball joints (gear arm side)

4. Remove nut securing gear arm on sector shaft, and remove gear arm with the use of Pitman Arm Puller ST29020001. See Figure ST-6.
5. Remove idler arm assembly from frame by backing off fixing bolt and nut.




Fig. ST-12 Removing idler arm

6. Cross rod, both side rods and the adjacent parts can then be freed from the vehicle as an assembly.
7. Then separate the ball joints of steering linkage assembly following the procedure for removal of the side rods ball joints at knuckle arm sides.

#### Assembly

Install steering linkage in the reverse sequence of removal observing the following notes:

1. Tightening torque:

Ball stud: 5.5 to 10.0 kg-m  
(40 to 72 ft-lb)

Idler arm assembly:

3.2 to 3.7 kg-m  
(23 to 27 ft-lb)

Cross rod adjust bar lock nut:  
8 to 10 kg-m  
(58 to 72 ft-lb)

2. When cross rod sockets and cross rod are separated, adjust cross rod length correctly.

Adjustment should be done between the centers of ball joints at the both end of cross rod assembly.

Standard cross rod length:

516 mm (20.31 in)

3. Adjust toe-in and steering angle.

The procedures of toe-in and steering angle adjustments are described in Section FA.


Toe-in:

1 to 5 mm (0.04 to 0.20 in)

Steering angle:

Inner wheel: 35°30' to 36°30'

Outer wheel: 30°30' to 31°30'




- 1 Cross rod
- 2 Side rod
- 3 Cross rod socket
- 4 Idler arm assembly
- 5 Gear housing assembly

\*After adjustment of toe-in, be sure that dimension "A" at both ends of cross rod is not less than 20 mm (0.79 in).

ST210

Fig. ST-13 Adjusting cross rod assembly

#### Idler arm assembly



- 1 Idler body
- 2 Collar (welded to idler body)
- 3 Plain bushing
- 4 Screw bushing

ST529

Fig. ST-14 Sectional view of idler arm assembly

## STEERING SYSTEM

1. Apply recommended grease to screw bushing interior, plain bushing interior, dust seal inside and bushing sliding surface of idler arm.

Screw bushing tightening torque:  
12 kg-m (87 ft-lb)

2. Before installing idler arm assembly, replace filler plug with grease nipple, and apply recommended grease to idler arm through this grease nipple until grease is forced out at the lower end of the dust seal lip. Remove grease


nipple and reinstall filler plug.

3. In installing idler arm assembly, make sure that the standard dimension "A" is adjusted correctly.

Standard dimension "A":  
137.8 to 139.8 mm  
(5.425 to 5.504 in)

See Figure ST-14.

Furthermore, be sure to install washers correctly. See Figure ST-15.



ST212

Fig. ST-15 Locations of washers

## Inspection and repair

### Ball joint

1. When ball stud is worn or axial play is too excessive, replace cross rod socket or side rod with a new one.

2. When dust cover is broken or deformed, be sure to replace with a new one.

Axial end play: 0.1 to 0.5 mm  
(0.004 to 0.020 in)

Initial swing torque:  
5 to 15 kg-cm (70 to 209 in-oz)




Fig. ST-16 Sectional view of ball joint

Note: At the recommended intervals, check grease and renew if neces-

sary. To renew grease, remove grease nipple cap and apply recommended grease to ball joint through grease nipple until grease is forced out at the grease vent hole.

### Idler arm assembly

Remove old grease and dirt, and check idler arm assembly for wear, deformation and damage.

### Cross rod, side rod and gear arm

Check them for bending, damage and crack, and replace as necessary.

### Inspecting steering system on the vehicle which comes into collision

Steering system is very important for driving a vehicle. When the vehicle comes into collision, especially the front of the vehicle is damaged, special inspection should be done for the following matters.

If any component parts of steering system is found to be damaged, replace them with new ones.

#### 1. Steering angles correctness

Inspect side rods and cross rod for bend, and sector shaft for distortion.

#### 2. Level of steering wheel bar (with the front wheels in a straight ahead position)

If its deflection is more than about 90 degrees, the bend or distortion of sector shaft and column shaft can be seen.

#### 3. Noise during operation of steering wheel.

Inspect column shaft and jacket tube for bend.

#### 4. Smooth operation of steering wheel

Inspect sector gear for breakage, ball nut screw for dint and column shaft for bend.

#### 5. Gear arm breakage

#### 6. Gear housing breakage

In addition, inspect gear housing fixing bolts for looseness.

#### 7. Distortion of sector shaft serration

#### 8. Sector gear breakage

## STEERING SYSTEM

9. Column shaft breakage (on the welded section)

In addition, inspect column shaft for scratch.

10. Deformation of body construction and frame

Inspect the installation portion of

steering system on the body construction and frame for deformation or any other faulty conditions.

## SERVICE DATA AND SPECIFICATIONS

### SPECIFICATIONS

Gear type .....	Recirculating ball type
Gear ratio .....	19.8 : 1

### SERVICE DATA

Standard thickness of worm bearing adjusting shims	mm (in) .....	1.5 (0.059)
Initial turning torque of steering column:		
New worm bearing	kg-cm (in-lb) .....	4.0 to 6.0 (3.5 to 5.2)
Used worm bearing	kg-cm (in-lb) .....	2.4 to 4.4 (2.1 to 3.8)
End clearance of sector shaft adjusting screw	mm (in) .....	0.01 to 0.03 (0.0004 to 0.0012)
Backlash at the gear arm top end	mm (in) .....	0 to 0.1 (0 to 0.004)
Oil capacity	ℓ (U.S. pt., Imper. pt.) .....	0.33 (¾, ⅝)
Ball joint axial end play	mm (in) .....	0.1 to 0.5 (0.004 to 0.020)
Standard cross rod length	mm (in) .....	516 (20.31)
Toe-in	mm (in) .....	1 to 5 (0.04 to 0.20)
Steering angle:		
Inner wheel	.....	35°30' to 36°30'
Outer wheel	.....	30°30' to 31°30'

### Tightening torque

	Unit: kg-m (ft-lb)	
Steering column jacket to gear housing .....	1.5 to 2.5	(11 to 18)
Sector shaft cover .....	1.5 to 2.5	(11 to 18)
Sector shaft lock nut .....	3.0 to 4.0	(22 to 29)
Gear housing .....	4.6 to 5.3	(33 to 38)
Gear arm .....	13 to 15	(94 to 108)
Steering wheel .....	7 to 7.5	(51 to 54)
Ball studs of cross rod .....	5.5 to 10.0	(40 to 72)
Ball studs of side rod:		
Knuckle arm side .....	5.5 to 10.0	(40 to 72)
Gear or idler arm side .....	5.5 to 10.0	(40 to 72)





## STEERING SYSTEM

### TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
Steering wheel moves heavily.	Wheel alignment out of specifications or air pressure in tires too low.	Align or inflate tires to correct pressure.
	Steering linkage out of adjustment.	Adjust and see relative topic under Front Suspension.
	Steering column out of alignment.	Repair.
Steering wheel turns but sluggishly.	Wheels out of alignment or air pressure in tires too low.	Repair or inflate tires to correct air pressure.
	Damaged steering linkage.	Replace and see relative topic under Front Suspension.
Vehicle pulls to one side.	Wheels out of proper alignment.	Align.
	Wheel bearing out of adjustment.	Adjust.
	Damaged steering linkage.	Replace and see relative topic under Front Suspension.

# STEERING SYSTEM

## SPECIAL SERVICE TOOLS

No.	Tool number & tool name	Description  Unit: mm (in)	For use on	Reference page or Figure No.
1.	ST27180001 Steering wheel puller	<p>This tool is used to drive out steering wheel.</p> <p>Caution: Do not hammer on steering column shaft.</p>  <p>SE 116</p>	All models	Fig. ST-4
2.	ST29020001 Pitman arm puller	<p>This tool is used to remove steering pitman arm from steering sector shaft.</p>  <p>SE 401</p>	620 B210 710 610	Fig. ST-6
3.	ST3127S000 Preload gauge 1. GG91030000 Torque wrench 2. HT62940000 Socket adaptor 3. HT62900000 Socket adaptor	<p>This tool is used to measure the worm bearing preload.</p>  <p>1/4" x 3/8"</p> <p>3/8" x 1/2"</p>	All models	Page ST-5
4.	HT72520000. Ball joint remover	<p>This tool is used to remove ball joint.</p>  <p>PAT. P</p> <p>SE 399</p>	All models	Page ST-6

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

## SECTION FE

### ENGINE CONTROL, FUEL & EXHAUST SYSTEMS

FE

ENGINE CONTROL SYSTEM .....	FE- 2
FUEL SYSTEM .....	FE- 4
EXHAUST SYSTEM .....	FE- 6

# ENGINE CONTROL SYSTEM

## CONTENTS


DESCRIPTION .....	FE-2	INSPECTION .....	FE-3
REMOVAL AND INSTALLATION .....	FE-3	ADJUSTMENT .....	FE-3

## DESCRIPTION

The accelerator control system is of flexible cable type so that the linkage

operates smoothly and the system is not affected by engine vibration.

The choke system is automatically controlled.



E: 78 mm (3.07 in)  
T: 2 to 4 mm (0.08 to 0.16 in)

(MG) Multi-purpose grease

- |   |   |
|---|---|
| 1 Accelerator pedal                           | 11 Screw  |
| 2 Accelerator pedal bracket and return spring | 12 Pedal stopper bolt   |
| 3 Accelerator pedal arm                       | 13 Kickdown switch striker (Automatic transmission models only) |
| 4 Pedal stopper lock nut                      | 14 Kickdown switch (Automatic transmission models only)         |
| 5 Spring clamp                                | 15 Switch stopper nut   |
| 6 Lock nut                                    | 16 Carburetor   |
| 7 Adjust nut                                  |   |
| 8 Wire holder                                 |   |
| 9 Accelerator wire                            |   |
| 10 Accelerator wire outer case                |   |

FE260

Fig. FE-1 Accelerator control system

## REMOVAL AND INSTALLATION

### Accelerator wire

1. Remove air cleaner assembly.
2. Disconnect accelerator wire from carburetor.
3. Loosen lock nut and disconnect accelerator wire outer case from wire holder. See Figure FE-1.
4. Remove spring clamp and disconnect accelerator wire from accelerator pedal arm.
5. Remove two screws securing accelerator wire outer case to body, and detach accelerator wire.
6. To install, reverse the order of removal. Apply recommended multi-purpose grease slightly to portion (MG) shown in Figure FE-1.

### Accelerator pedal assembly

1. Remove spring clamp, then disconnect accelerator wire from tip of pedal arm.
2. Remove two screws securing accelerator pedal bracket to body.
3. Remove accelerator pedal from dash panel. See Figure FE-1.
4. To install, reverse the order of removal.

## INSPECTION

1. Check accelerator pedal return spring for rust, fatigue or damage. Replace if necessary.
2. Check accelerator wire, cases and fastening locations for rust, damage or looseness.  
Repair or replace if necessary.

## ADJUSTMENT

### Accelerator pedal and wire

1. Adjust pedal stopper bolt (Section A) so as to obtain specified height "E" as shown in Figure FE-1. Secure pedal stopper bolt with stopper lock nut. Refer to Figure FE-1.

E: 78 mm (3.07 in)

Tightening torque of nut:  
0.38 to 0.45 kg-m  
(2.7 to 3.2 ft-lb)


2. Release auto choke effect, since throttle lever is opened by fast idle cam until engine warms up.

- (1) Keep choke valve fully open with fingers.
- (2) Pull throttle lever up by hand,

then automatic choke effect will be released.

3. Set throttle valve to completely closed position and, with wire sufficiently slackened, tighten adjust nut until throttle lever is about to move. Accelerator pedal play is zero at this time. See Figure FE-2.

4. Unscrew adjust nut approximately two and a half turns so that accelerator pedal play is 3 mm (0.012 in). Tighten lock nut securely. See Figure FE-2.



FE184

Fig. FE-2 Adjusting accelerator wire play

5. After completing the adjustment as previously explained, check the following:

- (1) Make sure that accelerator system functions smoothly and quietly without disturbing any adjacent parts.
- (2) Depress accelerator pedal down until throttle valve fully opens. Make sure that the clearance "T" between accelerator pedal reverse side and dash floor is 2 to 4 mm (0.08 to 0.16 in) without floor mat. Adjust pedal stopper bolt and lock nut if beyond limits.
- (3) Check throttle lever if it returns to the original position as soon as accelerator pedal is released.

- (4) Apply recommended multi-purpose grease slightly on the portion as shown in Figure FE-1. Also refer to the periodic maintenance schedule.

### Kickdown switch (Automatic transmission models only)

Kickdown switch adjustment is correct if it is actuated by kickdown switch striker when accelerator pedal is fully depressed.

Always tighten switch stopper nut securely after proper adjustment is obtained.



## FUEL SYSTEM

### CONTENTS

DESCRIPTION .....	FE-4	INSPECTION .....	FE-6
REMOVAL .....	FE-5	INSTALLATION .....	FE-6

### DESCRIPTION


The fuel tank is 45 liters (11 $\frac{3}{4}$  U.S. gal., 9 $\frac{3}{4}$  Imper. gal.) in capacity. The tank unit is mounted to the right side of the rear floor.

The filler shutter is installed to the filler tube on California models.

The electric fuel pump is adopted on air conditioner equipped models.


For the electric fuel pump, refer to Section EF.

- 1 Fuel tank
- 2 Drain plug
- 3 Filler tube
- 4 Reservoir tank
- 5 Filler hose
- 6 Breather hose
- 7 Ventilation hose
- 8 Evaporation hose
- 9 Fuel outlet hose and tube
- 10 Fuel tank gauge unit
- 11 Protector
- 12 Bracket
- 13 Retainer
- 14 Return tube



FE194

Fig. FE-3 Fuel tank



FE261

Fig. FE-4 Fuel piping

## REMOVAL

### Fuel tank (See Figure FE-3)

1. Disconnect battery ground cable.
2. Remove drain plug and receive the remaining fuel into a suitable container.
3. Disconnect filler tube from filler hose.
4. Remove fuel tank securing bolts.
5. Disconnect two ventilation hoses, fuel return hose and fuel outlet hose from fuel tank.
6. Disconnect fuel tank gauge unit wires at connector.
7. Remove fuel tank.

**Note:** Plug hose and tube openings to prevent entry of dust or dirt while removing.

### Reservoir tank

1. Disconnect battery ground cable.
2. Disconnect two ventilation hoses, evaporation hose and breather hose.
3. Remove reservoir tank securing bolts, and remove tank with protector.

**Note:** Plug hose and tube openings to prevent entry of dust or dirt while removing.

### Fuel tank gauge unit

1. Disconnect battery ground cable.
2. Disconnect wires from fuel tank gauge unit.
3. Remove fuel tank. For details, refer to fuel tank removal.
4. Unit gauge is a bayonet type and can be removed by turning it counter-clockwise with screwdriver.

### Fuel piping (See Figure FE-4)

Fuel tubes are serviced as an assembly, so that replacement of fuel tube can be easily done. However, do not disconnect any fuel line unless absolutely necessary.

1. Drain fuel from fuel tank.
2. Loosen fuel hose clamps and disconnect fuel tubes on each end.


**Note:** Plug hose and tube openings to

prevent entry of dust or dirt while removing.

3. Unfasten clips that hold tube on under body and remove tube from the vehicle.

### Fuel filter

1. Disconnect fuel hoses from fuel filter by removing clamps. See Figure FE-5.



FE185

Fig. FE-5 Removing fuel filter clamps

## Engine Control, Fuel & Exhaust Systems

2. Remove fuel filter.

### INSPECTION

1. Fuel tank.

Check fuel tank for cracks or deformation. If necessary, replace.

2. Fuel hose

Inspect all hoses for cracks, fatigue, sweating or deterioration. Replace any hose that is damaged.

3. Fuel tube

Replace any fuel tube that is cracked, rusted, collapsed or deformed.

**Note:** Inspect hoses and tubes according to the periodic maintenance schedule.

4. Fuel filter

Replace fuel filter according to the periodic maintenance schedule or when it is clogged or restricted.

Fuel filter is of a cartridge type and cannot be cleaned. Always replace with a new one.

5. Fuel tank gauge unit

Check gauge unit for rust, deformation or deterioration. If necessary, replace.

### INSTALLATION

To install, reverse the order of removal. Observe the following:

1. Install hose clamps securely. Do not tighten excessively to avoid damaging hoses.

2. Fasten clips holding fuel tube on under body securely. Failure to follow this caution could result in damage to the surface of fuel tube.

3. Do not kink or twist hose and tube when they are routed.

4. Install filler hose after fuel tank has been mounted in place. Failure to follow this caution could result in leakage from around hose connections.

5. When installing fuel tank gauge unit, align the projection of tank gauge unit with the notch in fuel tank and tighten it securely. Be sure to install gauge unit with O-ring in place.

6. Run engine and check for leaks at connections.

Tightening torque:

Drain plug:

5.0 to 6.0 kg-m  
(36 to 43 ft-lb)

Fuel tank securing bolt:

0.8 to 1.1 kg-m  
(6 to 8 ft-lb)

Reservoir tank securing bolt:

0.32 to 0.44 kg-m  
(2 to 3 ft-lb)

## EXHAUST SYSTEM

### CONTENTS

DESCRIPTION .....	FE-6	INSPECTION .....	FE-8
REMOVAL .....	FE-8	INSTALLATION .....	FE-8

### DESCRIPTION

The exhaust systems installed on the non-California models differ in specifications from those installed on the California models.

#### Non-California models:

The exhaust system consists of a front exhaust tube, a main muffler assembly (with rear tube), mounting hangers, brackets and a heat insulator.


#### California models:

The exhaust system consists of a front exhaust tube, a catalytic converter assembly, a center tube, a main muffler assembly (with rear tube), mounting hangers, brackets and heat insulators.


The catalytic converter is connected to the front tube and the center tube with bolts and nuts.

# Engine Control, Fuel & Exhaust Systems

## Non-California model



## California model



FE390

Fig. FE-6 Exhaust system

## REMOVAL

### Non-California models

1. Remove exhaust tube U-bolt clamp.
2. Break sealant off at front tube to main muffler connection.
3. Remove rear tube mounting bolt, and remove muffler assembly with rear tube.
4. Remove front tube heat insulator.
5. Remove nuts securing front tube to exhaust manifold, and remove front tube mounting bolts. Then detach front tube.

When disconnecting the exhaust tube connections, pay attention to the following points.

- (1) Break old sealant off at the connection by lightly tapping around the tube with a hammer and twisting muffler. See Figures FE-7 and FE-8.
- (2) Using a rubber hammer, tap on the front end of muffler while pushing it toward rear. The muffler assembly can then be taken out. See Figure FE-9.




Fig. FE-7 Breaking sealant





Fig. FE-8 Twisting muffler



FE189

Fig. FE-9 Tapping muffler with a rubber hammer

### California models

1. Remove all heat insulators.
2. Remove exhaust tube U-bolt clamp.
3. Break sealant off at center tube to main muffler connection.
4. Remove rear tube mounting bolt, and remove muffler assembly with rear tube.
5. Remove bolts securing catalytic converter to center tube and remove center tube mounting bolts.  
Then detach center tube.
6. Remove bolts and nuts securing catalytic converter to front tube, and detach catalytic converter.
7. Remove nuts securing front tube to exhaust manifold, and remove front tube mounting bolts. Then detach front tube.

## INSTALLATION

Install the exhaust system assembly in reverse order of removal. Observe the following:

### Notes:

- a. Insert front tube until it touches emboss.
- b. When there is no clearance between front tube and floor or propeller shaft, turn tube along center line of tube in the manifold connecting unit, and obtain proper clearance.
- c. Check all tube connections for exhaust gas leaks, and entire system for unusual noises, with engine running.
- d. After installation, check that mounting brackets and mounting rubbers are free from undue stress. If any of the above parts is not installed properly, excessive noises or vibrations may be transmitted to the vehicle body.
- e. Tightening torque:
  - Exhaust manifold to front tube nut:  
1.9 to 2.5 kg-m  
(14 to 18 ft-lb)
  - U-bolt securing nut:  
1.9 to 2.1 kg-m  
(14 to 15 ft-lb)
  - Mounting bracket bolt:  
1.0 to 1.2 kg-m  
(7 to 9 ft-lb)
  - Front tube mounting bracket bolt: (California models)  
1.9 to 2.1 kg-m  
(14 to 15 ft-lb)
  - Catalytic converter to front and center tube bolt:  
(California models)  
3.2 to 4.3 kg-m  
(23 to 31 ft-lb)

## INSPECTION

1. Check muffler and tubes for cracks or damage.  
Replace any part that is damaged beyond limits.
2. Replace bracket and mounting insulator that are cracked, fatigued, or sweated.

If exhaust tubes are separated at connection to renew muffler assembly, etc., use the Genuine Nissan Sealant "Exhaust Sealant Kit 20720-N2225" or equivalent (See Figure FE-10) to eliminate gas leakage at the joint. Be sure to observe the following.




Fig. FE-10 Exhaust sealant kit

1. Wipe clean all the contact portions of tube joints; allow them to dry thoroughly.
2. Temporarily mount in place muffler assembly as an assembled unit on the vehicle.
3. Insert front tube until it touches emboss.




Fig. FE-11 Exhaust tube connection

4. Torque nut securing the male and female tubes at the connection. Tightening torque is 1.6 to 2.0 kg-m (12 to 14 ft-lb).
5. Squeeze approximately 5 cc (0.31 cu in) of sealant into injection from sealant tube. See Figure FE-12.

Be sure to place cap back to sealant tube since sealant will dry.




Fig. FE-12 Squeezing sealant to injector

6. Position nozzle of injector to the guide and press it there firmly. Inject sealant slowly until sealant begins to flow out of the slit of tube. This indicates that the bead requires no further sealant. Excessive sealant can cause a clogged tube. See Figure FE-13.

After injecting, wash injector thoroughly in clean water to remove all traces of sealant.




Fig. FE-13 Injecting sealant

7. Start engine and let it idle slowly for ten minutes (minimum) to harden sealant with the heat of exhaust gas.
8. Check the condition of sealant before driving the vehicle. It is also essential that the vehicle should not be accelerated sharply for 20 to 30 minutes subsequent to this operation.

## Notes:

- a. The sealant should be used within guaranty term indicated on the kit case.
- b. Exposure of sealant to the skin may cause a rash. Wash sealant off the skin with water.
- c. Do not keep the sealant tube in a place where the ambient temperature is above 40°C (104°F). A sealant hardened above 40°C (104°F) cannot be used. The most suitable storage temperature is from 15 to 35°C (59 to 95°F). If sealant becomes hardened because of low temperatures, warm the sealant tube with lukewarm water until the sealant is softened. Do not warm tube at a temperature over 40°C (104°F) for a long time.
- d. Thoroughly read the instruction sheet furnished with the kit before using the sealant.

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES

## SECTION BF

### BODY & FRAME

CAB BODY AND FRAME .....	BF- 2
REAR BODY .....	BF- 5
BODY FRONT END .....	BF- 7
HOOD .....	BF- 8
DOOR .....	BF-11
WINDSHIELD GLASS .....	BF-16
INSTRUMENT PANEL .....	BF-17
INTERIOR TRIM AND CENTER CONSOLE .....	BF-18
SEAT .....	BF-19


BF



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

heavy loads. The second crossmember is located somewhat to the rear to permit individual replacement of the transmission.


## STANDARD WHEELBASE MODEL





## Body & Frame


### LONG WHEELBASE MODEL



BF026B

Fig. BF-2 Underbody dimensions (Long wheelbase)


### DELUXE CAB




BF027B

Fig. BR-3 Underbody dimensions (Delux Cab)


## CAB BODY




BF639A



1st mounting



2nd mounting



3rd mounting

- 1 Bolt
- 2 Plain washer
- 3 Rubber washer
- 4 Upper rubber
- 5 Bottom rubber
- 6 Plain washer
- 7 Upper washer
- 8 Lower washer

BF472A

Unit: mm (in)

Fig. BF-4 Cab body mountings

## REMOVAL AND INSTALLATION

1. Remove battery from engine compartment.
2. Disconnect oil cooler hoses from radiator. (automatic transmission model only).
3. Disconnect air conditioner tubes from condenser, if so equipped.
4. Drain water from cooling system completely and remove radiator and condenser (if so equipped).
5. Remove engine hood from hood hinges after scribing hood for reinstallation.
6. Remove bumper stay from frame and remove front bumper.
7. Remove radiator grille.
8. With the aid of Steering Wheel Puller ST27180001, remove steering wheel from steering shaft.
9. Remove steering gear arm from steering sector shaft using suitable puller.
10. Remove screws securing steering shaft dust seat and insulator in position.

11. Remove steering gear housing from frame and pull it out into engine compartment.
12. Disconnect speedometer cable at transmission.
13. Disconnect carbon canister hoses between canister to vacuum gallery and canister to intake manifold at canister.
14. Disconnect air pump to air pump air cleaner hose at air cleaner.
15. Disconnect air conditioner hoses from compressor, if so equipped.
16. Disconnect air cleaner duct from body.
17. Disconnect Master-Vac vacuum hose at intake manifold.
18. Remove snap-ring and control lever pin from transmission striking guide, and remove control lever.
19. Disconnect fuel hoses at fuel strainer.
20. Disconnect fuel return hose and evaporation hose at connectors.
21. Disconnect brake and clutch tubes from each master cylinder.
22. Remove all clips securing fuel tubes, brake tubes and clutch tube at cab body.

23. Loosen hand brake control cable at brake control lever. Then disconnect cable from dash panel.

**Note:** Place blocks against front and rear wheels to prevent vehicle from rolling off accidentally.

24. Free accelerator wire from carburetor.
25. Disconnect heater hoses at engine side.
26. Disconnect wire harnesses from related engine electrical parts.
27. Disconnect engine and chassis harnesses at their connection on right sidemember near rear engine mounting member.
28. Remove six bolts securing body to frame.
29. With the use of suitable ropes and an overhead hoist, lift cab body straight up slowly and place it on a level surface.


**Note:** In lifting up cab body, use care not to dash it against engine or rear body. Cab body weighs approximately 220 kg (485 lb).

30. For installation, reverse above steps. However, observe the following instructions.

- (1) If the cab body is to be replaced, note position and location of insulators and washers used. See Figure BF-4.
- (2) Adjust hand brake stroke properly.
- (3) Air bleed brake and clutch system thoroughly.

Cab body to frame mounting  
bolt torque:


1.6 to 2.2 kg-m  
(12 to 16 ft-lb)



BF630

Fig. BF-5 Lifting up cab body

## REAR BODY



- 1 Bolster
- 2 Shim B
- 3 Bolster
- 4 Shim A
- 5 Frame
- 6 Rubber washer
- 7 Plain washer

BF664

Fig. BF-6 Rear body mountings

## REAR BODY

### REMOVAL AND INSTALLATION


The rear body is securely fastened to the frame at eight places. It should be hoisted after the fuel tank is removed from the rear body.

Use the following procedures as a guide when removal or installation of rear body is necessary.

1. Apply parking brake.
2. Disconnect cables from battery.
3. Disconnect rear combination lamp wiring harness at connectors.
4. Disconnect fuel hoses from fuel

tank. Remove fuel tank from rear body.

5. Remove eight rear body attaching bolts.




BF665

Fig. BF-7 Rear body mountings

6. Attach lifting ropes to hooks in rear body as shown in Figure BF-8, and lift up rear body slowly and carefully.

## Notes:

- When lifting rear body, make sure that it is in a good balanced condition.
- While lifting, use care not to allow rear body to hit against cab body or any adjacent parts.
- The rear body weighs approximately 130 kg (286 lb).



BF028B


Fig. BF-8 Lifting up rear body

7. To install rear body, reverse the order of removal. Carefully observe the following instructions.

Make sure that spacers and shims (used with bolts) are properly placed in their original positions. Refer to Figure BF-6 for the location of these parts.

The rear body-to-frame attaching bolts should be torqued to 3.3 to 4.2 kg-m (24 to 30 ft-lb).

## REAR GATE REMOVAL AND INSTALLATION



BF667

Fig. BF-9 Rear gate

- Open rear gate.
- Remove rear gate chain from rear gate.
- Remove rear gate hinge attaching bolts and take out rear gate and rear gate hinge shims.
- To install rear gate, reverse the order of removal.

## ALIGNMENT

The rear gate should be adjusted so that there exists an equal clearance between body and the periphery of rear gate. There should be no stepped portion at any points.

- To adjust the height of rear gate, add or remove shims at rear gate hinge. Two sizes of shim are available in thickness; 1.6 mm (0.0630 in) and 0.8 mm (0.0315 in).


2. To adjust rear gate in the left and right directions, loosen rear gate hinge attaching bolts, and move rear gate as required.

3. To adjust rear gate hook, loosen two attaching bolts and move rear gate hook up-down or left-right in elongated holes as required.

## GUARD FRAME (Optional) REMOVAL AND INSTALLATION

The guard frame is furnished as an optional equipment.


- Remove nine guard frame attaching bolts and detach guard frame.
- To install optional guard frame, reverse the order of removal.



BF673

Fig. BF-10 Guard frame

## BODY FRONT END




BF029B

Fig. BF-11 Body front end

### FRONT BUMPER REMOVAL AND INSTALLATION

1. Remove bumper to fender attaching bolts.
2. Remove four bumper stay-to-side frame front attaching bolts. Pull bumper assembly straight forward.
3. For installation, reverse above steps. Align bumper with front fender and apron; then tighten them up.

3. For installation, reverse above steps, observing the following:  
(1) Check to be certain that six guide studs enter holes in radiator support lower frame before tightening top screws.



- 1 Radiator grille
- 2 Guide stud
- 3 Guide stud hole
- 4 Radiator support lower frame

Fig. BF-12 Radiator grille guide studs

### RADIATOR GRILLE REMOVAL AND INSTALLATION


1. Remove radiator grille by removing attaching screws, six on top and two on both ends.
2. Remove ornament on radiator grille by removing nuts from behind radiator grille.

- (2) Align grille with head lamps and fenders.

### FRONT APRON REMOVAL AND INSTALLATION

1. Remove front bumper.
2. Remove radiator grille.
3. Disconnect front turn signal wire harness at connector.
4. Remove front apron by removing attaching bolts.
5. For installation, reverse above steps.

## COWL TOP GRILLE



- 1 Cowl top grille
- 2 Cap
- 3 Air box drain seal
- 4 Cowl top
- 5 Air box drain
- 6 Screw

BF633

Fig. BF-13 Cowl top grille

### REMOVAL AND INSTALLATION

1. Open engine hood.
2. Remove two windshield wiper blades.
3. Remove cowl top grille attaching

screws. Pull grille straight forward to remove.

4. Remove air box drain.
5. To install, reverse above steps.

However, observe the following items:

- (1) When installing air box drain, apply adhesive to its lower end.
- (2) Align cowl top grille with fenders.

## FRONT FENDER REMOVAL AND INSTALLATION


1. Remove front bumper.
2. Remove radiator grille.
3. Remove front apron.
4. Remove cowl top grille.
5. Remove hood bumpers (two on each side).
6. Remove nine screws attaching front fender to hood ledge. See Figure BF-11.
7. To install, reverse above steps.

## HOOD

### REMOVAL AND INSTALLATION

1. Place protective covers over front fender and cowl top grille.
2. Open engine hood. Mark hinge locations on hood and loosen off four bolts securing hood to hood hinge. Use extra caution to avoid damaging painted surfaces of fender and cowl top grille.
3. Remove engine hood.
4. To install, reverse above procedures.

## HOOD



BF641A

Fig. BF-14 Hood lock male and female

### ADJUSTMENT


Four slotted holes in hood hinge provide for fore-aft and side adjustment to correct space between hood and fender, and hood and cowl top grille.

Loosen four bolts just enough to move engine hood and move hood to desired position if necessary to correct space.

To make vertical adjustment, adjust height of dove-tail bolt at hood lock male until hood is flush with fender.

1. Loosen hood to hinge bolts just far enough to permit movement of hood.

2. Shift hood in elongated hole until parallel space is reached between hood and fender or cowl top grille. Tighten bolts securely.



BF635

Fig. BF-15 Engine hood alignment

## Body & Frame

Note: Vertical adjustment should be carried out after hood lock male and female adjustment has been completed.

3. To correct hood lock alignment, loosen two hood lock male attaching bolts and move hood lock male and female in the lateral and fore-and-aft directions as required.

Tightening torque:

Male and female attaching bolts  
0.45 to 0.60 kg-m  
(3.3 to 4.3 ft-lb)





Fig. BF-16 Adjusting hood lock male

4. Dove-tail bolt at hood lock male provides for vertical adjustment in aligning hood to make it flush with fender. To correct, loosen lock nut on dove-tail bolt and turn dove-tail bolt in or out as necessary to obtain a correct height.

5. Tighten lock nut firmly while holding dove-tail bolt with a screwdriver to secure adjustment.

Tightening torque:


Lock nut of dove-tail:  
1.9 to 2.6 kg-m  
(14 to 19 ft-lb)



1 Lock nut  
2 Hood lock male 3 Safety catch

Fig. BF-17 Dove-tail bolt height adjustment

## HOOD LOCK CONTROL



- 1 Dove-tail bolt seat
- 2 Lock nut
- 3 Cushion rubber
- 4 Spring
- 5 Spring retainer
- 6 Dove-tail bolt
- 7 Clamp
- 8 Clamp
- 9 Hood lock female
- 10 Control cable assembly

BF644A

Fig. BF-18 Hood lock and control cable

## REMOVAL AND INSTALLATION


1. Remove hood lock male by removing two attaching bolts.
2. To remove hood lock female, first remove radiator grille. Back off two bolts securing hood lock female in position. Hood lock female can now be taken out.
3. Remove two bolts attaching hood lock handle assembly to dash side panel.

Disconnect cable at hood lock female and remove cable clamps. Pull cable out into cab.

4. To install hood lock male and female, reverse removal procedure. After installation, check to insure that they are properly aligned.

5. To install hood lock handle assembly, reverse steps, observing the following notes:

- (1) Check to be certain that cable clamps are tight and secure.
- (2) Install hood lock handle bracket in place by using two of four holes. See Figure BF-19.



BF645A

- |                            |                  |
|----------------------------|------------------|
| 1 Hood lock handle         | 3 Clamp          |
| 2 Hood lock handle bracket | 4 Hole           |
|                            | 5 Attaching bolt |

Fig. BF-19 Installing hood lock handle bracket

## ADJUSTMENT AND INSPECTION


1. If hood lock handle is heavy, turn dove-tail bolt of hood lock male counterclockwise to reduce tension of hood lock spring.

Lock nut of dove-tail bolt should first be loosened.

If looseness is noticed, hood is not tight and will vibrate. To correct this, turn bolt clockwise and recheck.

2. Check hood lock mechanism as follows:

- (1) Check safety catch lever and spring for deformation, fatigue or rusting.
- (2) Check female lever and return spring for deformation, fatigue or rusting. Improper operation of female lever may cause disengagement between female lever and dove-tail bolt.
- (3) Make sure that safety catch hooks engine hood properly when hood latch has been disengaged.



BF409A

Fig. BF-20 Safety catch lever to radiator upper support adjustment

## Lubrication


When checking or adjusting the hood lock, lubricate the pivot, catcher and return spring of secondary latch thoroughly. Also, lubricate the lever of the hood lock female for smooth and correct operation.



## DOOR

### CONTENTS


DESCRIPTION .....	BF-12	DOOR GLASS AND REGULATOR .....	BF-14
DOOR .....	BF-12	REMOVAL AND INSTALLATION .....	BF-14
REMOVAL AND INSTALLATION .....	BF-12	ADJUSTMENT .....	BF-14
ALIGNMENT .....	BF-12	DOOR LOCK .....	BF-14
DOOR TRIM AND SEAL .....	BF-12	REMOVAL AND INSTALLATION .....	BF-15
REMOVAL AND INSTALLATION .....	BF-12	ADJUSTMENT .....	BF-15
GLASS RUN .....	BF-13	DOOR LOCK STRIKER .....	BF-15
REMOVAL AND INSTALLATION .....	BF-13	WEATHERSTRIP .....	BF-15
DOOR VENTILATOR WINDOW (Optional) .....	BF-13	DESCRIPTION .....	BF-15
REMOVAL AND INSTALLATION .....	BF-13	REMOVAL AND INSTALLATION .....	BF-15



- 1 Door sash
- 2 Window outside weatherstrip
- 3 Window inside weatherstrip
- 4 Door weatherstrip
- 5 Rear glass run rubber
- 6 Door finish holder
- 7 Rear lower sash
- 8 Seal screen
- 9 Door weatherstrip clip
- 10 Front glass run rubber
- 11 Lower door hinge
- 12 Upper door hinge
- 13 Front lower sash
- 14 Door glass
- 15 Glazing rubber
- 16 Door glass bottom channel

BF030B

Fig. BF-21 Door without ventilator window



- 1 Door sash
- 2 Window outside weatherstrip
- 3 Window inside weatherstrip
- 4 Door weatherstrip
- 5 Rear glass run rubber
- 6 Door finish holder
- 7 Rear lower sash
- 8 Seal screen
- 9 Door weatherstrip clip
- 10 Front glass run rubber
- 11 Lower door hinge
- 12 Upper door hinge
- 13 Front lower sash
- 14 Door glass
- 15 Glazing rubber
- 16 Door glass bottom channel
- 17 Lower support
- 18 Upper support
- 19 Door ventilator assembly

BF031B

Fig. BF-22 Door with ventilator window (Optional)

## DESCRIPTION

The door consists of inner and outer panels welded together to form a rigid structure.


The curved glass provides greater shoulder room.

A door that incorporates a ventilator window is also available as an option.

The weatherstrip is inserted into the groove on the door sash side and is attached by clips on the door side.

## DOOR REMOVAL AND INSTALLATION


1. With door in full open position, place a garage jack or stand beneath door to support its weight when bolts are removed. Place rag between door and jack or stand to avoid damaging painted surface.



BF023

Fig. BF-23 Supporting door

2. Separate lower door hinge hole cover from dash side trim.
3. While supporting door as above, back off body to upper and lower hinge attaching bolts accessible from inside cab (three each). Door can now be taken out from cab body.



BF024

Fig. BF-24 Removing door hinge bolts

4. To install, reverse removal procedure.

## ALIGNMENT

Elongated holes (three each) in door hinge and door lock striker provide for up and down, forward and backward, and/or sideways adjustment to assure proper door fit to door opening.

To adjust door alignment, loosen bolts and move door to desired position to obtain a parallel space between door sides and door opening. Also check to be certain that weatherstrip contacts body opening evenly to prevent entry of mud and water.

## DOOR TRIM AND SEAL REMOVAL AND INSTALLATION

1. Remove screw securing inside door handle escutcheon; remove escutcheon.
2. Remove screws which hold pull handle and arm rest in position. Pull handle and arm rest can then be taken out.
3. Pull retaining spring off regulator handle. Take out regulator handle and seat washer.




Fig. BF-25 Removing regulator handle

4. When removing door finish, it is important that inside door panel and door finish are not damaged.

With a screwdriver, pry off retaining clips, exercising care not to damage clips.




Fig. BF-26 Removing door finish

5. Separate water seal screen from inside door panel.

6. To install, reverse removal procedure. However, observe the following installation notes:

(1) When water seal screen is to be replaced, be sure to cement it back into position securely to ensure a water sealed door. This can be done by evenly applying adhesive to grooves in inside door panel.

Broken screen or one suspected to be leaking must be replaced with a new one.




Fig. BF-27 Adhesive for seal screen

(2) With door glass up, set regulator handle at an angle shown in Figure BF-28.




Fig. BF-28 Installation angle of regulator handle

## GLASS RUN REMOVAL AND INSTALLATION

1. With door in full out position, lower glass all the way.
2. Remove pull handle, arm rest and regulator handle.
3. Remove door finish and water seal screen.
4. Remove outer and inner weatherstrips from door.

5. Remove door glass.

6. Remove glass run rubbers from front and rear lower sashes, and from those of fixed door.

Use caution to avoid damaging rubbers during removal operation.

7. Remove front and rear lower door sashes (when ventilator window is not provided).

8. On vehicles equipped with ventilator window, remove ventilator window frame and rear lower door sash.

9. To install, reverse removal procedure. However, observe the following notes:

(1) Before applying adhesive, clean the inside of door sash.

(2) Apply adhesive to glass run rubber on door sash contacting face and fit it correctly. Particularly, care should be taken at corners and contact face to assure a good fit.




Fig. BF-29 Applying adhesive to glass run rubber

## DOOR VENTILATOR WINDOW (Optional)

### REMOVAL AND INSTALLATION

1. Remove five ventilator window frame attaching bolts. Lift frame out of door. For detailed procedure, refer to relative topic under "Door Glass and Regulator."
2. Remove nuts and spring securing lower end of ventilator window to frame.
3. Work off rivets which hold upper end of ventilator window to frame; take out window.
4. To install, reverse removal procedure.

## DOOR GLASS AND REGULATOR




Fig. BF-30 Door glass and regulator

### REMOVAL AND INSTALLATION

1. Open door; lower glass all the way.
2. Remove inside door handle escutcheon.
3. Remove pull handle.
4. Remove arm rest.
5. Remove regulator handle.
6. Remove door finish.
7. Peel off water seal screen.
8. Work off outer and inner weatherstrips from door, being sure not to scratch door paint during operation. Use a suitable plain screwdriver or similar flat-bladed tool to remove and place a piece of rag between screwdriver and door panel.




Fig. BF-31 Removing outer weatherstrip

9. Remove three door glass bottom channel attaching bolts. Remove door glass by lifting it straight-up.

10. On door equipped with ventilator, remove three bolts securing door glass bottom channel, then let glass go to the bottom of door.

Remove ventilator frame attaching bolts, and lift frame straight-up out of door. Remove door glass by lifting it straight-up.

11. Back off the five guide channel-to-regulator base attaching screws. Take out regulator assembly through large access hole in inside door panel.




Fig. BF-32 Removing door glass

12. To install, reverse removal procedure.

### ADJUSTMENT

1. In-and-out and fore-and-aft adjustment can be made by moving front- or rear-sash and guide channel as required.

The ease with which window assembly raises and lowers depends on adjustment of rear lower sash. Rear lower sash should be parallel with front lower sash.

2. Fore-and-aft adjustment is determined by position of guide channel and front lower sash. Moving front lower sash backward reduces play in window assembly.

## DOOR LOCK




Fig. BF-33 Door lock mechanism

## REMOVAL AND INSTALLATION

1. Open door.
2. Remove inside door handle escutcheon.
3. Remove pull handle.
4. Remove arm rest.
5. Remove regulator handle.
6. Remove door finish.
7. Peel off water seal screen.
8. Raise door glass to full-up position.
9. Remove inside door lock knob.
10. Remove rear lower sash attaching bolts.
11. Disconnect remote control rod from key cylinder and outside door handle.
12. Remove three door lock assembly attaching screws.
13. Remove two inside door handle attaching screws.
14. Together with inside door handle, take out door lock as an assembly through large access hole in door panel.
15. Remove two outside door handle attaching nuts. Outside door handle can then be taken out.
16. Remove lock plate from key cylinder and detach key cylinder.
17. To install door lock assembly, outside and inside door handles and key cylinder, reverse removal procedure.
18. Lubricate door lock with grease which meets the requirements of MIL-G-10924B or equivalent as listed below:

ALVANIA GREASE RA (SHELL)  
BEACON 325 (ESSO)  
MOBILE GREASE 22 (MOBIL)

## ADJUSTMENT

### Outside door handle

Adjustment of play in outside door handle is controlled by play adjustment of nylon nut on threaded end of outside door handle rod.

Correct play is 1.0 mm (0.039 in) or below as measured between nylon nut and locking plate.

### Inside door handle

Elongated hole in inside door handle provides for play adjustment of inside door handle.

Correct play is 1.0 mm (0.039 in) or below as measured at control rod.



## DOOR LOCK STRIKER

Adjustment of door lock striker should be made after door hinge has been adjusted correctly.


Elongated holes (three) provide for up-and-down or fore-and-aft adjustment to establish proper engagement between door lock striker and door lock latch.

## WEATHERSTRIP DESCRIPTION

The weatherstrip is retained by clamp to the door sash and by 19 clips to the door panel. No adhesive is used to retain the weatherstrip to door.



Section A-A



Section B-B

BF645

Fig. BF-34 Door weatherstrip

## REMOVAL AND INSTALLATION

1. Open door.
2. Free weatherstrip from door sash clamp.

3. Pry off clips from door panel; remove weatherstrip.
4. To install, reverse removal procedure.

## WINDSHIELD GLASS

### WINDSHIELD GLASS

#### DESCRIPTION

The windshield glass is retained in the body glass opening through the weatherstrip. There are twelve water drain holes; one on each side of the bottom of the glass opening, and ten along the length of the weatherstrip.




Fig. BF-35 Windshield glass and weatherstrip

#### REMOVAL

1. Place protective covers over engine hood, front fender, seat and instrument panel.
2. Remove inside rearview mirror and sun visor.
3. Remove windshield mouldings if so equipped.
4. Using a putty knife or similar flat-bladed tool, pry lips of weatherstrip out of place from top and side flanges of body opening.

If weatherstrip is to be reused, it is important that it not be damaged during this operation.




Fig. BF-36 Removing weatherstrip

5. Working from inside vehicle, push windshield glass out of body opening by hand, starting at right and left upper corners and working out toward ends.

6. After removing weatherstrip from top and sides of body opening, lift glass up sufficiently to permit removal of weatherstrip from bottom flange; pry weatherstrip out of position.

This operation requires two men.

#### INSPECTION

Prior to installing windshield glass, make the following checks on body glass opening and weatherstrips:

1. Clean weatherstrip channels, replacing those found with cracks or signs of deterioration.
2. Clean body openings noting if these are distorted or corroded.

#### INSTALLATION

1. Fit weatherstrip on glass, making sure it is properly seated and positioned. Adhesive need not be applied.




Fig. BF-37 Fitting weatherstrip on glass

2. Insert a draw-cord completely around weatherstrip outer channel.




Fig. BF-38 Inserting draw-cord around weatherstrip outer channel

3. With aid of a helper, press windshield assembly against body opening from outside, being sure weatherstrip lip aligns with body opening flange.

4. Slowly pull cord ends from inside to overlap weatherstrip channel on body opening flange, starting at center top and working out toward ends. This operation should be done while one man pushes glass against body opening from outside.

The same technique should be applied to right, left and bottom weatherstrips.




Fig. BF-39 Fitting weatherstrip (top)




Fig. BF-40 Fitting weatherstrip (bottom)


5. Install windshield moldings on weatherstrip if so equipped.

6. Install inside rearview mirror and sun visor.

### BACK WINDOW GLASS AND SIDE WINDOW GLASS

Refer to relative topics under "Removal," "Inspection" and "Installation" of windshield glass.

## INSTRUMENT PANEL



BF646A

Fig. BF-41 Instrument panel assembly

## INSTRUMENT PANEL

### REMOVAL AND INSTALLATION

1. Disconnect battery cables.


2. Disconnect heater control cables from heater assembly.
3. Disconnect speedometer cable on the back of speedometer.
4. Disconnect antenna and speaker

wiring harnesses at connectors.

5. Disconnect relative wiring harnesses from instrument panel at connectors.

6. Remove steering column shell. Removal of steering wheel at this stage facilitates further removal of instrument panel.

7. Remove two side ventilator knobs. Remove package tray attaching bolt and detach package tray.



BF647A

Fig. BF-42 Package tray

8. Support instrument panel assembly and remove five attaching bolts from it.

9. Withdraw instrument panel assembly while lifting it slightly.

10. To install, reverse the order of removal.

## INTERIOR TRIM AND CENTER CONSOLE

### HEADLINING

#### DESCRIPTION

The headlining assembly is of a suspension type, which is held in place

by listing wires. The design is quite similar to that used in a passenger car.




Fig. BF-43 Headlining

#### REMOVAL

1. Remove two inside rearview mirror attaching screws and detach rearview mirror.
2. Remove three sun visor attaching screws and detach sun visor.
3. Remove two assist rail attaching screws and detach assist rail.
4. Remove room lamp.
5. Open doors and remove body side welts on each side.
6. Remove windshield glass and weatherstrip.
7. Remove back window and weatherstrip.
8. Remove garnish securing the end of headlining to rear pillar.




Fig. BF-44 Removing garnish

9. Detach all cemented edges of headlining from flanged portion of roof rail.
10. Disengage listing wires from roof rail, and detach headlining.

#### INSTALLATION

1. Apply adhesive cement to the outer surface of flange and headlining attaching surface evenly.

2. Install listing wires in place on roof rail.
3. First, attach front headlining to the flanged portion of roof rail. Secondly, attach the rear edges of headlining in place while pulling the headlining material to avoid wrinkles.
4. Attach the right and left edges of headlining material to the flanged portions, using care to avoid wrinkles.
5. Cut excess headlining material except for that (at the upper areas of front, center and rear pillars) not covered by body side welt. The edges of headlining material at these areas should be so cut that it can be folded properly in place.
6. Install garnish on the extreme end of headlining at rear pillar.
7. Drill a hole in headlining where room lamp is located. Install room lamp.
8. Install body side welts.
9. Install windshield glass.
10. Install back window glass.
11. Install assist rail, sun visor and inside rearview mirror.

### BACK TRIM AND BACK INSIDE FINISHER (DELUXE CAB)

#### REMOVAL AND INSTALLATION


##### Back trim

1. Move floor carpet aside.
2. Remove four bolts attaching back trim to floor.
3. Remove five trim clips and detach back trim.
4. Installation is the reverse order of removal.

##### Back inside finisher

1. Remove seat belt retractor.
2. Remove five trim clips and detach back inside finisher.
3. Installation is the reverse order of removal.





BF032B


Fig. BF-45 Back trim and back inside finisher

## CENTER CONSOLE

### REMOVAL AND INSTALLATION


Except for air conditioner equipped models

1. Remove two bolts from rear of center console.
2. Remove center console by pulling it back.
3. To properly install center console, insert its front portion into bracket on the floor, and install and tighten rear attaching bolts.



BE033B

Fig. BF-46 Removing center console



BF034B

Fig. BF-47 Console with armrest

### Air conditioner equipped models

1. Remove two bolts from front of center console.
2. Remove two bolts from the rear, and remove center console.

## CONSOLE WITH ARMREST (DELUXE CAB)

### REMOVAL AND INSTALLATION

1. Remove two bolts from front of console/armrest unit.
2. Remove one bolt in the console box, and remove center console.
3. Installation is the reverse order of removal.

## SEAT

### SEAT

#### DESCRIPTION


There are two types of seats: a semi separate bench seat for the standard wheelbase and long wheelbase models, and a separate seat for the Deluxe Cab models.

#### CAUTION:

In conforming with M.V.S.S. No. 302, be sure to remove the thin polyethylene covers from seat cushions, seat backs and head restraints at the time of:

- a. Pre-delivery service
- b. Parts replacement

### BENCH SEAT



BF474A

Fig. BF-48 Bench seat

## Removal and installation


1. Remove four bolts retaining seat slide assembly to floor; take out seat

assembly.

2. To install seat, reverse above removal procedure.

## SEPARATE SEAT

- 1 Head restraint
- 2 Seat assembly
- 3 Reclining device
- 4 Seat slide outer
- 5 Seat slide inner



BF035B


Fig. BF-49 Separate seat

## Removal and installation

1. Remove two nuts attaching front of seat slide to floor.
2. Remove two bolts attaching rear of seat slide to floor.

3. Then remove seat with seat slides from the vehicle.
4. Installation is the reverse order of removal.

## SEAT BELT



- 1 Inner belt
- 2 Tongue stopper
- 3 Emergency locking retractor
- 4 Outer anchor plate
- 5 Lap-shoulder belt
- 6 Shoulder through anchor

BF036B

Fig. BF-50 Seat belt

## DESCRIPTION

The seat belt is a three-point type, consisting essentially of a lap-shoulder belt and an inner lap belt.

The lap-shoulder belt is fitted with an emergency locking retractor which senses the speed at which the webbing is being pulled and the deceleration of the vehicle.

The inner lap belt has a buckle. The buckle of the driver's seat belt includes a switch which functions as a seat belt warning device.

## CAUTIONS:

- In conformity with M.V.S.S. No. 302, be sure to remove the thin polyethylene covers from seat belts at the time of:
  - (1) Pre-delivery service
  - (2) Parts replacement
- If the vehicle has overturned or been in a collision, replace the entire belt assembly, regardless of nature of accident.
- If the condition of any component of a seat belt is questionable, have entire belt assembly replaced rather than attempting to repair seat belt.
- If webbing is cut, frayed, or damaged, replace belt assembly.
- Do not spill drinks, oil, etc. on inner lap belt buckle. Never oil tongue and buckle.
- Use only a genuine Nissan seat belt assembly.

## REMOVAL AND INSTALLATION

1. Disconnect battery ground cable.
2. Disconnect buckle switch harness at connector under seat.
3. Loosen bolt retaining inner lap belt and remove inner lap belt.
4. Remove bolt securing emergency locking retractor.
5. Remove shoulder anchor bolt, and remove lap-shoulder belt assembly.
6. Installation is the reverse order of removal.

Tightening torque:

Anchor bolts:  
2.5 to 3.0 kg-m  
(18 to 22 ft-lb)

Note: When installing emergency locking retractor, make sure that it is set vertically.




Fig. BF-51 Seat belt anchorages

## INSPECTION OF BUCKLE SWITCH

The contacts of the buckle switch are normally closed. When tongue latches the buckle, tip end of the tongue pushes the push rod to open the switch contacts.

1. Disconnect battery ground cable.
2. Disconnect buckle switch wire harness.
3. Using a test light, check buckle switch for proper operation. The light should go out when tongue of outer lap belt latches buckle, and go on when it unlatches buckle. Replace belt assembly if necessary.

Note: When checking buckle switch operation, make sure that power is held below 16 volts and 13 mA.

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES

## SECTION BE

### BODY ELECTRICAL SYSTEM

BODY ELECTRICAL WIRING .....	BE- 2
LIGHTING AND SIGNAL LAMP SYSTEM .....	BE- 3
METERS AND GAUGES .....	BE-14
ELECTRICAL ACCESSORIES .....	BE-21
EMISSION WARNING SYSTEM (California models) .....	BE-43

BE



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

## BODY ELECTRICAL WIRING

### DESCRIPTION

Cables are covered with color-coded vinyl for easy identification. In the wiring diagram, colors are indicated by one or two alphabetical letters.

It is recommended that the battery be disconnected before performing any electrical service other than bulb or fuse replacement.

In addition to fuses, a fusible link has been installed to protect wiring. The fusible link functions almost the same as a fuse, though its characteristics are slightly different than normal fuses.

### CABLE COLORS

Cable colors are indicated by one or two alphabetical letters:

B: Black, Br: Brown, G: Green,  
L: Blue, Lg: Light green,  
R: Red, W: White, Y: Yellow

The main cable is generally coded with a single color. The others are coded with a two-tone color as follows:

BW: Black with white stripe  
LgR: Light green with red stripe

### INSPECTION

Inspect all electrical circuits, referring to wiring or circuit diagrams. Circuits should be tested for continuity or short circuit with a conventional test lamp or low reading voltmeter. Before inspection of circuit, ensure that:

1. Each electrical component part or cable is securely fastened to its connector or terminal.
2. Each connection is firmly in place and free from rust and dirt.
3. No cable covering shows any evidence of cracks, deterioration or other damage.
4. Each terminal is at a safe distance away from any adjacent metal parts.
5. Each cable is fastened to its proper connector or terminal.

6. Each grounding bolt is firmly planted.
7. Wiring is kept away from any adjacent parts with sharp edges or high temperature parts (such as exhaust pipe).
8. Wiring is kept away from any rotating or working parts: fan pulley, fan belt, etc.
9. Cables between fixed portions and moving parts are long enough to withstand shocks and vibratory forces.

#### Notes:

- a. Before starting to inspect and repair any part of electrical system or other parts which may lead to a short circuit, disconnect cables at battery terminals as follows:

Disconnect cable at negative (-) terminal, and then disconnect cable at positive (+) terminal.

Before connecting cables to battery terminal, be sure to clean terminals with a rag. Fasten cable at positive (+) terminal, and then ground cable at negative (-) terminal. Apply grease to top of these terminals to prevent rust from developing on them.

- b. Never use a screwdriver or service tool to conduct a continuity test. Use test leads.
- c. Never ground an open circuit or circuits under no load. Use a test lamp (12V-3W) or circuit tester as a load.


### FUSE AND FUSIBLE LINK DESCRIPTION

The fuse and fusible link are protective devices used in an electrical circuit. When current increases beyond rated amperage, fusible metal melts and the circuit is broken.

### MAINTENANCE INSTRUCTIONS

#### Fuse

The fuse block is installed under the instrument panel on the left-hand drive vehicle.



BE848A

Fig. BE-1 Fuse block

When, for one reason or another, fuse has melted, use systematic procedure to check and eliminate cause of problem before installing new fuse.

#### Notes:

- a. If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- b. Use fuse of specified rating. Never use fuse of more than specified rating.
- c. Check condition of fuse holders. If much rust or dirt is found thereon, clean metal parts with fine-grained sandpaper until proper metal-to-metal contact is made. Poor contact in any fuse holder will often lead to voltage drop or heating in the circuit and could result in improper circuit operation.


#### Fusible link

Fusible link protects lighting, starting, charging and accessory circuits.

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp, as required, to conduct continuity test. This continuity test can be performed in the same manner as for any conventional fuse.

## Notes:

- a. If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- b. Never wrap periphery of fusible link with vinyl tape. Extreme care should be taken with this link to ensure that it does not come into contact with any other wiring harness or vinyl or rubber parts.



BE849A

Fig. BE-2 Fusible link

## LIGHTING AND SIGNAL LAMP SYSTEM

### CONTENTS

DESCRIPTION .....	BE- 4	INSPECTION .....	BE- 9
LIGHTING SYSTEM CIRCUIT DIAGRAM ..	BE- 4	KNOB ILLUMINATION LAMP .....	BE-10
HEADLAMP .....	BE- 5	BULB REPLACEMENT .....	BE-10
HEADLAMP BEAM REPLACEMENT .....	BE- 5	LAMP BODY REPLACEMENT .....	BE-10
AIMING ADJUSTMENT .....	BE- 5	TURN SIGNAL AND DIMMER SWITCH .....	BE-10
FRONT COMBINATION LAMP .....	BE- 7	REMOVAL AND INSTALLATION .....	BE-10
BULB REPLACEMENT .....	BE- 7	INSPECTION .....	BE-10
REMOVAL AND INSTALLATION .....	BE- 7	STOP LAMP SWITCH .....	BE-10
SIDE MARKER LAMP .....	BE- 7	REMOVAL AND INSTALLATION .....	BE-10
BULB REPLACEMENT .....	BE- 7	INSPECTION .....	BE-10
REMOVAL AND INSTALLATION .....	BE- 7	DOOR SWITCH .....	BE-10
ROOM LAMP .....	BE- 8	REMOVAL AND INSTALLATION .....	BE-10
BULB REPLACEMENT .....	BE- 8	INSPECTION .....	BE-11
REMOVAL AND INSTALLATION .....	BE- 8	HAZARD SWITCH .....	BE-11
REAR COMBINATION LAMP .....	BE- 8	REMOVAL AND INSTALLATION .....	BE-11
BULB REPLACEMENT .....	BE- 8	INSPECTION .....	BE-11
REMOVAL AND INSTALLATION .....	BE- 8	FLASHER UNIT .....	BE-11
LICENSE LAMP .....	BE- 8	REPLACEMENT .....	BE-11
BULB REPLACEMENT .....	BE- 8	BULB SPECIFICATIONS .....	BE-12
REMOVAL AND INSTALLATION .....	BE- 8	TROUBLE DIAGNOSES AND	
ENGINE COMPARTMENT LAMP .....	BE- 9	CORRECTIONS .....	BE-12
LIGHTING SWITCH .....	BE- 9	HEADLAMP .....	BE-12
REMOVAL AND INSTALLATION .....	BE- 9	TURN SIGNAL LAMP .....	BE-13
INSPECTION .....	BE- 9	TAIL LAMP, STOP LAMP AND	
ILLUMINATION CONTROL RHEOSTAT .....	BE- 9	BACK-UP LAMP .....	BE-13
REMOVAL AND INSTALLATION .....	BE- 9		







## Body Electrical System

To adjust vertical aim, use adjusting screw on upper side of headlamp; and to adjust horizontal aim, use adjusting screw on side of headlamp.


### Notes:

Before making headlamp aiming adjustment, observe the following instructions.


- a. Keep all tires inflated to correct pressures.
- b. Place vehicle and tester on the same flat surface.
- c. See that there is no load in vehicle.
  - 1) Gasoline, radiator and engine oil pan filled up to correct levels
  - 2) Without passenger

When performing headlamp aiming adjustment, use an aiming device, aiming wall screen or headlamp tester. For operating instructions of any aimer, refer to respective operation manuals supplied with the unit.

### DRIVING BEAM (HIGH BEAM)



### PASSING BEAM (LOW BEAM)



Item	Driving beam (High beam)				Passing beam (Low beam)				
	H <sub>1</sub> mm (in)	W <sub>1</sub> mm (in)	θ <sub>1</sub> (°)	h <sub>1</sub> mm (in)	H <sub>2</sub> mm (in)	W <sub>2</sub> mm (in)	θ <sub>2</sub> (°)	h <sub>2</sub> mm (in)	d mm (in)
All models	715 (28.15)	780 (30.71)	48'	140 (5.51)	715 (28.15)	1,160 (45.67)	2°18'	392 (15.43)	349 (13.74)

BE302

Fig. BE-8 Aiming adjustment

## FRONT COMBINATION LAMP


### BULB REPLACEMENT

1. Remove two retaining screws and lens.
2. Push in on bulb, turn it counter-clockwise and remove it from socket.
3. Insert new bulb into socket, press it inward and rotate it clockwise. Make sure that bulb is locked in its socket.
4. Place packing to lamp body in position and install lamp body (with packing), lens and two retaining screws.

### REMOVAL AND INSTALLATION

To remove lamp body, disconnect wiring at connector and remove wire grommet from panel. Remove two retaining screws and lens and withdraw lamp body from vehicle.

Install new lamp assembly in the reverse sequence of removal.



- 1 Screw
- 2 Lens
- 3 Bulb
- 4 Lamp body

BE698B

Fig. BE-9 Front combination lamp

## SIDE MARKER LAMP

### BULB REPLACEMENT


1. Remove two retaining screws, lens and rim.
2. Push in on bulb, turn it counter-clockwise and remove it from socket.
3. Insert new bulb into socket, press it inward and rotate it clockwise. Make sure that bulb is locked in its socket.
4. Place packing to lamp body in position and install lamp body (with packing), lens and two retaining screws.

### REMOVAL AND INSTALLATION

To remove lamp body, disconnect two lead wires at connectors and remove wire grommet (if so equipped) from panel.

Remove two retaining screws, lens and rim and withdraw lamp body from vehicle.

Install new lamp assembly in the reverse sequence of removal.




- 1 Packing
- 2 Lamp body
- 3 Rim
- 4 Bulb
- 5 Lens
- 6 Screw

BE699B


Fig. BE-10 Side marker lamp

## ROOM LAMP

### BULB REPLACEMENT



- 1 Lens
- 2 Bulb
- 3 Lamp body
- 4 Screw



(Delux Cab)

BE700B

Fig. BE-11 Room lamp

1. Remove lens from lamp housing.
2. Pull bulb forward and remove it from socket.
3. Push new bulb into socket.
4. Install lens.

housing from roof rail and disconnect two wires at connectors.


Install new lamp assembly in the reverse sequence of removal.

### REMOVAL AND INSTALLATION

To remove lamp assembly, disconnect battery ground cable, remove two retaining screws with lens removed from lamp housing, dismount lamp

## REAR COMBINATION LAMP

### BULB REPLACEMENT



- 1 Screw
- 2 Lens
- 3 Bulb
- 4 Rim
- 5 Lamp body

BE701B

Fig. BE-12 Rear combination lamp

1. Remove six lens retaining screws and lens.
2. Push in on bulb and turn it counterclockwise to remove it from socket.

3. Insert new bulb into socket, press it inward, and rotate it clockwise. Make sure that bulb is locked in its socket.


4. Place lens into position and install retaining screws.

### REMOVAL AND INSTALLATION

1. Disconnect wiring assembly at connector.
2. Remove two nuts from combination lamp mounting studs.
3. Dismount combination lamp assembly from vehicle.
4. Replace lamp assembly with a new one.
5. Install new lamp assembly in the reverse sequence of removal.

## LICENSE LAMP

### BULB REPLACEMENT



- 1 Screw
- 2 Bracket
- 3 Lens
- 4 Bulb

BE702B


Fig. BE-13 License lamp

1. Remove lens retaining screw, if so equipped, and remove lens.
2. Pull out bulb and replace it with a new one.
3. Install lens.

### REMOVAL AND INSTALLATION

1. Disconnect lead wire at connector.
2. Remove lamp bracket retaining screws and lamp assembly.
3. Install new lamp assembly in the reverse sequence of removal.

## ENGINE COMPARTMENT LAMP



- 1 Screw
- 2 Bracket
- 3 Bulb

BE703B

Fig. BE-14 Engine compartment lamp

Bulb can be replaced by pushing in on bulb and turning it counterclockwise.

To replace engine compartment lamp assembly, remove one screw retaining lamp bracket to upper dash panel and disconnect wires at connectors.


Engine compartment lamp switch can be replaced by disconnecting lead wire at connector and pulling switch assembly out of its bracket. To install switch assembly to bracket, clean dirt, dust and rust from the opening groove of bracket and press down on switch head until it fits in with bracket.

## INSPECTION

Remove lighting switch from vehicle, following the procedures given in

Removal and Installation.

Test continuity through lighting switch by using test lamp or ohmmeter.



TERMINAL	SWITCH POSITION		
	OFF	1	2
1			○
4			○
3		○	○
6		○	○


BE855A

Fig. BE-15 Lighting switch

## ILLUMINATION CONTROL RHEOSTAT

This illumination control rheostat controls the brightness of the illumina-

tion lamps of the combination meter, heater control, wiper and lighting switch knob; it is a variable resistor and its value can be controlled by a knob.



BE704B

Fig. BE-16 Illumination control rheostat

## LIGHTING SWITCH

### REMOVAL AND INSTALLATION

1. Disconnect battery ground cable.
2. Press in switch knob, turn it counterclockwise and pull it out of switch.
3. Unscrew escutcheon and remove escutcheon and spacer.
4. Reach up from underneath instrument panel, disconnect lighting switch multiple connector from instrument harness wiring assembly and remove spacer and lighting switch.
5. Install new switch in the reverse sequence of removal.

### REMOVAL AND INSTALLATION

1. Pull out knob of switch.
2. Remove ring nut retaining switch to instrument panel.
3. Disconnect lead wires for switch at connector.
4. Switch body can be taken out from behind instrument panel.
5. Installation is in the reverse sequence of removal.

## INSPECTION


Test continuity between two lead wires with a test lamp or an ohmmeter. When switch is in the OFF position, continuity must not exist. In the ON position, resistance between the two lead wires must be between 0 and 35Ω.

## KNOB ILLUMINATION LAMP

The illumination lamp is located on the illumination control rheostat.

This lamp illuminates the knob of the wiper switch and lighting switch with fiberscopes.

The fiberscopes between the knobs and cap of the illumination lamp carry the light through their tubes with the inner reflective wall.



- 1 Bulb socket
- 2 Screw
- 3 Lamp body

BE705B

Fig. BE-17 Knob illumination lamp

## BULB REPLACEMENT

1. Reach up from under the instrument panel, and pull out socket with bulb from lamp body.
2. Pick up bulb and install a new one.
3. Installation is in the reverse sequence of removal.

## LAMP BODY REPLACEMENT

1. Remove illumination control rheostat. Refer to section of illumination control rheostat for removal.
2. Disconnect lead wires for illumination lamp at connector.
3. Remove screw retaining lamp body to instrument panel. Lamp body can then be taken out easily.
4. Installation is in the reverse sequence of removal.

## TURN SIGNAL AND DIMMER SWITCH

### REMOVAL AND INSTALLATION


1. Remove steering wheel.
- Refer to the related section Steering.

2. Unhook wiring assembly from clip that retains wiring assembly to lower instrument panel.
3. Disconnect multiple connector and lead wire from instrument harness wiring.
4. Remove shell covers (Upper and Lower).
5. Loosen two screws attaching switch assembly to steering column jacket and remove switch assembly.
6. Position switch assembly to steering column jacket. Make sure that a location tab (or screw) fits in with hole of steering column jacket.

7. Tighten two attaching screws.
8. Install shell covers.
9. Connect multiple connector and lead wire to instrument harness wiring.
10. Clip wiring assembly at lower instrument panel.
11. Install steering wheel.

## INSPECTION

Test continuity through lighting switch by using test lamp or ohmmeter.



TERMINAL	LEVER POSITION		
	L	N	R
1 FLASH	○	○	○
2 STOP	○	○	○
3 FR LH	○	○	○
4 FR RH	○	○	○
5 RR LH	○	○	○
6 RR RH	○	○	○

BE706B

Fig. BE-18 Turn signal and dimmer switch

## STOP LAMP SWITCH

### REMOVAL AND INSTALLATION

Stop lamp switch is mounted at the bottom of (pedal and steering post) bracket.

1. Disconnect battery ground cable.
2. Disconnect lead wires at connectors.
3. Loosen lock nut, unscrew switch assembly and remove switch assembly.
4. Install switch assembly as described under Brake Pedal in Section BR.

## INSPECTION

When plunger is pressed into switch assembly (when brake pedal is released), stop lamp switch contacts are open. On the contrary, contacts are closed with plunger projected.

## DOOR SWITCH

Door switch is installed on both L.H. and R.H. front door pillars.

### REMOVAL AND INSTALLATION

1. Disconnect battery ground cable.
2. To pull switch assembly out of lower pillar, withdraw switch and wiring assembly.
3. Disconnect lead wire at connector.
4. Installation is in the reverse sequence of removal.

## INSPECTION


Test continuity through door switch by using test lamp or ohmmeter.

When plunger is pressed into switch assembly, door switch contacts are open. Contacts are closed when plunger is projected.

## HAZARD SWITCH

### REMOVAL AND INSTALLATION

1. Disconnect multiple connector and lead wire from instrument harness wiring.



TERMINAL	SWITCH POSITION	
	OFF	ON
1		○
2		○
3		○
4		○
5		○
6	○	
7	○	

BE308

Fig. BE-19 Hazard switch

2. Remove shell covers (Upper).
3. Remove two screws attaching switch to lower shell cover and remove switch.
4. Install hazard switch in the reverse sequence of removal.

## INSPECTION


Test continuity through hazard switch by using test lamp or ohmmeter.

## FLASHER UNIT

There are two flasher units. One is for turn signal and the other for hazard.

They are located at both sides of instrument panel near steering column. They can be distinguished from each other by their shape.

The large one is for turn signal; the smaller for hazard. See Figure BE-20.



- 1 Hazard flasher unit
- 2 Turn signal flasher unit

BE707B

Fig. BE-20 Flasher unit

## REPLACEMENT

1. Disconnect battery ground cable.
2. Disconnect connector fitted to bottom of unit.
3. Remove screw retaining flasher unit.
4. Installation is in the reverse sequence of removal.

## Body Electrical System

### BULB SPECIFICATIONS

Item	Bulb	
	Wattage (Candlepower)	SAE trade number
Headlamp      Inner Outer	37.5W 37.5/50W	4001 4002
Front combination lamp Turn signal and parking lamp	23/8W (32/3C)	1034
Side marker lamp Front Rear	8W (4C) 8W (4C)	67 67
Rear combination lamp Turn signal lamp (A, B) Tail lamp (B, C) Stop lamp (A, B) Back-up lamp (D)	A: 23W (32C) B: 23/8W (32/3C) C: 8W (4C) D: 23W (32C)	1073 1034 67 1073
License plate lamp	7.5W (6C)	89
Engine compartment lamp	6W	—
Room lamp	5W	—
Combination meter illumination	1.7W (1C) x 3	161
Knob illumination lamp	3.4W (2C)	158
Heater control illumination lamp	3.4W (2C)	158

### TROUBLE DIAGNOSES AND CORRECTIONS

#### HEADLAMP

Condition	Probable cause	Corrective action
Headlamps do not light for both high and low beams.	Burnt fuse. Loose connection or open circuit. Faulty lighting switch. Faulty dimmer switch. Faulty light relay.  No ground.	Correct cause and replace fuse. Check wiring and/or repair connection. Conduct continuity test and replace if necessary.  Check light relay for proper operation and replace if necessary. Clean and tighten ground terminal.
High beam cannot be switched to low beam or vice versa.	Faulty dimmer switch.  Faulty light relay.	Conduct continuity test and replace if necessary.  Check light relay for proper operation and replace if necessary.

## Body Electrical System

Condition	Probable cause	Corrective action
Headlamps dim.	Partly discharged or faulty battery.  Faulty charging system.  Poor ground or loose connection. Burnt sealed beams.	Measure specific gravity of electrolyte and recharge or replace battery if necessary. Measure voltage at headlamp terminals. If it is less than 12.8V, check charging system for proper operation. Clean and/or tighten. Replace.
Headlamp in only one side lights.	Loose headlamp connection. Damaged sealed beam.	Repair. Replace.

### TURN SIGNAL LAMP

Condition	Probable cause	Corrective action
Turn signals do not operate.	Burnt fuse. Loose connection or open circuit. Faulty flasher unit. Faulty turn signal switch.	Correct cause and replace. Check wiring and/or repair connection. Replace. Conduct continuity test and replace if necessary.
Flashing cycle is too slow. (Pilot lamp does not go out.) or too fast.	Bulbs having wattage other than specified wattage are used. Burnt bulbs. Loose connection. Inoperative flasher unit.	Replace with specified one.  Replace. Repair. Replace.
Flashing cycle is irregular.	Burnt bulb. Loose connection. Bulb having wattage other than specified wattage is used.	Replace. Repair. Replace with specified one.

### TAIL LAMP, STOP LAMP AND BACK-UP LAMP

Condition	Probable cause	Corrective action
Both right and left lamps do not light.	Burnt fuse. Inoperative stop lamp switch.  Faulty back-up lamp switch.  Loose connection or open circuit.	Correct cause and replace. Conduct continuity test and replace if necessary.  Conduct continuity test and replace if necessary. Check wiring and/or repair connection.
Lamp in only one side lights.	Burnt bulb. Loose bulb.	Replace. Repair lamp socket.




# METERS AND GAUGES

## CONTENTS


COMBINATION METER .....	BE-14	CHARGE WARNING LAMP .....	BE-17
COMBINATION METER CIRCUIT		DESCRIPTION .....	BE-17
DIAGRAM .....	BE-14	HAND BRAKE WARNING LAMP .....	BE-18
REMOVAL AND INSTALLATION .....	BE-16	DESCRIPTION .....	BE-18
SPEEDOMETER .....	BE-16	HAND BRAKE SWITCH .....	BE-18
REMOVAL AND INSTALLATION .....	BE-16	METER ILLUMINATION, INDICATOR	
ODOMETER SWITCH .....	BE-16	AND WARNING BULBS .....	BE-18
REMOVAL AND INSTALLATION .....	BE-16	REMOVAL AND INSTALLATION .....	BE-18
FUEL GAUGE AND WATER TEMPERATURE		BULB SPECIFICATIONS .....	BE-18
GAUGE .....	BE-16	TROUBLE DIAGNOSES AND	
DESCRIPTION .....	BE-16	CORRECTIONS .....	BE-18
REMOVAL AND INSTALLATION .....	BE-16	SPEEDOMETER .....	BE-18
OIL PRESSURE WARNING LAMP .....	BE-17	WATER TEMPERATURE AND FUEL	
DESCRIPTION .....	BE-17	GAUGES .....	BE-19
OIL PRESSURE SWITCH .....	BE-17	OIL PRESSURE AND CHARGE WARNING	
		LAMPS .....	BE-20

## COMBINATION METER

### COMBINATION METER CIRCUIT DIAGRAM



BE856A



BE682B

- 1 Speedometer
- 2 Thermometer
- 3 Fuel meter
- 4 Tachometer (Option)
- 5 Cluster lid
- 6 Speedometer cable
- 7 Speed switch amplifier  
(Manual transmission only)

Fig. BE-21 Circuit diagram of combination meter

## Circuit diagram of combination meter system




Fig. BE-22 Circuit diagram of combination meter system

## REMOVAL AND INSTALLATION

1. Disconnect battery ground cable.
2. Working through meter openings of cluster lid, remove three screws retaining cluster lid to instrument panel.
3. From underneath instrument panel, remove one screw retaining meter assembly to lower panel of instrument.
4. Withdraw cluster lid slightly. For access to switches, knobs, etc., follow the procedures given in each section.
5. From behind combination meter disconnect speedometer cable at speedometer head and multiple connector (instrument wire assembly) from printed circuit.
6. On vehicle with clock, disconnect wires at each connection on meter printed circuit.
7. Remove four screws retaining meter assembly to cluster lid.
8. Remove combination meter assembly.
9. When installing combination meter assembly, follow the reverse sequence of removal.




Fig. BE-23 Removing cluster lid

## SPEEDOMETER

### REMOVAL AND INSTALLATION

1. Remove combination meter assembly. Follow the procedures under Removal and Installation in Combination Meter.

2. Remove meter front cover and shadow plate by removing clips and screws.
3. Remove screws retaining speedometer to printed circuit housing and remove speedometer.
4. Install speedometer in the reverse sequence of removal.

## ODOMETER SWITCH

### REMOVAL AND INSTALLATION

1. Remove speedometer as outlined under Speedometer.
2. Remove odometer retaining screws.
3. Install odometer in the reverse sequence of removal.




Fig. BE-24 Odometer switch.

## FUEL GAUGE AND WATER TEMPERATURE GAUGE

### DESCRIPTION

The fuel gauge consists of a tank unit located in the fuel tank and fuel gauge. The tank unit detects fuel level with its float, converts fuel level variation to a resistance of slide resistor installed on the float base, and thus, controls current flowing to the fuel gauge.

The water temperature gauge consists of a gauge and thermal transmitter located in the engine block. The thermal transmitter is equipped with a thermistor element which converts cooling water temperature variation to a resistance, and thus, the thermal transmitter controls current flowing to the gauge.

The fuel gauge and water temperature gauge are provided with a bi-metal arm and heater coil. When the ignition switch is set to "ON", current flows to the heat coil, and the heat coil is heated. With this heat, the bi-metal arm is bent, and thus, the pointer connected to the bi-metal arm is operated. The characteristics of both gauges are the same.

A tolerance may occur on the water temperature gauge or fuel gauge due to source voltage fluctuation. The voltage regulator is used to supply a constant voltage so that the water temperature gauge and fuel gauge operate correctly.

The operating part of the regulator consists of a bi-metal arm and a heater coil. When the ignition switch is turned on, the bi-metal arm is heated and bent by the coil, opening the contact. Consequently, current to the coil is interrupted. As the bi-metal cools, the contact closes. The repetition of this operation produces a pulsating voltage of 8 volts which is applied to the water temperature and fuel gauges.

If both the water temperature gauge and fuel gauge become faulty at the same time, this may be attributed to problem in the voltage regulator.

### REMOVAL AND INSTALLATION

1. Remove combination meter assembly. Follow the procedures under Removal and Installation in Combination Meter.
2. Remove meter front cover and shadow plate by removing clips and screws.
3. Remove retaining nuts at the back side of combination meter assembly and remove meter.
4. Install meter in the reverse sequence of removal.




Fig. BE-25 Circuit diagram of fuel gauge and water temperature gauge

## OIL PRESSURE WARNING LAMP

### DESCRIPTION

The engine lubricating system incorporates an oil pressure warning lamp which glows whenever engine oil

pressure falls below 0.4 to 0.6 kg/cm<sup>2</sup> (5.7 to 8.5 psi). Under normal operation, when the engine is stationary, the light glows with the ignition switch turned on. When the engine is running and oil pressure reaches the above range, the circuit opens and the light goes out.




Fig. BE-26 Circuit of oil pressure warning system

## OIL PRESSURE SWITCH

To replace oil pressure switch, disconnect lead wire from switch terminal and unscrew switch from engine cylinder block.

Prior to installing switch to cylinder block, be sure to apply conductive sealer to threads of new switch.

## CHARGE WARNING LAMP

### DESCRIPTION

The charge warning lamp glows when the ignition switch is set to "ON" with the engine shut down, or when the generator falls to charge with the engine operated.

When the ignition switch is set to "ON", the charge warning circuit is closed and current flows from the ignition switch to the warning lamp and grounds through the regulator (Fig. BE-27-1). When the engine is started and the generator comes into operation, the generator output current (N) opposes the current flowing from the warning lamp; as the current (N) increases, the solenoid is more energized and the pilot lamp relay contacts are open, in effect it breaks the warning circuit ground connection, and the lamp goes out (Fig. BE-27-2).




Fig. BE-27-1




Fig. BE-27-2

Circuit of charge warning system

## HAND BRAKE WARNING LAMP

### DESCRIPTION

The hand brake warning lamp glows when the hand brake is applied.

When the ignition switch is set to "ON", current flows from the ignition switch to the warning lamp. When the hand brake is applied, hand brake warning switch is closed and warning lamp glows.




Fig. BE-28 Circuit of hand brake warning system

## HAND BRAKE SWITCH

To remove hand brake switch, disconnect lead wire, pull switch out of hand brake control bracket and withdraw switch and wiring assembly.

## METER ILLUMINATION, INDICATOR AND WARNING BULBS

### REMOVAL AND INSTALLATION

To replace bulb, turn bulb socket counterclockwise to dismount it from combination meter (if necessary, disconnect lead wire connector from printed circuit) and remove bulb from socket.

## BULB SPECIFICATIONS

Item	SAE Trade Bulb No.	Wattage (Candle power) W (C)
Meter illumination lamp	161	1.7 (1) x 3
Turn signal indicator lamp	161	1.7 (1)
High beam indicator lamp	161	1.7 (1)
Oil pressure warning lamp	161	1.7 (1)
Charge warning lamp	161	1.7 (1)
Hand brake warning lamp	158	3.4 (2)
Clock illumination lamp	158	3.4 (2)

## TROUBLE DIAGNOSES AND CORRECTIONS

### SPEEDOMETER

Condition	Probable cause	Corrective action
Speedometer pointer and odometer do not operate.	Loose speedometer cable union nut. Broken speedometer cable. Damaged speedometer drive pinion gear (Transmission side). Inoperative speedometer.	Retighten. Replace. Replace. Replace.
Unstable speedometer pointer.	Improperly tightened or loose speedometer cable union nut. Faulty speedometer cable. Inoperative speedometer.	Retighten. Replace. Replace.
Unusual sound occurs in response to increase in driving speed.	Excessively bent or twisted speedometer cable inner wire or lack of lubrication. Inoperative speedometer.	Replace or lubricate. Replace.

## Body Electrical System

Condition	Probable cause	Corrective action
Inaccurate speedometer indication.	Inoperative speedometer.	Replace.
Inaccurate odometer operation.	Improperly meshed second and third gear worn gears.	Replace speedometer.
	Faulty feeding due to deformed odometer and pinion carrier.	Replace speedometer.

## WATER TEMPERATURE AND FUEL GAUGES

Condition	Probable cause	Corrective action
Both water temperature gauge and fuel gauge do not operate.	Burnt fuse.	Correct cause and replace fuse.
	Inoperative gauge voltage regulator.	Replace water temperature gauge.
Both water temperature gauge and fuel gauge indicate inaccurately.	Inoperative gauge voltage regulator. (Gauge pointer fluctuates excessively.)	Replace water temperature gauge.
	Loose or poor connection. (Gauge pointer fluctuates slightly.) Correct conn	Correct connector contact.
Water temperature gauge  Water temperature gauge does not operate.	Faulty thermal transmitter or loose terminal connection. (When thermal transmitter yellow/white wire is grounded, gauge pointer fluctuates.)	Replace thermal transmitter or correct terminal connection.
	Faulty water temperature gauge. Open circuit.	Replace water temperature gauge.
Gauge indicates only maximum temperature.	Faulty thermal transmitter. (Gauge pointer returns to original position when ignition switch is turned off.)	Replace thermal transmitter.
	Faulty water temperature gauge. (Gauge pointer indicates maximum temperature even after ignition switch is turned off.)	Replace water temperature gauge.
Water temperature gauge does not operate accurately.	Faulty water temperature gauge. Faulty thermal transmitter.	[Connect a 115Ω resistance between thermal transmitter yellow/white wire and ground. When gauge indicates approximately 50°C (122°F), gauge is serviceable.]
	Loose or poor connection.	Correct gauge terminal contact.

## Body Electrical System

Condition	Probable cause	Corrective action
<b>Fuel gauge</b> Fuel gauge does not operate.	Faulty tank unit or loose unit terminal connection. (Pointer indicates a half level when a 35Ω resistance is connected between tank unit yellow wire and ground.) Faulty fuel gauge. Poor or loose connection. Open circuit.	Replace tank unit or correct terminal connection.  Replace fuel gauge. Correct connector terminal contact.
Pointer indicates only "F" position.	Faulty tank unit. (Pointer lowers below "E" mark when ignition switch is turned off.) Faulty fuel gauge. (Pointer still indicates "F" position when ignition switch is turned off.)	Replace tank unit.  Replace fuel gauge.

## OIL PRESSURE AND CHARGE WARNING LAMPS

Condition	Probable cause	Corrective action
<b>Oil pressure warning lamp</b> Lamp does not light when ignition switch is set to "ON".	Inoperative oil pressure switch or loose switch terminal connection. (When switch yellow/black wire is grounded, warning lamp lights.) Burnt bulb or loose bulb. Open circuit.	Replace switch or correct terminal connection.  Replace bulb or correct bulb socket.
Lamp does not go out while engine is being operated.	Lack of engine oil. Oil pressure too low. Inoperative oil pressure switch.	Check oil level and add oil as required. Inspect engine oil pressure system. Replace oil pressure switch.
<b>Charge warning lamp</b> Lamp does not light when ignition switch is set to "ON".	Burnt bulb or loose bulb. (Warning lamp does not light when voltage regulator white/red wire is grounded.) Open circuit.	Replace bulb or correct bulb socket.
Lamp does not go out when engine is started.	Faulty charging system.	Inspect charging system.

# ELECTRICAL ACCESSORIES

## CONTENTS

HORN .....	BE-21	HEATER CORE .....	BE-29
DESCRIPTION .....	BE-21	FAN MOTOR .....	BE-29
REMOVAL AND INSTALLATION .....	BE-21	CONTROL ASSEMBLY .....	BE-29
IGNITION SWITCH .....	BE-22	ADJUSTMENT .....	BE-29
REMOVAL AND INSTALLATION .....	BE-22	SPECIFICATIONS .....	BE-30
INSPECTION .....	BE-22	TACHOMETER .....	BE-30
WINDSHIELD WIPER AND WASHER .....	BE-23	REPLACEMENT .....	BE-30
REMOVAL AND INSTALLATION .....	BE-23	BULB REPLACEMENT .....	BE-30
INSPECTION .....	BE-23	SEAT BELT WARNING SYSTEM .....	BE-31
RADIO .....	BE-25	DESCRIPTION .....	BE-31
REMOVAL AND INSTALLATION .....	BE-25	REMOVAL AND INSTALLATION .....	BE-31
ADJUSTMENT .....	BE-25	WARNING LAMP BULB REPLACEMENT .....	BE-31
CLOCK .....	BE-25	INSPECTION .....	BE-31
REMOVAL .....	BE-25	TROUBLE DIAGNOSES AND .....	BE-33
INSTALLATION .....	BE-26	CORRECTIONS .....	BE-33
HEATER .....	BE-26	HORN .....	BE-33
DESCRIPTION .....	BE-26	WINDSHIELD WIPER AND WASHER .....	BE-34
AIRFLOW .....	BE-28	RADIO .....	BE-35
HEATER UNIT ASSEMBLY .....	BE-29		

## HORN

### DESCRIPTION

The horn circuit includes a horn relay. Current from the battery flows through the fusible link and fuse to the horn relay (terminal B), where it is shunted by the two circuits. In one circuit (terminal S), the current flow is supplied through the solenoid and

horn button to the ground. In the other circuit (terminal H), the current flow is supplied through the relay contacts and horn. (Horn bracket serves as a grounding.)

When the horn button is pressed, current from the battery energizes the solenoid. As the solenoid is energized, the relay contacts are closed. This allows the current to flow to the horn.

### REMOVAL AND INSTALLATION


#### Horn

1. Disconnect battery ground cable.
2. Disconnect horn wire at terminal on horn body.
3. Remove horn retaining bolt.
4. Install horn in the reverse sequence of removal.

#### Horn relay

The horn relay is installed on the hoodledge on the right side of the engine compartment.


1. Disconnect battery ground cable.
2. Disconnect horn relay wire connector at terminals on horn relay.
3. Remove retaining screws.
4. Install horn relay in the reverse sequence of removal.



BE859A

Fig. BE-29 Circuit diagram of horn system






- 1 Voltage regulator
- 2 Horn relay
- 3 Headlamp relay
- 4 Ignition relay (California only)
- 5 Auto-choke heater relay
- 6 Compressor relay  
(Air conditioner equipped model)
- 7 Floor sensor relay (California only)
- 8 Inhibitor relay (Automatic transmission only)

BE683B

Fig. BE-30

## Horn switch

The horn switch is integral with the turn signal and dimmer switch assembly. Remove switch assembly as outlined in Turn Signal and Dimmer Switch.



BE861A

Fig. BE-31 Removing ignition switch

## INSPECTION


### Continuity test

Test continuity through ignition switch by using test lamp or ohmmeter.

## IGNITION SWITCH

### REMOVAL AND INSTALLATION

1. Disconnect battery ground cable from battery.
2. Unscrew and remove escutcheon from the front of ignition switch.
3. Withdraw ignition switch and wiring assembly (with spacer), from shell cover as shown in Figure BE-31.
4. Disconnect wiring connector from the back of ignition switch.
5. Replace ignition switch with a new one.
6. Connect ignition switch to wiring connector.
7. Position ignition switch to shell cover opening, install and tighten escutcheon and secure ignition switch to shell cover.




TERMINAL	KEY POSITION			
	OFF	ACC	ON	START
B		○	○	○
IG			○	○
ST				○
A		○	○	
R				○

BE684B

Fig. BE-32 Ignition switch

# WINDSHIELD WIPER AND WASHER

## REMOVAL AND INSTALLATION



BE685B

Fig. BE-33 Windshield wiper

### Wiper linkage

1. Remove wiper blade and arm assembly from pivot.
2. Remove cowl top grille. See Section BF.
3. Remove two flange nuts retaining pivot (wiper linkage) to cowl top.
4. Remove stop ring that retains connecting rod to wiper motor arm.
5. Remove wiper motor linkage assembly.
6. Install wiper motor linkage in the reverse sequence of removal.




Fig. BE-34 Removing wiper linkage

7. Install wiper arm and blade assembly in correct sweeping angle. See Figure BE-35 for correct installing dimensions.




Fig. BE-35 Wiper arm installation

### Wiper motor

1. Remove cowl top grille.
3. Remove stop ring that connects wiper motor arm to connecting rod.
3. From under instrument panel, disconnect wiper motor harness at connector on wiper motor body.
4. Remove three retaining screws and pull out wiper motor forward.
5. Install wiper motor in the reverse sequence of removal.




Fig. BE-36 Removing wiper motor

### Wiper and washer switch

1. Press in switch knob, turn it counterclockwise and pull it out of switch.
2. Unscrew escutcheon and remove escutcheon and spacer.
3. Reach up from underneath instrument panel, disconnect wiper switch multiple connector from instrument harness wiring assembly and remove spacer and switch.
4. Install new switch in the reverse sequence of removal.

### Washer pump

The washer pump and washer fluid tank are integral parts and are serviced as an assembly.

### Caution for windshield washer operation

1. Be sure to use only washing solution.

Never use mix powder soap or detergent with solution.

2. Do not operate windshield washer continuously more than 30 seconds or without washer fluid. This often causes improper windshield washer operation. Normally, windshield washer should be operated 10 seconds or less at one time.

1. Disconnect two washer pump lead wires at connectors.

2. Remove hose from washer pump and drain washer fluid.


3. Pull out washer tank and motor assembly from tank bracket.

4. Install washer tank and motor assembly in the reverse sequence of removal.

### Washer nozzle

Access for washer nozzle removal is obtained by disconnecting vinyl tube and removing washer nozzle retaining screw from cowl top.

When washer nozzle is installed or when washer fluid is not sprayed properly, adjust nozzle direction by bending nozzle tube so that washer fluid is sprayed in range indicated in Figure BE-37.



Unit: mm (in)

BE863A

Fig. BE-37 Washer nozzle adjustment

## INSPECTION

### Wiper motor

1. Disconnect wiring connector from wiper motor.
2. Connect test lead between B terminal on motor side and battery posi-

## Body Electrical System


tive terminal (or B terminal and blue/red wire terminal in wiring connector plug).

3. To check wiper low speed operation, connect L terminal to ground with ground cable (or connect L terminal to black wire terminal), make sure that wipers sweep at low speed.

4. To check wiper high speed operation, connect ground cable to H terminal in the same manner as in step 3; make sure that wipers sweep fast.

5. During low speed operation, connect E terminal to ground and connect P and L terminals with lead wire as shown in Figure BE-38. At this time, make sure that auto-stop mechanism actuates to stop wiper blade at the specified position.

6. Wiper is in good condition if above tests are made as indicated.



BE864A


Fig. BE-38 Wiper motor

### Wiper and washer switch

#### Continuity test

Remove wiper switch from vehicle as outlined in Wiper Switch.



Test continuity through wiper switch by using test lamp or ohmmeter.



BE865A

Fig. BE-39 Circuit diagram of windshield wiper-washer system

TERMINAL	SWITCH POSITION			
	OFF	1	2	Twist
1				
2				
3				
4				
5				



BE686B

Fig. BE-40 Wiper switch

### RADIO


#### REMOVAL AND INSTALLATION

##### Radio

##### Removal

1. Pull radio knobs off radio control shafts.

2. Remove radio holding nuts and washer from radio control shafts.
3. Remove radio bezel from the front of radio.
4. From under instrument panel, disconnect antenna cable and lead wires (power lead and speaker lead).
5. Remove radio from instrument panel.



BE323

Fig. BE-41 Radio

##### Installation

1. From behind instrument panel position radio to instrument panel.
2. Install radio bezel to the front of radio.
3. Install washers and nuts on radio control shafts and tighten them securely. Then install control knobs.
4. Connect antenna cable and lead wires (power lead and speaker lead).


##### Antenna and antenna cable

##### Removal

1. From behind instrument panel disconnect antenna cable at connector.
2. Remove plug on antenna base and remove antenna base retaining screw.
3. Remove antenna and cable assembly from front pillar.
4. Unscrew antenna clip from front pillar if necessary.

##### Installation

1. Remove rubber plugs that cover antenna mounting opening in front pillar (when installing radio antenna on vehicle that is not equipped with radio).
2. Thread mounting stud of antenna clip into (upper) antenna mounting opening.
3. Insert antenna cable into (lower) antenna mounting opening and place antenna base in position.
4. Install antenna base retaining screw.
5. Route antenna cable along upper dash panel to radio.
6. Connect antenna cable at connector.



BE867A

Fig. BE-42 Radio antenna

### ADJUSTMENT


#### Antenna trimmer

When a new radio receiver, antenna or antenna feeder is installed, antenna trimmer should be adjusted.

1. Extend antenna completely.
2. Tune in the weakest station between 12 and 16 (1,200 to 1,600KC) on dial.

Noise may be generated but disregard it.

3. Turn antenna trimmer to right and left slowly and set it at a position where receiving sensitivity is highest.



BE133

Fig. BE-43 Adjusting antenna trimmer


### CLOCK

#### REMOVAL

1. Remove battery ground cable.
2. Remove cluster lid, following instructions in steps 1 to 4 of Removal in Combination Meter.
3. Disconnect three wire connectors of clock from combination meter printed circuit and instrument harness wiring.
4. Remove three screws and remove clock from cluster lid.

## INSTALLATION

1. Position clock to cluster lid and install three screws.
2. Connect three wire connectors of clock to each connection, two to combination meter printed circuit, one to instrument harness wiring.
3. Install cluster lid to instrument panel.
4. Connect battery ground cable.




BE349A

Fig. BE-44 Clock

## HEATER

### DESCRIPTION



- |                           |                            |
|---------------------------|----------------------------|
| 1 Defroster nozzle (L.H.) | 7 Ventilator knob          |
| 2 Defroster duct (L.H.)   | 8 Heater core              |
| 3 Heater control          | 9 Control cable clip       |
| 4 Resistor                | 10 Heater cock             |
| 5 Heater motor            | 11 Defroster duct (R.H.)   |
| 6 Heater case             | 12 Defroster nozzle (R.H.) |

BE687B

Fig. BE-45 Heater construction

## Body Electrical System

Operation of the heater is controlled by two control levers located on the instrument panel and a hand operated knob on the center of the heater unit.

The AIR LEVER controls the air intake valve and/or room valve by its lever positions (OFF, DEFROST and ROOM) through the control cables. The air intake valve draws the fresh outside air from the cowl top grille and supplies the air into the heater unit. The room valve is located at the bottom of the heater unit. The air coming through the air intake valve opening is forced through the heater core to the room valve, where the air is distributed to the floor outlet and/or defroster outlets, depending on the position of the room valve.

The VENT KNOB is directly linked to the vent valve which provides fresh air for the passenger. Push the knob all the way in to open the valve. The fresh ventilating air comes out of the heater center outlet.

The TEMP lever is a dual purpose control; one is for regulating the flow of engine coolant flowing into

the heater unit and the other for the operation of the fan motor. When the lever is in the OFF position, the water cock is closed and the circulation of engine coolant through the heater core stops. When the lever is slid to any other position than OFF, the water

cock opens in proportion to the lever setting and allow engine coolant to flow into heater core.

To control the fan motor operation, push or pull the lever knob. Two speeds are provided for the fan motor by using a three position switch.





Fig. BE-46 Circuit diagram of heater



## AIRFLOW

OFF





Push

VENTILATING




Pull

DEFROSTING




Pull

VENTILATING-HEATING




Pull

DEFROSTING-HEATING



Pull

HEATING



Pull

BE397

Fig. BE-47 Airflow

## HEATER UNIT ASSEMBLY

### Removal

1. Disconnect battery ground cable.
2. Drain engine coolant.
3. Remove defroster hoses.
4. Remove three cable retaining clips and disconnect control cables from valves and water cock.
5. Disconnect two fan motor lead wires from each connector.
6. Disconnect two resistor lead wires from each connector.
7. Disconnect water hoses from core and water cock.
8. Remove three heater housing mounting bolts and dismount heater unit from vehicle.


### Installation

1. Position heater unit under instrument panel and install three heater unit securing bolts.
2. Install water hoses.
3. Position heater control cables to room valve, air intake valve and water cock.
4. Adjust control cable length for proper operation as outlined in Adjustment.
5. Connect fan motor wires and resistance wires to each connector plug.
6. Install defroster hoses.
7. Connect battery ground cable.
8. Fill cooling system.
9. Run engine at 2,000 rpm with AIR lever in the "HOT" position. Make sure that engine coolant is filled up to correct level.

## HEATER CORE

### Removal and installation


1. Drain engine coolant.
2. Remove defroster hoses.
3. Disconnect water hoses from inlet and outlet pipes of heater core.
4. Remove four clips and front cover.



BE869A

Fig. BE-48 Removing front cover

5. Withdraw heater core from heater housing.



BE870A

Fig. BE-49 Removing heater core

6. Install heater core in the reverse sequence of removal.

## FAN MOTOR

### Removal and Installation

1. Dismount heater unit assembly from vehicle as outlined in Removal of Heater Unit Assembly.
2. Remove nine spring clips and disassemble heater housing.
3. Remove fan from fan motor.
4. Remove fan motor retaining screws and fan motor.
5. Assemble heater housing and install heater unit to vehicle in the reverse sequence of removal as outlined in Installation of Heater Unit Assembly.

## CONTROL ASSEMBLY

### Removal and Installation


1. Remove three cable retaining clips and disconnect control cables from valves and cock.

2. Disconnect three lead wires from each connector plug.
3. Remove radio bezel from the front of radio, following instructions in steps 1 to 3 in Removal of Radio.
4. Remove heater control knobs and heater bezel.
5. Remove two retaining bolts and heater control assembly.
6. Install control assembly in the reverse sequence of removal. When connecting control cables to valves and cock, adjust control cable length as outlined in Adjustment.

## ADJUSTMENT

### AIR lever


1. Move AIR lever to the "DEF" position.
2. Open air intake valve and connect control cable to air intake valve.
3. Clip control cable with cable retaining clip.



BE331

Fig. BE-50 Air intake valve

4. Pull room valve upward and connect control cable to room valve.
5. Clip control cable with cable retaining clip.



BE871A


Fig. BE-51 Room valve



## Body Electrical System

### TEMP lever

1. Move TEMP lever to the "OFF" position.
2. Connect control cable to the lever of water cock when water cock lever is pulled forward (fully closed).
3. Install control cable on water cock bracket with cable retaining clip.



BE872A

Fig. BE-52 Water cock

### SPECIFICATIONS

Item	General use	Extremely cold weather use
FAN MOTOR		
Rated power consumption	12V less than 36W	12V less than 55W
Revolution rpm	3,600	2,800
Fan dia. mm (in)	110 (4.33)	110 (4.33)

### TACHOMETER

The tachometer is optional on model HL620. It is an integral part of the ignition system. It counts the pulses entering the ignition coil and indicates the number of engine revolutions.

### REPLACEMENT

1. Remove battery ground cable.
2. Remove cluster lid, following instructions in steps 1 to 4 of Removal in Combination Meter.

3. Disconnect four tachometer lead wire connectors. They are connected to combination meter and tachometer cable.
4. Remove three screws and then remove tachometer from cluster lid.
5. Install in reverse sequence of removal. When connecting lead wire, note the following.

1. BW .. The black with white striped lead wire must be connected to identically colored tachometer cable coming from engine compartment.

2. RG .. The red with green stripe lead wire must be connected to flat plate terminal at back of combination meter.
3. B .... The black lead wire must be connected to "T" shaped terminal at back of combination meter.
4. YR .. The yellow with red stripe lead wire must be connected to pole terminal at back of combination meter.

6. Pass tachometer wires through grommet on hood lock control wire, and connect to negative terminal of ignition coil.

#### Notes:


- a. Fix grommet with an adhesive tape or a sealing compound to prevent water leakage.
- b. Attach tachometer wires to hood lock control wire with an adhesive tape.

### BULB REPLACEMENT

1. Remove tachometer as previously described.
2. Twist illumination bulb socket at back of tachometer. Bulb with socket can then be easily removed.
3. Remove bulb.
4. Install new bulb in reverse sequence of removal.

Bulb wattage:

Tachometer illumination lamp: 3.4W



BE965

Fig. BE-53 Tachometer

## SEAT BELT WARNING SYSTEM

### DESCRIPTION

#### Except Canada

When the ignition switch is turned to the "ON" position, the warning lamp comes on and remains on for 4 to 8 seconds. The warning buzzer sounds for 4 to 8 seconds intermittently if the driver's seat belt is not fastened properly.

The seat belt warning system consists of a driver's belt switch, a warning buzzer, a warning lamp, a timer unit, and an ignition switch.

#### For Canada

When the ignition switch is turned

to the "ON" position, the warning lamp comes on, and the warning buzzer sounds if the driver's seat belt is not fastened properly.

The seat belt warning system consists of a driver's belt switch, a warning buzzer, a warning lamp, and an ignition switch.

### REMOVAL AND INSTALLATION

#### Ignition switch

Refer to page BE-22 for Removal and Installation.

#### Timer unit

Timer unit is fixed on a reinforcement behind glove box.

#### Warning lamp body

Warning lamp is located on instrument panel.

1. Remove cluster lid.
2. Disconnect lead wire at connector.
3. Remove two screws retaining lamp body.
4. Installation is in the reverse sequence of removal.

### WARNING LAMP BULB REPLACEMENT

1. Remove cluster lid.
2. Twist warning lamp socket. Socket with bulb can then be taken out.
3. Pick up bulb from socket.
4. Install new bulb in the reverse sequence of removal.

Bulb wattage:

Seat belt warning lamp: 1.7W

### INSPECTION

#### Warning buzzer

Apply 12V direct current between ① and ②, and check whether buzzer sounds or not.

The buzzer must sound when ① and ② are connected to power circuit. See Figure BE-55 for warning buzzer.


**Note:** Make sure that (–) negative terminal of power circuit is always connected to ② terminal.

#### Timer unit


Turn ignition key to the "ON" position. The voltage between ⑧ and ground must be 12V for 4 to 8 seconds and then go out. See Figures BE-54 and BE-56.

#### Belt switch

Test continuity between two lead wires from seat belt switch with ohmmeter or test lamp.



BE688B



BE282B


Fig. BE-54 Timer unit

1. Disconnect battery ground cable.
2. Remove glove box.
3. Disconnect timer unit connector.
4. Remove two screws retaining timer unit on reinforcement. Timer unit can then be taken out.
5. Installation is in the reverse sequence of removal.

#### Warning buzzer

Warning buzzer is fixed on a reinforcement behind glove box.

Refer to the preceding timer unit for Removal and Installation.



BE967A

Fig. BE-55 Warning buzzer


#### Driver's seat belt switch

1. Remove seat belt securing bolt.
2. Disconnect belt switch lead wire at connector.
3. Seat belt can then be taken out.
4. Installation is in the reverse sequence of removal.


## Body Electrical System

### Circuit diagram of seat belt warning system


Non-California models except for Canada



California models



Canada models



BE689B

Fig. BE-56 Circuit diagram of seat belt warning system

## TROUBLE DIAGNOSES AND CORRECTIONS

### HORN

Condition	Probable cause	Corrective action
Horn does not operate.	<p>Discharged battery. (Measure specific gravity of electrolyte.)</p> <p>Burnt fuse.</p> <p>Faulty horn button contact. (Horn sounds when horn relay terminal(s) is grounded.)</p> <p>Inoperative horn relay. (Horn sounds when (B) and (H) horn relay terminals are connected with a test lead).</p> <p>Damaged horn or loose horn terminal connection.</p>	<p>Recharge or replace battery.</p> <p>Correct cause and replace fuse.</p> <p>Repair horn button.</p> <p>Replace horn relay.</p> <p>Correct horn terminal connection or replace horn.</p>
Horn sounds continuously.	<p>Short-circuited horn button and/or horn button lead wire. (When light green lead wire is disconnected from horn relay terminal(s), horn stops to sound.)</p> <p>Inoperative horn relay.</p>	<p>Repair horn button or its wiring.</p> <p>Replace horn relay.</p>
Reduced volume and/or tone quality.	<p>Loose or poor connector contact. (Fuse, relay, horn and/or horn button)</p> <p>Damaged horn.</p>	<p>Repair.</p> <p>Replace.</p>

## Body Electrical System

### WINDSHIELD WIPER AND WASHER

Condition	Probable cause	Corrective action
Windshield wiper motor does not operate.	Burnt fuse. Damaged motor. (Check wiper motor as outlined in Inspection.) Loose connection. Faulty wiper and washer switch. (Test continuity through switch as outlined in Inspection.) Open power circuit or ground circuit.	Correct cause and replace fuse. Replace wiper motor.  Repair. Replace.  Repair.
Wiper operating speed is too slow.	Damaged motor. Loose or poor connection. Seized or rusted wiper linkage. (Humming occurs on motor in wiper blade operating cycle.) Wiper blades stick on windshield glass. (Raise arm and operate wiper without load.)	Replace motor. Repair. Lubricate or replace.  Clean windshield glass and/or replace wiper blade.
Wiper speed cannot be changed correctly.	Faulty wiper switch. Damaged motor.	Replace. Replace.
Wiper motor continues to run after switch is turned off or wiper blades do not return to correct position.	Faulty auto-stop operation.  Poor connection. Faulty switch.	Remove auto-stop device cover, and check relay contacts. Clean dirty contacts or repair relay plate bending if necessary.  Repair. Replace.

## Body Electrical System

### RADIO

#### Noise prevention


Position vehicle in an open area away from steel buildings, run engine, extend antenna to its maximum length, set volume control to maximum and set dial at a medium point without catching broadcasting wave.

Condition	Probable cause	Corrective action
<b>Ignition system</b> Noise occurs when engine is operated.	High tension wire.  Ignition coil.  Distributor.	Install new high tension wire.  Install a 0.5 $\mu$ F capacitor to primary side + terminal of ignition coil. <b>Note: Be careful not to install capacitor to secondary or primary breaker side, otherwise engine becomes improper.</b>  Install bond strap.  Secure contact of carbon electric pole and rotor. Eliminate sharp tip on rotor pole or cap pole by scrubbing with a screwdriver. Check stagger between rotor and stator.
<b>Charging system.</b> Sound of alternating current presents.	Alternator.	Install a 0.5 $\mu$ F capacitor to charging terminal A. <b>Note: Do not use a larger capacitor.</b> <b>If capacitor is installed to terminal F, alternator coil will be damaged.</b>
When accelerator pedal is depressed or released, noise presents.	Regulator.	Install a 0.5 $\mu$ F capacitor to "IGN" terminal of voltage regulator.
<b>Supplement equipment</b> When engine starts, noise presents. Noise still presents even after stopping engine.	Operative noise of water temperature and fuel gauges.	Install 0.1 $\mu$ F capacitor between terminal and ground wire. <b>Note: If a capacitor having a larger capacity is used, indication of gauge will be deviated.</b>

#### Notes:

- a. Be sure to locate capacitor as close as to noise source and connect in parallel.
- b. Cut lead wire as short as possible.
- c. Ground wire should be attached on the body completely.
- d. Make installation and connection securely.
- e. Carefully identify "+," "-", "IN" or "OUT" mark.

# Body Electrical System




BE690B

Fig. BE-57 Engine compartment








- 1 Kickdown solenoid (A/T)
- 2 Clip
- 3 Inhibitor switch (A/T)
- 4 Clip
- 5 Engine
- 6 Battery cable (-)
- 7 Engine slinger
- 8 Battery cable (+)

BE692B


Fig. BE-59 Engine harness No. 2



## COLOR CODE


B : Black  
 Br : Brown  
 G : Green  
 L : Blue  
 Lg : Light green  
 R : Red  
 W : White  
 Y : Yellow  
 BW : Black with white stripe  
 LgR : Light green with red stripe

- 1 To kickdown solenoid  
(for Automatic Transmission)
- 2 To reverse switch  
(for Manual Transmission)
- 3 To inhibitor switch  
(for Automatic Transmission)
- 4 To oil pressure switch
- 5 To starter motor
- 6 To engine room harness  
(for Manual Transmission)
- 7 To engine room harness  
(for Automatic Transmission)



- |    |   |    |  |
|----|---|----|--|
| 1  | To room lamp cable  | 19 | To wiper switch & light switch illumination lamp   |
| 2  | To light switch   | 20 | To wiper switch  |
| 3  | To fuse   | 21 | To cigar lighter   |
| 4  | To tachometer or clock  | 22 | To heater control illumination lamp  |
| 5  | To hazard flasher unit  | 23 | To radio   |
| 6  | To stop lamp switch   | 24 | To heater control  |
| 7  | To ignition switch  | 25 | To belt and E.G.R. warning lamp (Non-California models) or floor temperature (California models) |
| 8  | To hazard switch  | 26 | To heater control illumination lamp  |
| 9  | To turn and dimmer switch   | 27 | To buzzer  |
| 10 | To check connector  | 28 | To belt warning timer (U.S.A. models)  |
| 11 | To AMP, (M/T only)  | 29 | To indicator lamp (A/T only)   |
| 12 | To combination instrument (Non-California models except for Canada) | 30 | To cooler harness  |
| 13 | To combination meter  | 31 | To wiper motor   |
| 14 | To flasher unit   | 32 | To door switch R.H.  |
| 15 | To kickdown switch (A/T only)                                       | 33 | To engine compartment harness  |
| 16 | To hand brake switch  | 34 | To floor harness   |
| 17 | To heater motor   |    |  |
| 18 | To illumination control rheostat                                    |    |  |


# Body Electrical System



BE695B

Fig. BE-62 Instrument

# Body Electrical System



BE696B

Fig. BE-63 Body

## EMISSION WARNING SYSTEM (California models)

### CONTENTS

FLOOR TEMPERATURE WARNING SYSTEM (California models) .....	BE-43	WARNING LAMP .....	BE-43
DESCRIPTION .....	BE-43	TROUBLE SHOOTING GUIDE .....	BE-44

### FLOOR TEMPERATURE WARNING SYSTEM (California models) DESCRIPTION

The floor temperature warning system consists of a floor temperature sensing switch installed on the vehicle floor, a floor temperature relay, a floor temperature warning lamp and harnesses.

When the floor temperature rises to an abnormal level, the warning lamp will come on to call the attention of the driver.

The warning lamp also comes on during operation of the starter motor, permitting inspection of the lamp's condition. The lamp goes out after the engine starts.

Refer to Section EC for details.

### WARNING LAMP

#### Bulb replacement


1. Remove cluster lid.
2. Twist warning lamp socket. Socket with bulb can then be taken out.
3. Pick up bulb from socket.

4. Installation is in the reverse sequence of removal.

Bulb wattage:  
Floor temperature warning lamp:  
1.7W

#### Lamp body replacement

1. Remove cluster lid.
2. Disconnect lead wire at connector.
3. Remove two screws retaining lamp body.
4. Installation is in the reverse sequence of removal.



BE697B

Fig. BE-64 Circuit diagram of floor temperature warning system

## Body Electrical System

### TROUBLE SHOOTING GUIDE

Condition	Probable cause	Corrective action
Warning lamp does not light in "START" position of ignition switch.	Burnt or loose bulb. Faulty floor temperature relay.  Loose connection or open circuit.	Replace bulb or correct bulb socket. Conduct continuity test and repair or replace. Refer to Section EC. Check wiring and/or repair if necessary.

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

## SECTION AC

# AIR CONDITIONING

DESCRIPTION .....	AC- 2
TROUBLE DIAGNOSES AND CORRECTION .....	AC-19
REMOVAL AND INSTALLATION .....	AC-25
COMPRESSOR .....	AC-33
SPECIAL SERVICE TOOLS .....	AC-39

AC



## DESCRIPTION

### CONTENTS

OUTLINE OF AIR CONDITIONER .....	AC-2	DESCRIPTION .....	AC-5
REFRIGERATION SYSTEM .....	AC-3	MAIN RELAY .....	AC-7
CONDENSER .....	AC-3	FAN SWITCH .....	AC-7
COMPRESSOR .....	AC-3	THERMO SWITCH .....	AC-7
RECEIVER DRYER .....	AC-4	PRESSURE SWITCH .....	AC-7
COOLING UNIT .....	AC-4	COMPRESSOR RELAY .....	AC-7
ELECTRICAL CIRCUIT .....	AC-5	F.I.C.D. SOLENOID VALVE .....	AC-7

## OUTLINE OF AIR CONDITIONER

The air conditioner consists essentially of a cooling unit, compressor, condenser, receiver dryer and piping.

The cooling unit, secured with three brackets, is attached to the location occupied by the package tray in the dash panel.

The cooled air from the duct is directed into the passenger compart-

ment through the three outlets at the instrument panel.


The compressor serves to compress the vaporized refrigerant and is attached, through the bracket, to the location occupied by the mechanical fuel pump on the engine.

The condenser cools the compressed refrigerant vapor sent by the compressor and is located on the front of

the radiator in the engine compartment.

The receiver dryer, serving as a reservoir for storage of the liquid sent by the condenser, is located on the right in the engine compartment.

The piping consists of two flexible hoses and five copper tubes which connect various components of the air conditioning system.



- |                   |                   |
|-------------------|-------------------|
| 1 Cooling unit    | 5 Condenser       |
| 2 Expansion valve | 6 Duct            |
| 3 Receiver dryer  | (A) Flexible hose |
| 4 Compressor      | (B) Copper tube   |

AC724

Fig. AC-1 Cooling system

## REFRIGERATION SYSTEM


If you were to paint your finger with alcohol, your finger would feel cold. This is because the liquid alcohol takes heat away from your finger while it evaporates. If a quickly evaporating liquid such as alcohol is placed in a container inside a box, the tem-

perature inside the box will drop. This is because the alcohol is evaporated absorbing the heat from the air inside the box. If the gaseous alcohol is collected and cooled with cold water, it will be changed back into a liquid by absorption of its heat by the cold water.

The cooler operates on this princi-

ple. The liquid used is the refrigerant R-12. The heat inside the passenger compartment is absorbed by changing the refrigerant from a liquid to a gas and then dissipated to the outside by changing the refrigerant from a gas back to a liquid.

The refrigeration system is shown in Figure AC-2




AC458

Fig. AC-2 Refrigeration cycle

## CONDENSER

The condenser is installed to the front of the radiator. The heated and compressed refrigerant gas from the

compressor condenses to a liquid by being cooled by air passing between the fins of the condenser.




AC459

Fig. AC-3 Condenser

## COMPRESSOR

The compressor is installed to the side of the engine and is driven by crank pulley through a belt. The refrigerant gas leaving the evaporator is forced out to the condenser by compressor and the low pressure refrigerant gas is compressed to a high pressure and high temperature.

The driving force is transmitted by an electrical clutch. Because engine rpm is very low during idling, the clutch will not transmit the driving force, thus ensuring smooth engine idling.



AC728


Fig. AC-4 Compressor

## RECEIVER DRYER

The receiver dryer serves the purpose of storing the liquid refrigerant. The amount of the liquid refrigerant flowing through the system varies with the operating condition of the air conditioner. To be accurate, the receiver dryer stores excess amount of refrigerant when the heat load is lowered. It also releases stored refrigerant when additional cooling is needed, thus maintaining the optimum flow of refrigerant within the system.

The receiver dryer includes a strainer and desiccant. They have the job of removing moisture and foreign particles as the refrigerant circulates within the system.

The pressure switch is installed beside sight glass of receiver dryer. The purpose of the switch is to stop the compressor operation in the event an excessive system pressure builds up on the high pressure lines.



- 1 Pressure switch
- 2 Sight glass
- 3 Strainer
- 4 Desiccant

AC230

Fig. AC-5 Receiver dryer

## COOLING UNIT

The cooling unit includes an evaporator and an expansion valve. From the electrical point of view, the cooling unit consists of a blower motor, a resistor for fan speed control and some switches and relays.

The liquid refrigerant evaporates in the evaporator with the aid of the expansion valve. Consequently the air drawn by the blower motor is cooled in passing through the evaporator.

The expansion valve restricts the liquid refrigerant as it passes through it and delivers sprayed refrigerant to the evaporator for facilitating refrigerant evaporation.

## Air Conditioning

The refrigerant within the thermo bulb changes in pressure through the super heat condition of vaporized refrigerant gas which comes out of the evaporator, causing the deflection of the diaphragm. The lift of the ball valve attached to the diaphragm is changed by the deflection of the diaphragm, thus controlling the amount of refrigerant passing the orifice.




Fig. AC-6 Expansion valve




Fig. AC-7 Cooling unit

## ELECTRICAL CIRCUIT

### DESCRIPTION


The electrical circuit of the air conditioner consists of four switches, two relays, a solenoid valve, a fan motor and a compressor magnetic clutch.

The following wiring diagram provides a complete description of the whole circuit.

When the ignition switch and the fan switch are ON, the main relay is activated, causing battery power to flow through the fan motor and the magnetic clutch. The magnetic clutch is activated by the thermo switch,

pressure switch and compressor relay. The blower motor fan speed is controlled by the fan switch and resistor. The solenoid valve is also activated. This in turn causes the fast idle control device (F.I.C.D.) to increase engine speed when the vehicle is at rest with the engine ON.

# Air Conditioning




AC727  
Fig. AC-8 Wiring diagram of air conditioner system

## MAIN RELAY

The main relay is located on the cooling unit.

When the ignition switch and fan switch are both turned on, the con-

tacts in the relay are closed. Then electrical power from the battery is supplied to the blower motor and the electrical clutch for the compressor.



AC465

Fig. AC-9 Main relay

## FAN SWITCH

The fan switch, serving as a control unit, is installed on the center console. This switch controls the blower motor speed through the resistor. It is also used as a main relay switch.




Fig. AC-10 Fan switch

## THERMO SWITCH

The thermo switch is located on the upper side of the cooling unit and is controlled by the cable and the control lever attached to the console box.

It is so designed that when the air passing through the evaporator core is cooled down to the predetermined

temperature (set by the control lever), it automatically turns off. When the switch is turned off, the magnetic clutch is turned off, stopping the flow of refrigerant inside the cooling system and increasing the cooling system temperature.

When the air rises to the predetermined temperature, the thermo switch automatically turns on. In this way, the temperature of the air discharged from the cooling unit is automatically controlled as desired.

## PRESSURE SWITCH

The pressure switch is turned off when refrigerant pressure in the cooling system rises to an abnormally high level [ $28 \text{ kg/cm}^2$  (398 psi)]. This in turn turns off the compressor magnetic clutch, actuating the compressor relay and gradually decreasing pressure in the cooling system. When the pressure drops to or below  $24 \text{ kg/cm}^2$  (341 psi), the pressure switch again turns on.

Thus, cooling system refrigerant pressure is automatically maintained at the proper value at all times.

## COMPRESSOR RELAY

The compressor relay is attached to the receiver dryer bracket on the right side of the engine compartment. This relay is actuated by the fan switch, thermo switch and pressure switch to turn on and off the compressor magnetic clutch.




Fig. AC-11 Pressure switch and compressor relay

## F.I.C.D. SOLENOID VALVE

The F.I.C.D. solenoid valve is attached to the dash panel in the engine compartment. This valve supplies vacuum to the F.I.C.D. diaphragm through the vacuum hose connected to the engine intake manifold when the engine is at idle and the cooling system is ON, thereby raising idle speed to the predetermined rpm (800).




Fig. AC-12 F.I.C.D. solenoid valve

## GENERAL SERVICE

### CONTENTS

REFRIGERANT R-12 ..... AC- 8 COMPRESSOR OIL ..... AC- 8 MAINTENANCE ..... AC- 8 PERIODIC MAINTENANCE AND SEASON-IN INSPECTION ..... AC- 8 GENERAL SERVICE INSTRUCTION ..... AC- 8 SAFETY PRECAUTIONS ..... AC- 9 EVACUATING AND CHARGING SYSTEM ..... AC- 9 HANDLING MANIFOLD GAUGE ..... AC- 9 HANDLING SERVICE VALVE ..... AC-10 HANDLING CAN TAP ..... AC-11 DISCHARGING SYSTEM ..... AC-12	EVACUATING SYSTEM ..... AC-12 CHARGING REFRIGERANT ..... AC-13 CHECKING FOR LEAKS ..... AC-15 HALIDE LEAK DETECTOR ..... AC-15 ELECTRIC LEAK DETECTOR ..... AC-16 REFRIGERANT LEVEL CHECK ..... AC-16 SIGHT GLASS ..... AC-16 PERFORMANCE TEST ..... AC-17 COMPRESSOR OIL LEVEL CHECK ..... AC-17 PERFORMANCE TEST ..... AC-17 REFRIGERANT LEAKS ..... AC-18
---	--

### REFRIGERANT R-12

The refrigerant used in the air conditioner is generally called "Refrigerant-12 (R-12)". No other refrigerant than the above refrigerant should be used.

This refrigerant is usually available in a small can or a cylinder. In either case, it is liquefied under high pressure in the container.

Refrigerant evaporates easily (has a low evaporation point) and, moreover, since the latent heat of the refrigerant is large, it can absorb a large amount of heat when evaporating. Extreme care must be exercised when handling the refrigerant.

### COMPRESSOR OIL

The "SUNISO 5GS" or "SUNISO 351" should be used as refrigeration lubricant.

Mixing of the two is allowable.

The refrigeration lubricant should be used to assure the successful compressor operation. Use of oils other than recommended or mixing of the oil with other oils would cause chemical reaction or lead to lowered viscosity or deficient lubrication.

The oil absorbs moisture as it contacts the air. This points out the need for care not to expose it to atmosphere for an extended period of time.

### MAINTENANCE

#### PERIODIC MAINTENANCE AND SEASON-IN INSPECTION

Both periodic maintenance and season-in inspection are most essential to enable the air conditioner to give full performance.

Perform the following checks.

1. Start engine and check refrigerant level through sight glass on receiver dryer. For details, refer to relative topics under "Refrigerant Level Check".
2. Check the entire system for sign of refrigerant leaks. Refer to relative topics under "Checking for Leaks" and "Refrigerant Leaks".

If any trace of oil is noted at and around connection fittings, it is a sure indication that refrigerant is leaking. This condition can be corrected easily by retightening the joints. If any joint on line is suspected of small amount of leakage, use a leak detector to locate leaking points.

3. Check compressor drive belts for proper deflection.

#### Season-off

Observe the following maintenance tips to allow the air conditioner to operate normally in the next season.

1. Keep the entire system free from

refrigerant leakage by periodically checking for refrigerant gas leak even out of season.

2. Turn the compressor for 10 minutes at least once a month by running the engine at 1,500 rpm.

### GENERAL SERVICE INSTRUCTION

The servicing of the air conditioner should be carried out only by well-trained servicemen. This chapter describes essential points of servicing.

- If a large amount of dirt and sand enter the system, they will be carried with refrigerant and may clog the system or scratch rotating parts. This points out the need for care in servicing the system. That is, disconnecting joints should be carried out in a clean place.
- Water should not be allowed to get inside the system. The refrigerant does not readily mix with water. However, the presence of even a minute amount of water will cause a chemical reaction at high temperature which will in turn produce hydrochloric acid (HCl). Since hydrochloric acid is highly corrosive to metals, the aluminum and copper piping, etc. will become corroded and the refrigeration system will become clogged.

- Water in the system will ice the orifice when the high pressure refrigerant is changed to low pressure refrigerant by expansion valve, etc., and will obstruct the refrigerant flow.

The following items are general instructions to be closely observed in servicing the system.

1. When a system line is disconnected, plug the opening immediately. This is especially necessary to prevent moisture condensation from forming in the line and to keep out dirt and dust. It is also necessary to keep the line at and above surrounding air temperatures at all times. When connecting system lines, do not attempt to remove the plug from the opening until ready for immediate use.
2. Always keep the working place clean and dry and free from dirt and dust. Wipe water off with a clean cloth.
3. Have all necessary tools in preparation beforehand and have tools clean and dry.
4. The compressor oil will easily absorb moisture when exposed to air. Immediately close the opening of the container after use. It is also necessary to observe the following notes:

### Notes:

- a. The oil should not be transfused from a container into another, as the failure will possibly cause moisture to mix with the oil.
  - b. The used oil should not be returned into a container.
  - c. The oil should not be used if its state of preservation is not clear enough.
5. When connecting or disconnecting pipes from the refrigeration system, use two wrenches. One wrench is used for holding the fixing nut in place while the other for turning the mating flare nut. Failure to do so may result in a twisted tube or may damage connection.
  6. Also use care not to give scratches to the seating surface at connections. A small scratch on the seating surface

may be the cause of gas leakage. Before connecting pipes, be sure to give coating of compressor oil to the seating surfaces.

## SAFETY PRECAUTIONS

1. Since direct contact of the liquid refrigerant with your skin will cause frostbite, always be careful when handling the refrigerant. **Wear gloves or wrap a piece of cloth around service valve to protect your fingers against frostbite by refrigerant.** If any of the refrigerant should get into your eyes when charging the refrigerant, splash your eyes with cool water to raise the temperature gradually. Apply a protective film to the eye to avoid infection. Do not rub your eyes. Consult an eye specialist. **Always wear goggles or glasses to protect your eyes when working around the system. Should refrigerant strikes your body, splash on cool water and apply a protective film.**
2. The refrigerant service container has a safe strength. However, if handled incorrectly, it will explode. Therefore, **always follow the instructions on the label. In particular, never store it in a hot location [above 52°C (125°F)] or drop it from a high height.**
3. The refrigerant gas is odorless and colorless and breathing may become difficult due to the lack of oxygen. Since the refrigerant gas is heavier than air and will lay close to the floor, be especially careful when handling it in small, confined spaces.
4. The refrigerant itself is nonflammable. However, a toxic gas (phosgene gas) is produced when it contacts fire and special care is therefore required when checking for leaks in the system with a halide torch.
5. Do not steam clean on the system, especially condenser since excessively high pressure will build up in the system, resulting in explosion of the system.

The above precautions are essential in handling of Refrigerant-12, and their strict observation requires suffi-

cient training. Therefore, it is of first importance that any other personnel than a well-trained serviceman should not be allowed to handle the refrigerant.

## EVACUATING AND CHARGING SYSTEM

During servicing, use caution to keep air from getting into refrigerant. When air enters the system, all refrigerant must be evacuated from system prior to charging new refrigerant. Air in refrigerant has the following deleterious effects:

1. Since the condensation temperature of the air is extremely low, the air will not be condensed when refrigerant gas is condensed in the condenser, and the air will thus remain in gaseous form. Consequently, the effective thermal transmission area of condenser for refrigerant gas will be reduced and refrigerant gas to be condensed will be reduced. The pressure rise will become proportional to the volume of the air in system.
2. When air and refrigerant are mixed in system, a chemical reaction will be produced and hydrochloric acid which will adversely affect the aluminum, copper, iron, and other materials in system may be generated.

## HANDLING MANIFOLD GAUGE

The pressure at the high- and low-sides of system should be measured when evacuating and charging refrigerant and when diagnosing trouble in the system. The manifold gauge is used for these purposes. A manifold gauge has two pressure gauges; a low pressure gauge and a high pressure gauge. These gauges are connected to the high- and low-side service valves of system through flexible charging hoses. The construction of manifold gauge is shown in Figure AC-13.

When valve stem is fully screwed, the valve is front-seated and valve path and the center path are blocked. When valve stem is backed off, the paths are opened.






Fig. AC-13 Manifold gauge

## Connection to service valve

1. Fully close both valves of manifold gauge. Connect high- and low-pressure charging hoses to manifold gauge.
2. Remove caps from service valves. Connect high- and low-pressure charging hoses to service valves in system. The refrigerant gas will be discharged since check valve is open when pressing charging hose onto service valve.
3. Next, loosen the connection fitting of charging hose at manifold gauge side for 2 to 3 seconds to purge any air inside charging hose by the pressurized gas in system.

## Disconnection from service valve

1. Fully close both valves of manifold gauge.
2. Disconnect two charging hoses from service valves. At this time, the gas will be discharged until check valve is closed. Therefore, disconnect hose quickly.

**Caution:** Work with fingers protected with cloth against frostbite by refrigerant.

## HANDLING SERVICE VALVE

An automatic check valve is built into service valve. When this valve presses against the connection fitting, that is, when charging hose is connected to service valve, the valve is open. When charging hose is disconnected, the valve is closed automatically. Always observe the following usage precautions:

1. Always install valve cap after using service valve.

When high speed operation is performed without valve cap, a negative pressure will gradually build up at the low pressure side of system and air may be sucked in. In addition, dirt and dust will easily enter the valve resulting in foreign matter entering the system.

2. Check valve will be half opened during connection and disconnection of charging hoses and refrigerant will be forcefully discharged. Therefore, connect and disconnect charging hoses quickly while pressing flare nut of charging hose against service valve.

**Caution:** Work with fingers protected with cloth against frostbite by refrigerant.

3. Since close contact between the thread of valve cap and the thread of service valve will prevent gas leakage, keep these sections clean and free of scratches and damage.

4. Since packing of charging hose will be lost during long use, always check packing prior to installing charging hose.





Fig. AC-14 Service valve



AC734

Fig. AC-15 Service valve

## HANDLING CAN TAP

A wide variety of can taps are available. The following procedures apply to conventional can taps.

For the correct usage, refer to the manufacturer's instructions.

**Caution:** Use can tap of good quality.

1. Connect charging hose to the center fitting of manifold gauge. At this time, confirm that both stems are fully turned in (front-seated).
2. Turn can tap handle fully coun-


terclockwise so that the needle is pulled up.

3. Attach can tap to refrigerant can firmly.


4. Turn can tap handle fully clockwise to make a hole in refrigerant can.

5. Turn the handle fully counterclockwise to raise the needle. Refrigerant gas will flow up to the center fitting of manifold gauge.

6. Loosen the connection at the center fitting of manifold gauge for a few seconds to purge air inside charging hose. See Figure AC-16.




(Clockwise)



(Counterclockwise)

- 1 Can tap handle
- 2 Charging hose
- 3 Needle
- 4 Refrigerant can

AC246



Purging air

AC247


Fig. AC-16 Can tap and purging air

## DISCHARGING SYSTEM

The pressurized refrigerant gas inside system must be discharged to a pressure approaching atmospheric pressure prior to evacuating refrigerant inside system. This operation should be made to permit safe removal when replacing system components.

1. Close high- and low-pressure valves of manifold gauge fully.
2. Connect two charging hoses of manifold gauge to their respective service valves.
3. Open both manifold gauge valves slightly and slowly discharge refrigerant from system. See Figure AC-17.

**Note:** Do not allow refrigerant to rush out. Otherwise, compressor oil will be discharged along with refrigerant.



AC735

Fig. AC-17 Discharging system

## EVACUATING SYSTEM

1. Connect high- and low-pressure charging hoses of manifold gauge to their respective service valves of system and discharge refrigerant from system. Refer to "Discharge System".
2. When refrigerant has been discharged to a pressure approaching atmospheric pressure, connect center charging hose to a vacuum pump.
3. Close both valves of manifold gauge fully. Then start vacuum pump.
4. Open low-pressure valve and suck old refrigerant from system. See Figure AC-18.
5. When low-pressure gauge reading has reached to approximately 500 mm Hg (20 in Hg), slowly open high-pressure valve. See Figure AC-19.
6. When pressure inside system has dropped to 710 mm Hg (28 in Hg), fully close both of valves of manifold gauge and stop vacuum pump. Let stand it for 5 to 10 minutes in this state and confirm that the reading does not rise.

### Notes:

- a. The low-pressure gauge reads lower by 25 mm Hg (1 in Hg) per a 300 m (1,000 ft) elevation. Perform evacuation according to the following table.

Elevation m (ft)	Vacuum of system mm Hg (in Hg)
0 (0)	710 (28)
300 (1,000)	685 (27)
600 (2,000)	660 (26)
900 (3,000)	635 (25)


**Note:** Values show readings of the low-pressure gauge.

- b. The rate of ascension of the low-pressure gauge should be less than 25 mm Hg (1 in Hg) in five minutes.

If the pressure rises or the specified negative pressure can not be obtained, there is a leak in the system. In this case, immediately charge system with refrigerant and repair the leak described in the following.


- (1) Confirm that both valves of manifold gauge are fully closed and then disconnect center charging hose from vacuum pump.
- (2) Connect center hose to can tap in place of vacuum pump. Attach refrigerant can to can tap and pass refrigerant to manifold gauge.
- (3) Loosen the connection of center fitting of manifold gauge to purge air from center hose.
- (4) Open low-pressure valve of manifold gauge and charge refrigerant into system. After one can [about 0.4 kg (1 lb)] of refrigerant has been charged into system, close low-pressure valve.
- (5) Check for refrigerant leakage with a leak detector. Repair any leakages found. Refer to "Checking for Leaks" and "Refrigerant Leaks".
- (6) Confirm that both valves of manifold gauge are fully closed and then change center charging hose from can tap to vacuum pump.
- (7) Open high- and low-pressure valves and operate vacuum pump to suck refrigerant from system. When the pressure in system has dropped to 710 mm Hg (28 in Hg), fully close both valves of manifold gauge.
7. The above operation completes evacuation of system. Next, charge refrigerant. Refer to "Charging Refrigerant".

**Caution:** Protect fingers with cloth against frostbite by refrigerant when connecting the charging hose to the service valve or disconnecting it therefrom.



AC736

Fig. AC-18 Evacuating system - First step



AC737

Fig. AC-19 Evacuating system - Second step

## CHARGING REFRIGERANT

1. Install manifold gauge to system.  
Refer to "Handling Manifold Gauge".


### Notes:

- a. Be sure to purge air from the high- and low-pressure charging hoses.
- b. If air is mixed with refrigerant gas in system, evacuation of system should be performed. Refer to "Evacuating System".

2. Attach center charging hose of manifold gauge to refrigerant can through can tap. Break seal of refrigerant can to allow refrigerant to enter manifold gauge. Loosen charging hose at the center fitting of manifold gauge and purge air from inside charging hose. Refer to "Handling Can Tap".
3. Open high- and low-pressure valves of manifold gauge and charge refrigerant into system. See Figure AC-20.

### Notes:

- a. When refrigerant charging speed is




AC738

Fig. AC-20 Charging refrigerant

slow, immerse refrigerant can in water heated to a temperature of about 40°C (104°F). However, note that this is dangerous when water is hot. See Figure AC-21.

### Cautions:

- a. Under any circumstances the refrigerant can must not be warmed in water heated to a temperature of over 52°C (125°F).
- b. A blow torch or stove must never be used to warm up the can.




AC252

Fig. AC-21 Heating refrigerant

## Air Conditioning

b. When charging liquefied refrigerant into the system with the can turned upside down to reduce charging time, charge it only through high pressure valve, but not through

low-pressure valve. After completion of charging, the compressor should always be turned several times manually. See Figure AC-22.



AC739

Fig. AC-22 Charging refrigerant - First step

4. If refrigerant charging speed slows down, charge it while running the compressor for ease of charging. After having taken the steps up to (3) above, proceed with charging in the following order.

(1) Shut off high pressure valve of manifold gauge.


**Caution:** Never charge refrigerant through high pressure side of system since this will force refrigerant

back into refrigerant can and can may explode.

(2) Run the engine at idling speeds about 1,500 rpm.

(3) Set the temperature control lever and fan switch at maximum cool and maximum speed respectively.

(4) Charge refrigerant while controlling low-pressure gauge reading at 2.8 kg/cm<sup>2</sup> (40 psi) or less by turning in or out low-pressure valve of manifold gauge. See Figure AC-23.




AC740

Fig. AC-23 Charging refrigerant - Second step

5. When refrigerant can is empty, fully close both valves of manifold gauge and replace refrigerant can with a new one.

Before opening manifold gauge valve to charge refrigerant from new can, be sure to purge air from inside charging hose.

6. Charge the specified amount of refrigerant into system by weighing charged refrigerant with scale. Overcharging will cause discharge pressure to rise.



AC255

Measure the amount of charged refrigerant with a scale. Make a note of the amount charged from can.

Fig. AC-24 Measuring refrigerant

Refrigerant capacity

Unit: kg (lb)

Refrigerant	Minimum	Maximum
R-12	0.7 (1.5)	0.9 (2.0)

**Note:** The presence of bubbles in sight glass of receiver dryer is an unsuitable method of checking the amount of refrigerant charged in system. The state of the bubbles in sight glass should only be used for checking whether the amount of charged refrigerant is small or not. The amount of charged refrigerant can be correctly judged by means of discharge pressure. Refer to "Refrigerant Level Check".

7. After the specified amount of refrigerant has been charged into system, close manifold gauge valves. Then detach charging hoses from service valves of system. Be sure to install valve cap to service valve.

8. Confirm that there are no leaks in system by checking with a leak detector.

Refer to "Checking for Leaks".

**Note:** Conducting a performance test prior to removing manifold gauge is a good service operation. Refer to "Performance Test".

## CHECKING FOR LEAKS

Conduct a leak test whenever leakage of refrigerant is suspected and when conducting service operations which are accompanied by disassembly or loosening of connection fittings.




Fig. AC-25 Checking for leaks

Refrigerant is a colorless, odorless gas and leakage from system is difficult to detect. Accordingly, the use of a leak detector facilitates check for leaks. Two methods of checking are available; one employs a halide leak detector which burns propane gas or butane gas and the other is an electric type leak detector.

## HALIDE LEAK DETECTOR

Since the propane leak detector and butane leak detector are the same in respect to their operation, this section describes the operation of the propane leak detector.

The copper screen is heated by the burning of propane. Refrigerant gas decomposes to color the flame when it contacts the heated screen. The gas to be checked is drawn into the sampling tube and sent out to the burner. A refrigerant leak can clearly be detected by variations in the color of the flame.

1. Discharge refrigerant in one or two seconds to ascertain that system has a sufficient pressure needed for leak detection. Charge with 0.4 kg (1 lb) of refrigerant, if necessary.

2. Light leak detector. Adjust the height of the flame between flame adjusting lines at the top and bottom of combustion tube. A reaction plate will immediately become red hot.

3. Place the end of sampling tube near the point of the suspected leak in system.

### Notes:

- a. Since refrigerant gas is heavier than air, small leaks can be easily detected by placing sampling tube directly below the check point.
- b. Suitable ventilation is required. If refrigerant gas is mixed with the surrounding air, leak detector will always indicate a response and detection of the actual leak will be difficult.
- c. Never hold leak detector at an angle.

### Cautions:

- a. Never inhale the fumes produced by combustion of refrigerant gas since they are toxic.
- b. Never use halide torch in a place where combustible or explosive gas is present.

4. The flame will be almost colorless when there is no refrigerant gas being burned. When there is a small refrigerant gas leak, the flame will be green or yellowgreen. When refrigerant gas leakage is large, the flame will be brilliant blue or purple. Since the color of the flame will be yellow when dust is being burned or there is aging scale on copper reaction plate, always keep the strainer of sampling tube and reaction plate clean.

### 5. Major check points

- (1) Compressor
  - Compressor shaft seal (rotate the compressor by hand)
  - Oil filler plug
  - Flexible hose connections
  - Rear cover and side cover gaskets.
  - Service valve
- (2) Condenser
  - Condenser pipe fitting
  - Condenser inlet and outlet pipe connections

	Propane type	Butane type
NO LEAK	Greenish blue	Pale blue
SMALL LEAK	Yellow	Bright blue
LARGE LEAK	Purple	Vivid green

## (3) Piping

- Flared section of high pressure and low pressure flexible hose.
- Pipe connections
- Service valve
- (4) Evaporator housing
- Inlet and outlet pipe connections
- Expansion valve

## ELECTRIC LEAK DETECTOR

For the operational procedures, refer to the instructions furnished with each electric leak detector.

## REFRIGERANT LEVEL CHECK

### SIGHT GLASS

Sight glass is provided at the top of receiver dryer. One guide for whether there is enough refrigerant in system is given by observing refrigerant flow through sight glass. However, this method is unsuitable for judging the amount of refrigerant. The correct refrigerant level can be judged by measuring the system pressures in accordance with the procedures as described "Performance Test".

1. Start the engine and hold engine speed at 1,500 rpm.

2. Set temperature control lever to maximum position.
3. Set blower to maximum speed.
4. Check sight glass after the lapse of about five minutes. Judge according to the following table.







Fig. AC-26 Temperature control lever

Check item	Amount of refrigerant			
	Almost no refrigerant	Insufficient	Suitable	Too much refrigerant
Temperature of high pressure and low pressure pipes.	Almost no difference between high pressure and low pressure side temperature.	High pressure side is warm and low pressure side is fairly cold.	High pressure side is hot and low pressure side is cold.	High pressure side is abnormally hot.
State in sight glass.	Bubbles flow continuously. Bubbles will disappear and something like mist will flow when refrigerant is nearly gone.  AC256	The bubbles are seen at intervals of 1 - 2 seconds.  AC257	Almost transparent. Bubbles may appear when engine speed is raised and lowered. No clear difference exists between these two conditions.  AC258	No bubbles can be seen.
Pressure of system.	High pressure side is abnormally low.	Both pressures on high and low pressure sides are slightly low.	Both pressures on high and low pressure sides are normal.	Both pressures on high and low pressure sides are abnormally high.
Repair.	Stop compressor and conduct an overall check.	Check for gas leakage, repair as required, replenish and charge system.		Discharge refrigerant from service valve of low pressure side.

**Notes:**

- a. The bubbles seen through the sight glass are influenced by the ambient temperature. Since the bubbles are hard to show up in comparatively low temperatures below 20°C (68°F), it is possible that a slightly larger amount of refrigerant would be filled, if supplied according to the sight glass. Be sure to recheck the amount when it exceeds 20°C (68°F). In higher temperature the bubbles are easy to show up.
- b. When the screen in the receiver dryer is clogged, the bubbles will appear even if the amount of refrigerant is normal. In this case, the outlet side pipe of the receiver dryer becomes considerably cold.

## PERFORMANCE TEST

Check for the amount of refrigerant in the system can be made by measuring pressure on discharge side.

The correct amount of refrigerant is in the system, if pressure on the discharge side is within the specified range. For details, refer to "Performance Test" described later.

Overcharging will show up in higher pressure on discharge side.

## COMPRESSOR OIL LEVEL CHECK

The oil used to lubricate compressor circulates into system from the oil sump while compressor is operating. Therefore, to correctly measure compressor oil, the amount of oil flowing to system must be considered. If a considerable amount of leakage of refrigerant gas happens, the leakage of compressor oil is also considered. There will be no compressor oil leakage from a completely sealed system. When system operates under satisfying condition, the compressor oil level check is unnecessary.

When checking the level of compressor oil or when replacing any component part of the system, use the following service procedure. This facilitates to return oil to compressor.

1. Operate compressor at engine idling speed (1,000 rpm or below) with controls set for maximum cooling

and high blower speed for 10 to 15 minutes in order to return compressor oil to compressor.

2. Stop the engine and discharge refrigerant of system and then remove compressor from the vehicle.
3. Remove compressor filler plug.

Drain compressor oil from compressor oil sump and measure the amount.

4. Compressor oil is satisfactory if the following amount of oil remains in the compressor.

Residual oil:

85 to 128 gr (3 to 4 ½ oz)

5. Check the cleanliness of the oil. If the oil contains chips or other foreign material, clean oil sump with new oil.
6. Discard the used oil and fill with the same amount of new oil. Add oil if found less than above amount.




Fig. AC-27 Filler plug

If compressor is inoperative due to faulty compressor or heavy loss of refrigerant, remove compressor and repair as necessary. Then pour oil up to correct level and install on engine. After above steps have been completed, recheck oil level; drain oil to correct level if level is excessively high.

## PERFORMANCE TEST

The cooling performance of the air conditioner changes considerably with changes in surrounding conditions. Testing must be performed using the correct method. This test is used to judge whether system is operating correctly and can also be used as a guide in checking for problems.

1. Park the vehicle indoors or in the shade.

2. Open all the windows of the vehicle fully. However, close the doors.

3. Open the hood.

4. Connect manifold gauge to high- and low-side service valves of the system. Refer to "Handling Manifold Gauge".

5. Set fan control lever to maximum.

6. Set temperature control lever to max. cool position.

7. Start the engine and hold engine speed at 1,500 rpm.

8. After the air conditioner has been operated for about 10 minutes, measure system pressures at high-pressure (discharge) side and low-pressure (suction) side.

9. Measure the temperature of discharge air at outlet grille.

10. Measure the temperature of cabin.

11. Measure ambient temperature and humidity one meter (3.3 ft) away from condenser front. Be careful not to expose dry bulb and wet bulb to direct sunlight.

12. Check for any abnormalities by comparing the test results with standard pressure in "Performance Chart".

**Notes:**

- a. The pressure will change in the following manner with changes in conditions:

- When blower speed is low, discharge pressure will drop.
- When the relative humidity of intake air is low, discharge pressure will drop.

- b. The temperature will change in the following manner with changes in conditions:

When the ambient air temperature is low, the outlet air temperature will become low.

If the test reveals that there is any abnormality in system pressure, isolate the cause and repair by reference to the "Trouble Diagnoses and Corrections".



### REFRIGERANT LEAKS

If leaks are noticeable, leaky parts should be repaired. Then system should be filled with refrigerant. **Do not operate compressor with refrigerant level excessively low.**

If this caution is neglected, a burnt compressor will result since heavy loss of refrigerant usually indicates heavy loss of compressor oil.

If system has been exposed to atmosphere for an extended period of

time, receiver dryer must be replaced. If leaks are slight and no air is present in system, add refrigerant as necessary.

To detect leaks, refer to relative topics under "Checking for Leaks". Here is how leaks are stopped.

1. Check torque on the connection fitting and, if too loose, tighten to the proper torque. Check for gas leakage with a leak detector.
2. If leakage continues even after

the fitting has been retightened, discharge refrigerant from system, disconnect the fittings, and check its seating face for damage. Always replace even if damage is slight.

3. Check compressor oil and add oil if required.


4. Charge refrigerant and recheck for gas leaks. If no leaks are found, evacuate and charge system.

# TROUBLE DIAGNOSES AND CORRECTION

## CONTENTS

COOLING DIAGNOSES .....	AC-19	COMPRESSOR DIAGNOSES .....	AC-22
FUNCTION TEST .....	AC-20	NOISE DIAGNOSES .....	AC-23
STANDARD PERFORMANCE .....	AC-20	BLOWER MOTOR DIAGNOSES .....	AC-24
PERFORMANCE TEST DIAGNOSES .....	AC-21		


## COOLING DIAGNOSES



## FUNCTION TEST

### STANDARD PERFORMANCE

The air conditioner on the model 620 has the below performance characteristics when all systems are in good condition. Compressor pressure is also indicated below.




### TEMPERATURE

Intake (In the cabin)	Discharged air	Pressure
16°C (61°F)	3°C (37°F)	12 kg/cm <sup>2</sup> (170 psi)
18°C (64°F)	5°C (41°F)	13 kg/cm <sup>2</sup> (185 psi)
22°C (72°F)	7°C (45°F)	15 kg/cm <sup>2</sup> (213 psi)
27°C (81°F)	10°C (50°F)	18 kg/cm <sup>2</sup> (256 psi)

Note: Engine → 1,500 rpm  
 FAN → "3" position  
 TEMP → Cold (Max.)

ENGINE : 1,500 rpm  
 FAN : MAX.  
 TEMP : Full Cold



### REFRIGERANT PRESSURE

Temperature (outside)	Pressure (discharge)	Pressure (suction)
25°C (77°F)	18 kg/cm <sup>2</sup> (256 psi)	1.0 kg/cm <sup>2</sup> (14 psi)
30°C (86°F)	15 kg/cm <sup>2</sup> (213 psi)	1.2 kg/cm <sup>2</sup> (17 psi)
35°C (95°F)	13 kg/cm <sup>2</sup> (185 psi)	1.4 kg/cm <sup>2</sup> (20 psi)
40°C (105°F)	12 kg/cm <sup>2</sup> (170 psi)	1.6 kg/cm <sup>2</sup> (21 psi)

## PERFORMANCE TEST DIAGNOSES

Condition	Probable cause	Corrective action
<b>Discharge air too warm</b>		
a) Both discharge and suction pressure too high.	Air mixed with refrigerant in system. Overcharge of refrigerant.	Evacuate and charge system.  Discharge some of refrigerant to correct level.
b) Both discharge and suction pressure too low	Loose fan belt or engine overheating. Obstructed or dirty condenser fins.	Adjust fan belt or check cooling system. Clean exterior surface with water.
c) Discharge pressure too high and suction pressure too low.	Insufficient refrigerant charge.	Add refrigerant.
d) Suction pressure too high and discharge pressure too low.	Over-filling of compressor oil.	Drain oil and correct oil level. Refer to "Compressor oil level check."
	Damaged compressor valve or packing.	Repair or replace compressor. Refer to "Compressor".
	Loose compressor drive belt.	Adjust.
	Clutch slippage.	Repair. Refer to "Compressor".
e) Discharge pressure normal and suction pressure too high.	Faulty expansion valve.	Reinstall sensing bulb correctly to keep it tight to pipe. Replace.
f) Discharge pressure normal and suction pressure too low.	Clogged expansion valve strainer. Water has frozen at expansion valve. Faulty expansion valve.	Clean strainer. Evacuate and charge system.  Replace.
g) Suction pressure normal and discharge pressure too high.	Faults of both a ) and h) exist.	
h) Both discharge and suction pressure normal. (Air conditioning is operating properly)	Air leaks from engine compartment.	Correct sealing.
<b>Discharge air normal or too cold</b>		
a) Discharge pressure normal and suction pressure too low.	Restricted air flow through evaporator. Slow blower motor speed.	Clean evaporator fins.  Check and repair blower motor and wiring.

## COMPRESSOR DIAGNOSES

### COMPRESSOR TROUBLE

Turn the compressor clutch wheel by hand.

If OK

Apply 12V direct current to compressor clutch.  
Then, check clutch engagement.

Will not turn

Internal problem in compressor cylinder.  
Repair or replace compressor.

If OK

Clutch does not engage.

Check voltage of lead wire for compressor on  
cooler cable.

Clutch is damaged.  
Repair or replace clutch assembly.


If OK

No voltage


Internal problem in compressor.  
Repair or replace compressor.

Check or repair wiring system for compressor  
clutch.

## NOISE DIAGNOSES



## BLOWER MOTOR DIAGNOSES



# REMOVAL AND INSTALLATION


## CONTENTS

COMPRESSOR .....	AC-25	REMOVAL AND INSTALLATION .....	AC-29
REMOVAL .....	AC-25	INSPECTION .....	AC-29
INSTALLATION .....	AC-26	WIRING HARNESS AND COMPONENTS .....	AC-30
IDLER PULLEY .....	AC-27	WIRING DIAGRAM .....	AC-30
FAN BELT TENSION ADJUSTMENT .....	AC-27	MAINTENANCE .....	AC-31
REMOVAL AND INSTALLATION .....	AC-27	MAIN RELAY .....	AC-31
INSPECTION .....	AC-27	COMPRESSOR RELAY .....	AC-31
COOLING UNIT .....	AC-27	FAN SWITCH .....	AC-31
REMOVAL AND INSTALLATION .....	AC-27	RESISTOR FOR FAN SWITCH .....	AC-32
DISASSEMBLY AND ASSEMBLY .....	AC-28	THERMO SWITCH .....	AC-32
INSPECTION .....	AC-29	F.I.C.D. SOLENOID VALVE .....	AC-32
RECEIVER DRYER AND PIPING .....	AC-29		

## COMPRESSOR

### REMOVAL

1. Remove battery.
2. Disconnect compressor lead wire at connector.
3. Loosen idler pulley lock nut, then adjusting bolt. Remove compressor drive belt from compressor pulley.




AC477  
Fig. AC-28 Removing drive belt

4. Discharge system. Refer to Discharging System under General Service section.

5. Remove flexible hose fixing plate, and disconnect low and high pressure flexible hoses from compressor.


#### Notes:

- a. Use two wrenches when disconnecting pipe joints.
- b. Plug flexible hose and compressor joint openings immediately after disconnection to prevent entry of dust, moisture-laden air, etc.



AC743  
Fig. AC-29 Disconnecting flexible hoses from compressor

6. Remove bolts securing fuel tube to compressor attachment.




AC744  
Fig. AC-30 Removing fuel tube fixing bolts

7. Remove four bolts securing compressor to its bracket. Compressor and attachment can now be detached as an assembly.

#### Notes:

- a. There are a total of four bolts, two on upper side of bracket and two on lower side of compressor. Loosen upper bolts and remove lower bolts. When removing upper bolts, securely hold compressor with one hand.
- b. When installing, temporarily tighten upper bolts, then tighten lower bolts.





- 1 Compressor attachment
- 2 Compressor
- 3 Compressor bracket
- 4 Alternator
- 5 Idler pulley bracket

AC745

Fig. AC-31 Removing compressor

## INSTALLATION

To install compressor, reverse the order of removal. Observe the following: 1. Remove four bolts securing compressor bracket to engine. 2. When installing, fill compressor with the same amount of oil as that used previously.

Oil capacity (new compressor):

100 cc (6.10 cu in)

Note: Check quantity and quality of oil in compressor. Refer to Compressor Oil Check under General Service section.

2. Check tightening torque of compressor bracket mounting bolts; if necessary, retighten.

Tightening torque:

Flexible hose-to-compressor

6.0 kg-m (43 ft-lb)

Compressor-to-bracket bolts

2.2 to 3.0 kg-m

(16 to 20 ft-lb)

Compressor bracket-to-engine bolts

3.7 to 5.1 kg-m

(27 to 37 ft-lb)

3. Do not remove plugs or flexible hose before ready for immediate use.
4. When installing compressor, turn it several times.
5. When connecting flexible hose to compressor, apply a coat of fresh compressor oil to sealing surfaces of joints.

6. Evacuate cooling system, then recharge with refrigerant. Refer to Evacuating and Charging System under General Service section.


7. Whenever removing compressor, be sure to conduct leak test, make idle adjustment and adjust belt tension.

Notes:

- a. For compressor drive belt and cooling fan belt tensions, refer to Idler Pulley.
- b. Check refrigerant leakage; if necessary, correct.

1. Evacuate system. Refer to Discharging System under General Service section.





AC769

Fig. AC-37 Disconnecting connectors

11. To install cooling unit, reverse the order of removal.

## Notes:

- Apply a coat of fresh compressor oil to sealing surfaces when connecting pipe joints.
- Use two wrenches when connecting cooling pipes.
- Evacuate cooling system, then recharge with refrigerant. Refer to Evacuating and Charging System under General Service section.

d. Check refrigerant leakage; if necessary, repair. Refer to Checking for Leaks under General Service section.

## Tightening torque:

Copper tube joint nut

High pressure side (3/8 in)

2.5 to 3.5 kg-m


(18 to 25 ft-lb)

Low pressure side (1/2 in)

2.5 to 4.0 kg-m

(18 to 29 ft-lb)

## DISASSEMBLY AND ASSEMBLY



- Motor
- Fan
- Lower case
- Cooler duct
- Evaporator
- Expansion valve
- Upper case
- Resistor
- Main relay
- Thermo switch
- Cable clamp
- Cable
- Harness

AC725

Fig. AC-38 Disassembling cooling unit

1. Remove bracket and lead wire connector (main relay, thermo switch, resistor, motor, etc.) from cooling unit.

2. Remove five screws and duct.

3. Remove main relay.

4. Remove thermo switch.

5. Remove three screws and five springs securing upper case, lower case and rear bracket.

6. Unfasten fittings securing inlet and outlet pipes.

7. Upper and lower cases can now be separated.

8. Remove motor and fan as an assembly. Also remove evaporator.

9. Peel heat-insulating tape from expansion valve, and unfasten clip securing expansion valve capillary tube to pipe.

Remove expansion valve from evaporator.

10. To install, reverse the order of removal.

Expansion valve tightening torque:  
5 kg-m (36 ft-lb)

## Notes:

- When installing expansion valve on evaporator, make sure that temperature-sensing capillary tube is in its proper position on outlet side.
- Apply a coat of fresh compressor oil to sealing surfaces of pipes.

## INSPECTION

### Evaporator

Check evaporator for leakage or damage. If damaged, replace.

### Expansion valve


Check expansion valve for leakage or clogging. If clogged, clean filter in expansion valve. If damaged, replace.

## RECEIVER DRYER AND PIPING

### REMOVAL AND INSTALLATION

#### Receiver dryer

1. Disconnect battery ground cable.
2. Discharge system. Refer to Discharging System under General Service section.
3. Disconnect compressor lead wire at connector.
4. Disconnect cooling pipes at joints.



AC770

Fig. AC-39 Disconnecting cooling pipes

#### Notes:

- a. Plug all piping joints immediately after pipe disconnection to prevent entry of dust or moisture-laden air into receiver dryer or air conditioning system.
- b. Use two wrenches when disconnecting cooling pipes.

5. Remove four screws securing receiver dryer bracket to vehicle body, and detach compressor relay and pressure switch as an assembly.
6. To install receiver dryer and piping, reverse the order of removal.

#### Notes:

- a. Apply a coat of fresh compressor oil to sealing surfaces when connecting cooling pipes.
- b. Use two wrenches when connecting cooling pipes.
- c. Evacuate cooling system, then recharge with refrigerant.  
Refer to Evacuating and Checking System under General Service section.
- d. Check refrigerant leakage; if necessary, repair.  
Refer to Evacuating and Charging System under General Service section.

### Condenser


1. Disconnect battery ground cable.
2. Discharge system. Refer to Discharging System under General Service section.
3. Drain engine coolant.
4. Remove radiator grille.
5. Remove radiator shroud and radiator.

On automatic transmission models, disconnect both torque converter oil hoses.

Note: While cooling water is hot, take precautions against scalding.

6. Disconnect two pipes from condenser; remove two screws securing condenser.

Condenser can now be removed.



AC485

Fig. AC-40 Removing condenser

#### Notes:

- a. Use two wrenches when disconnecting pipe joints.
- b. Plug openings immediately after disconnecting pipes.
7. To install, reverse the order of removal.

#### Tightening torque:

Flare nut for copper tube  
(from compressor):  
2.5 to 4.0 kg-m  
(18 to 29 ft-lb)

Flare nut for copper tube  
(to receiver dryer):  
2.5 to 3.5 kg-m  
(18 to 25 ft-lb)

#### Notes:

- a. When disconnecting and connecting cooler pipes, be sure to use two wrenches.
- b. Apply a coat of fresh compressor oil to sealing surfaces when connecting cooler pipes.
- c. To prevent possibility of explosion due to high pressure within cooling system, do not clean condenser with steam. Always use cold water or cold compressed air.
- d. Evacuate cooling system, then recharge with refrigerant.  
Refer to Evacuating and Charging System under General Service section.
- e. Check refrigerant leakage; if necessary, repair. Refer to Checking for Leaks under General Service section.

## INSPECTION

### Receiver dryer

- Check for refrigerant leakage or damage.
- Check for proper connection of two lead wires running to pressure switch.
- If any component part is found damaged, replace receiver dryer and pressure switch as an assembly.

### Condenser


1. Check inlet and outlet pipe joints and sealing surfaces for damage. Replace parts if damaged or leaky.
2. Clogged condenser fins or air passages may reduce cooling efficiency of condenser. Clean these areas with dry compressed air.

### Piping

- Check piping for leakage. If leakage occurs at connections retighten connecting nuts. Replace if leakage persists.

# WIRING HARNESS AND COMPONENTS

## WIRING DIAGRAM



## MAINTENANCE

Replace any wiring harness which is cracked, deteriorated or poorly insulated.

Always replace wire with those of the same diameter. Do not use wire of smaller diameter.

Where necessary, securely retain wire harnesses with clips or tapes so that they will not be frayed or worn by vibration.

### Notes:

- Repair or replace any electrical part which is questionable or likely to cause a short-circuit.  
When disconnecting battery cables, always disconnect ground cable before positive cable. Clean battery and terminals before connecting cables, then connect positive cable and ground cable in that order. Apply a coat of grease to terminals to prevent rust formation.
- Do not attempt to conduct a continuity test with a screwdriver or service tools; always use test lead wires.
- Do not ground terminals when circuits are open or unloaded; always use a test lamp (12V - 3W) or circuit tester as a load.

## MAIN RELAY

### Removal and Installation


The main relay is attached to the cooling unit.

- Disconnect battery ground cable.
- Disconnect main relay lead wires at connector.
- Remove cooling unit assembly. Refer to Removal and Installation under Cooling Unit.
- Remove the screw securing main relay to cooling unit, and detach main relay.
- To install main relay, reverse the order of removal.

### Inspection

To check continuity in relay circuit, use a test lamp or an ohmmeter. Continuity between points (3) and (4) should exist.

When a 12 volt d-c is applied across points (3) and (4), continuity between points (1) and (2) should also exist.



AC465

Fig. AC-42 Main relay


## COMPRESSOR RELAY

### Removal and installation

- Disconnect compressor relay lead wires at connector.
- Remove two screws securing compressor relay to receiver dryer, and detach compressor relay.
- To install compressor relay, reverse the order of removal.

### Inspection

Using a test lamp or an ohmmeter, make sure that compressor relay contacts open and close continuously. Continuity always exists between points (3) and (4). When current flows through points (3) and (4), points (1) and (2) close. This causes current to flow through (1) and (2).




AC489

Fig. AC-43 Compressor relay

## FAN SWITCH

### Removal and installation

- Disconnect battery ground cable.
- Remove screws securing console box. Withdraw console box forward and disconnect lead wire connector.
- Detach switch knob.
- From rear side of console box, remove screws securing switch, and remove switch.
- To install fan switch, reverse the order of removal.



AC771

Fig. AC-44 Removing fan switch

## Inspection

Check continuity in fan switch circuit with a test lamp or an ohmmeter.




Fig. AC-45 Fan switch

## RESISTOR FOR FAN SWITCH

### Removal and installation

1. Disconnect battery ground cable.
2. Remove glove box.
3. Remove cooling unit. Refer to Removal and Installation under Cooling Unit.
4. Disconnect resistor lead wires at connector.




Fig. AC-46 Resistor for fan switch

5. Remove resistor assembly from upper side of cooling unit. Resistor is inserted into case.
6. To install resistor for fan switch, reverse the order of removal.

## Inspection

Test continuity between resistor and fuse.

## THERMO SWITCH

### Removal and installation

1. Disconnect battery ground cable.
2. Remove glove box.
3. Remove duct from cooling unit.
4. Disconnect thermo switch control cable and lead wires.
5. Remove thermo switch.

Note: Capillary tube is fitted into groove in cooler unit.

6. To install thermo switch, reverse the order of removal.




Fig. AC-47 Removing thermo switch

## Inspection

1. Fully move thermo switch lever to COLD.
2. Test continuity between terminals with a test lamp or an ohmmeter. Continuity should exist.
3. Dip capillary tube end into ice water. Test continuity between terminals. Continuity should not exist.
4. Replace if switch is found damaged.

## F.I.C.D. SOLENOID VALVE

### Removal and installation

1. Disconnect battery ground cable.
2. Disconnect lead wires and vacuum tube.
3. Remove two screws securing solenoid valve, and remove solenoid valve.




Fig. AC-48 Removing F.I.C.D. solenoid valve

4. To install solenoid valve, reverse the order of removal.

## Inspection

1. Test continuity in solenoid valve circuit with a test lamp or an ohmmeter.
2. Turn both fan switch and thermo switch on.
3. Run engine at idle, and check to be sure that vacuum is present in line between solenoid valve and diaphragm.

# COMPRESSOR

## CONTENTS

DESCRIPTION .....	AC-33	SHAFT SEAL ASSEMBLY .....	AC-36
COMPRESSOR CLUTCH .....	AC-34	REMOVAL .....	AC-36
REMOVAL .....	AC-34	INSTALLATION .....	AC-36
INSTALLATION .....	AC-34	INSPECTION .....	AC-37
DISASSEMBLY .....	AC-35	CYLINDER HEAD AND VALVES .....	AC-37
ASSEMBLY .....	AC-35	REMOVAL .....	AC-37
INSPECTION .....	AC-35	INSTALLATION .....	AC-37


## DESCRIPTION

Model CF206 is a crank type compressor specially designed, with minimum size and light weight, for use on compact vehicles.

The compressor crankshaft is driven by a belt from the crankshaft pulley through the electromagnetic clutch. Two pistons, positioned in line, are actuated by connecting rods connected to the crankshaft.

Discharge and suction valves are mounted in the valve liner between the crankcase and cylinder head.

As a lubricant, SUNISO NO. 5 is used. Simplified positive pressure lubrication utilizes existing pressure differential between suction intake and crankcase to provide a film of lubricating oil to bearings. All internal components have been designed to provide more than adequate lubrication to cylinder walls, connecting rod bearings and seal assembly. The result is improved lubrication, lower seal temperatures, reduced oil pumping and a reduction in the number of moving parts.




AC728

*Fig. AC-49 Sectional view of compressor*



- 1 Clutch wheel bearing
- 2 Snap ring
- 3 Clutch wheel assembly
- 4 Magnet coil
- 5 Shaft seal assembly
- 6 Service valve
- 7 Flange valve O-ring
- 8 Cylinder head
- 9 Cylinder head gasket
- 10 Cylinder gasket
- 11 Valve plate assembly
- 12 Base plate gasket
- 13 Base plate
- 14 O-ring
- 15 Oil filler plug
- 16 Clutch assembly
- 17 Compressor assembly




AC775

Fig. AC-50 Exploded view of compressor

## COMPRESSOR CLUTCH

The most likely source of problem is clutch slippage. Factors are listed here. Exercise ample care.


1. Clearance between clutch hub and pulley should be 0.4 to 0.6 mm (0.016 to 0.024 in) at all peripheral points.
2. Make sure that there is no oil or dirt on friction surfaces of clutch disc (clutch hub) and pulley. Remove oil or dirt with clean lint-free cloth.
3. Make sure that terminal voltage at magnetic coil is above 10.5V.



AC776

Fig. AC-51 Removing bolt

2. Then, using Clutch Removing Bolt, remove clutch assembly from crankshaft.




AC778

Fig. AC-53 Removing magnetic clutch

## REMOVAL

1. Using Clutch Spanner Wrench, hold clutch hub. With suitable socket wrench, remove bolt retaining clutch hub to crankshaft.



AC777

Fig. AC-52 Removing clutch

## INSTALLATION

Locate the electromagnetic coil at the correct position on compressor housing. Then, secure four electromagnetic coil mounting screws.

Tightening torque:

Electromagnetic coil mounting screws:

0.7 kg-m (5.1 ft-lb)

2. Install the clutch assembly on the crankshaft.

**Note:** Key should be set on crankshaft before installing clutch assembly.


3. Using Clutch Spanner Wrench, hold clutch hub. With socket wrench, secure clutch hub securing bolt.

Tightening torque:

Clutch hub securing bolt:  
1.5 kg-m (11 ft-lb)

## DISASSEMBLY


1. Remove two snap rings retaining bearing. They are located inside of clutch wheel.



AC500

Fig. AC-54 Removing snap rings


2. Using Clutch Wheel Remover KV99100700 and conventional puller, remove V-pulley with bearings from clutch wheel.



AC501


Fig. AC-55 Removing clutch wheel bearings

3. Using Bearing Remover ST33061000, press clutch wheel bearings out from clutch wheel.



AC502

Fig. AC-56 Removing V-pulley from clutch





AC503

Fig. AC-57 Installing bearings

## ASSEMBLY

1. Press bearings into V-pulley with Bearing Installer ST02371000.

2. Install outer snap ring in groove of V-pulley.
3. Using Installer KV99100610 and Stopper ST33061000, press clutch wheel into V-pulley.
4. Install inner snap ring in groove of clutch wheel.



- 1 Installer (KV99100610)
- 2 Stopper (ST33061000)


AC504

Fig. AC-58 Installing clutch wheel

## INSPECTION

1. Check friction surface of clutch for damage due to excessive heat, or excessive grooving due to slippage. If necessary, replace clutch wheel and V-pulley as a set.
2. The clearance between V-pulley and clutch wheel should be 0.4 to 0.6 mm (0.016 to 0.024 in).  
If not, replace clutch wheel assembly.

3. Oil or dirt on friction surfaces of clutch wheel and V-pulley should be cleaned with a clean lint-free cloth or suitable solvent.
4. Check coil for shorted or opened lead wire. Pay particular attention to grounding part of coil. If there is no continuity, replace electromagnetic coil.



AC506

Fig. AC-59 Grounding point of coil

5. If clutch assembly must be replaced, remember that break-in operation is necessary. The break-in operation consists of engaging and disengaging the clutch some thirty times.


## SHAFT SEAL ASSEMBLY

The shaft seal assembly of this compressor is of a simplified design, yet tight sealing and long lasting.

### REMOVAL

It is recommended that the compressor be removed from the vehicle for shaft seal replacement.


1. Remove oil filler plug with O-ring and drain the compressor oil.



AC806

Fig. AC-60 Removing filler plug


2. Remove clutch. Refer to Compressor Clutch Removal.  
3. Remove shaft key.



AC807

Fig. AC-61 Removing shaft key

4. Remove seal plate.




AC808

Fig. AC-62 Removing seal plate

5. With the Compressor Seal Puller, pull out seal gland and discard.

### Notes:

- Discard all parts of the seal including the O-ring.
- Do not use a screwdriver to pry shaft seal from shaft as damage to shaft may result.




AC809

Fig. AC-63 Removing shaft seal

### INSTALLATION

- Clean shaft and seal cavity with clean lint-free cloth.
- Dip seal gland in clean refrigerant oil.

- Push seal assembly, except carbon ring, over end of shaft with carbon ring retainer facing out.
- Move seal assembly into position on shaft.



AC810

Fig. AC-64 Inserting shaft seal assembly

5. Place carbon ring in ring retainer so lapped surface is facing outward.

**Note:** The indentions in outside edge of carbon ring must engage driving lugs and be firmly seated in retainer.

6. Install new O-ring in groove of seal plate.


**Note:** Use refrigeration oil to make it adhere to surface.

7. Space seal plate with equal clearance around shaft and insert cap screws.

8. Tighten these screws evenly.

### Tightening torque

Seal plate securing cap screws:  
0.7 to 1.0 kg-m  
(5 to 7 ft-lb)



AC811

Fig. AC-65 Spacing seal plate and tightening cap screws

9. Install clutch. Refer to Compressor Clutch Installation.

## INSPECTION

Check for gas leakage as follows:

1. Plug high- and low-pressure joints on compressor with blind caps.
2. Connect charging hoses in lines between manifold gauge and high- and low-pressure service valves.

Connect refrigerant can to middle hose of manifold gauge.

3. Open valve of can tap, and charge refrigerant. Loosen oil filler plug at side of compressor to purge air out of compressor.

4. Turn shaft 5 or 6 turns. Then confirm that pressure does not decrease on low pressure gauge. If gauge indicates a pressure decrease, there is a leak. Conduct a leak test. Under such a condition, remove and then install parts again.

## CYLINDER HEAD AND VALVES


Insufficient refrigerant compression is likely to be caused by damaged head gasket or damaged valves.

Prior to servicing the head and valve plate, both service valves should be opened to free any gas pressure which may be in the compressor.

## REMOVAL

1. Remove the bolts from flanged type service valves using Torx Driver Bit.


**Note:** The direction of flanged type service valves should be noted for reinstallation.



AC812

Fig. AC-66 Removing service valves

2. Remove the remaining bolts in the head.




AC813

Fig. AC-67 Removing cylinder head bolts

3. Remove valve plate and head from cylinder by prying or tapping under the ears which extend from valve plate.

If head and valve plate adhere, hold head and tap valve plate ears away from head with a soft hammer.

**Note:** Do not hit or tap head to separate head and valve plate because damage to head may result.




AC814

Fig. AC-68 Removing valve plate and head

4. When removing the gaskets, use a sharp-edged knife.

**Notes:**

- a. In removing head gasket, be very careful not to damage machined sealing surface.
- b. Do not reuse gaskets.




AC815

Fig. AC-69 Removing gasket

## INSTALLATION

Valves and valve plates are furnished only as a complete assembly.


1. Apply a thin film of clean refrigeration oil on area of crankcase to be covered by cylinder gasket.
2. Place cylinder gasket in position on cylinder so dowel pins in crankcase go through dowel pin holes in cylinder gasket.
3. Apply a thin film of clean refrigeration oil to top and bottom valve plate areas to be covered by gaskets.



AC816

Fig. AC-70 Applying clean refrigeration oil

4. Place valve plate in position on cylinder gasket so discharge valve assemblies (i.e. smaller diameter assemblies with restrainer over valve reed) are facing up and locating dowel pins go through dowel pin holes in valve plate.



AC817

Fig. AC-71 Placing valve plate

## Air Conditioning

---

5. Place head gasket in position on valve plate so dowel pins go through dowel pin holes in gasket.

6. Apply a thin film of clean refrigeration oil on the machined surface of cylinder head which matches head gasket.

7. Place head on cylinder head gasket so dowel pins go into dowel pin holes in head.

8. Apply a thin film of clean refrigeration oil to service valve flanges.

9. Place flange valve O-ring in position on cylinder head.

10. Place service valves in position on proper service valve ports (suction or discharge) and insert two longer screws through service valve mounting pads, head, valve plate, and into crank-

case.

11. Insert remaining head screws and run in all screws until the heads make contact.





### Tightening torque:

Head and service valve screws:






2.1 to 3.2 kg-m

(15 to 23 ft-lb)

## SPECIAL SERVICE TOOLS

No.	Tool number & tool name	Description  Unit: mm (in)	For use on	Reference page or Figure No.
1.	KV99100700 Clutch wheel remover	To remove clutch wheel from V-pulley.    BE436	620	Fig. AC-55
2.	KV991006S0 Clutch wheel installer set  KV99100610 Installer  ST33061000 Stopper	To install clutch wheel into V-pulley.    BE437	620	Fig. AC-58
3.	ST33061000 Bearing remover	To remove clutch wheel bearing from V-pulley.    BE438	620	Fig. AC-56
4.	ST02371000 Bearing installer	To install clutch wheel bearing into V-pulley.    BE439	620	Fig. AC-57

# Air Conditioning

No.	Tool number & tool name	Description Unit: mm (in)	For use on	Reference page or Figure No.	Remarks
5.	Clutch spanner wrench	To hold clutch wheel when removing clutch wheel.  BE440	620	Fig. AC-51	(J24878-1)
6.	Clutch removing bolt	To remove V-pulley from crankshaft.  BE441	620	Fig. AC-52	(J26344)
7.	Compressor seal puller	To remove shaft seal from crankshaft.  BE442	620	Fig. AC-63	(J10549)
8.	Torx driver bit	To remove flange bolts.  BE443	620	Fig. AC-66	(J24392)
9.	Oil dip stick	To inspect oil level.  BE434	620		(J10545)

# SERVICE MANUAL

DATSUN PICK-UP  
MODEL 620 SERIES

## SECTION SE

### SERVICE EQUIPMENT

SERVICE EQUIPMENT ..... SE- 2

SE



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN



# SERVICE EQUIPMENT

## GENERAL DESCRIPTION

Special Tools play very important role in the maintenance of vehicles. These are essential to the safe, accurate and speedy servicing.

The working times listed in the column under FLAT RATE TIME in FLAT RATE SCHEDULE are computed based on the use of Special Tools.

The identification code of maintenance tools is made up of 2 alphabetical letters and 8 digital figures.

The heading two letters roughly classify tools or equipment as follows:

ST00000000: Special Tool  
KV00000000: Special Tool  
(Recently established)  
EM00000000: Engine Overhauling  
Machine  
GG00000000: General Gauge  
HT00000000: Hand Tool

## HOW TO READ SPECIAL TOOL LIST

### APPLIED VEHICLE OR UNIT

In this column word "All" is given for tools applicable to all vehicle models and unit types treated in this manual; for tools applicable only to particular models or units, those vehicle models or unit types are indicated.

### NEWLY ADDED

"X" put in this column shows newly added tools.

## CLASS

Indicated in this column are classification figures in accordance with "Classification of Special Tool".

## REMARKS

As regards special tools which are also applicable to models other than those dealt with in this manual, this column names those other models.

### CLASSIFICATION OF SPECIAL TOOL

	Classification	
	Important	General
I. Inspection and minor repairs	1	4
II. General disassembly and assembly	2	5
III. Special disassembly and assembly	3	6

#### A. Important

- Exclusive with no alternative
- Parts will be damaged if repaired without special tool.
- Gauges

#### B. General

To facilitate servicing

- Inspection and minor repairs
  - Inspection and maintenance
  - Unit replacement
  - Minor unit disassembly

II. General disassembly and assembly  
General disassembly such as engine, transmission and differential

- III. Special disassembly and assembly
- Disassembly of exclusive parts such as automatic transmission and electrical accessories
  - Special work such as boring and welding
  - Work very rarely required.

## SPECIAL TOOL SET (See attached tool list)

The set is available for new and other dealers who must go through initial preparation.

### SET '77 620NA KV00102000

This set is designed for the chassis and body of the 620 models without regard to their destination.

### SET 3N71B KV00101000

This set is designed for use on the 3N71B automatic transmission. It consists of the same service tools as those previously available separately.

**TOOL LIST****ENGINE TOOL**

Tool Number	Tool Name	Newly added	Class	Remarks
ST0501S000	Engine stand assembly		5	F10, B210, 610, 710, S30
—ST05011000	Engine stand			
—ST05012000	Base			
ST05260001	Engine attachment		5	610, 710
ST10120000	Cylinder head bolt wrench		2	610, 710, S30
ST10640001	Pivot adjuster		1	610, 710, S30
KV101039S0	Valve guide reamer set		3	F10, B210, 610, 710, S30
—ST11081000	Reamer [12.2 mm (0.480 in) dia.]			
—ST11032000	Reamer [8.0 mm (0.315 in) dia.]			
—ST11320000	Drift			
ST11650001	Valve seat cutter set		2	610, 710, S30
ST12070000	Valve lifter		5	B210, 610, 710, S30
ST13030001	Piston pin press stand		2	610, 710, S30
ST15310000	Crankshaft rear oil seal drift		2	610, 710, S30
KV101041S0	Crankshaft main bearing cap puller		2	610, 710, S30
—KV10104110	Crankshaft main bearing puller			
—ST16512001	Adapter			
—ST16701001	Adapter			
ST16610001	Pilot bushing puller		3	610, 710, S30
ST17420001	Chain stopper		2	610, 710, S30
ST19320000	Oil filter wrench		1	F10, B210, 610, 710, S30
ST19870000	Air pump test gauge		1	F10, B210, 610, 710
ST19810000	Hexagonal wrench		3	F10, B210, 610, 710
ST19890000	Rotor adapter		2	F10, B210, 610, 710
ST19900000	Dummy shaft		2	F10, B210, 610, 710
ST19910000	Bearing drift		2	F10, B210, 610, 710
ST19920000	Rotor stand		2	F10, B210, 610, 710
ST19930000	Bearing adapter		2	F10, B210, 610, 710
ST19940000	Bearing pressing tool		3	F10, B210, 610, 710
EM03470000	Piston ring compressor		2	F10, B210, 610, 710, S30

## Service Equipment

### CHASSIS AND BODY TOOL

No.	Tool Number	Tool Name	Applied vehicle or unit	Set '77 620NA	Newly added	Class	Remarks
				KV00102000			
1.	Clutch						
	ST16610001	Pilot bushing puller	All	X		3	610, 710, S30
	KV30100200	Clutch aligning bar	All	X		2	610, 710, S30
	ST20050010	Base plate	All	X		5	B210, 610, 710, S30
	ST20050100	Distance piece	All	X		5	B210, 610, 710, S30
	ST20050051	Set bolt	All	X		5	B210, 610, 710, S30
	ST20050240	Diaphragm adjusting wrench	All	X		5	B210, 610, 710, S30
	GG94310000	Flare nut torque wrench	All	X		2	F10, B210, 610, 710, S30
2.	Manual transmission						
	ST22360002	Drift C	All	X		2	B210, S30
	ST23540000	Fork rod pin punch	All	X		2	F10, B210, 610, 710, S30
	ST23800000	Transmission adapter	All	X		2	F10, B210, 610, 710, S30
	ST23810001	Setting plate adapter	All	X		5	S30
	ST22520000	Wrench	All	X		2	B210, S30
	ST23860000	Counter gear drift	All	X		2	S30
	KV31100400	Transmission press stand	All	X		5	S30
	ST30031000	Bearing puller	All	X		2	F10, B210, 610, 710, S30
	KV32101330	Bearing puller	FS5W71B	X	X	2	B210, S30
3.	Differential						
	ST06310000	Diff. attachment	All	X		5	610
	ST31530000	Drive pinion flange wrench	All	X		2	B210, 610, 710, S30
	ST3306S001	Diff. side bearing puller	All	X		2	610, S30
	ST33051001	Puller					
	ST33061000	Adapter					
	ST3090S000	Drive pinion rear bearing inner race replacer	All	X		2	610, S30
	ST30031000	Puller					
	ST30901000	Base					
	ST33230000	Diff. side bearing drift	All	X		2	610
	ST3194S000	Drive pinion setting gauge ass'y	All	X		2	610
	ST31941000	Height gauge					
	ST31942000	Dummy shaft					

# Service Equipment


No.	Tool Number	Tool Name	Applied vehicle or unit	Set '77 620NA	Newly added	Class	Remarks
				KV00102000			
	ST31970000	Collar	All	X		2	610
	ST30611000	Drive pinion outer race drift bar	All	X		2	610
	ST30613000	Drive pinion outer race drift adapter	All	X		2	610
	ST30621000	Drive pinion outer race drift adapter	All	X		2	610
	KV31100300	Solid punch	All	X		2	610, 710, S30
	ST3127S000	Preload gauge	All	X		2	B210, 610, 710, S30
	KV381025S0	Oil seal fitting tool	All	X		2	610
4.	Front axle						
	ST35380000	Kingpin bushing drift	All	X		2	
	HT56802000	Kingpin bushing reamer	All	X		2	
	ST36070000	Transverse link bushing replacer	All	X		2	
	ST35390000	Kingpin grease seal drift	All	X		2	
5.	Rear axle						
	ST38020000	Bearing lock nut wrench	All	X		2	
	KV40101000	Rear axle stand	All	X		2	B210, 610, 710, S30
	ST36230000	Sliding hammer	All	X		5	B210, 610, 710, S30
	HT72480000	Rear axle shaft bearing puller	All	X		2	B210, 610, 710, S30
6.	Steering						
	ST29020001	Pitman arm puller	All	X		2	B210, 610, 710, S30
	ST27180001	Steering wheel puller	All	X		2	F10, B210, 610, 710, S30
	HT72520000	Ball joint remover	All	X		2	F10, B210, 610, 710, S30
	ST3127S000	Preload gauge	All	X		1	F10, B210, 610, 710, S30
7.	Brake						
	GG94310000	Brake pipe torque wrench	All	X		2	B210, 610, 710, S30
	ST08060000	Master-Vac oil seal retainer drift	All	X		3	B210, 610, 710, S30
	ST08080000	Master-Vac wrench	All	X		3	B210, 610, 710, S30

# Service Equipment

## AUTOMATIC TRANSMISSION TOOL

Tool Number	Tool Name	Applied vehicle or unit	Set 3N71B	Newly added	Class	Remarks
			KV00101000			
ST07870000	Transmission case stand	All	X		3	B210, 610, 710, S30
ST2505S001	Oil pressure gauge set	All	X		1	
ST25160000	Torque driver	All	X		3	
ST25320001	Snap ring remover	All	X		3	
ST25420001	Clutch spring compressor	All	X		3	
ST25490000	Socket extension	All	X		3	
ST25570001	Hex-head extension	All	X		3	
ST25580000	Oil pump assembling gauge	All	X		3	
ST25850000	Sliding hammers	All	X		3	
GG93010000	Torque wrench	All	X		3	
HT61000800	Hexagon wrench	All	X		3	
HT62350000	Spinner handle	All	X		6	
HT69860000	Snap ring remover	All	X		3	

## WIRING DIAGRAM



 **NISSAN MOTOR CO., LTD.**  
Tokyo, Japan

Issued: September 1976 (070795)  
Printed in Japan Publication No. SM7E-0620U0