

SERVICE MANUAL

MODEL
L14, L16 & L18 SERIES
ENGINES



NISSAN MOTOR CO., LTD.
TOKYO, JAPAN

SECTION EM

ENGINE MECHANICAL

EM

GENERAL DESCRIPTION	EM- 2
ENGINE DISASSEMBLY	EM- 5
INSPECTION AND REPAIR	EM- 8
ENGINE ASSEMBLY	EM-23
SERVICE DATA AND SPECIFICATIONS	EM-28
TROUBLE DIAGNOSES AND CORRECTIONS	EM-35

ENGINE MECHANICAL

GENERAL DESCRIPTION

CONTENTS

L14, L16 AND L18 ENGINE	EM-2	CAMSHAFT	EM-4
CYLINDER BLOCK	EM-3	VALVE MECHANISM	EM-4
CRANKSHAFT	EM-3	CAMSHAFT DRIVE	EM-4
PISTON AND CONNECTING ROD	EM-3	MANIFOLDS	EM-4
CYLINDER HEAD	EM-3		


L14, L16 AND L18 ENGINE

The 510 series models are powered by the L14 and L16 engines. The L16 engine is also utilized to power the 610. For the 610, the L18 engine is also available for faster, harder use on highways and streets. The engines

feature O.H.C. valves, wedge-shaped combustion chamber, aluminum heads and fully balanced 5-bearing crankshaft to turn out smooth, dependable power. The cylinder block is cast in a single unit, featuring deep skirting.

SU type carburetor is used to

provide proper air-fuel mixing for the L16 and L18 engines. These engines are also equipped with single, 2-barrel, downdraft carburetor. The L14 engine uses only the same single, 2-barrel carburetor that is used on the L16 and L18 engine.



EM076

Fig. EM-1 Cross section view
(L16 engine)

ENGINE MECHANICAL

Main specifications

	L14	L16		L18	
	Single carb.	Single carb.	Twin carb.	Single carb.	Twin carb.
Displacement cc (cu in)	1,428 (87.14)	1,595 (97.33)	←	1,770 (108.01)	←
Bore x stroke mm (in)	83 x 66 (3.268 x 2.598)	83 x 73.7 (3.268 x 2.902)	←	85 x 78 (3.346 x 3.071)	←
Compression ratio	9.0	8.5	9.5	8.5	9.5
Ignition timing for M/T B.T.D.C. (for A/T)	8°/600 rpm	10°/600 rpm (650)	14°/650 rpm (700)	10°/600 rpm (650)	14°/650 rpm (700)


M/T: Manual Transmission A/T: Automatic Transmission

Note: On vehicles equipped with an air conditioner, increase engine speed by 150 rpm higher than that indicated while F.I.C.D. is in operation.

CYLINDER BLOCK

The cylinder block, which is of a monoblock special casting structure, adopts five-bearing-support system for quietness and higher durability.

The cylinder bores are surrounded by cooling jackets and machined directly in the block. The oil ways in the block are arranged so that the full-flow oil filter is directly attached to the right hand side of the block.



EM077

Fig. EM-2 Cylinder block

CRANKSHAFT

The crankshaft is a special steel forging. Fully balanced, it turns out smooth, dependable power at high speed.

The L18 engine uses eight balance weights, while the others use four.

Main bearings gain lubrication from oil pumped through the main oil gallery and the oil holes which run in parallel with cylinder bores. There are drilled oilways in the crankshaft for the lubricating oil. The center main bearing is equipped with thrust washers to take up end thrust of the crankshaft.



EM078

Fig. EM-3 Crankshaft (L14 and L16)



EM079


Fig. EM-4 Crankshaft (L18)

PISTON AND CONNECTING ROD

The pistons are special aluminum casting with struts to control thermal expansion and have two compression

rings and one combined oil ring. The L16 engine equipped with twin carburetors, and the L14 engine equipped with single carburetor use the flat head pistons and others use slightly dished pistons. The piston pin is a special hollow steel shaft. It is full-floating fit to the piston and press fit to the connecting rods.

The connecting rods are special forged steel. Oil is directed to the connecting rod small ends through drilled passages in the large ends of rod. Oil holes in the connecting rods are located so as to insure optimum lubrication under heavy load.



EM080

Fig. EM-5 Piston and connecting rod

CYLINDER HEAD

The cylinder head is made of light and strong aluminum alloy with good cooling efficiency; it contains wedge type combustion chambers. A special aluminum bronze valve seat is used on the intake valve, while a heat resistant

steel valve seat is installed on the exhaust valve. These parts are all hot press-fitted.



EM081


Fig. EM-6 Cylinder head

CAMSHAFT

Camshaft is made of special cast iron and located inside rocker cover. Four aluminum alloy brackets support camshaft. Camshaft bearings are lubricated from oil holes which lead to the main oil gallery of the cylinder head.

The concentric passages are drilled in the front and rear part of the camshaft.

The oil to each cam lobe is supplied through an oil hole drilled in the base circle of each lobe. Lubricant is supplied to the front oil gallery from 2nd camshaft bearing and to the rear oil gallery from 3rd camshaft bearing. These holes on the base circle of lobe supply lubricant to the cam pad surface of the rocker arm and to the valve tip end.




EM082

Fig. EM-7 Camshaft

VALVE MECHANISM


The valve system has a pivot type rocker arm that is activated directly by the cam mechanism, and this has made its moving parts considerably lighter and provides an ideal highspeed performance.

Only the L14 engine uses the single type valve springs intake valve only and all other engines use the dual type valve springs.



EM083

Fig. EM-8 Valve mechanism (L14)



EM084

Fig. EM-9 Valve mechanism (L16 and L18)

CAMSHAFT DRIVE

Camshaft is driven by a double row roller chain driven by crankshaft. The tension of the chain is controlled by a chain tensioner which is operated by spring and oil pressure. The rubber shoe type tensioner insulates vibration of the chain and controls tension of the chain.



EM085

Fig. EM-10 Chain driving system

MANIFOLDS

The intake manifold is made of casted aluminum alloy. The twin-carburetor type engines use the one with an independent design for each carburetor, while the single carburetor type engines use a monoblock manifold.

The exhaust manifold, identical in design on both engine types is a dual exhaust system intended to prevent decrease in output due to exhaust interference and to increase output through the inertia scavenging action. It is connected to exhaust pipes by flanges, which insure complete absence of exhaust leaks.



EM086

Fig. EM-11 Manifolds for single carburetor



EM087

Fig. EM-12 Manifolds for twin carburetor

ENGINE MECHANICAL

ENGINE DISASSEMBLY

CONTENTS

PRELIMINARY CLEANING AND INSPECTION DISASSEMBLY	EM-5	PISTONS AND CONNECTING RODS	EM-6
	EM-5	CYLINDER HEAD	EM-7

PRELIMINARY CLEANING AND INSPECTION

Before disassembling engine, observe the following items:

1. Fuel, oil or water may leak past cylinder head and block. Prior to disassembling, check cylinder head, front chain cover, oil pan and oil filter gaskets and crankshaft and water pump seals for sign of leak past their gasketed surfaces.
2. Check carburetor and fuel pump for condition; fuel hoses for deterioration, cracks or otherwise leakage of fuel past their jointed or connected surfaces.
3. Remove air cleaner, alternator, distributor and starter, and plug up carburetor air-horn and distributor hole to prevent entry of foreign matter.
4. Wipe dust and mud off engine.
5. Inspect block, rocker cover, front chain cover, oil pan and all other outer parts for visual defects and broken or missing parts such as bolts and nuts.
6. Test all pipings and electrical circuits for discontinuity or broken or damaged insulation.

DISASSEMBLY

To remove engine from vehicle, refer to relative topic under "Engine Removal and Installation" in Chassis and Body Service Manual, Section ER.

1. Remove transmission from engine.
 2. Thoroughly drain engine oil and coolant by removing drain plugs.
 3. Place engine assembly on the engine stand.
- (1) Remove fan and fan pulley.
 - (2) Remove engine mounting R.H.

- (3) Remove oil filter using special tool "Oil Filter Wrench ST19320000."
- (4) Remove oil pressure switch.
- (5) Install engine attachment to cylinder block using bolt holes securing alternator bracket and water drain plug.
- (6) Set engine on the stand.

"Engine Attachment ST05260001"
"Engine Stand ST0501S000"



Fig. EM-13 Engine on engine stand

4. Remove oil level gauge.
5. Remove clutch assembly.
6. Remove high tension cable.
7. Remove spark plugs.
8. Remove thermostat housing.



Fig. EM-14 Removing thermostat housing

9. Remove rocker cover.
10. Remove carburetor.
11. Remove intake and exhaust manifolds.



Fig. EM-15 Removing manifolds

12. Remove engine mounting L.H.
13. Remove crank pulley.
14. Remove water pump.
15. Remove fuel pump.
16. Remove fuel pump drive cam.
17. Remove camshaft sprocket.



Fig. EM-16 Removing camshaft sprocket

18. Remove cylinder head assembly. Use special tool "Cylinder Head Bolt Wrench ST10120000" to remove cylinder head bolts. Loosen bolts from ① to ⑩ as shown in Figure EM-17.




Fig. EM-17 Cylinder head bolt loosening sequence

Note: For the convenience of cylinder head replacement, special tool "Chain Stopper ST17420001" is prepared to support timing chain during the service operation. By using this tool, timing marks on crankshaft sprocket and timing chain will be unchanged. So the work for aligning timing marks will be saved so much.




Fig. EM-18 Supporting timing chain

19. Invert engine.
20. Remove oil pan and oil strainer,




Fig. EM-19 Removing oil strainer and oil pump

21. Remove oil pump and its drive spindle.
22. Remove front cover.
23. Remove chain tensioner.




Fig. EM-20 Removing chain tensioner and timing chain

24. Remove timing chain.
25. Remove oil thrower, crankshaft worm gear and chain drive sprocket.




Fig. EM-21 Removing chain drive sprocket

26. Remove piston and connecting rod assembly. Take off connecting rod bearings and keep them in order.



Fig. EM-22 Removing piston and connecting rod assembly

27. Remove flywheel. Be careful not to drop it.




Fig. EM-23 Removing flywheel

28. Remove main bearing caps.

Use special tool "Crankshaft Main Bearing Cap Puller ST1651S000" to remove center and rear main bearing caps. Keep them in order.




Fig. EM-24 Removing rear main bearing cap

29. Remove rear oil seal.



Fig. EM-25 Removing rear oil seal

30. Remove crankshaft.
31. Remove baffle plate and cylinder block net.





Fig. EM-26 Removing baffle plate and net

PISTONS AND CONNECTING RODS


1. Remove piston rings with a ring remover.



EM102

Fig. EM-27 Removing piston ring

2. Press out piston pin with special tool. "Piston Pin Press Stand ST13030001."




EM103

Fig. EM-28 Removing piston pin

3. Keep the disassembled parts in order.

CYLINDER HEAD

1. Loosen valve rocker pivot lock nut and remove rocker arm by pressing down valve spring.



EM104

Fig. EM-29 Removing rocker arm

Note: Take care not to lose valve rocker guide.

2. Remove camshaft.



EM105

Fig. EM-30 Removing camshaft

Note: At this time, take care not to damage camshaft bearings and cam lobes.


3. Remove valves using special tool "Valve Lifter ST12070000."



EM106

Fig. EM-31 Removing valve

4. Take care not to lose valve spring seat, oil seal, valve collet, and valve rocker guide.



Exhaust

Intake

EM107

Fig. EM-32 Valve components

Notes:

- Be sure to leave camshaft bearing intact. Because the bearing center is liable to be out of alignment.
- Only the L14 engine uses the single type spring for intake valve.

INSPECTION AND REPAIR

CONTENTS


PREPARATION FOR INSPECTION	EM- 8	PISTONS, PISTON PINS AND PISTON RINGS	EM-17
CYLINDER HEAD AND VALVE	EM- 8	CONNECTING ROD	EM-18
Checking cylinder head mating face	EM- 8	CRANKSHAFT	EM-18
Valve assembly	EM- 8	BUSHING AND BEARING	EM-20
Valve spring	EM- 9	Measurement of main bearing clearance	EM-20
Rocker arm and valve rocker pivot	EM-10	Measurement of connecting rod bearing clearance	EM-20
Valve guide	EM-10	Fitting bearings	EM-20
Valve seat inserts	EM-11	MISCELLANEOUS COMPONENTS	EM-22
CAMSHAFT AND CAMSHAFT BEARING	EM-13	Crankshaft sprocket, camshaft sprocket	EM-22
Camshaft bearing clearance	EM-13	Chain tensioner and chain guide	EM-22
Valve timing	EM-13	Flywheel	EM-22
Camshaft alignment	EM-14	Front cover and rear oil seal	EM-23
CYLINDER BLOCK	EM-14		
How to measure cylinder bore	EM-15		
Cylinder boring	EM-15		

PREPARATION FOR INSPECTION

1. Before cleaning, check for sign of water and oil leaks in cylinder block and head.
2. Clean oil and carbon deposits from all parts. They should be clean from gasket or sealant.
3. Clean all oil holes with solvent and dry with compressed air. Make sure that they are not restricted.

CYLINDER HEAD AND VALVE

Checking cylinder head mating face



EM081

Fig. EM-33 Cylinder head

Note: Never remove camshaft bearings unless you have a suitable machine for boring camshaft bearing in line. If you once remove camshaft bearings, bearing centers will be out of alignment and reconditioning is very difficult without center borings.

1. Make a visual check for cracks and flaws.
2. Measure the surface of cylinder head (on cylinder block side) for warpage. If it is found to be beyond the limit designated below, regrind the affected surface with a surface grinder.




Fig. EM-34 Checking cylinder head surface

Head surface flatness

Standard	Maximum
less than 0.05 mm (0.0020 in)	0.1 mm (0.0039 in)

Valve assembly

1. Check each of the intake and exhaust valve for worn, damaged or deformed valve caps or stems. Correct or replace the valve that is defective.
2. Valve face or valve stem end surface should be refaced by using a valve grinder.



EM109

Fig. EM-35 Intake and exhaust valve dimensions

ENGINE MECHANICAL

H	Valve head diameter mm (in)	L14	In.	38.0 to 38.2 (1.496 to 1.504)
			Ex.	33.0 to 33.2 (1.299 to 1.307)
		L16	In.	42.0 to 42.2 (1.654 to 1.661)
			Ex.	33.0 to 33.2 (1.299 to 1.307)
		L18	In.	42.0 to 42.2 (1.654 to 1.661)
			Ex.	35.0 to 35.2 (1.378 to 1.386)
L	Valve length mm (in)	L14	In.	115.6 to 115.9 (4.551 to 4.562)
			Ex.	115.7 to 116.0 (4.555 to 4.567)
		L16 L18	In.	114.9 to 115.2 (4.524 to 4.535)
			Ex.	115.7 to 116.0 (4.555 to 4.567)
D	Valve stem diameter mm (in)	L14	In.	7.965 to 7.980 (0.3136 to 0.3142)
		L16	Ex.	7.945 to 7.960 (0.3128 to 0.3134)
		L18		
α	Valve seat angle In. & Ex.			45° 30'

Note: When valve head has been worn down to 0.5 mm (0.0197 in) in thickness, replace the valve.
Grinding allowance for the valve stem end surface is 0.5 mm (0.0197 in) or less.

Valve spring

1. Check valve spring for squareness using a steel square and surface plate. If spring is out of square more than 1.6 mm (0.063 in), replace with new ones.
2. Measure the free length and the tension of each spring. If the measured value exceeds the specified limit, replace spring.




EM112

Fig. EM-38 Measuring spring squareness



EM110

Fig. EM-36 Checking valve stem diameter



EM111

Fig. EM-37 Regrinding valve face



EM113

Fig. EM-39 Measuring spring tension

ENGINE MECHANICAL

Spring specifications

	L14	L16 and L18	
		Single carb.	Twin carb.
Valve spring free length mm (in)			
Intake Outer	49.0 (1.929)	49.98 (1.968)	
Intake Inner		44.85 (1.766)	
Exhaust Outer	49.98 (1.968)	49.98 (1.968)	
Exhaust Inner	44.85 (1.766)	44.85 (1.766)	
Valve spring pressured length (valve open) mm/kg (in/lb)			
Intake Outer	30.0/60.0 (1.181/132.3)	30.0/47.7 (1.181/105.2)	29.5/49.0 (1.161/108)
Intake Inner		25.0/24.9 (0.984/54.9)	24.5/25.5 (0.965/56.2)
Exhaust Outer	30.0/47.7 (1.181/105.2)	29.5/49.0 (1.161/108)	29.5/49.0 (1.161/108)
Exhaust Inner	25.0/24.9 (0.984/54.9)	24.5/25.5 (0.965/56.2)	24.5/25.5 (0.965/56.2)
Valve spring assembled height (valve close) mm/kg (in/lb)			
Intake Outer	40.0/28.4 (1.575/62.6)	40.0/21.3 (1.575/47.0)	
Intake Inner		35.0/12.3 (1.378/27.1)	
Exhaust Outer		40.0/21.3 (1.575/47.0)	
Exhaust Inner		35.0/12.3 (1.378/27.1)	

Rocker arm and valve rocker pivot

Check pivot head and cam contact and pivot contact surfaces of rocker arm for damage or wear. If defects are found, replace them. A defective pivot necessitates its replacement together with the corresponding rocker arm.

Valve guide

Measure the clearance between valve guide and valve stem. If the clearance exceeds the designated limit, replace the worn parts or both valve and valve guide. In this case, it is essential to determine if such a clearance has been caused by a worn or bent valve stem or by a worn valve guide.





Fig. EM-40 Standard valve guide

ENGINE MECHANICAL

		Intake valve	Exhaust valve
Stem to guide clearance mm (in)	L14 L16, L18	0.020 to 0.053 (0.0008 to 0.0021)	0.040 to 0.073 (0.0016 to 0.0029)
Max. tolerance of above clearance mm (in)	All	0.1 (0.0039)	

As an emergency expedient, a valve is pushed in valve guide and moved to the left and the right at which point if its tip deflects about 0.2 mm (0.0079 in) or more, it will be known that the clearance between stem and guide exceeds the maximum limit of 0.1 mm (0.0039 in).

Note: Valve should be moved in parallel with rocker arm. (Generally, a large amount of wear occurs in this direction.)




EM115
Fig. EM-41 Measuring clearance between valve stem and valve guide

Replacement of valve guide

1. To remove old guides, use a drift and a press (under a 2-ton pressure) or a hammer.

Drive them out from combustion chamber side toward rocker cover. Heated cylinder head will facilitate the operation.

2. Ream cylinder head side guide hole at room temperature.



EM116
Fig. EM-42 Valve guide hole




Fig. EM-43 Reaming valve guide

4. Ream the bore with valve guide pressed in, using special tool "Valve Guide Reamer Set ST1103S000."

Reaming bore:

8.000 to 8.018 mm
(0.3150 to 0.3157 in)

5. Correct valve seat surface with new valve guide as the axis.

Valve seat inserts

Check valve seat inserts for any evidence of pitting at valve contact surface, and reseal or replace if worn out excessively.

Valve seat insert of 0.5 mm (0.0197 in) oversize is available for service in this L series engine.



EM118
Fig. EM-44 Correcting valve seat


		L14, L16 and L18
Guide hole inner diameter "a" mm (in)	For standard valve guide	11.985 to 11.996 (0.4719 to 0.4723)
	For service valve guide	12.185 to 12.196 (0.4797 to 0.4802)

3. Press new valve guide into valve carefully so that it will fit smoothly after heating cylinder head to 150° to 200°C (302° to 392°F).

Valve guide of 0.2 mm (0.0079 in) oversize diameter is available for service.

		L14, L16 and L18
Interference fit of valve guide to guide hole mm (in)		0.027 to 0.049 (0.0011 to 0.0019)

ENGINE MECHANICAL



EM139

Fig. EM-45 Standard valve seat dimensions

Cylinder head recess diameter

Unit: mm (in)

		L14	L16 and L18
Intake	For standard insert	41.000 to 41.016 (1.6142 to 1.6148)	45.000 to 45.016 (1.7717 to 1.7723)
	For service insert	41.500 to 41.516 (1.6339 to 1.6345)	45.500 to 45.516 (1.7913 to 1.7920)
		L14, L16 and L18	
Exhaust	For standard insert	37.000 to 37.016 (1.4567 to 1.4573)	
	For service insert	37.500 to 37.516 (1.4764 to 1.4770)	

Interference fit mm (in)	Intake	0.081 to 0.113 (0.0032 to 0.0044)
	Exhaust	0.064 to 0.096 (0.0025 to 0.0038)

Replacing valve seat insert

1. Old insert can be removed by boring out until it collapses. The machine depth stop should be set so that boring cannot continue beyond the bottom face of the insert recess in cylinder head.
2. Select a suitable valve seat insert and check its outside diameter.
3. Machine cylinder head recess to the concentric circles to valve guide center so that insert will have the correct fit.
4. Ream the cylinder head recess at room temperature.
5. Heat cylinder head to a temperature of 150° to 200°C (302° to 392°F).
6. Fit insert ensuring that it beds on the bottom face of its recess, and caulk more than 4 points.
7. Valve seats newly fitted should be cut or ground at the specified dimensions as shown in Figure EM-46.
8. Apply small amount of fine grinding compound to valve contacting face and put valve into guide. Lap valve against its seat until proper valve seating is obtained. Remove valve and then clean valve and valve seat.

ENGINE MECHANICAL

	L14	L16 and L18
Intake		
Unit: mm (in)		
	L14 and L16	L18
Exhaust		
Unit: mm (in)		

EM121

Fig. EM-46 Valve seat dimensions

CAMSHAFT AND CAMSHAFT BEARING

Camshaft bearing clearance


1. Measure the inside diameter of camshaft bearing with an inside dial gauge and the outside diameter of camshaft journal with a micrometer. If wear is found inside bracket, replace cylinder head assembly.

Camshaft journal to bearing clearance

	Standard	Wear limit
Oil clearance mm (in)	0.038 to 0.067 (0.0015 to 0.0026)	0.1 (0.0039)
Inner diameter of cam shaft bearing mm (in)	48.000 to 48.016 (1.8898 to 1.8904)	—


Valve timing

This diagram will apply to all cylinders. If any valve is found "out of specifications," one possibility is that cam lobe is worn or damaged, calling for replacement of camshaft.



EM130

Fig. EM-47 Checking camshaft bearing



EM120

Fig. EM-48 Valve timing diagram

ENGINE MECHANICAL

Unit: degree

Camshaft alignment

1. Check camshaft, camshaft journal and cam surface for bend, wear or damage. If defects are beyond the limits, replace the affected parts.

2. A bend valve is one-half of the reading obtained when camshaft is turned one full revolution with a dial gauge to 2nd and 3rd journals.




Fig. EM-49 Checking camshaft bend

		a	b	c	d	e	f
L14		240	232	8	44	18	50
L16	Single	248	240	12	48	18	54
	Twin	248	248	16	52	18	54
L18	Single	248	240	12	48	18	54
	Twin	248	248	16	52	18	54

	Standard	Bend limit
Camshaft bend mm (in)	0.02 (0.0008)	0.05 (0.0020)

		Single carb.		Twin carb.
		L14	L16 and L18	L16 and L18
Standard height of cam mm (in)	Intake	39.95 to 40.00 (1.5728 to 1.5748)	39.95 to 40.00 (1.5728 to 1.5748)	40.30 to 40.35 (1.5866 to 1.5886)
	Exhaust		40.30 to 40.35 (1.5866 to 1.5886)	
Wear limit of cam height mm (in)		0.25 (0.0098)		
Allowable difference in diameter between max. worn and min. worn parts of camshaft journal mm (in)		0.05 (0.0020)		
Maximum tolerance in journal diameter mm (in)		0.1 (0.0039)		
Camshaft end play mm (in)		0.08 to 0.38 (0.0031 to 0.0150)		

CYLINDER BLOCK

1. Visually check cylinder block for cracks or flaws.

2. Measure the top of cylinder block (cylinder head mating face) for warp. If warp exceeds the limit, correct it.

	Standard	Maximum tolerance
Surface flatness mm (in)	less than 0.05 (0.0020)	0.10 (0.0039)

ENGINE MECHANICAL




Fig. EM-50 Checking cylinder block surface

3. Using a bore gauge measure cylinder bore for out-of-round or taper. If, out-of-round or taper is excessive, rebore the cylinder walls by means of a boring machine. Measurement should be taken along bores for taper and around bores for out-of-round. See Figure EM-52.

Out-of-round X-Y
Taper A-B



Fig. EM-51 Measuring cylinder bore diameter

4. When wear, taper or out-of-round is minor and within the limit, remove the step at the topmost portion of cylinder using a ridge reamer or other similar tool.

How to measure cylinder bore

A bore gauge is used. Measure

cylinder bore at top, middle and bottom positions toward A and B directions as shown in Figure EM-52 and record the measured values.




Fig. EM-52 Cylinder bore measuring positions

		Standard		Wear limit
		L14, L16	L18	
Cylinder bore mm (in)	Inner diameter	83.000 to 83.050 (3.2677 to 3.2697)	85.000 to 85.050 (3.3465 to 3.3484)	0.2 (0.0079)
	Out-of-round	0.015 (0.0006)		/
	Taper	0.015 (0.0006)		
Difference cylinder bore mm (in)		0.05 (0.0020)		0.2 (0.0079)

Oversize pistons specifications


	L14 and L16	L18
Piston diameter mm (in)		
Standard	82.985 to 83.035 (3.2671 to 3.2691)	84.985 to 85.035 (3.3459 to 3.3478)
0.25 (0.0098) Oversize	83.215 to 83.265 (3.2762 to 3.2781)	
0.50 (0.0197) Oversize	83.465 to 83.515 (3.2860 to 3.2880)	85.465 to 85.515 (3.3648 to 3.3667)
0.75 (0.0295) Oversize	83.715 to 83.765 (3.2959 to 3.2978)	
1.00 (0.0394) over size	83.965 to 84.015 (3.3057 to 3.3077)	86.965 to 86.015 (3.4238 to 3.3864)
1.25 (0.0492) over size	84.465 to 84.515 (3.3254 to 3.3274)	

Cylinder boring

1. When any of cylinders needs boring, all other cylinders must also be bored at the same time.
2. Determine piston oversize according to the amount of wear of cylinder.


ENGINE MECHANICAL

3. The size to which cylinders must be honed is determined by adding to the largest piston diameter (at piston skirt in thrust direction) piston-to-cylinder clearance.



EM126

Fig. EM-53 Measuring piston diameter



about 20 mm (0.7874 in)

EM127

Fig. EM-54 Measuring piston skirt diameter

Rebored size calculation

$$D = A + B - C = A + [0.005 \text{ to } 0.025 \text{ mm (0.0002 to 0.0010 in)}]$$

Where,

D: Honed diameter

A: Skirt diameter as measured

B: Piston-to-wall clearance

C: Machining allowance (0.02 mm) (0.0008 in)

Note: To prevent strain due to cutting heat, bore the cylinders in the order of 2-4-1-3.

4. Do not cut too much out of cylinder bore at a time, but cut 0.05 mm (0.0020 in) or so at a time.

5. Measurement of cylinder bore just machined requires the utmost care since it is expanded by cutting heat.

6. As a final step, cylinders should be honed to size.

7. Measure the finished cylinder bore for out-of-round or tapered part.

8. Measure piston to cylinder clearance.

This clearance can be checked easily by using a feeler gauge and a

spring balance hooked on feeler gauge, measuring the amount of force required to pull out gauge from between piston and cylinder.

Notes:

- When measuring the clearance, slowly pull the feeler gauge straight upward.
- It is recommended that piston and cylinder be heated to 20°C (68°F).



EM128

Fig. EM-55 Measuring piston fit in cylinder

		L14, L16 and L18
Standard clearance	mm (in)	0.025 to 0.045 (0.0010 to 0.0018)
Feeler gauge	mm (in)	0.04 (0.0016)
Extracting force	kg (lb)	0.2 to 1.5 (0.44 to 3.31)

Note: If cylinder bore has worn beyond the wear limit, use cylinder liner.

Undersize cylinder liners are available for service.

Interference fit of cylinder liner in cylinder block should be 0.08 to 0.09 mm (0.0031 to 0.0035 in).

Cylinder liner for service

Unit: mm (in)

	L14, L16 and L18	
	Outside diameter	Inner diameter
4.0 (0.1575) Undersize	87.00 to 87.05 (3.4252 to 3.4272)	82.45 to 82.60 (3.2461 to 3.2520)
4.5 (0.1772) Undersize	87.500 to 87.55 (3.4449 to 3.4468)	
5.0 (0.1969) Undersize	88.00 to 88.05 (3.4646 to 3.4665)	

ENGINE MECHANICAL

PISTONS, PISTON PINS AND PISTON RINGS


1. Remove carbon from piston and ring grooves with a carbon scraper and a curved steel wire. The wire will be useful in cleaning bottom land of ring groove. Clean out oil slots in bottom land of oil ring groove.

2. Check for damage, scratches and wear. Replace if such a defect is detected.

3. Measure the side clearance of rings in ring grooves as each ring is installed. Clearance with new pistons and rings should be as follows.


4. Push ring into cylinder with a piston so as to place it squarely in cylinder; measure ring gap with a feeler gauge.

Ring should be placed to diameter at upper or lower limit of ring travel.



EM129

Fig. EM-56 Measuring piston ring side clearance



EM130

Fig. EM-57 Measuring ring gap

Notes:

- a. When piston ring only is to be replaced, without cylinder bore being corrected, measure the gap at the bottom of cylinder where the wear is minor.
- b. Oversize piston rings are available for service. [0.5 mm (0.0197 in), 1.0 mm (0.0394 in) oversize]

Side clearance

Unit: mm (in)

	Standard			Wear limit
	L14	L16	L18	
Top ring	0.040 to 0.080 (0.0016 to 0.0031)	0.040 to 0.080 (0.0016 to 0.0031)	0.045 to 0.08 (0.0018 to 0.0031)	0.1 (0.0039)
Second ring	0.030 to 0.070 (0.0012 to 0.0028)	0.030 to 0.070 (0.0012 to 0.0028)	0.030 to 0.070 (0.0012 to 0.0028)	
Oil ring	—	—	—	—

Ring gap

Unit: mm (in)

	Standard			Wear limit
	L14	L16	L18	
Top ring	0.23 to 0.38 (0.0091 to 0.0150)	0.25 to 0.40 (0.0098 to 0.0157)	0.35 to 0.55 (0.0138 to 0.0217)	1.0 (0.0394)
Second ring	0.15 to 0.30 (0.0059 to 0.0118)	0.15 to 0.30 (0.0059 to 0.0118)	0.30 to 0.50 (0.0118 to 0.0197)	
Oil ring	0.30 to 0.90 (0.0118 to 0.0354)	0.3 to 0.9 (0.0118 to 0.0354)	0.3 to 0.9 (0.118 to 0.0354)	

ENGINE MECHANICAL

5. Measure piston pin hole in relation to the outer diameter of pin. If wear exceeds the limit, replace such piston pin together with piston on which it is installed.

6. Determine the fitting of piston

pin into piston pin hole to such an extent that it can be finger pressed at room temperature. This piston pin must be a tight press fit into connecting rod.

CONNECTING ROD

1. If a connecting rod has any flaw on both sides of the thrust face and the large end, correct or replace it.




Fig. EM-58 Piston pin fitting




Fig. EM-59 Measuring piston pin diameter




Fig. EM-60 Checking rod alignment

2. Check connecting rod for bend or torsion using a connecting rod aligner. If bend or torsion exceeds the limit, correct or replace.

3. When replacing connecting rod, select rod so that weight difference between new and old ones is within 5 gr (0.18 oz) for the L14 engine, 7 gr (0.25 oz) for the L16, L18 engines.

4. Install connecting rods with bearings on to corresponding crank pins and measure the thrust clearance. If the measured value exceeds the limit, replace such connecting rod.

Unit: mm (in)

	L14, L16 and L18
Piston pin outside diameter	20.995 to 21.000 (0.8266 to 0.8268)
Piston pin hole diameter	21.000 to 21.005 (0.82677 to 0.82697)
Piston pin to piston clearance	0.001 to 0.013 (0.00004 to 0.00051)
Interference fit of piston pin to connecting rod	0.015 to 0.033 (0.00059 to 0.00130)

	Model	Standard	Maximum
Connecting rod bend or torsion (per 100 mm or 3.94 in length) mm (in)	L14	0.025 (0.0010)	0.05 (0.0020)
	L16	0.03 (0.0012)	
	L18		





Fig. EM-61 Checking big end play

L14, L16 and L18	Standard	Maximum
Big end play mm (in)	0.2 to 0.3 (0.0079 to 0.0118)	0.6 (0.0118)

CRANKSHAFT

1. Whenever crankshaft is removed from engine, it should be cleaned thoroughly in a suitable solvent. After cleaning check crankshaft journal and crank pin for score, bias wear or cracks. Repair or replace as required. If defects are minor, dress with fine crocus cloth.

ENGINE MECHANICAL



2. Check with a micrometer journals and crank pins for taper and out-of-round. Measurement should be taken along journals for taper and around journals for out-of-round. See Figure EM-62 for detail information.

Out-of-round X-Y
Taper A-B

If journals or crank pins are tapered or out-of-round beyond limits, replace with a new shaft.

3. Crankshaft can be checked for bend by placing it on V-blocks and using a dial gauge with its indicating finger resting on center journal.

Note: When measuring bend, use a dial gauge. Bend value is a half of the reading obtained when crankshaft is turned one full revolution with a dial gauge attached to its center journal.

4. After regrinding crankshaft, finish it to the necessary size indicated in the list on page EM-21 by using an adequate undersize bearing according to the extent of required repair.

5. Install crankshaft in cylinder block and measure crankshaft free end play.





Fig. EM-64 Checking crankshaft bend




Fig. EM-65 Checking crankshaft end play

L14, L16 and L18	Standard	Maximum
Taper and out-of-round of journal and crank pin mm (in)	less than 0.01 (0.0004)	0.03 (0.0012)

L14, L16 and L18	Standard	Maximum
Crankshaft bend mm (in)	less than 0.05 (0.0020)	0.10 (0.0039)

ENGINE MECHANICAL

	Standard	Wear limit
Crankshaft free end play mm (in)	0.05 to 0.18 (0.0020 to 0.0071)	0.3 (0.0118)

6. At the rear end of crankshaft, check crankshaft pilot bushing for wear or damage. Replace it, if any defect is detected.

To replace crankshaft rear pilot bushing proceed as follows:

(1) Pull out bushing using special tool "Pilot Bushing Puller ST16610001."




Fig. EM-66 Pulling out pilot bushing

(2) Before installing a new bushing, thoroughly clean bushing hole. Press fit bushing so that its height above flange end is 4.5 to 5.0 mm (0.18 to 0.20 in). Do not oil bushing.




Fig. EM-67 Press-fitting new pilot bushing

BUSHING AND BEARING Measurement of main bearing clearance

1. Thoroughly clean all bearings check for scratches, melt, score or wear.

Replace bearings, if any defect is detected.

2. Crankshaft journals and bearings should be clean and free from dust and dirt before oil clearance is measured.




Fig. EM-68 Plastigage

3. Set main bearing on cap block.

4. Cut a plastigage to the width of bearing and place it in parallel with crank pin, getting clear of the oil hole. Install cap on the assembly and tighten them together to the specified torque.

Tightening torque:
4.5 to 5.5 kg-m
(33 to 40 ft-lb)

Note: Do not turn crankshaft while the plastigage is being inserted.

5. Remove cap, and compare width of the plastigage at its widest part with the scale printed in the plastigage envelope.




Fig. EM-69 Measuring bearing clearance

Measurement of connecting rod bearing clearance

1. Measure connecting rod bearing clearance in the same manner as above.

Tightening torque:
3.2 to 3.8 kg-m
(23 to 28 ft-lb)
for L16
4.5 to 5.5 kg-m
(33 to 40 ft-lb)
for L14 and L18

Bearing oil clearance

L14, L16 and L18	Standard	Wear limit
Main bearing clearance mm (in)	0.020 to 0.062 (0.0008 to 0.0024)	0.12 (0.0047)
Connecting rod bearing clearance mm (in)	0.025 to 0.055 (0.0010 to 0.0022)	0.12 (0.0047)

2. If clearance exceeds the specified valve, replace bearing with an under-size bearing and grind the crankshaft journal adequately.

Fitting bearings

Bearings are manufactured with crush to make bearings snug down into its bore. To measure this, proceed as follows:




Fig. EM-70 Checking bearing crush

ENGINE MECHANICAL

1. Set main bearing in main bearing cap recess or cylinder block bearing recess correctly.
2. Lock the one side end of bearing and press the other side until the bearing back surface touches the recess.
3. Then, measure bearing crush "H" with a feeler gauge. See Figure EM-70. The standard bearing crush value is listed below.
4. Handle connecting rod bearing in the same manner as above.

Bearing crush

		L14, L16 and L18
All main bearing	mm (in)	0 to 0.03 (0 to 0.0012)
All connecting rod bearing	mm (in)	0.015 to 0.045 (0.0006 to 0.0018)

Main bearing undersize

Unit: mm (in)

L14, L16 and L18	Bearing top thickness	Crank journal diameter
STD	1.822 to 1.835 (0.0717 to 0.0722)	54.942 to 54.955 (2.1631 to 2.1636)
0.25 (0.0098) Undersize	1.947 to 1.960 (0.0767 to 0.0772)	54.692 to 54.705 (2.1532 to 2.1537)
0.50 (0.0197) Undersize	2.072 to 2.085 (0.0816 to 0.0821)	54.442 to 54.455 (2.1434 to 2.1439)
0.75 (0.0295) Undersize	2.197 to 2.210 (0.0865 to 0.0870)	54.192 to 54.205 (2.1335 to 2.1341)
1.00 (0.0394) Undersize	2.322 to 2.335 (0.0914 to 0.0919)	53.942 to 53.955 (2.1237 to 2.1242)

Connecting rod bearing undersize

Unit: mm (in)

	Bearing top thickness	Crank pin diameter
	L14, L16 and L18	L14, L16 and L18
STD	1.493 to 1.506 (0.0588 to 0.0593)	49.961 to 49.974 (1.9670 to 1.9675)
0.6 (0.0236) Undersize	1.523 to 1.536 (0.0600 to 0.0605)	49.901 to 49.914 (1.9646 to 1.9651)
0.12 (0.0047) Undersize	1.553 to 1.566 (0.0611 to 0.0617)	49.841 to 49.854 (1.9622 to 1.9628)
0.25 (0.0098) Undersize	1.618 to 1.631 (0.0637 to 0.0642)	49.711 to 49.724 (1.9571 to 1.9576)
0.50 (0.0197) Undersize	1.743 to 1.756 (0.0686 to 0.0691)	49.461 to 49.474 (1.9473 to 1.9478)
0.75 (0.0295) Undersize	1.868 to 1.881 (0.00735 to 0.0741)	49.211 to 49.224 (1.9374 to 1.9379)
1.00 (0.0394) Undersize	1.993 to 2.006 (0.0785 to 0.0790)	48.961 to 48.974 (1.9276 to 1.9281)



Fig. EM-81 Installing valve

Notes:

- a. Check whether the valve face is free from foreign matters.
- b. On the L14 engine, the intake valve springs alone are of a single type. Other engines use double type valve springs.
2. Valve rocker pivot assembly
Screw valve rocker pivots joined with lock nuts into pivot bushing.
3. Camshaft assembly
Set locating plate and install camshaft in cylinder head carefully. Do not damage the bearing inside. The oblong groove of locating plate must be directed toward the front side of engine.
4. Install camshaft sprocket on camshaft and tighten it together with fuel pump cam to the specified torque.

Tightening torque:
12 to 16 kg-m
(86 to 116 ft-lb)

At this time, check camshaft end play.




Fig. EM-82 Installing camshaft sprocket

5. Install rocker arms by pressing down valve springs with a screwdriver.
6. Install valve rocker springs.
7. After assembling cylinder head, turn camshaft until No. 1 piston is at T.D.C. on its compression stroke.




Fig. EM-83 Assembling cylinder head

PISTON AND CONNECTING ROD

1. Assemble pistons, piston pins and connecting rods to the designated cylinder.




Fig. EM-84 Installing piston pin



Fig. EM-85 Assembling piston and connecting rod

Notes:

- a. Piston is pressed into connecting rod, and fitting force is from 0.5 to 1.5 tons and the aid of special tool "Piston Pin Press Stand ST13030001," is necessary. When pressing piston pin in connecting rod, apply engine oil to pin and small end of connecting rod.
- b. Arrange so that oil jet of connecting rod big end is directed toward the right side of cylinder block.
- c. Be sure to install piston in cylinders with notch mark of piston head toward the front of engine.

2. Install piston rings
Install top and second rings in right position, with the marked side up.
 - a. Top ring is chromium-plated on liner contacting face.
 - b. Second ring has larger taper surface than top ring.
 - c. In the combined oil ring, upper rail is the same as lower one.




Fig. EM-86 Installing piston ring

3. Fix bearings on connecting rod and connecting rod cap.

Note: Clean the back side of bearing carefully.

ENGINE ASSEMBLY

1. The first step in engine assembly is to bolt special tool "Engine Attachment ST05260001" to right hand side of cylinder block. In succession, install block in another special tool "Engine Stand ST0501S000" with engine bottom up.
2. Set main bearings at the proper portion of cylinder block.




Fig. EM-87 Main bearings

3. Install baffle plate including cylinder block net.

Notes:

- a. Only center bearing (No. 3) is a flanged type.
- b. All inter-bearings (No. 2 and No. 4) are the same type.
- c. Front bearing (No. 1) is also the

ENGINE MECHANICAL

same type as rear bearing (No. 5). The difference is that an oil hole is provided in the front bearing.

- d. All bearings except No. 1 bearing have a interchange ability between upper and lower bearings.

4. Apply engine oil to main bearing surfaces on both sides of cylinder block and cap.

Install crankshaft.

5. Install main bearing cap and tighten bolts to specified torque.

Tightening torque:
4.5 to 5.5 kg-m
(32.5 to 39.8 ft-lb)

Notes:

- Apply sealant to each side of rear main bearing cap and each corner of cylinder block as shown in Figure EM79.
- Arrange the parts so that the arrow mark on bearing cap faces toward the front of engine.
- Prior to tightening bearing cap bolts, place bearing cap in proper position by shifting crankshaft in the axial direction.
- Tighten bearing cap bolts gradually in separating two to three stages and outwardly from center bearing in the sequence as shown in Figure EM-88.
- After securing bearing cap bolts, ascertain that crankshaft turn smoothly.




Fig. EM-88 Torque sequence of cap bolts

6. Make sure that there exists proper end play at crankshaft.

Crankshaft end play:
0.05 to 0.18 mm
(0.0020 to 0.0071 in)



Fig. EM-89 Checking crankshaft end play

7. Install side oil seals into rear main bearing cap. Prior to installing, apply sealant to these seals.



Fig. EM-90 Driving side oil seal

8. Install rear oil seal using special tool "Crankshaft Rear Oil Seal Drift ST15310000." Apply a lithium grease to sealing lip of oil seal.




Fig. EM-91 Installing rear oil seal

9. Install rear end plate.
10. Install flywheel securely, and tighten bolts to specified torque.

Tightening torque:
14 to 16 kg-m
(101 to 116 ft-lb)

11. Insert pistons in corresponding cylinder using special tool "Piston

Ring Compressor EM03470000."




Fig. EM-92 Installing piston-rod assembly

Notes:

- Apply engine oil to sliding parts.
- Arrange so that the notch mark on piston head faces to the front of engine.
- Install piston rings at 180° to each other, avoiding their fit in the thrust and piston pin directions.




Fig. EM-93 Piston ring direction

12. Install connecting rod caps.

Tightening torque:
3.2 to 3.8 kg-m
(23 to 28 ft-lb)
for L16
4.5 to 5.5 kg-m
(33 to 40 ft-lb)
for L14 and L18




Fig. EM-94 Installing connecting rod cap

Note: Arrange connecting rods and connecting rod caps so that the cylinder numbers face in the same direction.

ENGINE MECHANICAL

13. Make sure that there exists proper end play at connecting rod big end.




Fig. EM-95 Checking big end play

Big end play:

0.2 to 0.3 mm
(0.0079 to 0.0118 in)

14. Install cylinder head assembly.




Fig. EM-96 Tightening sequence

(1) Thoroughly clean cylinder block and head surface.

Do not apply sealant to any other part of cylinder block and head surface.

Do not apply it to any other part of cylinder block and head surface.

(2) Turn crankshaft until No. 1 piston is at T.D.C. on its compression stroke.

(3) Make sure that camshaft sprocket location notch and plate oblong groove are aligned at their correct positions.

(4) When installing cylinder head, make sure that all valves are apart from head of pistons.

(5) Do not rotate crankshaft and camshaft separately, because valves will hit head of pistons.

(6) Temporarily tighten two bolts (1, 2) shown in Figure EM-96.

Tightening torque:

2 kg-m (14.5 ft-lb)

15. Install crankshaft sprocket and distributor drive gear and fit oil

thrower.

Note: Make sure that the mating marks of crankshaft sprocket faces to the front.

16. Install timing chain.

Notes:

a. Make sure that crankshaft and camshaft keys point upwards.




Fig. EM-97 Installing timing chain

b. Set timing chain by making its mating marks align with those of crankshaft sprocket and camshaft sprocket at the right hand side. There are forty-two chain links between two mating marks of timing chain.

c. No. 2 hole is factory adjusted. When chain stretches excessively, adjust camshaft sprocket at No. 3 hole.

d. Use a set of timing marks and location hole numbers.

17. Install chain guide to cylinder block.

18. Install chain tensioner.

Note: Adjust the protrusion of chain tensioner spindle to 0 mm (0 in).




Fig. EM-98 Installing chain tensioner

19. Press new oil seal in front cover. (front cover oil seal should be replaced when front cover is disassembled.)

20. Install front cover with gasket in place.




Fig. EM-99 Installing front cover

Notes:

a. Apply sealant to front side of cylinder block and front cover gasket as shown in Figure EM-78.

b. Apply sealant only to the top of front cover as shown in Figure EM-78.

c. Install front cover with head gasket in place.

d. Check the height difference between cylinder block upper face and front cover upper face. Its difference must be less than 0.15 mm (0.0059 in).

e. Note that different types of bolts are used.

f. Apply a lithium grease to sealing lip of oil seal.



Fig. EM-100 Front cover bolts

Tightening torque:

Size M8

(0.315 in)

1.0 to 1.6 kg-m
(7.2 to 11.6 ft-lb)

Size M6

(0.236 in)

0.4 to 0.8 kg-m
(2.9 to 5.8 ft-lb)

21. Install crankshaft pulley and water pump, then set No. 1 piston at T.D.C. on its compression stroke.

Crankshaft pulley nut

tightening torque:

12 to 16 kg-m

(86.8 to 115.7 ft-lb)

ENGINE MECHANICAL




Fig. EM-101 Installing crankshaft pulley and water pump


22. Finally tighten head bolts to the specified torque in three steps according to the tightening sequence as shown in Figure EM-96.

Note that two types of bolts are used.

Special tool "Cylinder Head Bolt Wrench ST1012000."

Tightening torque:

- 1st turn
4.0 kg-m (28.9 ft-lb)
- 2nd turn
6.0 kg-m (43.4 ft-lb)
- 3rd turn
6.5 to 8.5 kg-m
(47.0 to 61.5 ft-lb)



EM176

Fig. EM-102 Cylinder head bolts

Notes:

- a. Be sure to tighten two small bolts
- b. After engine has been operated for several minutes; if necessary, retighten.

23. Install oil pump and distributor driving spindle into front cover.

Tightening torque:

- 1.1 to 1.5 kg-m
(8.0 to 10.8 ft-lb)

Notes:


- a. Assemble oil pump and drive spindle, making driving spindle mark face to oil pump hole.

- b. Install oil pump together with drive spindle so that the projection on its top is located in 11:25 a.m. position, at this time, the smaller bow-shape will be placed toward the front.
- c. Do not forget to install gasket.



EL009

Fig. EM-103 Setting distributor driving spindle



EL011

Fig. EM-104 Installing oil pump

24. Install fuel pump, water inlet elbow and front engine slinger in their positions.

Fuel pump tightening torque:
1.2 to 1.8 kg-m
(8.7 to 13.0 ft-lb)

Note: Do not forget to install fuel pump spacer and packings inserted between spacer and block, fuel pump.

25. Install oil strainer, oil pan gasket and oil pan.

Notes:

- a. Apply sealant to the step portions at four mating surfaces as shown in Figure EM-80.
- b. Tightening oil pan should be performed in criss-cross pattern and finally to 0.6 to 0.9 kg-m (4.3 to 6.5 ft-lb) torque.

26. Adjust valve clearance to the specified dimensions.

Special tool "Pivot Adjuster ST10640001."

Tightening torque:

- 5.0 to 6.0 kg-m
(36.2 to 43.4 ft-lb)

Notes:

- a. First set clearance to the cold specifications.




Fig. EM-105 Adjusting valve clearance

- b. After engine has been assembled, run it for at least several minutes, finally adjust the clearance to the warm specifications.

27. Install rear engine slinger, exhaust manifold and intake manifold.

Tightening torque:

- 0.8 to 1.2 kg-m
(5.8 to 8.7 ft-lb)

			L14, L16 and L18
Valve clearance mm (in)	Cold	Intake	0.2 (0.0079)
		Exhaust	0.25 (0.0098)
	Warm	Intake	0.25 (0.0098)
		Exhaust	0.30 (0.0118)

ENGINE MECHANICAL




Fig. EM-106 Installing manifolds

28. Install distributor assembly.
29. Install carburetor assembly and carburetor insulator with stamp facing upward. Tightening torque 3.6 to 7.2 kg-m (26 to 52 ft-lb).
30. Install fuel pipes and vacuum hose.

All pipes and hoses should be clamped securely, being careful not to allow them to interfere with adjacent or surrounding parts.

31. Install thermostat housing, thermostat and water outlet in their positions. Do not forget to install gasket.

32. Install rocker cover.

Note: Bond gasket to rocker cover using sealant. Then, install rocker cover to cylinder head.

33. Install spark plugs.
34. Connect distributor to plug high tension lead wire.
35. Install engine mount bracket on left hand side.
36. Install clutch assembly.

Special tool "Clutch Aligning Bar ST20600000."

Tightening torque:

1.2 to 2.2 kg-m
(8.7 to 15.9 ft-lb)



Fig. EM-107 Installing clutch assembly

37. Using an overhead hoist and lifting cable, hoist engine up a way

from engine stand and then down onto engine carrier. Install alternator bracket, adjusting bar, alternator, fan pulley, fan and fan belt in this order. Then, check to be sure that deflection of fan belt is held within 8 to 12 mm (0.315 to 0.472 in) when thumb pressure is applied midway between pulleys (A pressed force is about 10 kg (22.0 lb)).




Fig. EM-108 Fan belt tension

38. Install engine mount bracket (right hand), oil filter, oil pressure switch, oil level gauge and water drain plug. When installing an oil filter, fasten it on cylinder block by hand.

Note: Do not overtighten filter, or oil leakage may occur.

39. Power engine oil up to specified level.

SERVICE DATA AND SPECIFICATIONS

GENERAL SPECIFICATIONS

Model	L14	L16		L18	
Cylinder arrangement		4, in line			
Displacement cc (cu in)	1,428 (87.14)	1,595 (62.80)		1,770 (108.01)	
Bore and stroke mm (in)	83 x 66.0 (3.2677 x 2.5984)	83 x 73.7 (3.2677 x 2.9016)		85 x 78 (3.3465 x 3.0709)	
Valve arrangement		O.H.C.			
Firing order		1-3-4-2			
	Single carb.	Single carb.	Twin carb.	Single carb.	Twin carb.
Engine idle rpm					
M/T	600	600	650	600	650
A/T	650	650	700	650	700
Compression ratio	9.0	8.5	9.5	8.5	9.5
Engine idle manifold mmHg (inHg) at idle rpm	450 (17.7)	450 (17.7)	400 (15.7)	450 (17.7)	400 (15.7)
Oil pressure (Warm at 2,000 rpm) kg/cm ² (psi)		3.5 to 4.0 (49.8 to 56.9)			

M/T: Manual Transmission A/T: Automatic Transmission

ENGINE MECHANICAL

TIGHTENING TORQUE

Model	L14	L16	L18
Cylinder head bolts kg-m (ft-lb)	1st Turn 4.0 (28.9)	2nd Turn 6.0 (43.4)	3rd Turn 6.5 to 8.5 (47.0 to 61.5)
Connecting rod big end nuts kg-m (ft-lb)	4.5 to 5.5 (33 to 40)	3.2 to 3.8 (23 to 27)	4.5 to 5.5 (33 to 40)
Flywheel fixing bolts kg-m (ft-lb)		14 to 16 (101 to 116)	
Main bearing cap bolts kg-m (ft-lb)		4.5 to 5.5 (33 to 40)	
Camshaft sprocket bolt kg-m (ft-lb)		12 to 16 (86.8 to 116)	
Oil pan bolts kg-m (ft-lb)		0.6 to 0.9 (4.3 to 6.5)	
Oil pump bolts kg-m (ft-lb)		1.1 to 1.5 (8.0 to 10.8)	
Oil pan drain plug kg-m (ft-lb)		2.0 to 3.0 (14.5 to 21.7)	
Rocker pivot lock nuts kg-m (ft-lb)		5.0 to 6.0 (36.2 to 43.4)	
Camshaft locating plate bolts kg-m (ft-lb)		0.6 to 0.9 (4.3 to 6.5)	
Carburetor nuts kg-m (ft-lb)		3.6 to 7.2 (26 to 52)	
Manifold nuts kg-m (ft-lb)		0.8 to 1.2 (5.8 to 8.7)	
Fuel pump nuts kg-m (ft-lb)		1.2 to 1.8 (8.7 to 13.0)	
Crank pulley bolt kg-m (ft-lb)		12.0 to 16.0 (86.8 to 115.7)	

SPECIFICATIONS

Model	L14	L16	L18
a) Valve mechanism			
Valve clearance (Warm) mm (in)		In. 0.25 (0.0098) Ex. 0.30 (0.0118)	
Valve clearance (Cold) mm (in)		In. 0.20 (0.0079) Ex. 0.25 (0.0098)	
Valve head dia. mm (in)			
- Intake	38 (1.5361)	42 (1.6535)	42 (1.6535)
- Exhaust	33 (1.2992)	33 (1.2992)	35 (1.3780)
Valve stem dia. mm (in)			
- Intake		7.965 to 7.980 (0.3136 to 0.3142)	
- Exhaust		7.945 to 7.960 (0.3128 to 0.3134)	

ENGINE MECHANICAL

Model	L14	L16		L18	
Valve length mm (in)	—Intake 115.6 to 115.9 (4.551 to 4.562)			114.9 to 115.2 (4.524 to 4.535)	
				115.7 to 116.0 (4.555 to 4.567)	
—Exhaust	115.7 to 116.0 (4.555 to 4.567)			115.7 to 116.0 (4.555 to 4.567)	
Valve lift mm (in)	—Intake 10.0 (0.394)	Single carb.	Twin carb.	Single carb.	Twin carb.
		10.0 (0.394)	10.5 (0.413)	10.0 (0.394)	10.5 (0.413)
—Exhaust	10.0 (0.394)	10.5 (0.413)	10.5 (0.413)	10.5 (0.413)	10.5 (0.413)
Valve spring free length mm (in)	—Outer 49.0 (1.929)			49.98 (1.968)	
				44.85 (1.766)	
Intake	—Inner 49.98 (1.968)			49.98 (1.968)	
				44.85 (1.766)	
—Outer	44.85 (1.766)			44.85 (1.766)	
Exhaust	—Inner			Single carb. Twin carb.	
				30.0/47.7 29.5/49.0 (1.181/105.2) (1.161/108)	
—Outer	30.0/60.0 (1.181/132.3)			25.0/24.9 24.5/25.5 (0.984/54.9) (0.965/56.2)	
				29.5/49.0 29.5/49.0 (1.161/108) (1.161/108)	
Intake	—Inner			24.5/25.5 24.5/25.5 (0.965/56.2) (0.965/56.2)	
—Outer	30.0/47.7 (1.181/105.2)			40.0/21.3 (1.575/47.0)	
				35/12.3 (1.378/27.1)	
Exhaust	—Inner			40.0/21.3 (1.575/47.0)	
				35.0/12.3 (1.378/27.1)	
—Outer	25.0/24.9 (0.984/54.9)				
Valve spring assembled height (valve close) mm/kg (in/lb)	—Outer 40.0/28.4 (1.575/62.6)			40.0/21.3 (1.575/47.0)	
				35/12.3 (1.378/27.1)	
Intake	—Inner			40.0/21.3 (1.575/47.0)	
				35.0/12.3 (1.378/27.1)	
—Outer	40.0/28.4 (1.575/62.6)				
Exhaust	—Inner			40.0/21.3 (1.575/47.0)	
				35.0/12.3 (1.378/27.1)	
—Outer	40.0/28.4 (1.575/62.6)				
Valve spring effective turns mm (in)	—Outer 4.5			5.0	
				5.5	
Intake	—Inner —			5.0	
				5.5	
—Outer	4.5			5.0	
				5.5	
—Inner	—			5.0	
				5.5	

ENGINE MECHANICAL

Model	L14	L16	L18
Exhaust	-Outer		5.0
	-Inner		5.5
Valve spring wire dia. mm (in)			
Intake	-Outer	4.4 (0.1723)	4.0 (0.1575)
	-Inner	-	2.9 (0.1142)
Exhaust	-Outer		4.0 (0.1575)
	-Inner		2.9 (0.1142)
Valve spring coil dia. mm (in)			
Intake	-Outer	30.0 (1.181)	29.4 (1.150)
	-Inner	-	21.9 (0.862)
Exhaust	-Outer		29.4 (1.150)
	-Inner		21.9 (0.862)
Valve guide length mm (in)			
	-Intake		59.0 (2.323)
	-Exhaust		59.0 (2.323)
Valve guide height from head surface mm (in)			
			10.6 (0.417)
Valve guide inner dia. mm (in)			
	-Intake	8.000 to 8.018 (0.3150 to 0.3154)	
	-Exhaust	8.000 to 8.018 (0.3150 to 0.3154)	
Valve guide outer dia. mm (in)			
	-Intake	12.023 to 12.034 (0.4733 to 0.4738)	
	-Exhaust	12.023 to 12.034 (0.4733 to 0.4738)	
Valve guide to stem clearance mm (in)			
	-Intake	0.020 to 0.053 (0.0008 to 0.0021)	

ENGINE MECHANICAL

Model	L14	L16	L18	
-Exhaust		0.040 to 0.073 (0.0016 to 0.0029)		
Valve seat width mm (in)				
-Intake	1.8 (1.1024)		1.4 (0.0551)	
-Exhaust	1.7 (1.0630)		1.3 (0.0512)	
Valve seat angle				
-Intake		45°		
-Exhaust		45°		
Valve seat interference fit mm (in)				
-Intake		0.081 to 0.113 (0.0032 to 0.0044)		
-Exhaust		0.064 to 0.096 (0.0025 to 0.0038)		
Valve guide interference fit mm (in)				
		0.027 to 0.049 (0.011 to 0.0019)		
b) Camshaft and timing chain				
Camshaft end play mm (in)		0.08 to 0.38 (0.0031 to 0.0150)		
	Single carb.	Single carb.	Twin carb.	Single carb. Twin carb.
Camshaft robe lift mm (in)				
-Intake		6.65 (0.2618)	7.00 (0.2753)	6.65 (0.2618) 7.00 (0.2753)
-Exhaust	6.65 (0.2618)	7.00 (0.2753)	7.00 (0.2753)	7.00 (0.2753)
Camshaft journal dia. mm (in)				
-1st		47.949 to 47.962 (1.8877 to 1.8883)		
-2nd		47.949 to 47.962 (1.8877 to 1.8883)		
-3rd		47.949 to 47.962 (1.8877 to 1.8883)		
-4th		47.949 to 47.962 (1.8877 to 1.8883)		
Camshaft bend mm (in)		0.02 (0.0007)		
Camshaft journal to bearing clearance mm (in)		0.038 to 0.067 (0.0015 to 0.0026)		
Camshaft bearing inner dia. mm (in)				
-1st		48.000 to 48.016 (1.8898 to 1.8904)		
-2nd		48.000 to 48.016 (1.8894 to 1.8904)		
-3rd		48.000 to 48.016 (1.8898 to 1.8904)		
-4th		48.000 to 48.016 (1.8898 to 1.8904)		
c) Rocker arm lever ratio				
	1.5		1.45	

ENGINE MECHANICAL

Model	L14	L16	L18
d) Connecting rod			
Center distance mm (in)	136.6 (5.35)	133.0 (5.24)	130.35 (5.132)
Bearing material	F770		
Bearing thickness (S.T.D.) mm (in)	1.493 to 1.506 (0.0588 to 0.0593)		
Big end play mm (in)	0.20 to 0.30 (0.0079 to 0.0118)		
Connecting rod bearing clearance mm (in)	0.025 to 0.055 (0.0010 to 0.0022)		
Connecting rod bend or torsion (per 100 mm or 2.937 in) mm (in)	less than 0.025 (0.0010)	less than 0.03 (0.0012)	
e) Crankshaft and main bearing			
Journal dia. mm (in)	54.942 to 54.955 (2.1631 to 2.1636)		
Journal taper & out-of-round mm (in)	less than 0.01 (0.0004)		
Crankshaft free end play mm (in)	0.05 to 0.18 (0.0020 to 0.0071)		
Wear limit of dittoed play mm (in)	0.3 (0.0118)		
Crank pin dia. mm (in)	49.961 to 49.974 (1.9670 to 1.9675)		
Crank pin taper & out-of-round mm (in)	less than 0.01 (0.0004)		
Main bearing material	F770		
Main bearing thickness (S.T.D.)	1.822 to 1.835 (0.0717 to 0.0722)		
Main bearing clearance mm (in)	0.020 to 0.062 (0.0008 to 0.0024)		
Wear limit of dittoted clearance mm (in)	0.12 (0.0047)		
Crankshaft bend mm (in)	0.05 (0.0019)		
f) Pistion			
Piston dia. -STD mm (in)	82.985 to 83.035 (3.2671 to 3.2691)	84.985 to 85.035 (3.3459 to 3.3478)	
0.25 (0.0098) Oversize	83.215 to 83.265 (3.2762 to 3.2781)		

ENGINE MECHANICAL

Model	L14	L16	L18
0.50 (0.0197) Oversize		83.465 to 83.515 (3.2860 to 3.2880)	85.465 to 85.515 (3.3648 to 3.3667)
0.75 (0.0295) Oversize		83.715 to 83.765 (3.2959 to 3.2978)	
1.00 (0.0394) Oversize		83.965 to 84.015 (3.3057 to 3.3077)	86.965 to 86.015 (3.3844 to 3.3864)
1.25 (0.0492) Oversize		84.465 to 84.515 (3.3254 to 3.3274)	
Ellipse difference mm (in)		0.32 to 0.35 (0.013 to 0.014)	
Ring groove width			
-Top		2.0 (0.0787)	
-Second		2.0 (0.0787)	
-Oil		4.0 (0.1575)	
Piston to bore clearance mm (in)		0.025 to 0.045 (0.0010 to 0.0018)	
Piston pin hole off-set mm (in)		0.95 to 1.05 (0.0374 to 0.0413)	
g) Piston pin			
Pin dia. mm (in)		20.995 to 21.000 (0.8266 to 0.8268)	
Pin length mm (in)	72.00 to 72.25 (2.8346 to 2.8445)		72.25 to 73.00 (2.8445 to 2.8740)
Piston pin to piston clearance mm (in)		0.001 to 0.013 (0.00004 to (0.00051)	
Interference fit of piston pin to connecting rod bushing mm (in)		0.015 to 0.033 (0.0006 to 0.0013)	
h) Piston ring			
Ring height mm (in)			
-Top		1.977 (0.0778)	
-Second		1.977 (0.0778)	
Side clearance mm (in)			
-Top		0.040 to 0.080 (0.0016 to 0.0031)	0.045 to 0.080 (0.0018 to 0.0031)
-Second		0.030 to 0.070 (0.0012 to 0.0028)	
Ring gap mm (in)			
-Top	0.23 to 0.38 (0.0091 to 0.0150)	0.25 to 0.40 (0.0098 to 0.0157)	0.35 to 0.55 (0.0138 to 0.0217)
-Second	0.15 to 0.30 (0.0059 to 0.0118)	0.15 to 0.30 (0.0059 to 0.0118)	0.30 to 0.50 (0.0118 to 0.0197)
-Oil	0.30 to 0.90 (0.0118 to 0.0354)	0.30 to 0.90 (0.0118 to 0.0354)	0.30 to 0.90 (0.0118 to 0.0354)

ENGINE MECHANICAL

TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
I. Noisy engine Knocking of crankshaft and bearing.	Loose main bearing. Seized bearing. Bent crankshaft. Uneven wear of journal. Excessive crankshaft end play.	Replace. Replace. Repair or replace. Correct. Replace center bearing.
Piston and connecting rod knocking	Loose bearing. Seized bearing. Loose piston pin. Loose piston in cylinder. Broken piston ring. Improper connecting rod alignment.	Replace. Replace. Replace pin or bushing. Recondition cylinder. Replace. Realign.
Camshaft knocking	Loose bearing. Excessive axial play. Rough gear teeth. Broken cam gear.	Replace. Replace bearing thrust plate. Repair. Replace.
Timing chain noise	Improper chain tension. Worn and/or damaged chain. Worn sprocket. Worn and/or broken tension adjusting mechanism. Excessive camshaft and bearing clearance.	Adjust. Replace. Replace. Replace. Replace.
Camshaft and valve mechanism knocking	Improper valve clearance. Worn adjusting screw. Worn rocker face. Loose valve stem in guide. Weakened valve spring. Seized valve.	Adjust. Replace. Replace. Replace guide. Replace. Repair or replace.
Water pump knocking	Improper shaft end play. Broken impeller.	Replace. Replace.
II. Other mechanical troubles Sticked valve	Improper valve clearance. Insufficient clearance between valve stem and guide. Weakened or broken valve spring. Biting or damage of valve stem. Poor quality of fuel.	Adjust. Clean stem or ream guide. Replace. Replace or clean. Use good fuel.

ENGINE MECHANICAL

Condition	Probable cause	Corrective action
Seized valve seat	Improper valve clearance. Weakened valve spring. Thin valve head edge. Narrow valve seat. Overheat. Over speeding. Sticked valve guide.	Adjust. Replace. Replace valve. Reface. Repair or replace. Drive under proper speed. Repair.
Excessively worn cylinder and piston	Shortage of engine oil. Dirty engine oil. Poor quality of oil. Overheat. Wrong assembly of piston with connecting rod. Improper piston ring clearance. Broken piston ring. Dirty air cleaner. Mixture too rich. Engine over run. Sticked choke valve. Overchoking.	Add or replace oil. Clean crankcase, replace oil and oil filter element. Use right oil. Repair or replace. Repair or replace. Adjust. Replace. Clean. Adjust. Drive at proper speeds. Clean and adjust. Start correct way.
Defective connecting rod	Shortage of engine oil. Low oil pressure. Poor quality of engine oil. Rough surface of crankshaft. Clogged oil passage. Wear or eccentricity of bearing. Wrong assembly of bearing. Loose bearing. Connecting rod alignment incorrect.	Add oil. Correct. Use right oil. Grind and replace bearing Clean. Replace. Correct. Replace. Repair or replace.
Defective crankshaft bearing	Shortage of engine oil. Low oil pressure. Poor quality of engine oil. Crankshaft journal worn or out-of-round. Clogged oil passage in crankshaft. Wear or eccentricity of bearing. Wrong assembly of bearing. Eccentric crankshaft or bearing.	Add or replace. Correct. Use right oil. Repair. Clean. Replace. Correct. Replace.