ELECTRICAL SYSTEM

MA

EM

LC

EC

FE

GI

SECTION

MODIFICATION NOTICE:

Wiring diagrams have been changed.

CONTENTS

PRECAUTIONS	4
Supplemental Restraint System (SRS) "AIR	
BAG" and "SEAT BELT PRE-TENSIONER"	4
POWER SUPPLY ROUTING	5
Schematic	5
Wiring Diagram - POWER	6
BATTERY	13
Service Data and Specifications (SDS)	13
STARTING SYSTEM	14
Wiring Diagram - START -/M/T Models	14
Wiring Diagram - START -/LHD A/T Models	15
Wiring Diagram - START -/RHD A/T Models	16
Service Data and Specifications (SDS)	17
CHARGING SYSTEM	18
Wiring Diagram - CHARGE -/Gasoline Engine	18
Wiring Diagram - CHARGE -/Diesel Engine	19
Construction	20
Service Data and Specifications (SDS)	22
COMBINATION SWITCH	23
Check	23
HEADLAMP - Conventional Type	25
Wiring Diagram - H/LAMP -/LHD Models	25
Wiring Diagram - H/LAMP -/RHD Models	27
HEADLAMP - Daytime Light System	29
Wiring Diagram - DTRL	29
HEADLAMP - Dim-dip Lamp System	32
Wiring Diagram - DIMDIP	32
HEADLAMP - Headlamp Aiming Control	35
Wiring Diagram - H/AIM	35
PARKING, LICENSE AND TAIL LAMPS	37
Wiring Diagram - TAIL/L -/Except LHD Models	
for Europe	37
Wiring Diagram - TAIL/L -/LHD Models for	
Europe	39
STOP LAMP	41
Wiring Diagram - STOP/L	41

	C
BACK-UP LAMP42	øĿ
Wiring Diagram - BACK/L -/M/T Models42	
Wiring Diagram - BACK/L -/A/T Models43	MT
REAR FOG LAMP44	
Wiring Diagram - R/FOG -/LHD Models44	. —
Wiring Diagram - R/FOG -/RHD Models45	AT
TURN SIGNAL AND HAZARD WARNING LAMPS46	
Wiring Diagram - TURN -/Type-146	TC
Wiring Diagram - TURN -/Type-248	IP
ILLUMINATION	
Wiring Diagram - ILL -/LHD Models51	PD
Wiring Diagram - ILL -/RHD Models	
INTERIOR ROOM LAMP	
Wiring Diagram - ROOM/L	FA
SPOT LAMP	
Wiring Diagram - INT/L	— •
METER AND GAUGES	RA
Combination Meter57	
Wiring Diagram - METER -/Gasoline Engine with	DD
Tachometer	۵n
Wiring Diagram - METER -/Diesel Engine with	
Tachometer	ST
Wiring Diagram - METER -/Gasoline Engine	0.
without Tachometer	
Wiring Diagram - METER -/Diesel Engine without	RS
Tachometer	
Unified Control Meter System Description	65
Meter/gauge Operation and Odo/Trip Meter	BI
Segment Check in Diagnosis Mode	
Flexible Print Circuit (FPC) (Models with	HA
Tachometer)	0.07-7
Trouble Diagnoses/Models with Tachometer	
Trouble Diagnoses/Models without Tachometer73	EL
Electrical Components Inspection	
WARNING LAMPS	
Schematic 80	IDX

CONTENTS (Cont'd)

Wiring Diagram - WARN -/Gasoline Engine81
Wiring Diagram - WARN -/Diesel Engine86
Electrical Components Inspection91
A/T INDICATOR
Wiring Diagram - AT/IND -/LHD Models92
Wiring Diagram - AT/IND -/RHD Models93
WARNING CHIME
Wiring Diagram - CHIME -/Diesel Engine Except
for Europe, Australia and The Middle East94
Wiring Diagram - CHIME -/LHD Models for
Europe
Furpe 96
FRONT WIPER AND WASHER 97
Wiring Diagram - WIPER -/I HD Models with
Intermittent
Wiring Diagram - WIPER -/LHD Models without
Intermittent
Wiring Diagram - WIPER -/RHD M/T Models with
Intermittent
Wiring Diagram - WIPER -/RHD A/T Models with
Intermittent101
Wiring Diagram - WIPER -/RHD Models without
Intermittent103
HEADLAMP WASHER105
Wiring Diagram - HLC105
HORN
Wiring Diagram - HORN106
CIGARETTE LIGHTER107
Wiring Diagram - CIGAR107
CLOCK
Wiring Diagram - CLOCK108
Niring Discusson DEE // UD Madala
Wiring Diagram DEF /LHD Models
Viring Diagram - DEF -/RHD Models
Wiring Diagram - AUDIO -/I HD Models Type-1 112
Wiring Diagram - AUDIO -/LID Models Type-1112
Wiring Diagram - AUDIO -/LID Models Type-2 113
Wiring Diagram - AUDIO -/RHD Models Type-0 114
Power Antenna/Wiring Diagram - P/ANT - 117
POWER DOOR MIRROR 118
Wiring Diagram - MIRROR -/LHD Models Except
for The Middle East
Wiring Diagram - MIRROR -/LHD Models for The
Middle East119
Wiring Diagram - MIRROR -/RHD Models120
HEATED SEAT121
Wiring Diagram - H/SEAT121

POWER WINDOW	123
Schematic/Without Interruption Detection	
Function	123
Wiring Diagram - WINDOW -/Without Interruptio	n
Detection Function	124
Trouble Diagnoses/Without Interruption Detectio	n
Function	128
System Description/With Interruption Detection	
Function	129
Schematic/With Interruption Detection Function.	130
Wiring Diagram - WINDOW -/With Interruption	
Detection Function	131
Trouble Diagnoses/With Interruption Detection	
Function	135
POWER DOOR LOCK/EXCEPT FOR EUROPE	137
System Description	137
Wiring Diagram - D/LOCK	138
Trouble Diagnosis	140
POWER DOOR LOCK/FOR EUROPE	144
System Description	144
Wiring Diagram - D/LOCK	145
Trouble Diagnosis	147
MULTI-REMOTE CONTROL SYSTEM	151
System Description	151
Schematic	152
Wiring Diagram - MULTI	153
Trouble Diagnoses	157
ID Code Entry Procedure	161
NATS (Nissan Anti-Theft System)/Models for	
Europe with KA24E	162
Wiring Diagram - NATS	162
NATS (Nissan Anti-Theft System)/Diesel engine	163
Wiring Diagram - NATS -/LHD Models	163
Wiring Diagram - NATS -/RHD Models	164
LOCATION OF ELECTRICAL UNITS	165
Engine Compartment	165
Passenger Compartment	166
HARNESS LAYOUT	168
Main Harness	168
Engine Room Harness	176
Engine Control Harness	184
Engine Harness	186
Alternator Harness	189
Instrument Harness	190
Room Lamp Harness/LHD Models	191
Room Lamp Harness/RHD Models	192
Chassis Harness and Tail Harness	193
Front Door Harness (LH side)	194
Front Door Harness (RH side)	195
WIRING DIAGRAM CODES (CELL CODES)	196
SUPER MULTIPLE JUNCTION (SMJ)F	oldout
Terminal ArrangementF	oldout

CONTENTS (Cont'd)

FUSE AND FUSIBLE LINK	Foldout	CONTROL UNITS/JOINT CONNECTOR (J/C)Foldout	GI
Terminal Arrangement	Foldout	Terminal ArrangementFoldout	MA
			EM
			LC
			EC
			FE
			CL
			MT
			AT
			TF
			PD
			FA
			RA
			BR
			ST
			RS
			BT
			HA
			EL
			IDX

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR **BAG**" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The SRS system composition which is available to NISSAN MODEL D22 is as follows (The composition varies according to the destination and optional equipment.):

Driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioner, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.

Information necessary to service the system safely is included in the **RS section** of this Service Manual. WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral Cable and wiring harnesses (except "SEAT BELT PRE-TENSIONER") covered with yellow insulation either just before the harness connectors or for the complete harness are related to the SRS.

POWER SUPPLY ROUTING

Schematic



HEL669A

Wiring Diagram — POWER —

BATTERY POWER SUPPLY - IGNITION SWITCH IN ANY POSITION



HEL670A



IDX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)





POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"

EL-POWER-05





IUX

Wiring Diagram — POWER — (Cont'd)

EL-POWER-07



BATTERY

Service Data and Specifications (SDS)

· IMA
EM
LC
EA
EV
FE
CL
MT
0
AT
76
UĽ
PD
FA
RA
BR
6T
01
RS
BT
HA
EL

Wiring Diagram — START —/M/T Models





Wiring Diagram — START —/LHD A/T Models

IDX

Wiring Diagram — START —/RHD A/T Models



STARTING SYSTEM

Service Data and Specifications (SDS)

STARTER			G	
	М0Т600			
Туре	MITSUB	ISHI	MIA	
	Reduct	ion		
	2WD	4WD	EM	
Applied model	KA24E			
	Standa			
System voltage V	12	LG		
No-load				
Terminal voltage V	11.0		EC	
Current A	Less tha	n 90		
Revolution rpm	More than	GG		
Minimum diameter of commutator mm (in)	28.8 (1.1			
Minimum length of brush mm (in)	7.0 (0.2	76)		
Brush spring tension N (kg, lb)	11.8 - 2 (1.2 - 2.4, 2	3.5 6 - 5.3)	CL	
Movement " ℓ " in height of pinion assembly mm (in)	0.5 - 2 (0.020 - 0	0.5 - 2.0 (0.020 - 0.079)		

*: Not include the current of the magnet switch circuit

AT

TF

PD

FA

RA

BR

ST

GI

RS

BT

HA

EL

IDX

Wiring Diagram — CHARGE —/Gasoline Engine





HEL681A

Construction



CHARGING SYSTEM



Service Data and Specifications (SDS)

ALTERNATOR

Turo	A5TA5271 A7TA8471 A5TA5372			LR170-765 LR160-728F		
туре		MITSUBISHI		HITA	ACHI	
Applied model	KARADE	Z	24	KA04	TD25, TD27, QD32	
Applied model	KA24DE	Standard	Option*	KA24		
Nominal rating V-A	12-70	12-35	12-70	12-70	12-60	
Ground polarity			Negative			
Minimum revolution under no- load (When 13.5V is applied) rpm		Less than 1,300	Less that	an 1,000		
Hot output current (When 13.5V is applied) A/rpm	More than 14/1,300 More than 54/2,500	More than 27/2,500	More than 18/1,300 More than 51/2,500	More than 17/1,300 More than 54/2,500 More than 75/5,000	More than 17/1,300 More than 48/2,500 More than 57/5,000	
Regulated output voltage V			14.1 - 14.7			
Minimum length of brush mm (in)		5.0 (0.20)	6.0 (0).236)		
Brush spring pressure N (g, oz)	4.80 - 5	4.80 - 5.98 (490 - 610, 17.28 - 21.51)			350, 3.60 - 12.34)	
Slip ring minimum outer diameter mm (in)		22.1 (0.870)			1.024)	
Rotor (Field coil) resistance Ω	2.5 - 2.9	2.6 - 3.1	2.58			

*: Models with power steering and air conditioner



EL-23

COMBINATION SWITCH

Check (Cont'd)

RHD MODELS EXCEPT FOR EUROPE



LIGHTING	SWITCH
----------	--------

\mathbb{N}	C	DFF	-	1	ST	-	2ND					
$ \setminus$	А	В	С	Α	В	С	Α		В		С	
5			Q			Q	(2	(Ş	(2
6			9			6	(5			(5
7									0	Ş		
8			Q			Q	Q		Q	Γ	Q	П
9			6			6	Q				Q	
10									6			
11				Q	Q	Q	Q		Q		Q	Π
12				Q	6	6	Q		6		6	
25								5		5	(51

WIPER AND WASHER SWITCH (A/T models with intermittent)

	internitionity									
	OFF	١١	T٧	L	0	HI	WASH			
13	Q	Ŷ								
14	6	6		6		(ρ			
15		(2							
16						Ŷ				
17		(5	(5	6	Q			
18							6			

WIPER AND WASHER SWITCH (M/T models with

int	ermi	ttent)		
OFF	INT	LO	HI	WASH	ГШ

					WASH		IШ I
13				Ë			
14	Ŷ	Q	Q				<u>Ч</u> 5
\times	6	6				-	atio
imes		Q				-	¶ Su S
15				() ——(2 g g g
16				Ŷ			It S E
17		6	6	0	Ŷ	-	UID N U
18					6	-	≤="

WIPER AND WASHER SWITCH (Without intermittent)

\searrow	OFF	L	0	H	11	WASH	
13	Q						1
14	6	Ŷ					1
15							
16				(ρ		
17		(5	(5	Ŷ	
18						0	





HORN SWITCH







Wiring Diagram — H/LAMP —/RHD Models



3 €13, €26 12 B, B



IDX





Wiring Diagram — DIMDIP —





IDX



Wiring Diagram — H/AIM —




Wiring Diagram — TAIL/L —/Except LHD Models for Europe GI EL-TAIL/L-01 MA BATTERY EM Refer to EL-POWER. 10A 4 LC (RA): RHD A/T models Ρ (NR): Except (RA) 11 IN: For Europe and LHD models except for Europe 2ND LIGHTING SWITCH (RX): RHD models except for Europe (UA): For Europe, Australia and China 1ST FE OFF (M24) (NU): Except (UA) 12 GL P/L (M121) (C9) ■ P/L ■4 = P/L I P/L A Next Page MT AT (M85) (E104) RA P/L IM P/L RA \bigcirc TF (M5) (E101) FRONT COMBINATION ■●= P/L •3 (NR)> PD (PARKING LAMP) в (E27) : (NU) (E28) : (UA) FA FRONT COMBINATION LAMP LH (PARKING LAMP) P/L 3 RA Z **ا**ل E11 : (NU) в (E12) : (UA) ST В в Ē39 **E6** RS Refer to last page (Foldout page). (123) E11, E12, E27, E28 GY BR GY BR (M24) BT (\mathbb{R}) (LN) 1210511 11 5 10 12 BR (M5) (E101) HA (M85) (E104) 123 4567 C9 8910111213141516 W EL

Wiring Diagram — TAIL/L —/Except LHD Models for Europe (Cont'd)

EL-TAIL/L-02







HEL696A

GI



Wiring Diagram — STOP/L —

EL-STOP/L-01

GI



IDX

HEL698A

Wiring Diagram — BACK/L —/M/T Models





IDX

Wiring Diagram — R/FOG —/LHD Models

EL-R/F0G-01





HEL702A

Wiring Diagram — TURN —/Type-1

FOR EUROPE (Single cab) AND EXCEPT FOR EUROPE (Except LHD models with diesel engine except for the Middle East)



TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN —/Type-1 (Cont'd)





FOR EUROPE (King cab and Double cab) AND LHD MODELS WITH DIESEL ENGINE EXCEPT FOR EUROPE AND THE MIDDLE EAST (Except STD grade with QD engine)







IDX

TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN —/Type-2 (Cont'd)

EL-TURN-05



Wiring Diagram — ILL —/LHD Models



Wiring Diagram — ILL —/LHD Models (Cont'd)

EL-ILL-02







Wiring Diagram — ILL —/RHD Models (Cont'd)

EL-ILL-04



Wiring Diagram — ROOM/L —



GI

Wiring Diagram — INT/L —

EL-INT/L-01



Combination Meter

WITH TACHOMETER



HEL714A

GI

Combination Meter (Cont'd)

WITHOUT TACHOMETER



Combination Meter (Cont'd)

CONSTRUCTION (Without tachometer)



AT

TF

PD

FA

RA

ST

RS

BT

HA

EL

IDX

Wiring Diagram — METER —/Gasoline Engine with Tachometer





IDX

Wiring Diagram — METER —/Diesel Engine with Tachometer





IDX

Wiring Diagram — METER —/Gasoline Engine without Tachometer





Unified Control Meter System Description

UNIFIED CONTROL METER

Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by unified meter control unit.

Meter/gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

DIAGNOSIS FUNCTION

- Odo/trip meter segment can be checked in diagnosis mode.
- Meters/gauges can be checked in diagnosis mode.



HOW TO ALTERNATE DIAGNOSIS MODE

- 1. Turn ignition switch to ON and change odo/trip meter to "TRIP A" or "TRIP B".
- 2. Turn ignition switch to OFF.
- 3. Turn ignition switch to ON when pushing odo/trip meter switch.
- 4. Confirm that trip meter indicates "000.0".
- 5. Push odo/trip meter switch more than three times within 5 seconds.
- 6. All odo/trip meter segments should be turned on.
- NOTE: If some segments are not turned on, unified meter control unit should be replaced.
 - At this point, the unified control meter is turned to diagnosis mode.



7. Push odo/trip meter switch. Indication of each meter/gauge should be as shown left during pushing odo/trip meter switch if it is no malfunctioning.

NOTE: It takes about 1 minute for indication of fuel gauge to become stable.

Meter/gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode (Cont'd)



GI MA EM LC

Flexible Print Circuit (FPC) (Models with Tachometer)

Tachometer, fuel gauge and water temperature gauge are connected with unified meter control unit (speedometer) by Flexible Print Circuit (FPC) connector. When replace or remove and install unified control unit (speedometer), disconnect and connect FPC connector according to the following steps.

MT

EC



- BT
- HA

EL

IDX

SEL162V

Trouble Diagnoses/Models with Tachometer

PRELIMINARY CHECK



Trouble Diagnoses/Models with Tachometer (Cont'd)

Before starting trouble diagnoses below, perform PRELIMINARY CHECK, EL-68.

SYMPTOM CHART 1 (MALFUNCTION IS INDICATED IN DIAGNOSIS MODE)

	\	/	0000-0
Symptom	Possible causes	Repair order	
Speedometer and/or odo/trip meter indicate(s) malfunction in Diagnosis mode.	 Speedometer (Unified meter control unit) 	 Replace speedometer (unified meter control unit). 	EM
Multiple meter/gauge indicate malfunction in Diagnosis mode.			LC
One of tachometer/fuel gauge/ water temp. gauge indicates malfunction in Diagnosis	Meter/GaugeSpeedometer (Unified meter control unit)	1. Check resistance of meter/gauge indicating malfunction. If the resistance is NG, replace the meter/gauge. Refer to "METER/GAUGE RESISTANCE CHECK", EL-78.	EC
mode.		 If the resistance is OK, replace speedometer (unified meter control unit). 	FE

SYMPTOM CHART 2 (NO MALFUNCTION IS INDICATED IN DIAGNOSIS MODE)

Symptom	Possible causes	Repair order
Speedometer and odo/trip meter are malfunctioning.	 Sensor Speedometer, Odo/Trip meter FPC connector Speedometer (Unified meter control unit) 	 Check vehicle speed sensor. INSPECTION/VEHICLE SPEED SENSOR (Refer to EL-71.) Check FPC connector. Refer to "FLEXIBLE PRINT CIRCUIT (FPC)", EL-67. Replace speedometer (unified meter control unit).
Multiple meter/gauge are mal- functioning. (except speedometer, odo/trip meter)	 FPC connector Speedometer (Unified meter control unit) 	 Check FPC connector. Refer to "FLEXIBLE PRINT CIRCUIT (FPC)", EL-67. Replace speedometer (unified meter control unit).
One of tachometer/fuel gauge/ water temp. gauge is malfunc- tioning.	 Sensor/Engine revolution signal Tachometer Fuel gauge Water temp. gauge FPC connector Speedometer (Unified meter control unit) 	 Check the sensor for malfunctioning meter/gauge. INSPECTION/ENGINE REVOLUTION SIGNAL (Refer to EL-71.) INSPECTION/FUEL TANK GAUGE (Refer to EL-72.) INSPECTION/THERMAL TRANSMITTER (Refer to EL-72.) Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-67. Replace speedometer (unified meter control unit).

RA

BR

ST

RS

BT

HA

EL

IDX

G]

MA



Trouble Diagnoses/Models with Tachometer (Cont'd)

POWER SUPPLY AND GROUND CIRCUIT CHECK

Power supply circuit check

Terminals		Ignition switch position		
\oplus	\ominus	OFF	ACC	ON
2	Ground	Battery voltage	Battery voltage	Battery voltage
3)	Ground	0V	0V	Battery voltage

If NG, check the following.

- 7.5A fuse [No. 3], located in fuse block (J/B)] 10A fuse [No. 20], located in fuse block (J/B)] •
- •
- Harness for open or short between fuse and combination meter •



Ground circuit check

Terminals	Continuity
③ - Ground	Yes



If NG, check the following.

Engine	Check item	HA
ECM con- trolled engine	Harness for open or short and connection	F
Carburetor	Harness for open or short and connectionResistor etc.	
Diesel TD27 and QD32	Harness for open or short and connectionEngine revolution sensor etc.	- [D)

EL-71



EL-72
Trouble Diagnoses/Models without Tachometer

GI PRELIMINARY CHECK MA CHECK-IN EM Yes No Can Diagnosis mode Do meter warning be activated? Refer to lamps operate? LC "Meter/Gauge Opera-No tion and Odo/Trip Can Diagnosis mode Meter Segment be activated? Check in Diagnosis Yes No Mode", EL-66. FE Yes Check power supply GL and ground circuit. Refer to "POWER SUPPLY AND MT **GROUND CIRCUIT** CHECK", EL-75. AT Check meter/gauge operation in Diagno-TF sis mode. PD FA Malfunction is indi-No malfunction is Replace unified meter control cated in Diagnosis indicated in Diagnosis unit. mode. mode. RA SYMPTOM CHART 2 Check the following: Screws securing Refer to EL-74. the malfunctioning meter/gauge NG (The screws are located behind the RS combination meter. For details refer to EL-78.) OK HA **SYMPTOM CHART 1** Retighten the loose screw. Refer to EL-74. EL

IDX

Trouble Diagnoses/Models without Tachometer (Cont'd)

Before starting trouble diagnoses below, perform PRELIMINARY CHECK, EL-73.

SYMPTOM CHART 1 (MALFUNCTION IS INDICATED IN DIAGNOSIS MODE)

Symptom	Possible causes	Repair order
Odo/trip meter indicate(s) mal- function in Diagnosis mode.	Unified meter control unit	Replace unified meter control unit.
Multiple meter/gauge indicate malfunction in Diagnosis mode.		
One of speedometer/ tachometer/fuel gauge/water temp. gauge indicates mal- function in Diagnosis mode.	Meter/GaugeUnified meter control unit	 Check resistance of meter/gauge indicating malfunction. If the resistance is NG, replace the meter/gauge. Refer to "METER/GAUGE RESISTANCE CHECK", EL-78. If the resistance is OK, replace unified meter control unit.

SYMPTOM CHART 2 (NO MALFUNCTION IS INDICATED IN DIAGNOSIS MODE)

Symptom	Possible causes	Repair order
One/or more of speedometer/ tachometer/fuel gauge/water temp. gauge is malfunctioning.	 Sensor Vehicle speed signal Fuel gauge Water temp. gauge Unified meter control unit 	 Check the sensor for malfunctioning meter/gauge. INSPECTION/VEHICLE SPEED SENSOR (Refer to EL-76.) INSPECTION/FUEL LEVEL SENSOR (Refer to EL-77.) INSPECTION/THERMAL TRANSMITTER (Refer to EL-77.) Replace unified meter control unit.



Trouble Diagnoses/Models without Tachometer (Cont'd)

POWER SUPPLY AND GROUND CIRCUIT CHECK

Power supply circuit check

Terminals		Ignition switch position			- M/
\oplus	Θ	OFF	ACC	ON	-
(21)	Ground	Battery voltage	Battery voltage	Battery voltage	ĒM
2	Ground	0V	0V	Battery voltage	LC

If NG, check the following.

7.5A fuse [No. 3], located in fuse block (J/B)] 10A fuse [No. 20], located in fuse block (J/B)] •

- •
- Harness for open or short between fuse and combination meter •

	Ground circuit
H.S. E	Term
Combination meter connector (N1)	3 - 0
B B SEL429W	

d aira it check

Terminals	Continuity	5 6 6	
3 - Ground	Yes	TF	

RS

BT

GI

EC

FE

GL

MT

PD

FA

RA

BR

ST

HA





EL-77

Electrical Components Inspection

METER/GAUGE RESISTANCE CHECK

- 1. Disconnect FPC connector (Combination meter with tachometer). Refer to EL-67.
- 2. Check resistance between terminals (the points of installation screws) of meter/gauge after removing meter/gauge.

Scr	ews	Resistance
Tachometer	Fuel/Temp. gauge	Ω
A - C	A - C	Approx. 140 - Approx. 260
B - D	B - C	Approx. 230 - Approx. 310







FUEL LEVEL SENSOR UNIT CHECK

• For removal, refer to FE section.

Check the resistance between terminals 1 and 3.

Ohm	meter		Float position mm (in)		Resistance		
(+)	(-)			60ℓ (13-1/4 Imp gal) tank	80ℓ (17-5/8 Imp gal) tank	c (17-5/8 value gal) tank Ω	
		*1	Full	253 (9.96)	77 (3.03)	Approx. 4 - 6	
3	1	*2	1/2	130 (5.12)	191 (7.52)	27 - 35	
		*3	Empty	27 (1.06)	299 (11.77)	78 - 85	

*1 and *3: When float rod is in contact with stopper.



Electrical Components Inspection (Cont'd) THERMAL TRANSMITTER CHECK

Check the resistance between the terminals of thermal transmitter $\ensuremath{\operatorname{\sc cm}}$ and body ground.

Water temperature	Resistance	MA
60°C (140°F)	Approx. 167 - 211Ω	
100°C (212°F)	Approx. 47 - 53Ω	EM

VEHICLE SPEED SENSOR SIGNAL CHECK

- . Remove vehicle speed sensor from transmission.
- Turn vehicle speed sensor pinion quickly and measure voltage between terminals (a) and (b).

CL

LC

EC

- MT
- AT
- TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Schematic



EL-80

Wiring Diagram — WARN —/Gasoline Engine



Wiring Diagram — WARN —/Gasoline Engine (Cont'd)



WARNING LAMPS

Wiring Diagram — WARN —/Gasoline Engine (Cont'd)



Wiring Diagram — WARN —/Gasoline Engine (Cont'd)

EL-WARN-04



WARNING LAMPS

Wiring Diagram — WARN —/Gasoline Engine (Cont'd)



 \mathbb{D}

Wiring Diagram — WARN —/Diesel Engine



Wiring Diagram — WARN —/Diesel Engine (Cont'd)



HEL729A

Wiring Diagram — WARN —/Diesel Engine (Cont'd)

EL-WARN-08



Wiring Diagram — WARN —/Diesel Engine (Cont'd)

EL-WARN-09



GI



Wiring Diagram — WARN —/Diesel Engine (Cont'd)

EL-WARN-10



OFF

NEUTRAL

(M55)

W

1234 567 N4 89101111213141516 W

21



(M5) E101)

HEL732A

W

*: This connector is not shown in "HARNESS LAYOUT".

(N6)BR

56789101112

36373839/22 404142 272829303132333435

2 GY , 402



Electrical Components Inspection

FUEL WARNING LAMP SENSOR CHECKIt will take a short time for the bulb to light.

LC EC

GI

MA

EM

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Wiring Diagram — AT/IND —/LHD Models

EL-AT/IND-01





Wiring Diagram — CHIME —/Diesel Engine Except for Europe, Australia and The Middle East

FUEL FILTER WARNING BUZZER



Wiring Diagram — CHIME —/LHD Models for Europe

LIGHT WARNING BUZZER



GI

Wiring Diagram — CHIME —/RHD Models for Europe

LIGHT WARNING BUZZER



Wiring Diagram — WIPER —/LHD Models with





Wiring Diagram — WIPER —/LHD Models without Intermittent

Wiring Diagram — WIPER —/RHD M/T Models with Intermittent



EL

IDX

Wiring Diagram — WIPER —/RHD M/T Models with Intermittent (Cont'd)

EL-WIPER-04



Wiring Diagram — WIPER —/RHD A/T Models with Intermittent GI EL-WIPER-05 MA IGNITION SWITCH ON or START EM Refer to EL-POWER. 20A Ò 16 LC FRONT WASHER MOTOR 14 L/Y (M85) (E104) (E104) (M85) EC L/B • [13] L/B - L/B • ■ L/Y ■111 L/Y ■1 2 -ɗMƊ Next page FE B ∎G L/Y (M47) GL (F55) L7Y MT AT В L/Y 1 โอ้า L7Y TF 5 FRONT STOP IGN WIPER FRONT WIPER AMPLIFIER MÕVE PD (M) WIPER HI LO **F21** MOTOR **F20** łł (AUTO STOP) FA Ľ 3 5 L L/R L/W L RA BR L/W . L/W . L/W 🕪 Next (E55) M47 page ST L/R 2 L/R L/R I RS Refer to last page (Foldout page). BT €14) GY 321 765 32 654 123 4567 F55 8910111213141516 W **F20** F21) **e**1 (M85 , E104) GY W HA

EL-101

HEL741A

EL

IDX

Wiring Diagram — WIPER —/RHD A/T Models with Intermittent (Cont'd)

EL-WIPER-06



12304567 (F55) 8910111213141516 W



Wiring Diagram — WIPER —/RHD Models without Intermittent (Cont'd)

EL-WIPER-08





1416 13 M2B	123-4567	-55)
181715 GY	8 9 10 11 12 13 14 15 16	W

Wiring Diagram — HLC —



GI

HORN

Wiring Diagram — HORN —

EL-HORN-01



EL-106





GI



IDX

Wiring Diagram — CLOCK —

EL-CLOCK-01


Wiring Diagram — DEF —/LHD Models





EL-110



Electrical Components Inspection

REAR WINDOW DEFOGGER SWITCH

Check continuity between terminals when rear window defogger switch is pushed and released.

Terminals	Condition	Continuity	
	Rear window defogger switch is pushed	Yes	EM
() - (2)	Rear window defogger switch is released	No	LC

EC

GI

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

Wiring Diagram — AUDIO —/LHD Models Type-1

WITH 1-SPEAKER EXCEPT FOR EUROPE EL-AUDIO-01 IGNITION SWITCH ACC or ON BATTERY Refer to EL-POWER. 10A 7.5A 3 25 G/W R/G ROD ANTENNA P/L 🌩 To EL-ILL R/G P/L G/W (M35) 10 8 M501) R/G Ρ L R∕G Ρ L Ē 10 r b LIGHTING SW BACK ACC AUDIO UNIT FRSP (+) FRSP (-) (1502) 2 ΒŔ BR/W BR BR/W (1501) 4 3 B/W M35 в в/w 5 В **M49** 031 B∕₩ в FRONT DOOR SPEAKER 2 1 ٥٥ ŘH 033 108642 (M35 , (M502) 1234 5678 031 91011121314151617181920 W 0 12 BR



HEL752A

Wiring Diagram — AUDIO —/LHD Models Type-3

WITH 4-SPEAKERS (With CD deck)





AUDIO Wiring Diagram — AUDIO —/LHD Models Type-3 (Cont'd)

EL-AUDIO-04

GI

MA





Wiring Diagram — AUDIO —/RHD Models



Wiring Diagram — MIRROR —/LHD Models Except for The Middle East



Wiring Diagram — MIRROR —/LHD Models for The Middle East



Wiring Diagram — MIRROR —/RHD Models



1234 5678 01 031		23 🗖 19 014
9 10 11 12 13 14 15 16 17 18 19 20 W ' W	(123) GY ' GY	574 68 GY

HEL818A

Wiring Diagram — H/SEAT —



EL





*: This connector is not shown in "HARNESS LAYOUT".

Schematic/Without Interruption Detection Function



Wiring Diagram — WINDOW —/Without Interruption Detection Function





Wiring Diagram — WINDOW —/Without Interruption Detection Function (Cont'd)

EL-WINDOW-03



W/B B/W R/B G/W GL To EL-W -01 W/B B/W R/B G/W W W MT 1 2 3 (M107 (M115) 1 13 <u>671</u> 051) W/B B/W W W/B B/W W AT W/B B/W W W/B B/W W TF 4 TA I 3 3 5 5 POWER POWER PD Ν Ν WINDOW Ν Ν WINDOW SUB-SWITCH SUB-SWITCH (REAR RH) U D U D U D U D (REAR LH) FA 077): (0) 057:00 2 1 2 RA L/B L/R L/B L/R LHD models [2] 2 RHD models POWER POWER OC : Double cab WINDOW WINDOW ſΜÞ ďΜþ models REGULATOR REGULATOR (REAR RH) (REAR LH) ST UP DOWN UP 075:00> DOWN (055): (00) RS

05: 🕞

41325

W

35

<u>_____</u>

W

16 15

W

]1

1110147

98 O5 : (R)

W

POWER WINDOW

REAR RH SWITCH

Ν

B/W

D

Ν

10

W/B

D U

02

(M4)

U

Preceding

G

123045 6789101112 W

W

123

051,071

page

Wiring Diagram — WINDOW —/Without Interruption Detection Function (Cont'd)

EL-WINDOW-04

POWER

MAIN

WINDOW

SWITCH

05:00

REAR LH SWITCH

DU

Ν

16

G/W

12

D

Ν

15

R∕B

U

HEL764A

EL-127

356

89

(<u>1</u>]

7 14 16 15

055,075

В

В

IDX

BT

HA

EL

GI

MA

EM

LC

FE

Trouble Diagnoses/Without Interruption Detection Function

Symptom	Possible cause	Repair order
None of the power windows can be operated using any switch.	 30A fusible link and circuit breaker-1 Grounds (M1) and (M54) Power window relay Open/short in power window main switch circuit 	 Check 30A fusible link (letter b), located in fusible link and fuse box) and circuit breaker-1, located in fuse block. Turn ignition switch "ON" and verify battery posi- tive voltage is present at terminal ① of power window main switch and terminal ⑤ of sub-switch. Check grounds M1 and M54. Check power window relay. Check harness between power window relay and power window main switch for open/short circuit.
Driver side power window cannot be operated but other windows can be operated.	 Driver side power window regula- tor circuit Driver side power window regula- tor 	 Check harness between power window main switch and power window regulator for open or short circuit. Check driver side power window regulator.
One or some of power window except driver side power window cannot be operated.	 Power window sub-switch Passenger side power window regulator Power window main switch Power window circuit 	 Check power window sub-switch. Check power window regulator of malfunctioning power window. Check power window main switch. Check harnesses between power window main switch and power window sub-switch for open/short circuit. Check harnesses between power window sub- switch and power window regulator for open/short circuit.
Passenger power window cannot be operated using power window main switch but can be operated by power window sub-switch.	1. Power window main switch	1. Check power window main switch.
Driver side power window auto func- tion cannot be operated using power window main switch.	1. Power window main switch	1. Check power window main switch.

System Description/With Interruption Detection Function

Function	GI
OUTLINE	MA
 Power window system consists of CPU (combined with power window main switch) four power window regulators When ignition switch is in the "ON" position, power window can be operated depending on power window sub/main switch condition 	EM
OPERATIVE CONDITION	LC
 Power windows can be raised or lowered with each sub-switch or the power window main switch located on the driver's door trim when ignition switch is in the "ON" position and power window lock switch on the driver's door trim is unlocked. 	EC
 When power window lock switch is locked, no windows can be raised or lowered except for driver's side window. 	FE
 When ignition switch is in the "ON" position, to fully open/close the driver's side window, press down/pull up completely on the automatic switch (main switch) and release it; it needs not be held. The window will automatically open/close all the way. To stop the window, pull up/press down then release the switch. 	CL
 After turning ignition switch to OFF, the driver's side window can be raised or lowered for 15 minutes. The timer control for supplying power after turning ignition switch to "OFF" will be canceled when the driver's side door is closed. (Except models for Europe) 	MT
INTERRUPTION DETECTION FUNCTION	AT
CPU (combined with power window main switch) monitors the power window regulator motor operation and the power window position (full closed or other) for driver's power window by the signals from encoder and limit switch in front power window regulator (driver's side).	
When CPU (combined with power window main switch) detects interruption during the following close opera- tion in the driver's side door,	PD
 automatic close operation when ignition switch is in the 'ON' position automatic close operation during power window timer operation manual close operation during power window timer operation CPU (combined with power window main switch) controls driver's power window regulator motor for open and the power window will be lowered about 150 mm (5.91 in) 	FA
	RA
	BR
	ST
	RS
	BT
	HA

EL

Schematic/With Interruption Detection Function



Wiring Diagram — WINDOW —/With Interruption Detection Function



GI

Wiring Diagram — WINDOW —/With Interruption Detection Function (Cont'd)





Wiring Diagram — WINDOW —/With Interruption Detection Function (Cont'd)

EL-WINDOW-08



Trouble Diagnoses/With Interruption Detection Function

Cumpton	Dessible source	Densir order	
Symptom	Possible cause	Repair order	MA
operated using any switch.		30A fusible link (letter b), located in fuse and fusible link box).	EM
	2. Ground circuit	2. Check ground circuit of power window main switch terminal (1).	
	3. Power window main switch	3. Check power window main switch.	LC
Driver side power window cannot be operated but other windows can be operated.	1. Driver side power window regula- tor circuit	1. Check harness between power window main switch and driver side power window regulator for open or short circuit.	EC
	2. Driver side power window regula-	2. Check driver side power window regulator.	
	tor 3. (M52) circuit breaker-2	3. Check (M52) circuit breaker-2.	FE
	4. (MS2) circuit breaker-2 circuit	 Check harness between (M52) circuit breaker-2 and 30A fusible link (letter b), located in fuse and fusible link box). 	CL
	5. Power window main switch circuit	5-1. Check harness between power window main switch terminal (3) and 10A fuse [No. 20], located in fuse block (J/B)].	MT
		5-2. Check harness between power window main switch terminal (5) and (M52) circuit breaker.	AT
One or more power windows except driver's side window cannot be oper- ated.	 Power window sub-switches Power window regulators Power window main switch Power window circuit 	 Check power window sub-switch. Check power window regulator. Check power window main switch. Check harnesses between power window main 	TF
		switch and power window sub-switch for open/ short circuit.	PD
		switch and power window regulator for open/ short circuit.	FA
Power windows except driver's side window cannot be operated using power window main switch but can be operated by power window sub-	1. Power window main switch	1. Check power window main switch.	RA
switch.			RD
Driver side power window automatic operation does not function properly.	 Power window main switch Encoder and limit switch 	 Check power window main switch. Check encoder and limit switch. (EL-136) 	UUN
Timer control for supplying power after turning ignition switch to "OFF"	1. Driver side door switch circuit	 Check harness between driver side door switch and power window main switch. 	ST
does not operate properly. (Except models for Europe)	 Driver side door switch Ignition switch ON signal circuit 	 Check driver side door switch. Check ignition switch ON signal circuit to power win- dow main switch. 	RS
	4. Power window main switch	4. Check power window main switch.	RT

HA

GI

POWER WINDOW



System Description

Power is supplied at all times	GI
 through soA rusible link (Letter D), located in the rusible link and ruse box) to circuit breaker-1 (terminal ① of fuse block) through circuit breaker-1 (terminal ⑦ of fuse block) 	MA
 to door lock timer terminal ③. Ground is supplied to door lock timer terminal ① through body grounds M1 and M54. 	EM
INPUT	
When the door lock & unlock switch (power window main switch) is in LOCKED position, ground signal is	LC
 to door lock timer terminal (5) through door lock & unlock switch terminal (4) to door lock & unlock switch terminal (3) 	EC
• through body grounds (m) and (m54). When the door lock & unlock switch (power window main switch) is in UNLOCKED position, ground signal is supplied	FE
 to door lock timer terminal (8) through door lock & unlock switch terminal (7) to door lock & unlock switch terminal (3) 	CL
• through body grounds (m) and (m). Driver side door key cylinder and driver side lock knob are connected to lock knob switch with a rod. When lock knob switch is in UNLOCKED position, ground signal is supplied	MT
 to door lock timer terminal (6) through lock knob switch terminal (2) to driver side lock knob switch terminal (1) 	AT
• Through body grounds (m) and (ms). When lock knob switch is in LOCKED position, ground signal is interrupted. Door lock operates according to the conditions of the door lock & unlock switch (power window main switch) and lock knob switch.	TF
	PD
	RA
Ground is supplied	P/A
• to passenger side door lock actuator, rear door lock actuator LH and RH terminal ① (double cab models)	RA
through door lock timer terminal ② . Power is supplied	
• to passenger side door lock actuator, rear door lock actuator LH and RH terminal ② (double cab models)	BR
• through door lock timer terminal (4). Then the doors are unlocked	ST
Lock	01
Ground is supplied	DQ
 to passenger side door lock actuator, rear door lock actuator LH and RH terminal (2) through door lock timer terminal (4) 	ΝØ
Power is supplied	BT
 to passenger side door lock actuator, rear door lock actuator LH and RH terminal (1) through door lock timer terminal (2) 	
Then, the doors are locked.	HA
	EL

Wiring Diagram — D/LOCK —





Trouble Diagnosis

SYMPTOM CHART

REFERENCE PAGE	EL-140	EL-141	EL-142	EL-143
SYMPTOM	Main power supply and ground circuit check	Diagnostic procedure 1 (Door lock and unlock switch check)	Diagnostic procedure 2 (Door lock actuator check)	Diagnostic procedure 3 (Driver side lock knob switch check)
None of the doors lock/unlock when operat- ing any switch.	Х		х	
One or more doors are not locked and/or unlocked.			Х	
Door lock and unlock switch does not oper- ate.		Х		
Lock knob switch on driver's door does not operate.				Х





MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK Main power supply for door lock timer

Tern	ninal		Ignition switch	
\oplus	Θ	OFF	ACC	ON
3	Ground	Battery voltage	Battery voltage	Battery voltage

Ground circuit for door lock timer

Terminals	Continuity
① - Ground	Yes



RS

BT

HA





RA

RS

BT

HA

EL

System Description

Power is supplied at all times

- through 30A fusible link (Letter b, located in the fusible link and fuse box)
- to circuit breaker-1 (terminal ① of fuse block)
- through circuit breaker-1 (terminal ⑦ of fuse block)
- to smart entrance control unit terminal (1).

Ground is supplied to smart entrance control unit terminal (1) through body grounds (1) and (1).

INPUT

When the door lock & unlock switch (power window main switch) is in LOCKED position, ground signal is supplied

- to smart entrance control unit terminal ④
- through door lock & unlock switch terminal (1)
- to door lock & unlock switch terminal (3)
- through body grounds (M1) and (M54).

When the door lock & unlock switch (power window main switch) is in UNLOCKED position, ground signal is supplied

- to smart entrance control unit terminal (5)
- through door lock & unlock switch terminal (7)
- to door lock & unlock switch terminal (3)
- through body grounds (M1) and (M54).

Driver side door key cylinder and driver side lock knob are connected to lock knob switch with a rod. When lock knob switch is in UNLOCKED position, ground signal is supplied

- to smart entrance control unit terminal 2
- through lock knob switch terminal ②
- to driver side lock knob switch terminal ①
- through body grounds (M1) and (M54).

When lock knob switch is in LOCKED position, ground signal is interrupted.

Door lock operates according to the conditions of the door lock & unlock switch (power window main switch) and lock knob switch.

OUTPUT

Unlock

Ground is supplied

- to passenger side door lock actuator, rear door lock actuator LH and RH terminal ① (double cab models)
- through smart entrance control unit terminal (15)

Power is supplied

- to passenger side door lock actuator, rear door lock actuator LH and RH terminal 2 (double cab models)
- through smart entrance control unit terminal (16)

Then, the doors are unlocked.

Lock

Ground is supplied

- to passenger side door lock actuator, rear door lock actuator LH and RH terminal 2
- through smart entrance control unit terminal 16
- Power is supplied
- to passenger side door lock actuator, rear door lock actuator LH and RH terminal ①
- through smart entrance control unit terminal (15)

Then, the doors are locked.




Trouble Diagnosis

SYMPTOM CHART

REFERENCE PAGE	EL-147	EL-148	EL-149	EL-150	- DAA
	circuit check	heck)		heck)	EM
	d ground	switch c	eck)	switch c	LC
	supply and	ocedure 1 id unlock	ocedure 2 stuator che	ocedure 3 ock knob	EC
	in power s	ignostic pr	ignostic pr	iver side l	FE
SYMPTOM	Ma	Dia (Dc	(Dc	Dia (Dr	CL
None of the doors lock/unlock when operat- ing any switch.	х		х		-
One or more doors are not locked and/or unlocked.			х		- 000 0
Door lock and unlock switch does not oper- ate.		Х			AT
Lock knob switch on driver's door does not operate.				X	TF

PD

GI

FA



Smart entrance control unit connector (M62)

MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK RA Main power supply for door lock timer

Tern	ninal		Ignition switch		BR
\oplus	Θ	OFF	ACC	ON	-
(f)	Ground	Battery voltage	Battery voltage	Battery voltage	ST

RS

BT

Ground circuit for door lock timer

Terminals	Continuity	ΠM
(1) - Ground	Yes	LT/A

IDX





RA

RS

HA

EL

IDX



System Description

FUNCTION	GI
 Multi-remote control system has the following function. Door lock Door unlock 	MA
Hazard reminder	EM
LOCK OPERATION	
 To lock door by multi-remote controller, the following two signals must be received. Key switch OFF (when ignition key is not in ignition key cylinder.) All door switches CLOSED 	LC
When the LOCK signal is input to multi-remote control unit (the antenna of the system is combined with multi- remote control unit), ground is supplied	EC
 to door lock timer terminal (5) (models except for Europe)/smart entrance control unit terminal (4) (models for Europe) and 	FE
• to door lock relay terminal (6). Then door lock timer (models except for Europe)/smart entrance control unit (models for Europe) operates to lock doors (except for driver's door) and door lock relay energized to lock driver's door.	CL
UNLOCK OPERATION	MT
 To unlock door by multi-remote controller, the following signal must be received. Key switch OFF (when ignition key is not in ignition key cylinder) 	AT
 When the UNLOCK signal is input to multi-remote control unit (the antenna of the system is combined with multi-remote control unit), ground is supplied through multi-remote control unit terminal ① 	TF
 to door lock timer terminal (8) (models except for Europe)/smart entrance control unit terminal (5) (models for Europe) and to door lock relay terminal (5). 	PD
Then door lock timer (models except for Europe)/smart entrance control unit (models for Europe) operates to unlock doors (except for driver's door) and door lock relay is energized to unlock driver's door.	FA
HAZARD REMINDER	RA
 When the doors and locked or unlocked by multi-remote controller, ground is supplied to terminal ① of multi-remote control relay-1 and 2 through multi-remote control unit terminal ①. 	BR
 Then the relays are energized and hazard warning lamp flashes as follows Lock operation: Flash once Unlock operation: Flash twice 	ST
	DQ
MULTI-REMOTE CONTROLLER ID CODE ENTRY	NÐ
ID codes previously entered. Therefore, be sure to receive all remote controllers from the vehicle owner when any ID code entry is performed.	BT
 To enter ID code entry, the following signals must be input to the multi-remote control unit. Driver side LOCKED signal (from driver side door unlock sensor) Door switch CLOSED signal 	HA
 Key switch signal (INSERTED/WITHDRAWN) Accessory power supply Signal from remote controller 	EL
For detailed procedure, refer to "ID Code Entry Procedure" in EL-161.	IDX

Schematic



Wiring Diagram — MULTI — GI EL-MULTI-01 MA IGNITION SWITCH ACC or ON BATTERY EM Refer to EL-POWER. 30A þ 7.5A LC 10A 3 24 b (EU): For Europe R∕G G/R W/B EC (NE) : Except for Europe W/B FE (E101) Õ**-**NE (M5) Ð ₩∕в GL R∕G MT KEY SWITCH INSERTED R/G (M64): (EU) W/B WITHDRAWN AT 2 1 KEY SWITCH FUSE BLOCK (CURCUIT BREAKER-1) INSERTED R∕₩ TF (M77): (NE) WITHDRAWN M12 M14 2 PD 7 R/W EU) ₩7G (NE) \bigcirc FA 🖬 W/G \Lambda To EL-MULTI-03 RA R∕₩ G/R W/G B **B** r **–** BR MULTI-REMOTE KEY INPUT ACC INPUT BATT POWER CONTROL UNIT ST (M58) RS Refer to last page (Foldout page). 123 M12 78 M14 543021 M58 12 (M64) M77 456 1211109876 W W 12 BR 910 BT W W (M5), (E101) HA EL

IDX



EL-MULTI-02

010 GY

32

1234 91011121314151617181920

>5678 01

W



EL-MULTI-04



Trouble Diagnoses

SYMPTOM CHART

Symptom	Possible cause	Diagnoses/service order	
No doors can be locked or un- locked by remote control opera- tion. (See NOTE.)	 Remote controller battery Key switch (insert) 	 Check remote controller battery. Refer to EL-158. Check key switch (insert) signal at terminal ⑦ of multi- remote control unit. 	
	3. Door switch	3. Check door switch signal at terminals ① and ② of multi-remote control unit.	
	4. Power supply circuit for multi-re- mote control unit	4. Make sure battery voltage is present at terminal ③ of multi-remote control unit.	LC
	 Ground circuit for multi-territie control unit Remote controller 	 Check continuity between terminal (a) of multi-remote control unit and ground. Replace remote controller. Refer to EL-161. 	EC
Driver's door cannot be locked or unlocked by remote controller operation.	Driver side door lock actuator circuit	Check driver side door lock actuator circuit. Refer to EL-159.	FE
Doors other than driver side cannot be locked or unlocked by remote control operation.	Lock/unlock signal to door lock timer (models except for Europe)/smart entrance control unit (models for	 When locking is not possible: Check continuity between terminal (1) of multi-remote control unit and terminal (5) of door lock timer (models) 	GL
(If the power door lock system does not operate correctly, check power door lock system. Refer to EL-140.)	Europe)	except for Europe)/terminal ④ of smart entrance con- trol unit (models for Europe).	MT
		 When this call is not possible. Check continuity between terminal (f) of multi-remote control unit and terminal (g) of door lock timer (models except for Europe)/terminal (f) of smart entrance control unit (models for Europe). 	AT TF
Hazard reminder does not operate properly.	 1. 10A fuse 2. Multi-remote control relay-1 and 	 Check 10A fuse (No. 5, located in the fuse block). Check multi-remote control relay-1 and 2. 	
	3. Hazard reminder circuit	3. Check harness for open or short between relays and multi-remote control unit terminal (2).	
The new ID of remote controller cannot be entered.	 Remote controller battery Key switch (insert) 	 Check remote controller battery. Refer to EL-158. Check key switch (insert) signal at terminal ⑦ of multi- remote control unit. 	DA
	3. Door switch	3. Check door switch signal at terminals ① and ② of multi-remote control unit.	
	4. Driver's door unlock sensor	 4. Check driver's door unlock sensor signal at terminal 6 of multi-remote control unit. 	BR
	5. Accessory power supply circuit for multi-remote control unit	 wake sure battery voltage is present at terminal (8) of multi-remote control unit while ignition switch is in ACC position. 	ST
	6. Remote controller	6. Replace remote controller. Refer to EL-161.	

Refer to "MULTI-REMOTE CONTROL UNIT INSPECTION TABLE" on next page to check the control unit signals.

NOTE:

- Always check remote controller battery before replacing remote controller.
- The unlock operation of multi-remote control system does not activate with key inserted in the ignition key cylinder.
- Cylinder.
 The lock operation of multi-remote controller does not activate with the key inserted ignition key cylinder or if one of the door is opened.

EL

BT

GI

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

MULTI-REMOTE CONTROL UNIT INSPECTION TABLE

Terminal No.	Connections	Conditior	1	Voltage V (approximate values)
1	Driver side door switch	Driver side deer	Opened	0
			Closed	12
2	Door switch (all doors)	One of doors is opened		0
2		All doors are closed		12
3	Power source (BAT)	_		12
5	Ground	_		—
6	Driver side deer unleek sonser	Driver side deer	Locked	5
0			Unlocked	0
7	Kay awitch (incast)	Key is in ignition key cylinder		12
	Key switch (insert)	Key is not in ignition key cylinder		0
0		Ignition switch	OFF	0
0	Accessory power supply		ACC or ON	12
10	Lock signal	Remote controller LOCK button is pr (All doors are closed and key is not	ushed in ignition key cylinder.)	0
		Other than above condition		12
11	Unlock signal	Remote controller UNLOCK button is (Key is not in ignition key cylinder.)	s pushed	0
		Other than above condition		12
12	Multi-remote control relay-1, 2	Remote controller LOCK/UNLOCK b (All doors are closed and key is not	utton is pushed in ignition key cylinder.)	0
		Other than above condition		12





REMOTE CONTROLLER BATTERY CHECK

Remove battery and measure voltage across battery positive and negative terminals, \oplus and $\bigcirc.$

Measuring	g terminal	Standard value
\oplus	\ominus	Stanuaru value
Battery positive terminal	Battery negative terminal	25 201/
\oplus	\ominus	2.5 - 3.00

Note:

Remote controller does not function if battery is not set correctly.

MULTI-REMOTE CONTROL SYSTEM



EL-159

MULTI-REMOTE CONTROL SYSTEM



Trouble Diagnoses (Cont'd) DOOR LOCK RELAY CHECK

Conditio	n	0	Continu	ity betv	ween te	erminal	S
Conditio	11	1	2	3	4	5	6
Battery voltage not	3 and 5	0-	-0				
terminal	3 and 6		0-		-0		
Battery voltage	3 and 5	0-		-0			
terminal	3 and 6			0-	-0		
Always				0-		-0-	-0

CAUTION:

While applying battery voltage to relay terminals, insert fuse into the circuit.

ID Code Entry Procedure

GI

EM

LC

Note:

A maximum of four remote controllers can be entered. Any attempt to enter a remote controller will erase all ID codes previously entered. Therefore, be sure to receive all remote controllers from the vehicle owner when any ID code entry is performed.

Enter the identity (ID) code manually when:

• remote controller or control unit is replaced.

• an additional remote controller is activated.

To enter the ID code, follow the procedures below.

PROCEDURE

Close all doors and lock driver side door.	EC
Insert and remove the key from the ignition more than seven times within 10 sec-	FE
onds.	GL
Turn ignition key switch to "ACC" position. (The hazard warning lamps will then flash twice.)	MT
	AT
Turn ignition key switch to "OFF" and remove the key from the ignition.	TF
Push any button on the new remote controller once. (The hazard warning lamps will then flash twice.)	PD
At this time, the new ID code is entered and all previous ID memory is com- pletely erased.	FA
	RA
A maximum four ID codes may be entered. (After 4th ID code is entered, the registration mode is ended.)	BR
No Yes	07
ADDITIONAL ID CODE ENTRY Release the door lock, then lock again	51
with driver side knob lock switch.	RS
Open driver side door.	BT
END.	HA
After entering the identity (ID) code, check the operation of multi-remote con- trol system.	EL

NOTE:

- If you need to activate more than two additional new remote controllers, repeat the procedure [D] "Additional ID code entry" for each new remote controller.
- Any ID codes cannot be entered after termination of the "setting mode".

Wiring Diagram — NATS —

EL-NATS-01







Wiring Diagram — NATS —/RHD Models



Engine Compartment



Passenger Compartment

LHD MODELS



• Door lock relay (With multi-remote control system for Europe)



LOCATION OF ELECTRICAL UNITS

IDX

Main Harness

INSTRUMENT PANEL — LHD MODELS



HARNESS LAYOUT Main Harness (Cont'd)

A4 (M1) -	: Body	ground			E E	ି ଜୁନ	10 :	Audio ur	nit			F1 (M74)	W/2	: Intake ai	r tempera	ature sen	sor
A4 (M2) W/2	: Warni	ng buzzer	r (Diesel	engine	EI EI	≶ ຼົ	: //9	Audio ur	nit (KA24	E and wi	th			(With aut	O A/C)		
	exceb	t for Euro	pe and t	he				4-speak	ers radio)			F1 (M75)	B/2	: Sunload	sensor (With auto	A/C)
	Middle	e East)			F3	ы Б	: 7	Cigarette	e lighter			B4•G4 M76	W/6	: Door loch	< relay (1	ب را)	
A4 (M3) W/20	0 ₽ 	Ē			G2 M	≥ @	/3 :	A/C swit	tch (Withe	out auto	A/C)	D3 (M77)	BR/2	: Key switd	sh (For T	urkey)	
A3 M4 W/12	р Р	2 (With	power w	/indow)	G2 M	് ഉ	: 9/	Fan swit	tch (Withe	out auto	A/C)	C3 M78	L/2	: Shift lock	t brake s	witch	
A3 M5 SMJ	р С С	പ്ര			E2	2 0		Fan swit	tch illumin	nation				(A/T moc	lels)		
B3 MG W/24	₽ 2	Ē						(Without	auto A/0	()		E4 M79	Y/12	: Air bag d	diagnosis	sensor	unit
A3 M7 BR/24	₽ 	ାଲ			E2	≤ ⊡	: 8//	Hazard	switch					(With pre	-tensione	er seat b	elt)
A2 (MB) -/2	: Diode	(Diesel e	sngine ex	cept for	E2	< ଜ୍ର	: 9//	Defogge	r switch	(For Eurc	pe and	E4 (M80)	Y/20	: Air bag d	diagnosis	sensor	unit
	Europ	e and the	Middle	East)				SE grad	le with di	esel engi	ne)	F4 (M81)	Y/12	: Air bag d	diagnosis	sensor	unit
C3 M9 L/4	: Acces	sory relay	>		G G	≻ ଜ	: 7	Air bag	module p	oassengei	side			(With pre	-tension	er seat b	elt)
B4 (M10)	: Fuse	block			E E	E E	3/4 :	Thermo	control a	mplifier		F4 (M82)	W/2	: Jumping	connecto	r	
C3 M11 GY/14	: Data	link conne	ector for	CONSULT	G2 🕅	स ख	3/4 :	Fan resi	istor (Witl	hout auto	A/C)			(With pre	-tension	er seat b	elt)
	(With	air bag, ,	ABS or E	ECM)	G2 M	≤ @	2/	Blower n	notor			B4 (M83)	L/10	: Diode (K	A24DE)		
B3 (M12) W/6	: Fuse	block			G3 M	ଁ ⊜ା	:	To D31	~			A3 (M84)	BR/2	: Resistor	(A/T mo	dels)	
B4 (M13) B/10	: Check	connectc	or (Z24S)		G3 G3	≥ @	: 9/	To 032) (With p	ower win	dow)	E3 (M86)	BR/10	: Mode do	or motor	(With au	ito A/C)
B3 (M14) W/4	: Fuse	block			E3	≥ ⊡	. 8/	Door loo	ck timer (With pow	er window	/ E3 (M87)	W/2	: In-vehicle	sensor	(With au	to A/C)
E3 (M15) B/3	: Comb	ination fla	asher unit					except f	or Europe	e)		F3 (M88)	GY/20	: A/C auto	amp. (V	Vith auto	A/C)
C3 (M16) B/2	: Stop I	amp switt	ch		G3 G3	_≤ ଲ୍ର	.//2	Circuit b	oreaker-2	(For Eur	ope)	G3 M89	GY/4	: A/C auto	amp. (V	Vith auto	A/C)
C2 (M17) W/16	P ₽ 	18 (With	air bag)		G3 ME	্র ক্রি		Body gr	ound			G3 M90	L/2	: Aspirator	motor (Nith auto	A/C)
B1 M18 W/16	₽ 	(With	air bag)		E	< ଜ୍ର	//2 :	NATS se	ecurity in	dicator (F	or Europe	() G2 (M91	B/6	: Air mix c	loor mote	or (With	auto A/C)
A1 (M19) W/6	۳ 2 	Ģ			A3 ME	്		Diode (4	41)			F1 (M92	W/4	: Fan cont	rol amp.	(With au	to A/C)
D3 (M20) W/6	: Ignitio	n switch			B2	े जि		Diode (4	41)			F1 (M93	W/4	: Intake do	or motor	· (With a	uto A/C)
C2 (M21) W/1	: Parkin	ig brake s	switch (Si	tick type)	C2	َدَ چ	12 :	Multi-rer	note cont	rol unit (* 1)						
G4 M22 W6	: Fuel p	iuoo dunc	trol modu	ile (Z24S)	F3	ы С	3/6 :	Multi-rer	note cont	rol relay-	2 (*1)	Sub-ha	rness				
D2 (M23) BR/8	: Lightir	ng switch			F4	ш Ю	/5 :	Multi-rer	note cont	rol relay-	1 (*1)	D1 (M501)	W/10	: To M35			
	• Turn	i signal la	amp switc	ř	F4	ш Ш	:- /2	Jumping	connecto	or (* 1)		D2 (M502)	W/10	: Audio un	ij		
D2 (M24) BR/4	: Lightir	ng switch			F3 ME	ଁ ଜୁ	.18	Smart e	ntrance c	control un	it	E1 (M503)	W/4	: Compact	disk deo	×	
D3 (M25) Y/7	: Spiral	cable (W	lith air be	(DE	ļ	1		(For Eur	rope))		-			
C3 (M26) L/2	: A/T cl	heck switc	ch (A/T n	nodels)	D2 (ME	୍ଲ ≲	: :: ::	Rear foo	g lamp sv	vitch		Diode M8	\sim				
D2 (M27) B/1	: Horn	switch (W	lithout air	· bag))	ì		(For Eur	rope and	China)						l filter sv	vitch
D2 (M28) GY/8	: Wiper	and wash	her switc	; ч	D3 (ME	٤	//2 :	Kev swit	tch .			FILTER V	varning la	amp – dma			
C3 (M29) W/12	: Glow	control ur	nit		J	ì		(For Eur	rope exce	ept Single	cab)					zna bulu	Jaz
)	(TD27	engine e	except for		D3 Me	≷ ≷	: 4/	NATS a	ntenna ar								
	cold	areas and	d QD en(gine)				(Diesel	engine fo	r Europe	_	anoin	, Mil				ſ
C3 (M30) W/16	: Glow	control ur	nit		D3 M	ଞ ସ୍	./20	ECM (D	iesel eng	ine for E	urope)		* 2	M56		oor lock	relay
)	(TD27	engine f	or cold a	ıreas)	C3 C3	ତ୍ର ଲା	./16 :	ECM (D	iesel eng	ine for E	urope)	Lock and	Ĺ		Í	Multi-rem	ote
D4 (M31) GY/6	: Joint	connector	1 (KA ei	ngine)	E3	≥ ⊛	: 8/1	NATS IN	AMU (KA	24E)		unlock sw	itch {			control u	nit
D4 (M32) W/64	ECM :	(KA24E)		5	B2 B2	ି ଭୁ	/24 :	TCM (Tr	ransmissio	on contro	I module)		ر				
) W/48	ECM :	(KA24DE)	-			1		(A/T mo	dels)							oor lock	relay
E4 (M33) —	: Bodv	around (K	(A24E)		B2 (M:	ч G	/24 :	TCM (Tr	ransmissio	on contro	I module)	*1 · With	multi-re	mote contro	l sveterr		
F3 (M34) W/2	: Ashtre	v illumina	ation (GL	and S-				(A/T mo	dels)			*2 · For	Furone	Smart enti	rance co	ntrol unit	
)	GL gr	ade for th	he Middle	(East	C2	ା ଲ୍ର	: 9/	Joint co	nnector-2	(A/T mo	dels)	Exc	ept for E	uropeDoc	or lock ti	mer	
H	B1	R	Sĩ	B	R/	FÆ		P	76	A1	M	F	E(L(Eì	M	G
A	ſ	S	ſ	R	A	4	_	D	-	ſ	_ IT		65	<i>L</i> 2	M	A	

IDX

HARNESS LAYOUT

Main Harness (Cont'd)





HARNESS LAYOUT Main Harness (Cont'd)



190



HARNESS LAYOUT

Main Harness (Cont'd)

HEL790A





EL-174

HARNESS LAYOUT

Main Harness (Cont'd)



Engine Room Harness





EL-176

Engine Room Harness (Cont'd)	
relay (2 engine) (KA engine except MT models for the Middle East) strion (PNP) relay (AT models) For Europe) g motor LH (For Europe) g motor LH (For Europe) g motor RH (For Europe) g motor	gi Ma Em LC EC
E1 (E3) B/5 : Automatic choke L/4 : Fuel pump relay the Middle East) BR/6 : ECM relay (KA e BR/6 : ECM relay (KA e BR/6 : Defogger relay (K BR/6 : Headlamp aiming C1 (E3) GY/6 : Headlamp washe GY/6 : Headlamp washe C1 (E3) GY/2 : Headlamp washe GY/6 : Headlamp washe C1 (E3) GY/6 : Headlamp washe C2 (E3) GY/6 : Headlamp washe C3 (E6) GY/6 : Headlamp washe C3 (E0) BH/2 : Ambient tempera D2 (F7) L4 : Cooling fan relay M/6 : Headlamp washe C3 (M/6 : Headlamp washe C4 (F7) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F7) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F7) L4 : Cooling fan relay M/6 : Headlamp washe C3 (M/6 : Headlamp washe C4 (F7) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F7) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Headlamp washe C4 (F1) L4 : Cooling fan relay M/6 : Hea	FE CL MT AT
 Side turn signal lamp LH (For Europe and China) Haated oxygen sensor (KA24E engine) Haated oxygen sensor (KA24E engine) ABS actuator and electric unit (For ABS) Body ground Il grition coil (Z engine) Il grition coil (Z engine) Front combination lamp LH (For Europe and China) In exclusion (X a engine) Front compressor (Z engine) Conpressor (Z engine) Front compressor (Z engine) Front compressor (Z engine) Front compressor (Z engine) In Horn Iow Front combination lamp RH (For Europe and China) Front control solenoid valve (Z engine) Sc-FI pot control solenoid valve (Z engine)	PD FA RA BR ST RS BT
8 8	HA

IDX

HARNESS LAYOUT

HEL795A

HARNESS LAYOUT

Engine Room Harness (Cont'd)

LHD MODELS — DIESEL ENGINE



HEL796A

EL-178



HARNESS LAYOUT Engine Room Harness (Cont'd)

IDX

EL-179

HARNESS LAYOUT

Engine Room Harness (Cont'd)

RHD MODELS — GASOLINE ENGINE



EL-180


HARNESS LAYOUT Engine Room Harness (Cont'd)

HEL799A

EL-181

Engine Room Harness (Cont'd)

RHD MODELS — DIESEL ENGINE



HEL800A

 1. Fuel heater relay (For Europe) 2. Defogger relay (TD27 engine for Australia and TD25, 25T1 and CD engine) 2. Tenel fitter (For fuel heater)(For Europe) 2. EGRC-solenoid valve (Throttle chamber)(For Europe) 2. EGRC-solenoid valve (FGR valve)(For Europe) 2. EGRC-solenoid valve (TD engine for Australia) 2. Elon-dip lamp unit (For Europe) 2. Elon-dip lamp unit (For Europe) 2. Elon-dip lamp unit (For Europe) 3. Elon-dip lamp unit (For Europe) 4. Elon elay-2 (TD engine for Australia) 4. Elon relay-2 (TD engine for Australia) 4. Elon elon 	GI MA EM LC EC FE
G1 E54 L/4 : Fuel heater rel G1 E55 BR/6 : Defogger relay and TD25, 257 F2 E56 GY/4 : Fuel filter (For C3 E59 BR/2 : EGRC-solenoid D2 E61 B/2 : EGRC-solenoid D1 E66 GY/6 : Dim-dip lamp L C1 E67 GY/1 : Glow relay-2 (1 D1 E83 W/1 : Glow relay-2 (1 D1 E83 W/1 : Glow relay-2 (1 D1 E83 W/1 : Glow relay-2 (1 D1 E84 G/2 : Fuse block B/2 : Fuse block D1 E80 B/1 : To E48 (0 D1 E80 B/1 : To E48 (0 D1 E80 C0 P10	FE CL MT
Australia) engine) ustralia) engine) ia) Australia)	TF
e and Australia) be and Australia r Europe and v ABS and QD ABS and QD ABS and QD r Europe and pe and Australia ustralia) ustralia WD model with MD models	fa
(For Europe unit (For A H (Except fo G QD engin models with models with models with models with models with models with models to H (For Europe e except for A Scept for A Sce	RA
gnal lamp LH evel switch ir and electric witch ation lamp Ll hation lamp Ll h b cor Europe an motor except 2WD ire switch H nation lamp R nation lamp R nation lamp R nation lamp R nation lamp R h ation lamp R h and fuse box er relay relay (For Europ	BR ST
Side turn sig Brake fluid 1 ABS actuato Fuel filter sv Body grounc Front combir Headlamp LI Washer mott Front wheel Horn high (f For Europe Horn high (f For Europe Horn high (f For Europe Triple-pressu Headlamp R Front combir Front combir Front combir front combir front combir front combir front sig fr front sig flow relay-1 Glow relay-1 Glow relay-1 Glow relay-1 Front front fr front sig fr front sig front	RS
By B	BT
	HA

HARNESS LAYOUT Engine Room Harness (Cont'd)

HEL801A

EL-183

Engine Control Harness



HARNESS LAYOUT Engine Control Harness (Cont'd)



Engine Harness

Z ENGINE



HARNESS LAYOUT Engine Harness (Cont'd)

KA ENGINE

GI MA Back-up lamp switch (M/T models) Park/Neutral position (PNP) switch Transfer switch (4WD models) Transfer switch (4WD models) Oil pressure switch (KA24E) EM Vehicle speed sensor LC Œ Starter motor Starter motor (M/T models) EC FE GY/1 GY/2 B/2 GY/1 GY/1 GY/2 B/1 (E212) CL P (E210) E211 \odot MT (E201) E213) <u>س</u> Power steering oil pressure switch (Except RHD 4WD models) AT (E208) \mathbb{O}^{-} Power steering oil pressure switch (RHD 4WD models) ന (E207) TF PD E218 E202 \odot (E215)¹ E204 FA (E203) Fusible link and fuse box RA E205) Alternator (B) Alternator (E) Alternator (S,L) BR E219 To To To ന Battery (E220) ST ġ, /2WD/ RS B/8 GY/2 GY/8 GY/2 B/2 GY/2 | |I BT (4WD) ģ Ş HA E222 E221 EL



Alternator Harness



LHD MODELS

N1 W/24 : To M6

N2 BR/24 : To M7 (For Europe)

N5 W/10 : Combination meter

N4) W/16 : Combination meter (With tachometer)

(A/T models with tachometer)

Instrument Harness



EL-190

N6 BR/16 : Combination meter (With tachometer)

N9 W/20 : Combination meter (Without tachometer) N10 BR/20 : Combination meter (Without tachometer)

N11) W/24 : Combination meter (Without tachometer)

N13) W/12 : NATS IMMU (Diesel engine for Europe)

HEL809A

Room Lamp Harness/LHD Models



Room Lamp Harness/RHD Models





Chassis Harness and Tail Harness

HEL813A

IDX



Front Door Harness (LH side)



Front Door Harness (RH side)



Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
AAC/V	EC	IACV-AAC Valve
ABS	BR	Anti-lock Brake System
A/C, M	HA	Manual Air Conditioner
A/C, A	HA	Auto Air Conditioner
AT/IND	EL	A/T Indicator
AUDIO	EL	Audio
BACK/L	EL	Back-up Lamp
BA/FTS	AT	BATT/A/T Fluid Temperature Sensor and TCM Power Supply
CHARGE	EL	Charging System
CHIME	EL	Warning Chime
CHOKE	EC	Automatic Choke
CIGAR	EL	Cigarette Lighter
CLOCK	EL	Clock
CMPS	EC	Camshaft Position Sensor
COOL/F	LC	Cooling Fan Control
DEF	EL	Rear Window Defogger and Mirror Defogger
DIMDIP	EL	Headlamp — With Dim-dip Lamp System
D/LOCK	EL	Power Door Lock
DTRL	EL	Headlamp — With Daytime Light System
ECTS	EC	Engine Coolant Temperature Sensor
EGRC/V	EC	EGRC — Solenoid Valve
ENGSS	AT	Engine Speed Signal
FCUT	EC	Fuel Cut Solenoid Valve
F/HEAT	EC	Fuel Heater System
FICD	EC	IACV-FICD Solenoid Valve
FIPOT	EC	ISC-FI Pot
FPCM	EC	Fuel Pump Control Module
F/PUMP	EC	Fuel Pump
GLOW	EC	Quick-glow System
H/AIM	EL	Headlamp Aiming Control
HEATER	HA	Heater
H/LAMP	EL	Headlamp
HLC	EL	Headlamp Washer
HO2S	EC	Heated Oxygen Sensor
HORN	EL	Horn
H/SEAT	EL	Heated Seat

Code	Section	Wiring Diagram Name
IGN	EC	Ignition System
IGN/SG	EC	Ignition Signal
ILL	EL	Illumination
INJECT	EC	Injector
INT/L	EL	Spot Lamp
KS	EC	Knock Sensor
LOAD	EC	Electric Load Signal
LPSV	AT	Line Pressure Solenoid Valve
MAFS	EC	Mass Air Flow Sensor
MAIN	EC, AT	Main Power Supply and Ground Cir- cuit
METER	EL	Speedometer, Tachometer, Temp. and Fuel Gauges
MIL/DL	EC	MIL and Data Link Connector For CONSULT
MIRROR	EL	Power Door Mirror
MULTI	EL	Multi-remote Control System
NATS	EL	Nissan Anti-theft System
NONDTC	AT	Non-detectable Items
OVRCSV	AT	Overrun Clutch Solenoid Valve
P/ANT	EL	Power Antenna
PGC/V	EC	EVAP Canister Purge Control Solenoid Valve
PLA	EC	Partial Load Advance Control
PNP/SW	EC	Park/Neutral Position Switch
POWER	EL	Power Supply Routing
PST/SW	EC	Power Steering Oil Pressure Switch
R/FOG	EL	Rear Fog Lamp
ROOM/L	EL	Interior Room Lamp
SHIFT	AT	Shift Lock System
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
SRS	RS	Supplemental Restraint System
S/SIG	EC	Start Signal
START	EL	Starting System
STOP/L	EL	Stop Lamp
SWL/V	EC	Swirl Control Valve Control Solenoid Valve
TAIL/L	EL	Parking, License and Tail Lamps
TCV	AT	Torque Converter Clutch Solenoid Valve

WIRING DIAGRAM CODES (CELL CODES)

Code	Section	Wiring Diagram Name
TPS	EC, AT	Throttle Position Sensor
TURN	EL	Turn Signal and Hazard Warning Lamps
VSS	EC	Vehicle Speed Sensor
VSSAT	AT	Vehicle Speed Sensor A/T (Revolu- tion Sensor)

			_
Code	Section	Wiring Diagram Name	_
VSSMTR	AT	Vehicle Speed Sensor Meter	- GI
WARN	EL	Warning Lamps	_
WINDOW	EL	Power Window	- M
WIPER	EL	Front Wiper and Washer	_
	1	l	EN
			LC

HA

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

IDX

EL