

SECTION EF

CONTENTS

PRECAUTIONS FOR AN E.F.I. ENGINE	EF- 2	With circuit tester	EF-24
DESCRIPTION	EF- 3	Throttle valve switch tests	EF-25
Component parts location	EF- 3	Air flow meter tests	EF-26
Engine control system diagram	EF- 4	Air temperature sensor tests	EF-28
E.F.I. SYSTEM OPERATION	EF- 5	Water temperature sensor test	EF-28
Fuel injection control	EF- 5	Control unit ground circuit tests	EF-29
Signals for control unit	EF- 5	Air regulator circuit tests	EF-29
Fuel system	EF- 5	Ignition coil trigger input test	EF-30
Air flow system	EF- 7	Injector circuit tests	EF-30
Electrical signal system	EF- 8	E.F.I. relay and fuel pump relay tests ...	EF-32
DIAGNOSTIC PROCEDURE FOR PROBLEMS	EF-11	Ignition start signal test	EF-33
Diagnosis	EF-11	FUEL SYSTEM	EF-34
Diagnostic procedure	EF-11	Releasing fuel pressure	EF-34
ELECTRICAL SYSTEM INSPECTION ..	EF-20	Fuel pressure check	EF-34
E.F.I. circuit diagram	EF-20	Removal and installation	EF-35
E.F.I. wiring diagram	EF-21	SERVICE DATA AND SPECIFICATIONS	EF-38
With E.F.I. harness checker	EF-22	Inspection and adjustment	EF-38
		Tightening torque	EF-38

